



Franchise 2.5 CLI Commands



Document Conventions

	Note: Provides related information or information of special importance.
	Caution: Indicates potential damage to hardware or software, or loss of data.
	Warning: Indicates a risk of personal injury.

Document Status

Doc Status: For Customer Review	
---------------------------------	--

For more information, visit our website at: www.marvell.com

Disclaimer

No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying and recording, for any purpose, without the express written permission of Marvell. Marvell retains the right to make changes to this document at any time, without notice. Marvell makes no warranty of any kind, expressed or implied, with regard to any information contained in this document, including, but not limited to, the implied warranties of merchantability or fitness for any particular purpose. Further, Marvell does not warrant the accuracy or completeness of the information, text, graphics, or other items contained within this document. Marvell products are not designed for use in life-support equipment or applications that would cause a life-threatening situation if any such products failed. Do not use Marvell products in these types of equipment or applications.

With respect to the products described herein, the user or recipient, in the absence of appropriate U.S. government authorization, agrees:

- 1) Not to re-export or release any such information consisting of technology, software or source code controlled for national security reasons by the U.S. Export Control Regulations ("EAR"), to a national of EAR Country Groups D:1 or E:2;
- 2) Not to export the direct product of such technology or such software, to EAR Country Groups D:1 or E:2, if such technology or software and direct products thereof are controlled for national security reasons by the EAR; and,
- 3) In the case of technology controlled for national security reasons under the EAR where the direct product of the technology is a complete plant or component of a plant, not to export to EAR Country Groups D:1 or E:2 the direct product of the plant or major component thereof, if such direct product is controlled for national security reasons by the EAR, or is subject to controls under the U.S. Munitions List ("USML").

At all times hereunder, the recipient of any such information agrees that they shall be deemed to have manually signed this document in connection with their receipt of any such information.

Copyright © 1999–2011, Marvell International Ltd. All rights reserved. M Logo, Marvell, Moving Forward Faster, Alaska, Link Street, Presteria, Virtual Cable Tester, Yukon, Datacom Systems On Silicon, AnyVoltage, DSP Switcher, Feroceon, ZX, ZXSTREAM, Armada, Qdeo & Design, QuietVideo, TopDog, TwinD, and Kinoma are registered trademarks of Marvell or its affiliates. Avanta, Avastar, Carrierspan, DragonFly, HyperDuo, HyperScale, Kirkwood, LinkCrypt, Marvell Smart, The World As You See It, Turbosan, and Vmeta are trademarks of Marvell or its affiliates.

Patent(s) Pending—Products identified in this document may be covered by one or more Marvell patents and/or patent applications.

Table of Contents

1	Preface	20
2	User Interface Commands	25
	enable	25
	disable	25
	login	26
	configure	26
	exit (Configuration)	27
	exit (EXEC)	27
	end	28
	help	28
	history	29
	history size	30
	terminal history	30
	terminal history size	31
	terminal datadump	32
	debug-mode	32
	show history	33
	show privilege	34
	do	34
	banner exec	35
	banner login	36
	banner motd	37
	exec-banner	39
	login-banner	39
	motd-banner	40
	show banner	41
3	Macro Commands	42
	macro name	42
	macro apply	44
	macro description	46
	macro global	47
	macro global description	48
	show parser macro	49
4	System Management Commands	51
	ping	51
	traceroute	53
	telnet	55
	resume	58
	hostname	58
	reload	59
	service cpu-utilization	59
	show cpu utilization	60
	clear cpu counters	60



service cpu-counters	61
show cpu counters	61
show users	62
show sessions	63
show system	64
show version	65
show version md5	65
system resources routing	66
show system resources	66
show system defaults	68
5 Stack Commands	70
stack master	70
switch renumber	70
show switch	71
6 Clock Commands	73
clock set	73
clock source	73
clock timezone	74
clock summer-time	74
clock dhcp timezone	76
sntp authentication-key	77
sntp authenticate	77
sntp trusted-key	78
sntp client poll timer	78
sntp broadcast client enable	79
sntp anycast client enable	80
sntp client enable	80
sntp unicast client enable	81
sntp unicast client poll	81
sntp server	82
sntp port	83
show clock	83
show sntp configuration	84
show sntp status	85
7 Auto-Update and Auto-Configuration	87
boot host auto-config	87
boot host auto-update	87
boot host dhcp	88
boot host auto-save	88
show boot	89
ip dhcp tftp-server ip address	91
ip dhcp tftp-server file	92
show ip dhcp tftp-server	92
8 Configuration and Image File Commands	94
copy	94
write memory	98
delete	98

	pwd	99
	dir	99
	more	100
	cd	101
	rename	102
	boot system	103
	show running-config	103
	show startup-config	104
	show backup-config	105
	show bootvar	106
9	Management ACL Commands	107
	management access-list	107
	permit (Management)	108
	deny (Management)	109
	management access-class	110
	show management access-list	110
	show management access-class	111
10	Network Management Protocol (SNMP) Commands	112
	snmp-server community	112
	snmp-server view	113
	show snmp views	114
	snmp-server group	115
	show snmp groups	116
	snmp-server user	117
	show snmp users	118
	snmp-server filter	119
	show snmp filters	120
	snmp-server host	120
	snmp-server engineID local	122
	snmp-server engineID remote	123
	show snmp engineID	123
	snmp-server enable traps	124
	snmp-server trap authentication	125
	snmp-server contact	125
	snmp-server location	126
	snmp-server set	126
	show snmp	127
11	RSA and Certificate Commands	129
	crypto key generate dsa	129
	crypto key generate rsa	129
	show crypto key mypubkey	130
	crypto certificate generate	131
	crypto certificate request	132
	crypto certificate import	133
	crypto certificate export pkcs12	135
	crypto certificate import pkcs12	136
	show crypto certificate mycertificate	137



12	Web Server Commands	139
	ip http server	139
	ip http port	139
	ip http timeout-policy	140
	ip http secure-server	140
	ip http secure-port	141
	ip https certificate	141
	show ip http	142
	show ip https	142
13	Teletype Network (Telnet), Secure Shell (SSH) and Secure Login (Slogin) Commands ..	144
	ip telnet server	144
	ip ssh server	144
	ip ssh port	145
	ip ssh pubkey-auth	145
	crypto key pubkey-chain ssh	146
	user-key	147
	key-string	148
	show ip ssh	149
	show crypto key pubkey-chain ssh	150
14	Line Commands	151
	line	151
	speed	151
	autobaud	152
	exec-timeout	152
	show line	153
15	Authentication, Authorization and Accounting (AAA) Commands	155
	aaa authentication login	155
	aaa authentication enable	156
	login authentication	157
	enable authentication	158
	ip http authentication	159
	show authentication methods	160
	password	161
	enable password	161
	username	162
	show user accounts	163
	aaa accounting login	164
	aaa accounting dot1x	165
	show accounting	166
	passwords complexity enable	167
	passwords complexity <attributes>	168
	passwords min-length	169
	passwords aging	170
	passwords history	170
	show passwords configuration	171
	show users login-history	172

16	Remote Authentication Dial-In User Service (RADIUS) Commands	174
	radius-server host	174
	radius-server key	175
	radius-server retransmit	176
	radius-server source-ip	176
	radius-server source-ipv6	177
	radius-server timeout	177
	radius-server deadtime	178
	show radius-servers	179
17	Terminal Access Controller Access-Control System Plus (TACACS+) Commands	180
	tacacs-server host	180
	tacacs-server key	181
	tacacs-server timeout	181
	tacacs-server source-ip	182
	show tacacs	182
18	Syslog Commands	184
	logging on	184
	logging host	184
	logging console	185
	logging buffered	186
	clear logging	187
	logging file	187
	clear logging file	188
	aaa logging	188
	file-system logging	189
	management logging	189
	logging aggregation on	190
	logging aggregation aging-time	190
	show logging	191
	show logging file	192
	show syslog-servers	193
19	Remote Network Monitoring (RMON) Commands	194
	show rmon statistics	194
	rmon collection stats	196
	show rmon collection stats	196
	show rmon history	197
	rmon alarm	199
	show rmon alarm-table	200
	show rmon alarm	201
	rmon event	202
	show rmon events	203
	show rmon log	204
	rmon table-size	204
20	802.1x Commands	206
	aaa authentication dot1x	206
	dot1x system-auth-control	206
	dot1x port-control	207



dot1x reauthentication	208
dot1x timeout reauth-period	208
dot1x re-authenticate	209
dot1x timeout quiet-period	209
dot1x timeout tx-period	210
dot1x max-req	211
dot1x timeout supp-timeout	211
dot1x timeout server-timeout	212
show dot1x	213
show dot1x users	215
show dot1x statistics	216
clear dot1x statistics	217
dot1x host-mode	218
dot1x violation-mode	219
dot1x guest-vlan	220
dot1x guest-vlan timeout	220
dot1x guest-vlan enable	221
dot1x mac-authentication	221
dot1x traps mac-authentication success	222
dot1x traps mac-authentication failure	223
dot1x radius-attributes vlan	223
dot1x radius-attributes filter-id	224
dot1x radius-attributes errors	225
show dot1x advanced	225
21 Ethernet Configuration Commands	227
interface	227
interface range	227
shutdown	228
description	229
speed	229
duplex	230
negotiation	230
flowcontrol	231
mdix	232
back-pressure	232
port jumbo-frame	233
clear counters	233
set interface active	234
errdisable recovery cause	234
errdisable recovery interval	235
show interfaces configuration	236
show interfaces status	236
show interfaces advertise	237
show interfaces description	238
show interfaces counters	239
show ports jumbo-frame	242
show errdisable recovery	242
show errdisable interfaces	243
storm-control broadcast enable	243
storm-control broadcast level kbps	244
storm-control include-multicast	245

22	PHY Diagnostics Commands	246
	test cable-diagnostics tdr	246
	show cable-diagnostics tdr	246
	show cable-diagnostics cable-length	247
	show fiber-ports optical-transceiver	248
23	Green Ethernet	250
	green-ethernet energy-detect (global)	250
	green-ethernet energy-detect (interface)	250
	green-ethernet short-reach (global)	251
	green-ethernet short-reach (interface)	251
	green-ethernet short-reach force	252
	green-ethernet short-reach threshold	252
	green-ethernet power-meter reset	253
	show green-ethernet	254
24	Port Channel Commands	256
	port-channel create	256
	channel-group	256
	port-channel load-balance	257
	show interfaces port-channel	258
25	Address Table Commands	260
	bridge multicast filtering	260
	bridge multicast mode	260
	bridge multicast address	262
	bridge multicast forbidden address	263
	bridge multicast ip-address	263
	bridge multicast forbidden ip-address	264
	bridge multicast source group	265
	bridge multicast forbidden source group	266
	bridge multicast ipv6 mode	267
	bridge multicast ipv6 ip-address	268
	bridge multicast ipv6 forbidden ip-address	269
	bridge multicast ipv6 source group	270
	bridge multicast ipv6 forbidden source group	271
	bridge multicast unregistered	272
	bridge multicast forward-all	273
	bridge multicast forbidden forward-all	273
	mac address-table static	274
	clear mac address-table	276
	mac address-table aging-time	276
	port security	277
	port security mode	278
	port security max	279
	port security routed secure-address	280
	show mac address-table	280
	show mac address-table count	281
	show bridge multicast mode	282
	show bridge multicast address-table	282
	show bridge multicast address-table static	284
	show bridge multicast filtering	286



	show bridge multicast unregistered	287
	show ports security	288
	show ports security addresses	289
	bridge multicast reserved-address	290
	show bridge multicast reserved-addresses	291
26	Port Monitor Commands	292
	port monitor	292
	show ports monitor	293
	port monitor mode	293
27	sFlow Commands	295
	sflow receiver	295
	sflow flow-sampling	295
	sflow counters-sampling	296
	clear sflow statistics	296
	show sflow configuration	297
	show sflow statistics	298
28	Link Layer Discovery Protocol (LLDP) Commands	299
	lldp run	299
	lldp transmit	299
	lldp receive	300
	lldp timer	300
	lldp hold-multiplier	301
	lldp reinit	302
	lldp tx-delay	302
	lldp management-address	303
	lldp notifications	304
	lldp notifications interval	304
	lldp optional-tlv 802.1	305
	lldp lldpdu	306
	lldp med enable	306
	lldp med notifications topology-change	307
	lldp med fast-start repeat-count	308
	lldp med network-policy (global)	308
	lldp med network-policy (interface)	309
	clear lldp table	310
	lldp med location	310
	show lldp configuration	311
	show lldp med configuration	313
	show lldp local tlvs-overloading	314
	show lldp local	315
	show lldp neighbors	316
	show lldp statistics	320
29	Spanning-Tree Commands	322
	spanning-tree	322
	spanning-tree mode	322
	spanning-tree forward-time	323
	spanning-tree hello-time	323

<hr/>	
spanning-tree max-age	324
spanning-tree priority	325
spanning-tree disable	325
spanning-tree cost	326
spanning-tree port-priority	327
spanning-tree portfast	327
spanning-tree link-type	328
spanning-tree pathcost method	328
spanning-tree bpdu (Global)	329
spanning-tree bpdu (Interface)	330
spanning-tree guard root	330
spanning-tree bpduguard	331
clear spanning-tree detected-protocols	332
spanning-tree mst priority	332
spanning-tree mst max-hops	333
spanning-tree mst port-priority	333
spanning-tree mst cost	334
spanning-tree mst configuration	335
instance (MST)	335
name (MST)	336
revision (MST)	337
show (MST)	337
exit (MST)	338
abort (MST)	338
show spanning-tree	339
show spanning-tree bpdu	348
spanning-tree loopback-guard	349
30 Virtual Local Area Network (VLAN) Commands	351
vlan database	351
vlan	351
show vlan	352
show default-vlan-membership	353
interface vlan	354
interface range vlan	355
name	355
switchport protected-port	356
show interfaces protected-ports	357
switchport community	357
switchport	358
switchport mode	359
switchport access vlan	359
switchport trunk allowed vlan	360
switchport trunk allowed vlan	361
switchport trunk native vlan	362
switchport general allowed vlan	363
switchport general allowed vlan	364
switchport general pvid	364
switchport general ingress-filtering disable	366
switchport general acceptable-frame-type	367
switchport customer vlan	367
map protocol protocols-group	368
switchport general map protocols-group vlan	369



show vlan protocols-groups	369
map mac macs-group	370
switchport general map macs-group vlan	371
show vlan macs-groups	372
map subnet subnets-group	372
switchport general map subnets-group vlan	373
show vlan subnets-groups	374
switchport forbidden default-vlan	374
switchport forbidden vlan	375
switchport default-vlan tagged	376
show interfaces switchport	377
show interfaces switchport	379
ip internal-usage-vlan	380
show vlan internal usage	380
switchport access multicast-tv vlan	381
switchport customer multicast-tv vlan	382
show vlan multicast-tv	382
31 Internet Group Management Protocol (IGMP) Snooping Commands	384
ip igmp snooping (Global)	384
ip igmp snooping vlan	384
ip igmp snooping vlan mrouter	385
ip igmp snooping vlan mrouter interface	386
ip igmp snooping vlan forbidden mrouter interface	386
ip igmp snooping vlan static	387
ip igmp snooping vlan multicast-tv	388
ip igmp snooping map cpe vlan	388
ip igmp snooping vlan querier	389
ip igmp snooping vlan querier address	390
ip igmp snooping vlan querier version	390
ip igmp robustness	391
ip igmp query-interval	391
ip igmp query-max-response-time	392
ip igmp last-member-query-count	393
ip igmp last-member-query-interval	393
ip igmp snooping vlan immediate-leave	394
show ip igmp snooping mrouter	394
show ip igmp snooping interface	395
show ip igmp snooping groups	396
show ip igmp snooping multicast-tv	396
show ip igmp snooping cpe vlans	397
32 IPv6 MLD Snooping Commands	398
ipv6 mld snooping (Global)	398
ipv6 mld snooping vlan	398
ipv6 mld robustness	399
ipv6 mld snooping mrouter	399
ipv6 mld snooping mrouter interface	400
ipv6 mld snooping forbidden mrouter interface	401
ipv6 mld snooping static	401
ipv6 mld query-interval	402
ipv6 mld query-max-response-time	403

	ipv6 mld last-member-query-count	403
	ipv6 mld last-member-query-interval	404
	ipv6 mld snooping vlan immediate-leave	404
	show ipv6 mld snooping mrouter	405
	show ipv6 mld snooping interface	406
	show ipv6 mld snooping groups	407
33	Link Aggregation Control Protocol (LACP) Commands	409
	lacp system-priority	409
	lacp port-priority	409
	lacp timeout	410
	show lacp	410
	show lacp port-channel	412
34	GARP VLAN Registration Protocol (GVRP) Commands	414
	gvrp enable (Global)	414
	gvrp enable (Interface)	414
	garp timer	415
	gvrp vlan-creation-forbid	416
	gvrp registration-forbid	416
	clear gvrp statistics	417
	show gvrp configuration	417
	show gvrp statistics	418
	show gvrp error-statistics	419
35	Voice VLAN Commands	422
	voice vlan oui-table	422
	voice vlan cos mode	423
	voice vlan cos	424
	voice vlan aging-timeout	425
	voice vlan enable	425
	voice vlan secure	426
	show voice vlan	426
36	Loopback Detection Commands	430
	loopback-detection enable (Global)	430
	loopback-detection enable (Interface)	430
	loopback-detection mode	431
	loopback-detection interval	432
	show loopback-detection	432
37	DHCP Snooping and ARP Inspection Commands	434
	ip dhcp snooping	434
	ip dhcp snooping vlan	434
	ip dhcp snooping trust	435
	ip dhcp snooping information option allowed-untrusted	435
	ip dhcp snooping verify	436
	ip dhcp snooping database	436
	ip dhcp snooping database update-freq	437
	ip dhcp snooping binding	438
	clear ip dhcp snooping database	438



show ip dhcp snooping	439
show ip dhcp snooping binding	439
ip source-guard	440
ip source-guard binding	441
ip source-guard tcam retries-freq	441
ip source-guard tcam locate	442
show ip source-guard configuration	443
show ip source-guard status	444
show ip source-guard inactive	445
ip arp inspection	445
ip arp inspection vlan	446
ip arp inspection trust	447
ip arp inspection validate	447
ip arp inspection list create	448
ip mac	449
ip arp inspection list assign	449
ip arp inspection logging interval	450
show ip arp inspection	450
show ip arp inspection list	451
show ip arp inspection statistics	451
clear ip arp inspection statistics	452
38 IP Addressing Commands	453
ip address	453
ip address dhcp	454
renew dhcp	455
ip default-gateway	455
show ip interface	456
arp	456
arp timeout (Global)	457
arp timeout	458
ip arp proxy disable	458
ip proxy-arp	459
clear arp-cache	459
show arp	460
show arp configuration	460
interface ip	461
directed-broadcast	462
broadcast-address	462
ip helper-address	463
show ip helper-address	464
source-precedence	464
ip domain lookup	465
ip domain name	465
ip name-server	466
ip host	467
clear host	467
clear host dhcp	468
show hosts	468
39 IPv6 Addressing Commands	470
ipv6 enable	470

	ipv6 address autoconfig	470
	ipv6 icmp error-interval	471
	show ipv6 icmp error-interval	472
	ipv6 address	472
	ipv6 address link-local	473
	ipv6 unreachable	474
	ipv6 link-local default zone	475
	ipv6 default-gateway	475
	show ipv6 interface	476
	show IPv6 route	477
	show ipv6 link-local default zone	478
	ipv6 nd dad attempts	479
	ipv6 host	480
	ipv6 neighbor	480
	ipv6 set mtu	481
	ipv6 mld version	482
	ipv6 mld join-group	482
	show ipv6 neighbors	483
	clear ipv6 neighbors	484
40	Tunnel Commands	485
	interface tunnel	485
	tunnel mode ipv6ip	485
	tunnel isatap router	486
	tunnel source	487
	tunnel isatap query-interval	487
	tunnel isatap solicitation-interval	488
	tunnel isatap robustness	489
	show ipv6 tunnel	489
41	DHCP Relay Commands	491
	ip dhcp relay enable (Global)	491
	ip dhcp relay enable (Interface)	491
	ip dhcp relay address	492
	show ip dhcp relay	492
	ip dhcp information option	494
	show ip dhcp information option	494
42	DHCP Server Commands	496
	ip dhcp server	496
	ip dhcp pool host	496
	ip dhcp pool network	497
	address (DHCP Host)	497
	address (DHCP Network)	498
	lease	499
	client-name	500
	default-router	500
	dns-server	501
	domain-name	502
	netbios-name-server	502
	netbios-node-type	503
	next-server	503



next-server-name	504
bootfile	505
time-server	505
option	506
ip dhcp excluded-address	507
ip dhcp ping enable	507
ping enable	508
ip dhcp ping count	509
ip dhcp ping timeout	509
clear ip dhcp binding	510
show ip dhcp	510
show ip dhcp excluded-addresses	511
show ip dhcp pool host	511
show ip dhcp pool network	512
show ip dhcp binding	513
show ip dhcp server statistics	515
show ip dhcp allocated	515
show ip dhcp declined	517
show ip dhcp expired	517
show ip dhcp pre-allocated	518
43 IP Routing Protocol-Independent Commands	520
ip route	520
ip routing	521
key chain	521
key (key chain)	523
key-string	524
accept-lifetime	525
send-lifetime	526
show ip route	528
show ip protocols	529
show key-chains	530
show keys	531
44 RIP Commands	533
router rip	533
shutdown	533
redistribute static	534
default-metric	535
network	536
clear statistics	537
ip rip shutdown	537
ip rip passive-interface	538
ip rip default-information originate	538
ip rip offset	539
ip rip distribute-list in	539
ip rip distribute-list out	540
ip rip authentication mode	541
ip rip authentication key-chain	541
ip rip authentication-key	542
show ip rip database	543
show ip rip statistics	545

	show ip rip peers	546
45	ACL Commands	547
	ip access-list	547
	permit (IP)	547
	deny (IP)	549
	ipv6 access-list (IPv6 extended)	551
	permit (IPv6)	551
	deny (IPv6)	553
	mac access-list	554
	permit (MAC)	555
	deny (MAC)	556
	service-acl input	557
	service-acl output	558
	service-acl input block	558
	time-range	560
	absolute	560
	periodic	561
	show time-range	562
	show access-lists	563
	show interfaces access-lists	564
	clear access-lists counters	564
	show interfaces access-lists counters	565
46	Quality of Service (QoS) Commands	566
	qos	566
	qos advanced-mode trust	566
	show qos	567
	class-map	568
	show class-map	569
	match	569
	policy-map	570
	class	571
	show policy-map	572
	trust	572
	set	573
	police	574
	service-policy	575
	qos aggregate-policer	576
	show qos aggregate-policer	577
	police aggregate	577
	wrr-queue cos-map	578
	wrr-queue bandwidth	579
	priority-queue out num-of-queues	580
	traffic-shape	581
	traffic-shape queue	581
	rate-limit (Ethernet)	582
	rate-limit (VLAN)	583
	qos wrr-queue wrtd	583
	show qos wrr-queue wrtd	584
	show qos interface	584
	wrr-queue	587



qos wrr-queue threshold	587
qos map policed-dscp	588
qos map dscp-queue	589
qos map dscp-dp	589
qos trust (Global)	590
qos trust (Interface)	591
qos cos	591
qos dscp-mutation	592
qos map dscp-mutation	592
show qos map	593
clear qos statistics	594
qos statistics policer	594
qos statistics aggregate-policer	595
qos statistics queues	595
show qos statistics	596
security-suite enable	597
security-suite dos protect	598
security-suite deny martian-addresses	599
security-suite deny syn	601
47 Revision History	602

1 Preface

About this Document

This CLI Reference Guide describes how to use the CLI and a list of the CLI commands and their arguments.

The CLI commands described in this document are organized according to feature groups in separate sections.

This section describes how to use the CLI. It contains the following topics:

- [CLI Command Modes](#)
- [Starting the CLI](#)
- [CLI Command Conventions](#)
- [Entering Commands](#)
-

CLI Command Modes

To configure devices, the CLI is divided into various command modes. Each command mode has its own set of specific commands. Entering a question mark "?" at the console prompt displays a list of commands available for that particular command mode.

A specific command, which varies from mode to mode, is used to navigate from one mode to another. The standard order to access the modes is as follows: *User EXEC* mode, *Privileged EXEC* mode, *Global Configuration* mode, and *Interface Configuration* modes.

When starting a session, the initial mode for non-privileged users is the User EXEC mode. Only a limited subset of commands is available in the User EXEC mode. This level is reserved for tasks that do not change the configuration.

Privileged users enter the Privileged EXEC mode directly using a password. This mode provides access to the device Configuration modes.

The modes are described below.

User EXEC Mode

After logging into the device, the user is automatically in *User EXEC* command mode unless the user is defined as a privileged user. In general, the *User EXEC* commands enable the user to perform basic tests, and display system information.

The user-level prompt consists of the device "host name" followed by the angle bracket (>).

```
console>
```

The default host name is "console" unless it has been changed using the **hostname** command in the *Global Configuration* mode.

Privileged EXEC Mode

Privileged access is password-protected to prevent unauthorized use, because many of the privileged commands set operating system parameters: The password is not displayed on the screen and is case sensitive.

Privileged users enter directly into the *Privileged EXEC* mode.

Use **disable** to return to the *User EXEC* mode.

Global Configuration Mode

Global Configuration mode commands apply to features that affect the system as a whole, rather than just a specific interface.

To enter the *Global Configuration* mode, enter **configure** in the Privileged EXEC mode, and press <Enter>.

The *Global Configuration* mode prompt is displayed.

```
console(config)#
```

Use **exit**, **end** or **ctrl/z** to return to the Privileged EXEC mode.

Interface Configuration Modes

Commands in the following modes perform specific interface operations:

- **Line Interface** — Contains commands to configure the management connections. These include commands such as line speed, timeout settings, etc. The *Global Configuration* mode command **line** is used to enter the *Line Configuration command* mode.
- **VLAN Database** — Contains commands to create a VLAN as a whole. The *Global Configuration* mode command **vlan database** is used to enter the *VLAN Database Interface Configuration* mode.
- **Management Access List** — Contains commands to define management access-lists. The *Global Configuration* mode command **management access-list** is used to enter the *Management Access List Configuration* mode.
- **Port Channel** — Contains commands to configure port-channels, for example, assigning ports to a VLAN or port-channel. The *Global Configuration* mode command **port-channel** is used to enter the *Port Channel Interface Configuration* mode.
- **SSH Public Key-Chain** — Contains commands to manually specify other device SSH public keys. The *Global Configuration* mode command **crypto key pubkey-chain ssh** is used to enter the *SSH Public Key-chain Configuration* mode.
- **Interface** — Contains commands that configure the interface. The *Global Configuration* mode command **interface** is used to enter the *Interface Configuration* mode.

Starting the CLI

The switch can be managed over a direct connection to the switch console port, or via a Telnet connection. The switch is managed by entering command keywords and parameters at the prompt. Using the switch CLI commands is similar to entering commands on a UNIX system.

If access is via a Telnet connection, ensure the device has an IP address defined, corresponding management access is granted, and the workstation used to access the device is connected to the device prior to using CLI commands.

Accessing the CLI from the Console Line

1. Start the device and wait until the startup procedure is complete. The User Exec mode is entered, and the prompt "console>" is displayed.
2. Configure the device and enter the necessary commands to complete the required tasks.
3. When finished, exit the session with the **quit** or **exit** command.

Accessing the CLI from Telnet

1. Enter **telnet** and the IP address of the device. A User Name prompt is displayed.
2. Enter the User Name and Password. You are in the Privileged Exec mode.

3. Configure the device and enter the necessary commands to complete the required tasks.
4. When finished, exit the session with the quit or exit command.

When another user is required to log onto the system, the **login** command is entered in the Privileged EXEC command mode. This effectively logs off the current user and logs on the new user.

CLI Command Conventions

The following table describes the command syntax conventions.

Conventions	Description
[]	In a command line, square brackets indicates an optional entry.
{ }	In a command line, curly brackets indicate a selection of compulsory parameters separated by the character. One option must be selected. For example: flowcontrol {auto on off} means that for the flowcontrol command either auto , on or off must be selected.
<i>Italic font</i>	Indicates a parameter.
<Enter>	Any individual key on the keyboard. For example click <Enter>.
Ctrl+F4	Any combination keys pressed simultaneously on the keyboard.
Screen Display	Indicates system messages and prompts appearing on the console.
all	When a parameter is required to define a range of ports or parameters and all is an option, the default for the command is all when no parameters are defined. For example, the command interface range port-channel has the option of either entering a range of channels, or selecting all . When the command is entered without a parameter, it automatically defaults to all .
<i>interface-id</i>	This indicates a port, VLAN or LAG. The syntax for interface_id is as follows: <code>{port_type}port-number {vlan} vlan-id {port-channel} LAG-number</code>
<i>port_type</i>	Port type can be one of the following depending on the port types on the device: <ul style="list-style-type: none"> ■ 10/100 Mbps - Fastethernet can be shortened to fa, as in fa1 ■ 1000 Gbps Gigabitethernet can be shortened to GE or gi, as in GE 1 or gi1. ■ 10G Gbps - 10 Gigabitethernet can be shortened to FE, as in FE 1.

Entering Commands

A CLI command is a series of keywords and arguments. Keywords identify a command, and arguments specify configuration parameters. For example, in the command "**show interfaces status gi1/0/5**" **show**, **interfaces** and **status** are keywords, **gi** is an argument that specifies the interface type, and **1/0/5** is an argument that specifies the port.

To enter commands that require parameters, enter the required parameters after the command keyword. For example, to set a password for the administrator, enter:

```
console(config)# username admin password smith
```

Help information can be displayed in the following ways:

- **Keyword Lookup** — The character ? is entered in place of a command. A list of all valid commands and corresponding help messages are displayed.

- **Partial Keyword Lookup** — A command is incomplete and the character ? is entered in place of a parameter. The matched parameters for this command are displayed.

The following describes features that assist in using the CLI:

Terminal Command Buffer

Every time a command is entered in the CLI, it is recorded on an internally managed Command History buffer. Commands stored in the buffer are maintained on a First In First Out (FIFO) basis. These commands can be recalled, reviewed, modified, and reissued. This buffer is not preserved across device resets. The keys that can be used to access the history buffer are described in [Table 2](#).

By default, the history buffer system is enabled, but it can be disabled at any time. For information about the command syntax to enable or disable the history buffer, see the **history** command.

There is a standard default number of commands that are stored in the buffer. The standard number of 10 commands can be increased to 256. By configuring 0, the effect is the same as disabling the history buffer system. For information about the command syntax for configuring the command history buffer, see the **history size** command.

To display the history buffer, see **show history** command.

Negating the Effect of Commands

For many configuration commands, the prefix keyword "no" can be entered to cancel the effect of a command or reset the configuration to the default value. This guide describes the negation effect for all applicable commands.

Command Completion

If the command entered is incomplete, invalid, or has missing or invalid parameters, an appropriate error message is displayed.

To complete an incomplete command, press the <Tab> button. If the characters already entered are not enough for the system to identify a single matching command, press "?" to display the available commands matching the characters already entered.

Incorrect or incomplete commands are automatically re-entered next to the cursor. If a parameter must be added, the parameter can be added to the basic command already displayed next to the cursor. The following example indicates that the command interface requires a missing parameter.

```
(config)#interface
%missing mandatory parameter
(config)#interface
```

Keyboard Shortcuts

The CLI has a range of keyboard shortcuts to assist in entering the CLI commands.



The following table describes these shortcuts:

Table 2: Keyboard Keys

Keyboard Key	Description
Up-arrow key	Recalls commands from the history buffer, beginning with the most recent command. Repeat the key sequence to recall successively older commands.
Down-arrow key	Returns the most recent commands from the history buffer after recalling commands with the up arrow key. Repeating the key sequence will recall successively more recent commands.
Ctrl+A	Moves the cursor to the beginning of the command line.
Ctrl+E	Moves the cursor to the end of the command line.
Ctrl+Z / End	Returns back to the Privileged EXEC mode from any mode.
Backspace key	Moves the cursor back one space.
Up-arrow key	Recalls commands from the history buffer, beginning with the most recent command. Repeat the key sequence to recall successively older commands.

2

User Interface Commands

2.1 enable

The **enable** EXEC mode command enters the Privileged EXEC mode.

Syntax

enable [*privilege-level*]

Parameters

privilege-level—Specifies the privilege level at which to enter the system. (Range: 1, 7, 15)

Default Configuration

The default privilege level is 15.

Command Mode

EXEC mode

Example

The following example enters privilege level 7.

```
switchxxxxxx# enable 7
enter password:*****
switchxxxxxx#Accepted
```

The following example enters privilege level 15.

```
switchxxxxxx# enable
enter password:*****
switchxxxxxx#Accepted
```

2.2 disable

The **disable** Privileged EXEC mode command leaves the Privileged EXEC mode and returns to the User EXEC mode.

Syntax

disable [*privilege-level*]

Parameters

privilege-level—Reduces the privilege level to the specified privileged level. If privilege level is left blank, the level is reduce to 1.

Default Configuration

The default privilege level is 1.

Command Mode

Privileged EXEC mode

Example

The following example returns the user to user level 7.

```
switchxxxxxxx# disable 7
switchxxxxxxx#
```

2.3 login

The **login** EXEC mode command enables changing the user that is logged in. When this command is logged in, the user is prompted for a username/password.

Syntax

login

Parameters

N/A

Default Configuration

N/A

Command Mode

EXEC mode

Example

The following example enters Privileged EXEC mode and logs in with the required username 'bob'.

```
switchxxxxxxx# login
User Name:bob
Password:*****
switchxxxxxxx#
```

2.4 configure

The **configure** Privileged EXEC mode command enters the Global Configuration mode.

Syntax

configure [*terminal*]

Parameters

terminal—Enter the Global Configuration mode with or without the keyword terminal.

Command Mode

Privileged EXEC mode

Example

The following example enters Global Configuration mode.

```
switchxxxxxx# configure
switchxxxxxx(config)#
```

2.5 exit (Configuration)

The **exit** command exits any mode and brings the user to the next higher mode in the CLI mode hierarchy.

Syntax

exit

Parameters

N/A

Default Configuration

N/A

Command Mode

All.

Examples

The following examples change the configuration mode from Interface Configuration mode to Privileged EXEC mode.

```
switchxxxxxx(config-if)# exit
switchxxxxxx(config)# exit
```

2.6 exit (EXEC)

The **exit** EXEC mode command closes an active terminal session by logging off the device.

Syntax

exit

Parameters

N/A

Default Configuration

N/A



Command Mode

EXEC mode

Example

The following example closes an active terminal session.

```
switchxxxxxx# exit
```

2.7 end

The **end** command ends the current configuration session and returns to the Privileged EXEC mode.

Syntax

end

Parameters

N/A

Default Configuration

N/A

Command Mode

All

Example

The following example ends the Global Configuration mode session and returns to the Privileged EXEC mode.

```
switchxxxxxx(config)# end  
switchxxxxxx#
```

2.8 help

The **help** command displays a brief description of the Help system.

Syntax

help

Parameters

N/A

Default Configuration

N/A

Command Mode

All

Example

The following example describes the Help system.

```
switchxxxxxx# help
```

Help may be requested at any point in a command by entering a question mark '?'. If nothing matches the currently entered incomplete command, the help list is empty. This indicates that there is no command matching the input as it currently appears. If the request is within a command, press the Backspace key and erase the entered characters to a point where the request results in a match.

Help is provided when:

1. There is a valid command and a help request is made for entering a parameter or argument (e.g. 'show ?'). All possible parameters or arguments for the entered command are then displayed.
2. An abbreviated argument is entered and a help request is made for arguments matching the input (e.g. 'show pr?').

2.9 history

The **history** Line Configuration mode command enables saving commands that have been entered. Use the **no** form of this command to disable the command.

Syntax

history

no history

Parameters

N/A

Default Configuration

Enabled.

Command Mode

Line Configuration mode

User Guidelines

This command enables saving user-entered commands for a specified line. You can return to previous lines by using the up or down arrows.

It is effective from the next time that the user logs in via console/telnet/ssh.

The following are related commands:

- Use the [terminal history size](#) EXEC mode command to enable or disable this command for the current terminal session.
- Use the [history size](#) Line Configuration mode command to set the size of the command history buffer.

Example

The following example enables the command for Telnet.

```
switchxxxxxx(config)# line telnet
switchxxxxxx(config-line)# history
```

2.10 history size

The **history size** Line Configuration mode command changes the maximum number of user commands that are saved in the history buffer for a particular line. Use the **no** form of this command to reset the command history buffer size to the default value.

Syntax

history size *number-of-commands*

no history size

Parameters

number-of-commands—Specifies the number of commands the system records in its history buffer. (Range: 10–207)

Default Configuration

The default command history buffer size is 10 commands.

Command Mode

Line Configuration mode

User Guidelines

This command configures the command history buffer size for a particular line. It is effective from the next time that the user logs in via console/telnet/ssh.

Use the **terminal history size** EXEC mode command to configure the command history buffer size for the current terminal session.

The allocated command history buffer is per terminal user, and is taken from a shared buffer. If there is not enough space available in the shared buffer, the command history buffer size cannot be increased above the default size.

Example

The following example changes the command history buffer size to 100 entries for Telnet.

```
switchxxxxxx(config)# line telnet
switchxxxxxx(config-line)# history size 100
```

2.11 terminal history

The **terminal history** EXEC mode command enables the command history function for the current terminal session, meaning it is not stored in the Running Configuration file. Use the **no** form of this command to disable the command.

Syntax**terminal history****terminal no history****Default Configuration**

The default configuration for all terminal sessions is defined by the [history](#) Line Configuration mode command.

Command Mode

EXEC mode

User Guidelines

The command enables the command history for the current session. The default is determined by the [history](#) Line Configuration mode command.

This command is effective immediately.

Example

The following example disables the command history function for the current terminal session.

```
switchxxxxxxx# terminal no history
```

2.12 terminal history size

The **terminal history size** EXEC mode command changes the command history buffer size for the current terminal session, meaning it is not stored in the Running Configuration file. Use the **no** form of this command to reset the command history buffer size to the default value.

Syntax**terminal history size** *number-of-commands***terminal no history size****Parameters**

number-of-commands—Specifies the number of commands the system maintains in its history buffer. (Range: 10–207)

Default Configuration

The default configuration for all terminal sessions is defined by the [history size](#) Line Configuration mode command.

Command Mode

EXEC mode

User Guidelines

The **terminal history size** EXEC command changes the command history buffer size for the current terminal session. Use the [history](#) Line Configuration mode command to change the default history buffer size.

The maximum number of commands in all buffers is 207.

Example

The following example sets the command history buffer size to 20 commands for the current terminal session.

```
switchxxxxxx#terminal history size 20
```

2.13 terminal datadump

The **terminal datadump** EXEC mode command enables dumping all the output of a show command without prompting. Use the **no** form of this command to disable dumping.

Syntax

terminal datadump

no terminal datadump

Parameters

N/A

Default Configuration

When printing, dumping is disabled and printing is paused every 24 lines.

Command Mode

EXEC mode

User Guidelines

By default, a **More** prompt is displayed when the output contains more than 24 lines. Pressing the **Enter** key displays the next line; pressing the **Spacebar** displays the next screen of output.

The **terminal datadump** command enables dumping all output immediately after entering the show command by removing the pause.

The width is currently not limited (previously the limit was 77 chars), and the width of the line being printed on the terminal is based on the terminal itself.

This command is relevant only for the current session.

Example

The following example dumps all output immediately after entering a show command.

```
switchxxxxxx# terminal datadump
```

2.14 debug-mode

The **debug-mode** Privileged EXEC mode command mode switches to debug mode.

Syntax

debug-mode

Parameters

N/A

Default Configuration

N/A

Command Mode

Privileged EXEC mode

Example

The following example enters Debug mode.

```
switchxxxxxx# debug-mode
```

2.15 show history

The **show history** EXEC mode command lists commands entered in the current session.

Syntax

show history

Parameters

N/A

Default Configuration

N/A

Command Mode

EXEC mode

User Guidelines

The buffer includes executed and unexecuted commands.

Commands are listed from the first to the most recent command.

The buffer remains unchanged when entering into and returning from configuration modes.

Example

The following example displays all the commands entered while in the current Privileged EXEC mode.

```
switchxxxxxx# show version
SW version 3.131 (date 23-Jul-2005 time 17:34:19)
HW version 1.0.0
switchxxxxxx# show clock
15:29:03 Jun 17 2005
switchxxxxxx# show history
show version
show clock
show history
```

3 commands were logged (buffer size is 10)

2.16 show privilege

The **show privilege** EXEC mode command displays the current privilege level.

Syntax

show privilege

Parameters

N/A

Default Configuration

N/A

Command Mode

EXEC mode

Example

The following example displays the privilege level for the user logged on.

```
switchxxxxxx# show privilege
Current privilege level is 15
```

2.17 do

The **do** command executes an EXEC-level command from Global Configuration mode or any configuration submode.

Syntax

do *command*

Parameters

command—Specifies the EXEC-level command to execute.

Command Mode

All configuration modes

Example

The following example executes the **show vlan** Privileged EXEC mode command from Global Configuration mode.

Example

```
switchxxxxxx(config)# do show vlan
Vlan  Name          Ports          Type          Authorization
----  -
-----
```

```

1      1      fe1/0/11-39, Po1, Po2,      other      Required
2      2      fe1/0/11                  dynamicGvrp Required
10     v0010   fe1/0/11                  permanent   Not Required
11     v0011   fe1/0/11, fe1/0/13      permanent   Required
20     20     fe1/0/11                  permanent   Required
30     30     fe1/0/11, fe1/0/13      permanent   Required
31     31     fe1/0/11                  permanent   Required
91     91     fe1/0/11, fe1/0/14      permanent   Required
4093  guest-vlan fe1/0/11, fe1/0/13      permanent   Guest
switchxxxxxx (config) #

```

2.18 banner exec

Use the **banner exec** Global Configuration mode command to specify and enable a message to be displayed after a successful logon. Use the **no** form of this command to delete the existing EXEC banner.

Syntax

banner exec *d message-text d*

no banner exec

Parameters

- **d**—Delimiting character of user's choice—a pound sign (**#**), for example. You cannot use the delimiting character in the banner message.
- **message-text**—The message must start in a new line. You can enter multi-line messages. You can include tokens in the form of **\$(token)** in the message text. Tokens are replaced with the corresponding configuration variable (see User Guidelines). The message can contain up to 2000 characters (after every 510 characters, press **<Enter>** to continue).

Default Configuration

Disabled (no EXEC banner is displayed).

Command Mode

Global Configuration mode

User Guidelines

Follow this command with one or more blank spaces and a delimiting character of your choice. Then enter one or more lines of text, terminating the message with the second occurrence of the delimiting character.

Use tokens in the form of **\$(token)** in the message text to customize the banner. The tokens are described in the table below:

Token	Information Displayed in the Banner
\$(hostname)	Displays the host name for the device.
\$(domain)	Displays the domain name for the device.

Token	Information Displayed in the Banner
\$(bold)	Indicates that the next text is a bold text. Using this token again indicates the end of the bold text.
\$(inverse)	Indicates that the next text is an inverse text. Using this token again indicates the end of the inverse text.
\$(contact)	Displays the system contact string.
\$(location)	Displays the system location string.
\$(mac-address)	Displays the base MAC address of the device.

Use the **no banner exec** Line Configuration command to disable the Exec banner on a particular line or lines.

Example

The following example sets an EXEC banner that uses tokens. The percent sign (%) is used as a delimiting character. Note that the **\$(token)** syntax is replaced by the corresponding configuration variable.

```
switchxxxxxx(config)# banner exec %
Enter TEXT message. End with the character '%'.
$(bold)Session activated.$(bold) Enter commands at the prompt.
%
```

When a user logs on to the system, the following output is displayed:
Session activated. Enter commands at the prompt.

2.19 banner login

Use the **banner login** command in Global Configuration mode to specify a message to be displayed before the username and password login prompts. This banner is applied automatically on all the CLI interfaces: Console, Telnet and SSH and also on the WEB GUI. Use the **no** form of this command to delete the existing login banner.

Syntax

banner login *d message-text d*

no banner login

Parameters

- **d**—Delimiting character of user's choice—a pound sign (#), for example. You cannot use the delimiting character in the banner message.
- **message-text**—Message text. The message must start on a new line. You can enter multi-line messages. You can include tokens in the form of **\$(token)** in the message text. Tokens are replaced with the corresponding configuration variable (see User Guidelines). The message can contain up to 2000 characters (after every 510 characters, you must press <Enter> to continue).

Default Configuration

Disabled (no Login banner is displayed).

Command Mode

Global Configuration mode

User Guidelines

Follow this command with one or more blank spaces and a delimiting character of your choice. Then enter one or more lines of text, terminating the message with the second occurrence of the delimiting character.

Use tokens in the form of **\$(token)** in the message text to customize the banner. The tokens are described in the table below:

Token	Information displayed in the banner
\$(hostname)	Displays the host name for the device.
\$(domain)	Displays the domain name for the device.
\$(bold)	Indicates that the next text is a bold text. Using this token again indicates the end of the bold text.
\$(inverse)	Indicates that the next text is an inverse text. Using this token again indicates the end of the inverse text.
\$(contact)	Displays the system contact string.
\$(location)	Displays the system location string.
\$(mac-address)	Displays the base MAC address of the device.

Use the **no banner login** Line Configuration command to disable the Login banner on a particular line or lines.

Example

The following example sets a Login banner that uses tokens. The percent sign (%) is used as a delimiting character. Note that the **\$(token)** syntax is replaced by the corresponding configuration variable.

```
switchxxxxxx(config)# banner login %
Enter TEXT message. End with the character '%'.
You have entered $(hostname) .$(domain)
%
When the login banner is executed, the user will see the following banner:
You have entered host123.ourdomain.com
```

2.20 banner motd

Use the **banner motd** command in Global Configuration mode to specify and enable a message-of-the-day banner. This message is displayed before the login banner. Use the **no** form of this command to delete the existing MOTD banner.

Syntax

banner motd *d message-text d*

no banner motd

Parameters

- **d**—Delimiting character of user’s choice—a pound sign (#), for example. You cannot use the delimiting character in the banner message.
- **message-text**—The message must start on a new line. You can enter multi-line messages. You can include tokens in the form of **\$(token)** in the message text. Tokens are replaced with the corresponding configuration variable. Tokens are described in the User Guidelines. The message can contain up to 2000 characters (after every 510 characters, you must press <Enter> to continue).

Default Configuration

Disabled (no MOTD banner is displayed).

Command Mode

Global Configuration mode

User Guidelines

Follow this command with one or more blank spaces and a delimiting character of your choice. Then enter one or more lines of text, terminating the message with the second occurrence of the delimiting character.

When a user connects to a device, the message-of-the-day (MOTD) banner appears first, followed by the login banner and prompts. After the user logs in to the device, the EXEC banner is displayed.

Use tokens in the form of **\$(token)** in the message text to customize the banner. The tokens are described in the table below:

Token	Information displayed in the banner
\$(hostname)	Displays the host name for the device.
\$(domain)	Displays the domain name for the device.
\$(bold)	Indicates that the next text is a bold text. Using this token again to indicates the end of the bold text.
\$(inverse)	Indicates that the next text is an inverse text. Using this token again indicates the end of the inverse text.
\$(contact)	Displays the system contact string.
\$(location)	Displays the system location string.
\$(mac-address)	Displays the base MAC address of the device.

Use the **no banner motd** Line Configuration command to disable the MOTD banner on a particular line or lines.

Example

The following example sets an MOTD banner that uses tokens. The percent sign (%) is used as a delimiting character. Note that the **\$(token)** syntax is replaced by the corresponding configuration variable.

```
switchxxxxxx(config)# banner motd %
Enter TEXT message. End with the character '%'.
$(bold)Upgrade$(bold) to all devices begins at March 12
%
```

When the login banner is executed, the user will see the following banner:
Upgrade to all devices begins at March 12

2.21 exec-banner

Use the **exec-banner** command in Line Configuration mode to enable the display of exec banners. Use the **no** form of this command to disable the display of exec banners.

Syntax

exec-banner

no exec-banner

Parameters

This command has no arguments or keywords.

Default Configuration

Disabled

Command Mode

Line Configuration mode

Example

```
switchxxxxxx# configure
switchxxxxxx(config)# line console
switchxxxxxx(config-line)# exec-banner
switchxxxxxx(config-line)# exit
switchxxxxxx(config)# line telnet
switchxxxxxx(config-line)# exec-banner
switchxxxxxx(config-line)# exit
switchxxxxxx(config)# line ssh
switchxxxxxx(config-line)# exec-banner
```

2.22 login-banner

Use the **login-banner** command in Line Configuration mode to enable the display of login banners. Use the **no** form of this command to disable the display of login banners.

Syntax

login-banner

no login-banner

Parameters

This command has no arguments or keywords.



Default Configuration

Enabled

Command Mode

Line Configuration mode

Example

```
switchxxxxxx# configure
switchxxxxxx(config)# line console
switchxxxxxx(config-line)# login-banner
switchxxxxxx(config-line)# exit
switchxxxxxx(config)# line telnet
switchxxxxxx(config-line)# login-banner
switchxxxxxx(config-line)# exit
switchxxxxxx(config)# line ssh
switchxxxxxx(config-line)# login-banner
```

2.23 motd-banner

Use the **motd-banner** command in Line Configuration mode to enable the display of message-of-the-day banners. Use the **no** form of this command to disable the display of MOTD banners.

Syntax

motd-banner

no motd-banner

Parameters

This command has no arguments or keywords.

Default Configuration

Enabled

Command Mode

Line Configuration mode

Example

```
switchxxxxxx# configure
switchxxxxxx(config)# line console
switchxxxxxx(config-line)# motd-banner
switchxxxxxx(config-line)# exit
switchxxxxxx(config)# line telnet
switchxxxxxx(config-line)# motd-banner
```

```
switchxxxxxx(config-line)# exit
switchxxxxxx(config)# line ssh
switchxxxxxx(config-line)# motd-banner
```

2.24 show banner

Use the **show banner** commands in EXEC mode to display the banners that have been defined.

Syntax

>show banner motd

show banner login

show banner exec

Parameters

This command has no arguments or keywords.

Command Mode

EXEC mode

Examples

```
switchxxxxxx# show banner motd
Banner: MOTD
Line SSH: Enabled
Line Telnet: Enabled
Line Console: Enabled
10000 giga ports switch
switchxxxxxx# show banner login
-----
Banner: Login
Line SSH: Enabled
Line Telnet: Enabled
Line Console: Enabled
switchxxxxxx# show banner exec
```

```
Banner: EXEC
Line SSH: Enabled
Line Telnet: Enabled
Line Console: Enabled
You have logged on
```

3

Macro Commands

3.1 macro name

Use the **macro name** Global Configuration mode command to define a macro. There are two types of macros that can be defined:

- Global macros define a group of CLI commands that can be run at any time.
- Smartport macros are associated with Smartport types ([Section 45 "Smartport Commands"](#)). For each Smartport macro there must be an anti macro (a macro whose name is concatenated with **no_**). The anti macro reverses the action of the macro.

If a macro with this name already exists, it overrides the previously-defined one.

Use the **no** form of this command to delete the macro definition.

Syntax

macro name [*macro-name*]

no macro name [*macro-name*]

Parameters

macro-name—Name of the macro. Macro names are case sensitive.

Default Configuration

N/A

Command Mode

Global Configuration mode

User Guidelines

A macro is a script that contains CLI commands and is assigned a name by the user. It can contain up to 3000 characters and 200 lines.

Keywords

Macros may contain keywords (parameters). The following describes keywords:

- A macro can contain up to three keywords.
- All matching occurrences of the keyword are replaced by the corresponding value specified in [macro apply](#).
- Keyword matching is case-sensitive
- Applying a macro with keywords does not change the state of the original macro definition.

User Feedback

The behavior of a macro command requiring user feedback is the same as if the command is entered from terminal: it sends its prompt to the terminal and accepts the user reply.

Creating a Macro

Use the following guidelines to create a macro:

- Use **macro name** to create the macro with the specified name.
- Enter one macro command per line.
- Use the **@** character to end the macro.

- Use the **#** character at the beginning of a line to enter a comment in the macro. In addition, **#** is used to identify certain preprocessor commands that can only be used within a macro. There are two possible preprocessor commands:
 - **#macro key description** - Each macro can be configured with up to 3 keyword/description pairs. The keywords and descriptions are displayed in the GUI pages when the macro is displayed.

The syntax for this preprocessor command is as follows:

```
#macro key description $keyword1 description1 $keyword2 description2 $keyword3 description3
```

A keyword must be prefixed with '\$'.
 - **#macro keywords** - This instruction enables the device to display the keywords as part of the CLI help. It accepts up to 3 keywords. The command creates a CLI help string with the keywords for the macro. The help string will be displayed if help on the macro is requested from the [macro apply](#) and [macro global](#) commands. The GUI also uses the keywords specified in the command as the parameter names for the macro. See Example 2 and 3 below for a description of how this command is used in the CLI.

The syntax for this preprocessor command is as follows:

```
#macro keywords $keyword-1 $keyword2 $keyword3
```

where \$keyword-n is the name of the keyword.

Editing a Macro

Macros cannot be edited. Modify a macro by creating a new macro with the same name as the existing macro. The newer macro overwrites the existing macro.

The exceptions to this are the built-in macros and corresponding anti-macros for the Smartport feature. You cannot override a Smartport macro. To change a Smartport macro, create a new macro (`my_macro`) and an anti macro (`no_my_macro`) and associate it with the Smartport type using [macro auto user smartport macro](#).

Scope of Macro

It is important to consider the scope of any user-defined macro. Because of the potential hazards of applying unintended configurations, do not change configuration modes within the macro by using commands such as **exit**, **end**, or **interface interface-id**. With a few exceptions, there are other ways of executing macros in the various configuration modes. Macros may be executed in Privileged Exec mode, Global Configuration mode, and Interface Configuration mode (when the interface is NOT a VLAN.)

Examples

Example 1 -The following example shows how to create a macro that configures the duplex mode of a port.

```
switchxxxxxx(config)# macro name dup
Enter macro commands one per line. End with the character '@'.
#macro description dup
duplex full
negotiation
@
```

Example 2 -The following example shows how to create a macro with the parameters: DUPLEX and SPEED. When the macro is run, the values of DUPLEX and SPEED must be provided by the user. The **#macro keywords** command enables the user to receive help for the macro as shown in Example 3.

```
switchxxxxxx(config) # macro name duplex
Enter macro commands one per line. End with the character '@'.
duplex $DUPLEX
no negotiation
speed $SPEED
#macro keywords $DUPLEX $SPEED
@
```

Example 3 -The following example shows how to display the keywords using the help character ? (as defined by the **macro keywords** command above) and then run the macro on the port. The **#macro keywords** command entered in the macro definition enables the user to receive help for the macro, as shown after the words e.g. below.

```
switchxxxxxx(config-if) #interface gi1
switchxxxxxx(config-if) #macro apply duplex ?
WORD <1-32> Keyword to replace with value e.g. $DUPLEX, $SPEED
<cr>
switchxxxxxx(config-if) #macro apply duplex $DUPLEX ?
WORD<1-32> First parameter value
<cr>
switchxxxxxx(config-if) #macro apply duplex $DUPLEX full $SPEED ?
WORD<1-32> Second parameter value
switchxxxxxx(config-if) #macro apply duplex $DUPLEX full $SPEED 100
```

3.2 macro apply

Use the **macro apply/trace** Interface Configuration command to either:

- Apply a macro to an interface without displaying the actions being performed
- Apply a macro to the interface while displaying the actions being performed

Syntax

macro {**apply** | **trace**} *macro-name* [*parameter-name1* {*value*}] [*parameter-name2* {*value*}] [*parameter-name3* {*value*}]

Parameters

- **apply**—Apply a macro to the specific interface.
- **trace**—Apply and trace a macro to the specific interface.
- **macro-name**—Name of the macro.
- **parameter-name value**—(Optional) For each parameter defined in the macro, specify its name and value. You can enter up to three parameter-value pairs. Parameter keyword matching is case sensitive. All matching occurrences of the parameter name in the macro are replaced with the corresponding value.

Default Configuration

The command has no default setting.

Command Mode

Interface Configuration mode

User Guidelines

The **macro apply** command hides the commands of the macro from the user while it is being run. The **macro trace** command displays the commands along with any errors which are generated by them as they are executed. This is used to debug the macro and find syntax or configuration errors.

When you run a macro, if a line in it fails because of a syntax or configuration error, the macro continues to apply the remaining commands to the interface.

If you apply a macro that contains parameters in its commands, the command fails if you do not provide the values for the parameters. You can use the **macro apply macro-name** with a '?' to display the help string for the macro keywords (if you have defined these with the **#macro keywords** preprocessor command).

Parameter (keyword) matching is case sensitive. All matching occurrences of the parameter are replaced with the provided value. Any full match of a keyword, even if it is part of a large string, is considered a match and replaced by the corresponding value.

When you apply a macro to an interface, the switch automatically generates a macro description command with the macro name. As a result, the macro name is appended to the macro history of the interface. The **show parser macro** command displays the macro history of an interface.

A macro applied to an interface range behaves the same way as a macro applied to a single interface. When a macro is applied to an interface range, it is applied sequentially to each interface within the range. If a macro command fails on one interface, it is nonetheless attempted to be applied and may fail or succeed on the remaining interfaces.

Examples.

Example 1 - The following is an example of a macro being applied to an interface with the trace option.

```
switchxxxxxx(config) # interface fe1/0/12
switchxxxxxx<config-if> # macro trace dup $DUPLEX full $SPEED 100
  Applying command.. 'duplex full'
  Applying command.. 'speed 100'
switchxxxxxx<config-if> #
```

Example 2 - The following is an example of a macro being applied without the trace option.

```
switchxxxxxx(config) # interface fe1/0/12
switchxxxxxx<config-if> # macro apply dup $DUPLEX full $SPEED 100
switchxxxxxx<config-if> #
```

Example 3 - The following is an example of an incorrect macro being applied.

```
switchxxxxxx(config-if) #macro trace dup
Applying command...'duplex full'
Applying command...'speed auto'
% bad parameter value
```

3.3 macro description

Use the **macro description** Interface Configuration mode command to append a description, for example, a macro name, to the macro history of an interface. Use the **no** form of this command to clear the macro history of an interface. When the macro is applied to an interface, the switch automatically generates a macro description command with the macro name. As a result, the name of the macro is appended to the macro history of the interface.

Syntax

macro description *text*

no macro description

Parameters

text—Description text. The text can contain up to 160 characters. The text must be double quoted if it contains multiple words.

Default Configuration

The command has no default setting.

Command Mode

Interface Configuration mode

User Guidelines

When multiple macros are applied on a single interface, the description text is a concatenation of texts from a number of previously-applied macros.

To verify the settings created by this command, run [show parser macro](#).

Example

```
switchxxxxxx(config)#interface fe1/0/12
switchxxxxxx(config-if)#macro apply dup
switchxxxxxx(config-if)#exit
switchxxxxxx(config)#interface fe1/0/13
switchxxxxxx(config-if)#macro apply duplex $DUPLEX full SPEED 100
switchxxxxxx(config-if)#macro description dup
switchxxxxxx(config-if)#macro description duplex
switchxxxxxx(config-if)#end
switchxxxxxx#show parser macro description
Global Macro(s):
Interface      Macro Description(s)
-----
fe1/0/12      dup
fe1/0/13      duplex | dup | duplex
-----
switchxxxxxx#configure
```

```

switchxxxxxx(config)#interface fel/0/12
switchxxxxxx(config-if)#no macro description
switchxxxxxx(config-if)#end
switchxxxxxx#show parser macro description
Global Macro(s):
Interface      Macro Description(s)
-----
gi3            duplex | dup | duplex
-----
switchxxxxxx#

```

3.4 macro global

Use the **macro global** Global Configuration command to apply a macro to a switch (with or without the trace option).

Syntax

```

macro global {apply | trace} macro-name [parameter-name1 {value}] [parameter-name2 {value}]
[parameter-name3 {value}]

```

Parameters

- **apply**—Apply a macro to the switch.
- **trace**—Apply and trace a macro to the switch.
- **macro-name**—Specify the name of the macro.
- **parameter-name value**—(Optional) Specify the parameter values required for the switch. You can enter up to three parameter-value pairs. Parameter keyword matching is case sensitive. All matching occurrences of the parameters are replaced with the corresponding value.

Default Configuration

The command has no default setting.

Command Mode

Global Configuration mode

User Guidelines

If a command fails because of a syntax error or a configuration error when you apply a macro, the macro continues to apply the remaining commands to the switch.

Keyword matching is case sensitive. All matching occurrences of the keyword are replaced with the corresponding value. Any full match of a keyword, even if it is part of a large string, is considered a match and replaced by the corresponding value.

If you apply a macro that contains keywords in its commands, the command fails if you do not specify the proper values for the keywords when you apply the macro. You can use this command with a '?' to display the help string for the macro keywords. You define the keywords in the help string using the preprocessor command **#macro keywords** when you define a macro.

When you apply a macro in Global Configuration mode, the switch automatically generates a global macro description command with the macro name. As a result, the macro name is appended to the global macro history. Use **show parser macro** to display the global macro history.

Example.

The following is an example of a macro being defined and then applied to the switch with the trace option.

```
switchxxxxxx(config)# macro name console-timeout
Enter macro commands one per line. End with the character '@'.
line console
exec-timeout $timeout-interval
@
switchxxxxxx(config)# macro global trace console-timeout $timeout-interval 100
Applying command... 'line console'
Applying command... 'exec-timeout 100'
switchxxxxxx(config)#
```

3.5 macro global description

Use the **macro global description** Global Configuration command to enter a description which is used to indicate which macros have been applied to the switch. Use the **no** form of this command to remove the description.

Syntax

macro global description *text*

no macro global description

Parameters

text—Description text. The text can contain up to 160 characters.

Default Configuration

The command has no default setting.

Command Mode

Global Configuration mode

User Guidelines

When multiple global macros are applied to a switch, the global description text is a concatenation of texts from a number of previously applied macros.

You can verify your settings by entering the **show parser macro description** privileged EXEC mode command.

Examples

```
switchxxxxxx(conf)# macro global description "set console timeout interval"
```


3.6 show parser macro

Use the **show parser macro** User EXEC mode command to display the parameters for all configured macros or for one macro on the switch.

Syntax

```
show parser macro [{brief | description [interface interface-id] | name macro-name}]
```

Parameters

- **brief**—Display the name of all macros.
- **description** [**interface** *interface-id*]—Display the macro descriptions for all interfaces or if an interface is specified, display the macro descriptions for that interface.
- **name** *macro-name*—Display information about a single macro identified by the macro name.

Command Mode

User EXEC mode

Examples

Example 1 - This is a partial output example from the **show parser macro** command.

```
switchxxxxxx# show parser macro
Total number of macros = 6
-----
Macro name : cisco-global
Macro type : default global
# Enable dynamic port error recovery for link state
# failures
<output truncated>
-----
Macro name : cisco-desktop
Macro type : default interface
# macro keywords $AVID
# Basic interface - Enable data VLAN only
# Recommended value for access vlan (AVID) should not be 1
switchport access vlan $AVID
switchport mode access
<output truncated>
```

Example 2 - This is an example of output from the **show parser macro name** command.

```
switchxxxxxx# show parser macro standard-switch10
Macro name : standard-switch10
Macro type : customizable
macro description standard-switch10
```

```
# Trust QoS settings on VOIP packets
auto qos voip trust
# Allow port channels to be automatically formed
channel-protocol pagp
```

Example 3 - This is an example of output from the **show parser macro brief** command.

```
switchxxxxxx# show parser macro brief
default global : cisco-global
default interface: cisco-desktop
default interface: cisco-phone
default interface: cisco-switch
default interface: cisco-router
customizable : snmp
```

This is an example of output from the **show parser macro description** command.

```
switchxxxxxx# show parser macro description
Global Macro(s): cisco-global
```

Example 4 - This is an example of output from the **show parser macro description interface** command.

```
switchxxxxxx# show parser macro description interface fel/0/12
Interface Macro Description
-----
fel/0/12 this is test macro
-----
```

4

System Management Commands

4.1 ping

Use the **ping** EXEC mode command to send ICMP echo request packets to another node on the network.

Syntax

ping [ip] {ipv4-address | hostname} [size packet_size] [count packet_count] [timeout time_out]

ping ipv6 {ipv6-address | hostname} [size packet_size] [count packet_count] [timeout time_out]

Parameters

- **ip**—Use IPv4 to check the network connectivity.
- **ipv6**—Use IPv6 to check the network connectivity.
- **ipv4-address**—IPv4 address to ping.
- **ipv6-address**—Unicast or Multicast IPv6 address to ping. When the IPv6 address is a Link Local address (IPv6Z address), the outgoing interface name must be specified. See [IPv6Z Address Conventions](#).
- **hostname**—Hostname to ping (Length: 1-160 characters. Maximum label size for each part of the host name: 63.)
- **size packet_size**—Number of bytes in the packet not including the VLAN tag. The default is 64 bytes. (IPv4:64–1518, IPv6: 68–1518)
- **count packet_count**—Number of packets to send, from 1 to 65535 packets. The default is 4 packets. If 0 is entered, it pings until stopped (0–65535).
- **time time_out**—Timeout in milliseconds to wait for each reply, from 50 to 65535 milliseconds. The default is 2000 milliseconds (50–65535).

Default Usage

N/A

Command Mode

EXEC mode

User Guidelines

Press **Esc** to stop pinging. Following are sample results of the ping command:

- **Destination does not respond**—If the host does not respond, a “no answer from host” appears within 10 seconds.
- **Destination unreachable**—The gateway for this destination indicates that the destination is unreachable.
- **Network or host unreachable**—The switch found no corresponding entry in the route table.

See [IPv6z Address Conventions](#).

When using the ping **ipv6** command to check network connectivity of a directly attached host using its link local address, the egress interface may be specified in the **IPv6Z** format. If the egress interface is not specified, the default interface is selected.

When using the ping **ipv6** command with a Multicast address, the information displayed is taken from all received echo responses.

Examples

Example 1 - Ping an IP address.

```
switchxxxxxx# ping ip 10.1.1.1
Pinging 10.1.1.1 with 64 bytes of data:
64 bytes from 10.1.1.1: icmp_seq=0. time=11 ms
64 bytes from 10.1.1.1: icmp_seq=1. time=8 ms
64 bytes from 10.1.1.1: icmp_seq=2. time=8 ms
64 bytes from 10.1.1.1: icmp_seq=3. time=7 ms
----10.1.1.1 PING Statistics----
4 packets transmitted, 4 packets received, 0% packet loss
round-trip (ms) min/avg/max = 7/8/11
```

Example 2 - Ping a site.

```
switchxxxxxx# ping ip yahoo.com
Pinging yahoo.com [66.218.71.198] with 64 bytes of data:
64 bytes from 10.1.1.1: icmp_seq=0. time=11 ms
64 bytes from 10.1.1.1: icmp_seq=1. time=8 ms
64 bytes from 10.1.1.1: icmp_seq=2. time=8 ms
64 bytes from 10.1.1.1: icmp_seq=3. time=7 ms
----10.1.1.1 PING Statistics----
4 packets transmitted, 4 packets received, 0% packet loss
round-trip (ms) min/avg/max = 7/8/11
```

Example 3 - Ping an IPv6 address.

```
switchxxxxxx# ping ipv6 3003::11
Pinging 3003::11 with 64 bytes of data:
64 bytes from 3003::11: icmp_seq=1. time=0 ms
64 bytes from 3003::11: icmp_seq=2. time=50 ms
64 bytes from 3003::11: icmp_seq=3. time=0 ms
64 bytes from 3003::11: icmp_seq=4. time=0 ms
----3003::11 PING Statistics----
4 packets transmitted, 4 packets received, 0% packet loss
round-trip (ms) min/avg/max = 0/12/50
```

```
switchxxxxxx# ping ipv6 FF02::1
Pinging FF02::1 with 64 bytes of data:
64 bytes from 3003::11: icmp_seq=1. time=0 ms
64 bytes from 3003::33: icmp_seq=1. time=70 ms
64 bytes from 3003::11: icmp_seq=2. time=0 ms
64 bytes from 3003::55: icmp_seq=1. time=1050 ms
64 bytes from 3003::33: icmp_seq=2. time=70 ms
```

```

64 bytes from 3003::55: icmp_seq=2. time=1050 ms
64 bytes from 3003::11: icmp_seq=3. time=0 ms
64 bytes from 3003::33: icmp_seq=3. time=70 ms
64 bytes from 3003::11: icmp_seq=4. time=0 ms
64 bytes from 3003::55: icmp_seq=3. time=1050 ms
64 bytes from 3003::33: icmp_seq=4. time=70 ms
64 bytes from 3003::55: icmp_sq=4. time=1050 ms
---- FF02::1 PING Statistics----
4 packets transmitted, 12 packets received

```

4.2 traceroute

To display the routes that packets will take when traveling to their destination, use the **traceroute** EXEC mode command.

Syntax

```
traceroute ip {ipv4-address | hostname} [size packet_size] [ttl max-ttl] [count packet_count]
[timeout time_out] [source ip-address] [tos tos]
```

```
traceroute ipv6 {ipv6-address | hostname} [size packet_size] [ttl max-ttl] [count packet_count]
[timeout time_out] [source ip-address] [tos tos]
```

Parameters

- **ip**—Use IPv4 to discover the route.
- **ipv6**—Use IPv6 to discover the route.
- **ipv4-address**—IPv4 address of the destination host.
- **ipv6-address**—IPv6 address of the destination host.
- **hostname**—Hostname of the destination host. (Length: 1-160 characters. Maximum label size for each part of the host name: 63.)
- **size packet_size**—Number of bytes in the packet not including the VLAN tag. The default is 64 bytes. (IPv4:64-1518, IPv6: 68-1518)
- **ttl max-ttl**—The largest TTL value that can be used. The default is 30. The **traceroute** command terminates when the destination is reached or when this value is reached. (Range: 1–255)
- **count packet_count**—The number of probes to be sent at each TTL level. The default count is 3. (Range: 1–10)
- **timeout time_out**—The number of seconds to wait for a response to a probe packet. The default is 3 seconds. (Range: 1–60)
- **source ip-address**—One of the interface addresses of the device to use as a source address for the probes. The device selects the optimal source address by default. (Range: Valid IP address)
- **tos tos**—The Type-Of-Service byte in the IP Header of the packet. (Range: 0–255)

Default Usage

N/A

Command Mode

EXEC mode

User Guidelines

The traceroute command works by taking advantage of the error messages generated by routers when a datagram exceeds its time-to-live (TTL) value.

The traceroute command starts by sending probe datagrams with a TTL value of one. This causes the first router to discard the probe datagram and send back an error message. The traceroute command sends several probes at each TTL level and displays the round-trip time for each.

The traceroute command sends out one probe at a time. Each outgoing packet can result in one or two error messages. A "time exceeded" error message indicates that an intermediate router has seen and discarded the probe. A "destination unreachable" error message indicates that the destination node has received the probe and discarded it because it could not deliver the packet. If the timer goes off before a response comes in, the traceroute command prints an asterisk (*).

The traceroute command terminates when the destination responds, when the maximum TTL is exceeded, or when the user interrupts the trace with Esc.

The traceroute command is not relevant to IPv6 link local addresses.

Example

```
switchxxxxxx# traceroute ip umaxp1.physics.lsa.umich.edu
Type Esc to abort.
Tracing the route to umaxp1.physics.lsa.umich.edu (141.211.101.64)
 1 i2-gateway.stanford.edu (192.68.191.83)  0 msec 0 msec 0 msec
 2 STAN.POS.calren2.NET (171.64.1.213) 0 msec 0 msec 0 msec
 3 SUNV--STAN.POS.calren2.net (198.32.249.73) 1 msec 1 msec 1 msec
 4 Abilene--QSV.POS.calren2.net (198.32.249.162)  1 msec 1 msec 1 msec
 5 kscyng-snvang.abilene.ucaid.edu (198.32.8.103)  33 msec 35 msec 35 msec
 6 iplsnq-kscyng.abilene.ucaid.edu (198.32.8.80)  47 msec 45 msec 45 msec
 7 so-0-2-0x1.aa1.mich.net (192.122.183.9)  56 msec  53 msec 54 msec
 8 atm1-0x24.michnet8.mich.net (198.108.23.82)  56 msec 56 msec 57 msec
 9 * * *
10 A-ARB3-LSA-NG.c-SEB.umnet.umich.edu(141.211.5.22)58 msec 58msec 58
msec
11 umaxp1.physics.lsa.umich.edu (141.211.101.64)  62 msec 63 msec 63 msec
Trace completed
```

The following table describes the significant fields shown in the display:

Field	Description
1	Indicates the sequence number of the router in the path to the host.
i2-gateway.stanford.edu	Host name of this router.
192.68.191.83	IP address of this router.
1 msec 1 msec 1 msec	Round-trip time for each of the probes that are sent.

The following are characters that can appear in the traceroute command output:

Field	Description
*	The probe timed out.
?	Unknown packet type.
A	Administratively unreachable. Usually, this output indicates that an access list is blocking traffic.
F	Fragmentation required and DF is set.
H	Host unreachable.
N	Network unreachable.
P	Protocol unreachable.
Q	Source quench.
R	Fragment reassembly time exceeded
S	Source route failed.
U	Port unreachable.

4.3 telnet

The **telnet** EXEC mode command enables logging on to a host that supports Telnet.

Syntax

```
telnet {ip-address | hostname} [port] [keyword...]
```

Parameters

- **ip-address**—Specifies the destination host IP address (IPv4 or IPv6).
- **hostname**—Specifies the destination host name. (Length: 1-160 characters. Maximum label size for each part of the host name: 63.)
- **port**—Specifies the decimal TCP port number or one of the keywords listed in the Ports table in the User Guidelines.
- **keyword**—Specifies the one or more keywords listed in the Keywords table in the User Guidelines.

Default Configuration

The default port is the Telnet port (23) on the host.

By default, Telnet is disabled.

Command Mode

EXEC mode

User Guidelines

Telnet software supports special Telnet commands in the form of Telnet sequences that map generic terminal control functions to operating system-specific functions. To enter a Telnet sequence, press the escape sequence keys (Ctrl-shift-6) followed by a Telnet command character.

Special Telnet Sequences

Telnet Sequence	Purpose
Ctrl-shift-6-b	Break
Ctrl-shift-6-c	Interrupt Process (IP)
Ctrl-shift-6-h	Erase Character (EC)
Ctrl-shift-6-o	Abort Output (AO)
Ctrl-shift-6-t	Are You There? (AYT)
Ctrl-shift-6-u	Erase Line (EL)

At any time during an active Telnet session, available Telnet commands can be listed by pressing the `?/help` keys at the system prompt.

A sample of this list follows.

```
switchxxxxxx# ?/help
[Special telnet escape help]
^^ B sends telnet BREAK
^^ C sends telnet IP
^^ H sends telnet EC
^^ O sends telnet AO
^^ T sends telnet AYT
^^ U sends telnet EL
?/help suspends the session (return to system command prompt)
```

Several concurrent Telnet sessions can be opened, enabling switching between the sessions. To open a subsequent session, the current connection has to be suspended by pressing the escape sequence keys (Ctrl-shift-6) and x to return to the system command prompt. Then open a new connection with the telnet EXEC mode command.

This command lists concurrent Telnet connections to remote hosts that were opened by the current Telnet session to the local device. It does not list Telnet connections to remote hosts that were opened by other Telnet sessions.

Keywords Table

Options	Description
<code>/echo</code>	Enables local echo.
<code>/quiet</code>	Prevents onscreen display of all messages from the software.
<code>/source-interface</code>	Specifies the source interface.
<code>/stream</code>	Turns on stream processing, which enables a raw TCP stream with no Telnet control sequences. A stream connection does not process Telnet options and can be appropriate for connections to ports running UNIX-to-UNIX Copy Program (UUCP) and other non-Telnet protocols.
Ctrl-shift-6 x	Returns to the System Command Prompt.

Ports Table

Keyword	Description	Port Number
BGP	Border Gateway Protocol	179
chargen	Character generator	19
cmd	Remote commands	514
daytime	Daytime	13
discard	Discard	9
domain	Domain Name Service	53
echo	Echo	7
exec	Exec	512
finger	Finger	79
ftp	File Transfer Protocol	21
ftp-data	FTP data connections	20
gopher	Gopher	70
hostname	NIC hostname server	101
ident	Ident Protocol	113
irc	Internet Relay Chat	194
klogin	Kerberos login	543
kshell	Kerberos shell	544
login	Login	513
lpd	Printer service	515
nntp	Network News Transport Protocol	119
pim-auto-rp	PIM Auto-RP	496
pop2	Post Office Protocol v2	109
pop3	Post Office Protocol v3	110
smtp	Simple Mail Transport Protocol	25
sunrpc	Sun Remote Procedure Call	111
syslog	Syslog	514
tacacs	TAC Access Control System	49
talk	Talk	517
telnet	Telnet	23
time	Time	37
uucp	Unix-to-Unix Copy Program	540
whois	Nickname	43
www	World Wide Web	80

Example

The following example displays logging in to IP address 176.213.10.50 via Telnet.

```
switchxxxxxx# telnet 176.213.10.50
```

4.4 resume

The **resume** EXEC mode command enables switching to another open Telnet session.

Syntax

resume [*connection*]

Parameters

connection—Specifies the connection number. (Range: 1-4 connections.)

Default Configuration

The default connection number is that of the most recent connection.

Command Mode

EXEC mode

Example

The following command switches to open Telnet session number 1.

```
switchxxxxxx# resume 1
```

4.5 hostname

The **hostname** Global Configuration mode command specifies or modifies the device host name. Use the **no** form of the command to remove the existing host name.

Syntax

hostname *name*

no hostname

Parameters

Name—Specifies the device host name. (Length: 1-160 characters. Maximum label size for each part of the host name: 63). The hostname must start with a letter, end with a letter or digit, and have as interior characters only letters, digits, and hyphens.

Default Configuration

No host name is defined.

Command Mode

Global Configuration mode

Example

The following example specifies the device host name as 'enterprise'.

```
switchxxxxxx(config)# hostname enterprise
enterprise(config)#
```

4.6 reload

The **reload** Privileged EXEC mode command reloads the operating system.

Syntax

reload [*slot unit-id*]

Parameters

slot unit-id—Specifies the new master unit number. (Range: 1–8). If unspecified, reloads all the units.

Default Usage

N/A

Command Mode

Privileged EXEC mode

Example

The following example reloads the operating system on all units.

```
switchxxxxxx# reload
This command will reset the whole system and disconnect your current
session. Do you want to continue? (y/n) [Y]
```

4.7 service cpu-utilization

The **service cpu-utilization** Global Configuration mode command enables measuring CPU utilization. Use the **no** form of this command to restore the default configuration.

Syntax

service cpu-utilization

no service cpu-utilization

Parameters

N/A

Default Configuration

Measuring CPU utilization is disabled.

Command Mode

Global Configuration mode

User GuidelinesUse the **service cpu utilization** command to measure information on CPU utilization.**Example**

The following example enables measuring CPU utilization.

```
switchxxxxxx(config)# service cpu-utilization
```

4.8 show cpu utilization

The **show cpu utilization** Privileged EXEC mode command displays information about CPU utilization.**Syntax****show cpu utilization****Parameters**

N/A

Default Usage

N/A

Command Mode

Privileged EXEC mode

User GuidelinesUse the **show cpu-utilization** command to enable measuring CPU utilization.**Example**

The following example displays CPU utilization information.

```
switchxxxxxx# show cpu utilization  
CPU utilization service is on.  
CPU utilization  
-----  
five seconds: 5%; one minute: 3%; five minutes: 3%
```

4.9 clear cpu counters

The **clear cpu counters** EXEC mode command clears traffic counters to and from the CPU.**Syntax****clear cpu counters**

Parameters

N/A

Default Usage

N/A

Command Mode

EXEC mode

Example

The following example clears the CPU traffic counters.

```
switchxxxxxx# clear cpu counters
```

4.10 service cpu-counters

The **service cpu-counters** Global Configuration mode command enables traffic counting to and from the CPU. To disable counting, use the **no** form of this command.

Syntax

service cpu-counters

no service cpu-counters

Parameters

N/A

Default Usage

N/A

Command Mode

Global Configuration mode

User Guidelines

Use the **show cpu counters** command to display the CPU traffic counters.

Example

The following example enables counting CPU traffic.

```
switchxxxxxx(config)# service cpu-counters
```

4.11 show cpu counters

The **show cpu counters** EXEC mode command displays traffic counter information to and from the CPU.



Syntax

show cpu counters

Parameters

N/A

Default Usage

N/A

Command Mode

EXEC mode

User Guidelines

Use the **service cpu-counters** command to enable traffic counting to and from the CPU.

Example

The following example displays the CPU traffic counters.

```
switchxxxxxx# show cpu counters
CPU counters are active.
In Octets: 987891
In Unicast Packets: 3589
In Multicast Packets: 29
In Broadcast Packets: 8
Out Octets: 972181
Out Unicast Packets: 3322
Out Multicast Packets: 22
Out Broadcast Packets: 8
```

4.12 show users

The **show users** EXEC mode command displays information about the active users.

Syntax

show users

Parameters

N/A

Default Usage

N/A

Command Mode

EXEC mode

Example

The following example displays information about the active users.

```
switchxxxxxx# show users

Username          Protocol          Location
-----          -
Bob               Serial
John              SSH               172.16.0.1
Robert            HTTP              172.16.0.8
Betty             Telnet            172.16.1.7
Sam               172.16.1.6
```

4.13 show sessions

The **show sessions** EXEC mode command displays open Telnet sessions.

Syntax

show sessions

Parameters

N/A

Default Usage

N/A

Command Mode

EXEC mode

User Guidelines

The **show sessions** command displays Telnet sessions to remote hosts opened by the current Telnet session to the local device. It does not display Telnet sessions to remote hosts opened by other Telnet sessions to the local device.

Example

The following example displays open Telnet sessions.

```
switchxxxxxx# show sessions

Connection  Host                Address            Port    Byte
-----
1           Remote router      172.16.1.1        23     89
2           172.16.1.2        172.16.1.2        23     8
```



The following table describes significant fields shown above.

Field	Description
Connection	The connection number.
Host	The remote host to which the device is connected through a Telnet session.
Address	The remote host IP address.
Port	The Telnet TCP port number.
Byte	The number of unread bytes for the user to see on the connection.

4.14 show system

The **show system** EXEC mode command displays system information.

Syntax

show system *unit unit-id*

Parameters

unit-id — Specifies the unit number. (Range: 1–8)

Command Mode

EXEC mode

Example

The following example displays the system information.

```
switchxxxxxx# show system unit 2
System Type:                               PowerConnect 5548
System Up Time (days,hour:min:sec):       08,23:03:46
System Contact:
System Name:
System Location:
System MAC Address:                         00:99:88:66:33:33
System Object ID:                           1.3.6.1.4.1.674.10895.3031
Type:                                       PowerConnect 5548
Main Power Supply Status:                   OK
Fans Status:                                OK
      Unit Temperature (Celsius) Status
-----
      2    42                               OK
```

4.15 show version

The **show version** EXEC mode command displays system version information.

Syntax

show version md5 [*unit unit-id*]

Parameters

unit *unit* — Specifies the unit number. (Range: 1–8)

Default Usage

Show version on all units if no unit is specified.

Command Mode

EXEC mode

Example

The following example displays system version information.

```
switchxxxxxx# show version
SW Version      1.1.0.5 ( date 15-Sep-2010 time 10:31:33 )
Boot Version    1.1.0.2 ( date 04-Sep-2010 time 21:51:53 )
HW Version      V01
Unit           SW Version   Boot Version   HW Version
-----
1              3.131         2.178         1.0.0
2              3.131         2.178         1.0.0
```

4.16 show version md5

Use the **show version md5** EXEC mode command to display external MD5 digest of firmware.

Syntax

show version md5 [*unit unit-id*]

Parameters

unit *unit*—Unit number. (Range: 1–8)

Default Usage

N/A

Command Mode

EXEC mode

Example

```
switchxxxxxx# show version md5
Unit  Filename      Status      MD5  Digest
-----
1     image1           Active      23FA000012857D8855AABC7577AB5562
1     image2           Not Active  23FA000012857D8855AABEA7451265456
1     boot             Active      23FA000012857D8855AABC7577AB8999
2     image1           Not Active  23FA000012857D8855AABC757FE693844
2     image2           Active      23FA000012857D8855AABC7577AB5562
2     boot             Active      23FA000012857D8855AABC7577AC9999
```

4.17 system resources routing

The **system resources routing** Global Configuration mode command configures the routing table maximum size. Use the **no** form of this command to return to the default size.

Syntax

system resources routing *routes hosts interfaces*

no system resources routing

Parameters

- **routes**—Specifies the maximum number of remote networks in the routing table.
- **hosts**—Specifies the maximum number of directly attached hosts.
- **interfaces**—Specifies the maximum number of IP interfaces.

Default Configuration

Hosts(Alleycat): 10-400, default = 100

Hosts(others): 20-800, default = 200

Routes: 20-128, default = 128

IP Interfaces: 2-32, default = 32

Command Mode

Global Configuration mode

User Guidelines

The settings are effective after reboot.

Example

The following example configures the routing table maximum size.

```
switchxxxxxx# system resources routing 20 23 5
```

4.18 show system resources

The **show system resources routings** EXEC mode command displays system routing resource information.

Syntax**show system resources {routing }****Parameters****routing**—Displays the number of hosts, routers and IP interfaces that are available.**Command Mode**

EXEC mode

Example

The following example displays the system routing resources information. The values in the Current Value column show what resources are currently available. The values in the After Reboot Value column show what resources will be available after reboot as a result of system resources routing command.

```
switchxxxxxx# show system resources routing
Parameters          Current Value      After Reboot Value
-----
Hosts:              100
Routes:             32
IP Interfaces:      32
```

The **show system tcam utilization** EXEC mode command displays the Ternary Content Addressable Memory (TCAM) utilization.

Syntax**show system tcam utilization [unit unit-id]****Parameters**

N/A

Default Usage

N/A

unit-id—Specifies the unit number. (Range: 1–8)**Command Mode**

EXEC mode

Example

The following example displays TCAM utilization information.

```
switchxxxxxx# show system tcam utilization
TCAM utilization: 58%
```



```
System: 75%
Unit    TCAM utilization [%]
----    -
1       58
2       57
```

4.19 show system defaults

Use the **show system defaults** EXEC mode command to display system defaults.

Syntax

show system defaults [*session*]

Parameters

session—Show information for specific session only. Available values are: management, 802.1x, port, fdb, port-mirroring, spanning-tree, vlan, voice-vlan, ip-addressing, network-security and qos-acl.

Command Mode

EXEC mode

Examples

```
switchxxxxxx# show system defaults
```

The **show system id** EXEC mode command displays the system identity information.

Syntax

show system id [*unit unit-id*]

Parameters

unit unit-id—Unit number or all. If unspecified, defaults to all. (Range: 1–8)

Command Mode

EXEC mode

Example

The following example displays the system identity information.

```
switchxxxxxx# show system id
```


5 Stack Commands

5.1 stack master

The **stack master** Global/Interface Configuration mode command forces a stack master selection. Use the **no** form of this command to restore the default configuration.

Syntax

stack master *unit unit-id*

no stack master

Parameters

unit-id—Specifies the new master unit number. (Range: 1–2)

Default Configuration

The default is no forced master.

Command Mode

Global Configuration mode or Interface Configuration mode

User Guidelines

This command has the same affect whether it is run from Global or Interface Configuration mode.

Example

The following example forces the stack master to be unit 2.

```
Console(config)# stack master unit 2
```

5.2 switch renumber

Use the **switch renumber** Global Configuration command to change the unit ID of a specific unit.

Syntax

switch *current-unit-id renumber new-unit-id*

Parameters

- **current-unit-id**—Specify Unit number. (Range: 1–8)
- **new-unit-id**—The new unit number. (Range: 1–8)

Default Usage

N/A

Command Mode

Global Configuration mode

Example

The following rennumbers unit 1 to unit 2.

```
console#configure
console(config)# switch 1 renumber 2
```

5.3 show switch

The **show switch** EXEC mode command displays stack status information for the stack or stack member.

Syntax

show switch [*unit-id*]

Parameters

unit-id— Specifies the unit number. (Range: 1–8)

Default Usage

Displays information for all units.

Command Mode

EXEC mode

Example

The following examples display the stack status information for all units on the stack and for the unit specified.

```
console#show switch 1
```

Unit	MAC Address	Software	Master	Uplink	Downlink	Status
1	00:31:06:13:16:11	1.2.0.38	Forced	2	link down	master
2	00:24:05:11:08:49	1.2.0.38	Enabled	1	link down	backup

Topology is Chain

Stack image auto synchronization is enabled

Unit Unit Id After Reset

1	0
2	0

```
console#show switch 1
Unit: 1
MAC address: 00:31:06:13:16:11
Master: Forced.
Product: SG500-28P. Software: 1.2.0.38
Uplink unit: 2 Downlink unit: 0.
Status: master
```



```
Active image:          image2.  
Selected for next boot: image1.  
Topology is Chain  
Stack image auto synchronization is enabled  
Unit Num After Reset:  0  
console#
```


6 Clock Commands

6.1 clock set

The **clock set** Privileged EXEC mode command manually sets the system clock.

Syntax

clock set *hh:mm:ss* {[*day month*] | [*month day*]} *year*

Parameters

- **hh:mm:ss**—Specifies the current time in hours (military format), minutes, and seconds. (Range: hh: 0-23, mm: 0-59, ss: 0-59)
- **day**—Specifies the current day of the month. (Range: 1-31)
- **month**—Specifies the current month using the first three letters of the month name. (Range: Jan–Dec)
- **year**—Specifies the current year. (Range: 2000–2037)

Command Mode

Privileged EXEC mode

User Guidelines

It is recommended that the user enter the local clock time and date.

Example

The following example sets the system time to 13:32:00 on March 7th, 2005.

```
switchxxxxxx# clock set 13:32:00 7 Mar 2005
```

6.2 clock source

The **clock source** Global Configuration mode command configures an external time source for the system clock. Use the **no** form of this command to disable the external time source.

Syntax

clock source {*sntp*}

no clock source

Parameters

sntp—Specifies that an SNTP server is the external clock source.

Default Configuration

There is no external clock source.

Command Mode

Global Configuration mode

Example

The following example configures an SNTP server as an external time source for the system clock.

```
switchxxxxxx(config)# clock source sntp
```

6.3 clock timezone

Use the **clock timezone** Global Configuration command to set the time zone for display purposes. Use the **no** form of this command to set the time to Coordinated Universal Time (UTC) or Greenwich Mean Time (GMT), which is the same.

Syntax

clock timezone *zone hours-offset [minutes-offset]*

no clock timezone

Parameters

- **zone**—The acronym of the time zone.(Range: Up to 4 characters)
- **hours-offset**—Hours difference from UTC. (Range: (-12)–(+13))
- **minutes-offset**—Minutes difference from UTC. (Range: 0–59)

Default Configuration

Offsets are 0.

Acronym is empty.

Command Mode

Global Configuration mode

User Guidelines

The system internally keeps time in UTC, so this command is used only for display purposes and when the time is manually set.

Example

```
switchxxxxxx(config)# clock timezone abc +2 minutes 32
```

6.4 clock summer-time

Use one of the formats of the **clock summer-time** Global Configuration command to configure the system to automatically switch to summer time (Daylight Saving Time). Use the **no** form of this command to configure the software not to automatically switch to summer time.

Syntax

clock summer-time *zone recurring {usa | eu | {week day month hh:mm week day month hh:mm}} [offset]*

clock summer-time zone *date* *day month year hh:mm date month year hh:mm [offset]*

clock summer-time zone *date* *month day year hh:mm month day year hh:mm [offset]*

no clock summer-time

Parameters

- **zone**—The acronym of the time zone to be displayed when summer time is in effect. (Range: up to 4 characters)
- **recurring**—Indicates that summer time starts and ends on the corresponding specified days every year.
- **date**—Indicates that summer time starts on the first date listed in the command and ends on the second date in the command.
- **usa**—The summer time rules are the United States rules.
- **eu**—The summer time rules are the European Union rules.
- **week**—Week of the month. Can be 1–4, first, last.
- **day**—Day of the week (first three characters by name, such as Sun).
- **date**—Date of the month. (Range: 1–31)
- **month**—Month (first three characters by name, such as Feb).
- **year**—year (no abbreviation). (Range: 2000–2097)
- **hh:mm**—Time (military format) in hours and minutes. (Range: hh:mmhh: 0-23, mm: 0-59)
- **offset**—Number of minutes to add during summer time (default is 60). (Range: 1440)

Default Configuration

Summer time is disabled.

Command Mode

Global Configuration mode

User Guidelines

In both the **date** and **recurring** forms of the command, the first part of the command specifies when summer time begins, and the second part specifies when it ends. All times are relative to the local time zone. The start time is relative to standard time. The end time is relative to summer time. If the starting month is chronologically after the ending month, the system assumes that you are in the southern hemisphere.

USA rules for Daylight Saving Time:

- From 2007:
 - Start: Second Sunday in March
 - End: First Sunday in November
 - Time: 2 AM local time
- Before 2007:
 - Start: First Sunday in April
 - End: Last Sunday in October
 - Time: 2 AM local time

EU rules for Daylight Saving Time:

- Start: Last Sunday in March
- End: Last Sunday in October
- Time: 1.00 am (01:00) Greenwich Mean Time (GMT)

Example

```
switchxxxxxx(config)# clock summer-time abc date apr 1 2010 09:00 aug 2  
2010 09:00
```

6.5 clock dhcp timezone

Use the **clock dhcp timezone** Global Configuration command to specify that the timezone and the Summer Time (Daylight Saving Time) of the system can be taken from the DHCP Timezone option. Use the **no** form of this command disable this option.

Syntax

clock dhcp timezone

no clock dhcp timezone

Parameters

N/A

Default Configuration

Disabled

Command Mode

Global Configuration mode

User Guidelines

The TimeZone taken from the DHCP server has precedence over the static TimeZone. If the TimeZone does not exist in the DHCP-TimeZone option, the static configuration will be active.

The Summer Time taken from the DHCP server has precedence over static SummerTime. If the Summer Time does not exist in the DHCP-TimeZone option, the static configuration will be active.

The TimeZone and SummerTime remain effective after the IP address lease time has expired.

The TimeZone and SummerTime that are taken from the DHCP server are cleared after reboot.

When the user disables taking the TimeZone and Summer Time from the DHCP server, the dynamic Time Zone and Summer Time from the DHCP server are cleared.

In case of multiple DHCP-enabled interfaces, the last accepted DHCP-Time Zone option overrides any previous DHCP-Time Zone option. This means that the last accepted DHCP-Time Zone option overrides the previous Time Zone and the Summer Time, even if it includes only one of them.

Disabling the DHCP client from where the DHCP-TimeZone option was taken, clears the dynamic Time Zone and Summer Time configuration.

Example

```
switchxxxxxx(config)# clock dhcp timezone
```

6.6 sntp authentication-key

The **sntp authentication-key** Global Configuration mode command defines an authentication key for Simple Network Time Protocol (SNTP). Use the **no** form of this command to remove the authentication key for SNTP.

Syntax

sntp authentication-key *key-number* **md5** *key-value*

no sntp authentication-key *key-number*

Parameters

- **key-number**—Specifies the key number. (Range: 1–4294967295)
- **md5 key-value**—Specifies the key value. (Length: 1–8 characters)

Default Configuration

No authentication key is defined.

Command Mode

Global Configuration mode

Examples

The following example defines the authentication key for SNTP.

```
switchxxxxxx(config)# sntp authentication-key 8 md5 ClkKey
switchxxxxxx(config)# sntp authentication-key 8 md5 ClkKey
switchxxxxxx(config)# sntp trusted-key 8
switchxxxxxx(config)# sntp authenticate
```

6.7 sntp authenticate

The **sntp authenticate** Global Configuration mode command enables authentication for received SNTP traffic from servers. Use the **no** form of this command to disable the feature.

Syntax

sntp authenticate

no sntp authenticate

Parameters

N/A

Default Configuration

Authentication is disabled.

Command Mode

Global Configuration mode

User Guidelines

The command is relevant for both Unicast and Broadcast.

Examples

The following example enables authentication for received SNTP traffic and sets the key and encryption key.

```
switchxxxxxx(config)# sntp authenticate
switchxxxxxx(config)# sntp authentication-key 8 md5 ClkKey
switchxxxxxx(config)# sntp trusted-key 8
```

6.8 sntp trusted-key

The **sntp trusted-key** Global Configuration mode command authenticates the identity of the system with which SNTP synchronizes. Use the **no** form of this command to disable system identity authentication.

Syntax

sntp trusted-key *key-number*

no sntp trusted-key *key-number*

Parameters

key-number—Specifies the key number of the authentication key to be trusted. (Range: 1–4294967295)

Default Configuration

No keys are trusted.

Command Mode

Global Configuration mode

User Guidelines

The command is relevant for both received unicast and broadcast.

Examples

The following example authenticates key 8.

```
switchxxxxxx(config)# sntp trusted-key 8
switchxxxxxx(config)# sntp authentication-key 8 md5 ClkKey
switchxxxxxx(config)# sntp trusted-key 8
switchxxxxxx(config)# sntp authenticate
```

6.9 sntp client poll timer

The **sntp client poll timer** Global Configuration mode command sets the polling time for the SNTP client. Use the **no** form of this command to restore the default configuration.

Syntax

sntp client poll timer *seconds*

no sntp client poll timer

Parameters

seconds—Specifies the polling interval in seconds. (Range: 60–86400)

Default Configuration

The default polling interval is 1024 seconds.

Command Mode

Global Configuration mode

Example

The following example sets the polling time for the SNTP client to 120 seconds.

```
switchxxxxxx(config)# sntp client poll timer 120
```

6.10 sntp broadcast client enable

The **sntp broadcast client enable** Global Configuration mode command enables SNTP Broadcast clients. Use the no form of this command to disable SNTP Broadcast clients.

Syntax

sntp broadcast client enable

no sntp broadcast client enable

Default Configuration

The SNTP Broadcast client is disabled.

Command Mode

Global Configuration mode

User Guidelines

Use the **sntp broadcast client enable** Interface Configuration mode command to enable the SNTP Broadcast client on a specific interface.

After entering this command, you must enter [clock source sntp](#) for the command to be run. If this command is not run, the switch will not synchronize with Broadcast servers.

Example

The following example enables SNTP Broadcast clients.

```
switchxxxxxx(config)# sntp broadcast client enable
```

6.11 sntp anycast client enable

The **sntp anycast client enable** Global Configuration mode command enables the SNTP Anycast client. Use the **no** form of this command to disable the SNTP Anycast client.

Syntax

sntp anycast client enable

no sntp anycast client enable

Parameters

N/A

Default Configuration

The SNTP anycast client is disabled.

Command Mode

Global Configuration mode

User Guidelines

Use this command to enable the SNTP Anycast client.

Example

The following example enables SNTP Anycast clients.

```
switchxxxxxx(config)# sntp anycast client enable
```

6.12 sntp client enable

The **sntp client enable** Global Configuration mode command enables the SNTP Broadcast and Anycast client on an interface when the device is in Router mode (Layer 3). Use the **no** form of this command to disable the SNTP Broadcast and Anycast client.

Syntax

sntp client enable *{interface-id}*

no sntp client enable *{interface-id}*

Parameters

interface-id—Specifies an interface ID, which can be one of the following types: Ethernet port, Port-channel or VLAN.

Default Configuration

The SNTP client is disabled on an interface.

Command Mode

Global Configuration mode - Ethernet port, Port-channel or VLAN.

User Guidelines

This command only works when the device is in Router mode (Layer 3).

The [sntp broadcast client enable](#) Global Configuration mode command globally enables Broadcast clients.

The [sntp anycast client enable](#) Global Configuration mode command globally enables Anycast clients.

This command enables both.

Example

The following example enables the SNTP Broadcast and Anycast client on port fe1/0/13.

```
switchxxxxxx(config)# sntp client enable fe1/0/13
```

6.13 sntp unicast client enable

The [sntp unicast client enable](#) Global Configuration mode command enables the device to use Simple Network Time Protocol (SNTP)-predefined Unicast clients. Use the **no** form of this command to disable the SNTP Unicast clients.

Syntax

sntp unicast client enable

no sntp unicast client enable

Parameters

N/A

Default Configuration

The SNTP unicast client is disabled.

Command Mode

Global Configuration mode

User Guidelines

Use the [sntp server](#) Global Configuration mode command to define SNTP servers.

Example

The following example enables the device to use SNTP Unicast clients.

```
switchxxxxxx(config)# sntp unicast client enable
```

6.14 sntp unicast client poll

The [sntp unicast client poll](#) Global Configuration mode command enables polling for the SNTP predefined Unicast clients. Use the **no** form of this command to disable the polling for the SNTP client.

Syntax**sntp unicast client poll****no sntp unicast client poll****Default Configuration**

Polling is disabled.

Command Mode

Global Configuration mode

User GuidelinesPolling time is configured with the **sntp client poll timer** Global Configuration mode command.**Example**

The following example enables polling for SNTP predefined unicast clients.

```
switchxxxxxx(config)# sntp unicast client poll
```

6.15 sntp server

The **sntp server** Global Configuration mode command configures the device to use the SNTP to request and accept Network Time Protocol (NTP) traffic from a specified server (meaning to accept system time from an SNTP server). Use the **no** form of this command to remove a server from the list of SNTP servers.

Syntax**sntp server** {*ip-address* | *hostname*} [**poll**] [**key** *keyid*]**no sntp server** {*ip-address* | *hostname*}**Parameters**

- **ip-address**—Specifies the server IP address. This can be an IPv4, IPv6 or IPv6z address. See [IPv6z Address Conventions](#):
- **hostname**—Specifies the server hostname. Only translation to IPv4 addresses is supported. (Length: 1–158 characters. Maximum label length for each part of the hostname: 63 characters)
- **poll**—Enables polling.
- **key** *keyid*—Specifies the Authentication key to use when sending packets to this peer. (Range: 1–4294967295)

Default Configuration

No servers are defined.

Command Mode

Global Configuration mode

User GuidelinesUp to 8 SNTP servers can be defined.

The `sntp unicast client enable` Global Configuration mode command enables predefined Unicast clients.

The `sntp unicast client poll` Global Configuration mode command globally enables polling.

Polling time is configured with the `sntp client poll timer` Global Configuration mode command.

Example

The following example configures the device to accept SNTP traffic from the server on 192.1.1.1 with polling.

```
switchxxxxxx(config)# sntp server 192.1.1.1 poll
```

6.16 sntp port

The `sntp port` Global Configuration mode command specifies a SNTP User Datagram Protocol (UDP) port. Use the `no` form of this command to use the SNTP server default port.

Syntax

`sntp port` *port-number*

`no sntp port`

Parameters

port-number—Specifies the UDP port number used by an SNTP server. (Range 1–65535)

Default Configuration

The default port number is 123.

Command Mode

Global Configuration mode

Example

The following example specifies that port 321 of the SNTP server is the UDP port.

```
switchxxxxxx(config)# sntp port 321
```

6.17 show clock

The `show clock` EXEC mode command displays the time and date from the system clock.

Syntax

`show clock` [*detail*]

Parameters

detail—Displays the time zone and summer time configuration.

Command Mode

EXEC mode

Examples

Example 1 - The following example displays the system time and date.

```
switchxxxxxx# show clock
15:29:03 PDT(UTC-7) Jun 17 2002
Time source is SNTP
```

Example 2 - The following example displays the system time and date along with the time zone and summer time configuration.

```
switchxxxxxx# show clock detail
15:29:03 PDT(UTC-7) Jun 17 2002
Time source is SNTP
Time zone:
Acronym is PST
Offset is UTC-8
Summertime:
Acronym is PDT
Recurring every year.
Begins at first Sunday of April at 2:00.
Ends at last Sunday of October at 2:00.
Offset is 60 minutes.
DHCP timezone: Disabled
```

6.18 show sntp configuration

The **show sntp configuration** Privileged EXEC mode command displays the SNTP configuration on the device.

Syntax

show sntp configuration

Parameters

N/A

Default Configuration

N/A

Command Mode

Privileged EXEC mode

Example

The following example displays the device's current SNTP configuration.

```
switchxxxxxx# show sntp configuration
SNTP port : 123 .
```

```

Polling interval: 1024 seconds.
No MD5 authentication keys.
Authentication is not required for synchronization.
No trusted keys.

```

```

Unicast Clients: Enabled
Unicast Clients Polling: Enabled
Server      Polling  Encryption Key
-----
1.1.1.121   Disabled Disabled
Broadcast Clients: disabled
Anycast Clients: disabled
No Broadcast Interfaces.
switchxxxxx#

```

6.19 show sntp status

The **show sntp status** Privileged EXEC mode command displays the SNTP servers status.

Syntax

show sntp status

Parameters

N/A

Default Configuration

N/A

Command Mode

Privileged EXEC mode

Example

The following example displays the SNTP servers status.

```
switchxxxxx# show sntp status
```

```

Clock is synchronized, stratum 4, reference is 176.1.1.8, unicast
Reference time is AFE2525E.70597B34 (00:10:22.438 PDT Jul 5 1993)

```

Unicast servers:

Server	Status	Last response	Offset [mSec]	Delay [mSec]
-----	-----	-----	-----	-----
176.1.1.8	Up	19:58:22.289 PDT Feb 19 2005	7.33	117.79
176.1.8.179	Unknown	12:17.17.987 PDT Feb 19 2005	8.98	189.19



Anycast server:

Server	Interface	Status	Last response	Offset	Delay
-----	-----	-----	-----	[mSec]	[mSec]
176.1.11.8	VLAN 118	Up	9:53:21.789 PDT Feb 19 2005	----- 7.19	----- 119.89

Broadcast:

Server	Interface	Last response
-----	-----	-----
176.9.1.1	VLAN 119	19:17:59.792 PDT Feb 19 2002

7

Auto-Update and Auto-Configuration

7.1 boot host auto-config

Use the **boot host auto-config** Global Configuration mode command to enable auto configuration via DHCP. Use the **no** form of this command to disable DHCP auto configuration.

Syntax

boot host auto-config

no boot host auto-config

Parameters

N/A

Default Configuration

Enabled by default.

Command Mode

Global Configuration mode

Default Configuration

Enabled by default.

Example

```
switchxxxxxx(conf) # boot host auto-config
```

7.2 boot host auto-update

Use the **boot host auto-update** Global Configuration mode command to enable the support of auto updated via DHCP. Use the **no** form of this command to disable DHCP auto configuration.

Syntax

boot host auto-update

no boot host auto-update

Parameters

N/A

Default Configuration

Enabled by default.

Command Mode

Global Configuration mode



Default Configuration

Enabled by default.

Example

```
switchxxxxxx(conf)# boot host auto-update
```

7.3 boot host dhcp

Use the **boot host dhcp** Global Configuration mode command to force downloading a configuration file at the next system startup. Use the **no** form of this command to restore the host configuration file to the default.

Syntax

boot host dhcp

no boot host dhcp

Parameters

N/A

Default Configuration

Disabled.

Command Mode

Global Configuration mode

User Guidelines

Configuring **boot host dhcp** does not take effect until the next reboot.

7.4 boot host auto-save

Use the **boot host auto-save** Global Configuration mode command to automatically save the Running configuration file in the Startup configuration file after download. Use the **no** form of this command restore default behavior.

Syntax

boot host auto-save

no boot host auto-save

Parameters

N/A

Default Configuration

Disable

Command Mode

Global Configuration mode

Examples

```
switchxxxxxx(conf)# boot host auto-save
```

7.5 show boot

Use the **show boot** Privilege EXEC mode command to show the status of the IP DHCP Auto Config process.

Syntax

show boot

Parameters

N/A

Default Configuration

N/A

Command Mode

Privilege EXEC mode

Examples

```
switchxxxxxx show boot
```

```
Auto Config
-----
Config Download via DHCP: enable
Next Boot Config Download via DHCP: force
Auto Config State: Finished
TFTP Server IP address: 1.2.20.2
Configuration filename: /config/configfile1.cfg
    Auto Update
    -----
Image Download via DHCP: enabled
```

```
switchxxxxxx# show boot
Auto Config
-----
Config Download via DHCP: enable
Next Boot Config Download via DHCP: default
Auto Config State: Opening <hostname>-config file
```

Auto Update

Image Download via DHCP: enabled

Example 3.

```
switchxxxxxx# show boot
```

Auto Config

Config Download via DHCP: enable

Next Boot Config Download via DHCP: default

Auto Config State: Downloading configuration file

Auto Update

Image Download via DHCP: enabled

```
switchxxxxxx# show boot
```

Auto Config

Config Download via DHCP: enable

Next Boot Config Download via DHCP: default

Auto Config State: Searching hostname in indirect configuration file

Auto Update

Image Download via DHCP: enabled

```
switchxxxxxx# show boot
```

Auto Config

Config Download via DHCP: enable

Next Boot Config Download via DHCP: default

Auto Config State: Quit - failed all steps of finding existing configuration file

Auto Update

Image Download via DHCP: enabled

```
switchxxxxxx# show boot
```

Auto Config

Config Download via DHCP: enable

Next Boot Config Download via DHCP: default

Auto Update

```
-----  
Image Download via DHCP: enabled  
Auto Update State: Downloaded indirect image file
```

```
switchxxxxxx# show boot  
Auto Config  
-----  
Config Download via DHCP: enable  
Next Boot Config Download via DHCP: default  
Auto Update
```

```
-----  
Image Download via DHCP: enabled  
Auto Update State: Downloading image file
```

```
switchxxxxxx# show boot  
Auto Config  
-----  
Config Download via DHCP: enable  
Next Boot Config Download via DHCP: default  
Auto Config State: Finished  
TFTP Server IP address: 1.2.20.2  
Configuration filename: /config/configfile1.cfg  
Auto Update  
-----  
Image Download via DHCP: enabled  
Auto Update State: Downloading image file
```

7.6 ip dhcp tftp-server ip address

Use the **ip dhcp tftp-server ip address** Global Configuration mode command to set the TFTP server's IP address. This address server as the default address used by a switch when it has not been received from the DHCP server.

Use the **no** form of this command to remove the address.

Syntax

ip dhcp tftp-server ip address *ip-addr*

no ip dhcp tftp-server ip address

Parameters

ip addr *ip-addr*—Address of TFTP server

Default Configuration

No IP address

Command Mode

Global Configuration mode

Examples

```
switchxxxxxx(conf)# ip dhcp tftp-server ip address 10.5.234.232
```

7.7 ip dhcp tftp-server file

Use the **ip dhcp tftp-server file** Global Configuration mode command to set the full file name of the configuration file to be downloaded on the TFTP server when it has not been received from the DHCP server. This serves as the default configuration file.

Use the **no** form of this command to remove the name.

Syntax

ip dhcp tftp-server file *file-path*

no ip dhcp tftp-server file

Parameters

file-path—Full file path and name of the configuration file on TFTP server

Default Configuration

No file name

Command Mode

Global Configuration mode

Examples

```
switchxxxxxx(conf)# ip dhcp tftp-server file conf/conf-file
```

7.8 show ip dhcp tftp-server

Use the **show ip dhcp tftp-server** EXEC mode command to display information about the TFTP server.

Syntax

show ip dhcp tftp-server

Parameters

N/A

Default Configuration

N/A

Command Mode

EXEC

Example

```
switchxxxxxx# show ip dhcp tftp server
tftp server address
active      1.1.1.1 from sname
manual     2.2.2.2
file path on tftp server
active     conf/conf-file from option 67
```

8 Configuration and Image File Commands

8.1 copy

The **copy** Privileged EXEC mode command copies a source file to a destination file.

Syntax

copy *source-url destination-url [snmp]*

Parameters

- **source-url**—Specifies the source file URL or source file reserved keyword to be copied. (Length: 1–160 characters)
- **destination-url**—Specifies the destination file URL or destination file reserved keyword. (Length: 1–160 characters).
- **snmp**—Specifies that the destination/source file is in SNMP format. Used only when copying from/to the Startup Configuration file.

The following table displays the URL options.

Keyword	Source or Destination
flash://	Source or destination URL for flash memory. This is the default URL if a URL is specified without a prefix.
running-config	Currently running configuration file.
startup-config	Startup configuration file.
image	Image file. If specified as the source file, it is the active image file. If specified as the destination file, it is the non-active image file.
boot	Boot file.
tftp://	Source or destination URL for a TFTP network server. The syntax for this alias is <i>tftp://host/[directory]/filename</i> . The host can be either an IP address or a host name.
xmodem:	Source for the file from a serial connection that uses the Xmodem protocol.
unit://member/image	Image file on one of the units. To copy from the master to all units, specify * in the member field.
unit://member/boot	Boot file on one of the units. To copy from the master to all units, specify * in the member field
unit://member/ startup-config	Configuration file used during initialization (startup) on one of the units.
null:	Null destination for copies or files. A remote file can be copied to null to determine its size. For instance copy running-conf null returns the size of the running configuration file.
backup-config	Backup configuration file. A configuration file can be downloaded to this file (without giving a file name). This can then be copied to the running-conf or startup-conf files.
unit://member/backup-config	Backup configuration file on one of the units.

Keyword	Source or Destination
mirror-config	Mirrored configuration file. If the running config and the startup config have been identical for 24 hours, the startup config is automatically copied to the mirror-conf file by the system. It can then be copied to the startup or running conf if required.
ogging	Specifies the SYSLOG file.
Word<1-128>	Name of file.

Command Mode

Privileged EXEC mode

User Guidelines

The location of the file system dictates the format of the source or destination URL.

The entire copying process may take several minutes and differs from protocol to protocol and from network to network.

IPv6z Address Format

If the IPv6 address is a Link Local address (IPv6z address), the outgoing interface name must be specified. The format of an IPv6z address is: *{ipv6-link-local-address}%{interface-id}*. The subparameters are:

- **ipv6-link-local-address**—Specifies the IPv6 Link Local address.
- **interface-id**—{<port-type>[]<port-number>}{<port-channel | po>[]<port-channel-number> | <tunnel | tu>[]<tunnel-number> | vlan[]<vlan-id>

If the egress interface is not specified, the default interface is selected. The following combinations are possible:

- **ipv6_address%interface_id** - Refers to the IPv6 address on the interface specified.
- **ipv6_address%0** - Refers to the IPv6 address on the single interface on which an IPv6 address is defined.
- **ipv6_address** - Refers to the IPv6 address on the single interface on which an IPv6 address is defined.

Invalid Combinations of Source and Destination

The following are invalid combinations of source and destination files:

- The source file and destination file are the same file.
- **xmodem**: is the destination file. The source file can be copied to **image**, **boot** and **null**: only.
- **fttp://** is the source file and destination file on the same copy.
- ***.prv** files cannot be copied. The source or destination is a slave unit (except for image and boot files).
- **mirror-config** cannot be used as a destination

The following table describes the characters displayed by the system when **copy** is being run:

Character	Description
!	For network transfers, indicates that the copy process is taking place. Each exclamation point indicates successful transfer of ten packets (512 bytes each).
.	For network transfers, indicates that the copy process timed out.

Various Copy Options Guidelines

- **Copying an Image File from a Server to Flash Memory**

Use the **copy source-url flash://image** command to copy an image file from a server to flash memory. When the administrator copies an image file from the server to a device, the image file is saved to the "inactive" image. To use this image, the administrator must switch the inactive image to the active image and reboot. The device will then use this new image.

- **Copying a Boot File from a Server to Flash Memory**

- Use the **copy source-url boot** command to copy a boot file from a server to flash memory.

- **Copying a Configuration File from a Server to the Running Configuration File**

Use the **copy source-url running-config** command to load a configuration file from a network server to the running configuration file of the device. The commands in the loaded configuration file are added to those in the running configuration file as if the commands were typed in the command-line interface (CLI). The resulting configuration file is a combination of the previous running configuration and the loaded configuration files, with the loaded configuration file taking precedence.

- **Copying a Configuration File from a Server to the Startup Configuration**

Use the **copy source-url startup-config** command to copy a configuration file from a network server to the device startup configuration file. The startup configuration file is replaced by the copied configuration file.

- **Storing the Running Config or Startup Config on a Server**

Use the **copy running-config destination-url** command to copy the current configuration file to a network server using TFTP.

Use the **copy startup-config destination-url** command to copy the startup configuration file to a network server.

- **Saving the Running Configuration to the Startup Configuration**

Use the **copy running-config startup-config** command to copy the running configuration to the startup configuration file.

- **-Backing Up the Running Configuration or Startup Configuration to a Backup Configuration file**

Use the **copy running-config flash://file_name** command to back up the running configuration to a backup configuration file.

Use the **copy startup-config flash://file_name** command to back up the startup configuration to a backup configuration file.

- **Backing Up the Running Configuration or Startup Configuration to the Backup Configuration**

Use the **copy running-config backup-config** command to back up the running configuration to the backup configuration file.

Use the **copy startup-config backup-config** command to back up the startup configuration to the backup configuration file.

- **Restoring the Mirror Configuration File.**

Use **copy mirror-config startup-config** or **copy mirror-config running-config** to copy the mirror configuration file to one of the configuration files being used.

Examples

Example 1 - The following example copies system image file1 from the TFTP server 172.16.101.101 to the non-active image file.

```
switchxxxxxx# copy tftp://172.16.101.101/file1 image
```

```
Accessing file 'file1' on 172.16.101.101...
Loading file1 from 172.16.101.101:
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
!!!!!!!! [OK]
Copy took 0:01:11 [hh:mm:ss]
```

Example 2 - Copying an Image from a Server to Flash Memory

The following example copies a system image named file1 from the TFTP server with an IP address of 172.16.101.101 to a non-active image file.

```
switchxxxxxx# copy tftp://172.16.101.101/file1 flash://image
Accessing file 'file1' on 172.16.101.101...
Loading file1 from 172.16.101.101:
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
!!!!!!!! [OK]
Copy took 0:01:11 [hh:mm:ss]
```

Example 3 - Copying the mirror-config file to the startup-configuration file

The following example copies the mirror configuration file, saved by the system, to the Startup Configuration file.

```
switchxxxxxx# copy mirror-config startup-config
```

8.2 write memory

Use the **write memory** Privileged EXEC mode command to save the Running Configuration file to the Startup Configuration file.

Syntax

write memory

Parameters

N/A

Default Configuration

N/A

Command Mode

Privileged EXEC mode

Examples

This example shows how to overwrite the startup-config with the running-config.

```
switchxxxxxx# write memory
Overwrite file [startup-config] ?[Yes/press any key for no]...15-Sep-2010
11:27
:48 %COPY-I-FILECPY: Files Copy - source URL running-config destination
URL flash://startup-config
15-Sep-2010 11:27:50 %COPY-N-TRAP: The copy operation was completed
successfully
Copy succeeded
```

8.3 delete

The **delete** Privileged EXEC mode command deletes a file from a flash memory device.

Syntax

delete url

Parameters

url—Specifies the location URL or reserved keyword of the file to be deleted. (Length: 1–160 characters)

The following table displays keywords and URL prefixes:

Keyword	Source or Destination
flash://	URL of the flash memory. This is the default URL if a URL is specified without a prefix.
startup-config	Startup configuration file.
WORD	Name of file.

Default Configuration

N/A

Command Mode

Privileged EXEC mode

User Guidelines

*.sys, *.prv, image-1 and image-2 files cannot be deleted.

Example

The following example deletes the file called 'test' from the flash memory.

```
switchxxxxx# delete flash://test
Delete flash:test? [confirm]
```

8.4 pwd

Use the **pwd** Privileged EXEC mode command to display a full, clarified path to the current directory.

Parameters

N/A

Default Configuration

N/A

Command Mode

EXEC mode

Example

The following example displays the current directory path.

```
switchxxxxx# pwd
```

8.5 dir

The **dir** Privileged EXEC mode command displays the list of files on a flash file system.

Syntax

dir *[directory-path]*

Parameters

N/A

Default Configuration

N/A



Command Mode

Privileged EXEC mode

Example

The following example displays the list of files on a flash file system

```

Total size of flash: 33292288 bytes
Free size of flash: 20708893 bytes
switchxxxxxx# dir
Directory of flash:
File Name      Permission  Flash Size  Data Size    Modified
-----
tmp            rw          524288      104          01-Jan-2010 05:35:04
image-1       rw          10485760    10485760     01-Jan-2010 06:10:23
image-2       rw          10485760    10485760     01-Jan-2010 05:43:54
dhcpsn.prv    --          262144      --           01-Jan-2010 05:25:07
sshkeys.prv   --          262144      --           04-Jan-2010 06:05:00
syslog1.sys   r-          524288      --           01-Jan-2010 05:57:00
syslog2.sys   r-          524288      --           01-Jan-2010 05:57:00
directry.prv  --          262144      --           01-Jan-2010 05:25:07
startup-config rw          786432      1081         01-Jan-2010 10:05:34
Total size of flash: 66322432 bytes
Free size of flash: 42205184 bytes

```

8.6 more

The **more** Privileged EXEC mode command displays a file.

Syntax

more *url*

Parameters

url—Specifies the location URL or reserved keyword of the source file to be displayed. (Length: 1–160 characters).

The following table displays options for the URL parameter:

Keyword	Source or Destination
flash://	Source or destination URL for flash memory. If a URL is specified without a prefix, this is the default URL.
running-config	Current running configuration file.
startup-config	Startup configuration file.
mirror-config	Mirrored configuration file.

Default Configuration

N/A

Command Mode

Privileged EXEC mode

User Guidelines

Files are displayed in ASCII format, except for the images, which are displayed in a hexadecimal format.

*.prv files cannot be displayed.

Example

The following example displays the running configuration file contents.

```
switchxxxxxx# more running-config
no spanning-tree
interface range fe1/0/11-48
speed 1000
exit
no lldp run
line console
exec-timeout 0
```

8.7 cd

Use the **cd** Privileged EXEC mode command to change the current directory, for example from flash to usb.

cd *new-directory*

Parameters

new-directory—The new directory. The new directory path may be specified as either a Full Clarified Path or a Relative Path.

Parameters

N/A

Default Configuration

N/A

Command Mode

Privileged EXEC mode

User Guidelines

When command **cd** changes the current file system, the current directory of the previous file system is saved and when the command specifying only the file system (for example, **cd:**) sets the file system as current, the current directory is restored.

Example



```
console cd ://private/conf
console pwd
switchxxxxxx# cd flash:
console pwd
flash://
console cd :
console pwd
switchxxxxxx# cd flash://
console pwd
flash:\\
console cd ://
console pwd
```

8.8 rename

The **rename** Privileged EXEC mode command renames a file.

Syntax

rename *url new-url*

Parameters

- **url**—Specifies the file location URL. (Length: 1–160 characters)
- **new-url**—Specifies the file's new URL. (Length: 1–160 characters)

The following table displays options for the URL parameter:

Keyword	Source or Destination
flash://	URL for flash memory. If a URL is specified without a prefix, this is the default URL.
WORD<1-128>	Name of file.

Default Configuration

N/A

Command Mode

Privileged EXEC mode

User Guidelines

*.sys and *.prv files cannot be renamed.

Example

The following example renames the configuration backup file.

```
switchxxxxxx# rename configuration.bak m-config.bak
```

8.9 boot system

The **boot system** Privileged EXEC mode command specifies the active system image file that will be loaded by the device at startup.

Syntax

boot system {*image-1* | *image-2*} [*switch unit-id* | *all*]

Parameters

- **switch unit-id**—Specifies the unit number. If unspecified, defaults to the master unit number.
- **all**—Specifies that the active image of all units is being set by the command.
- **image-1**—Specifies that image-1 is loaded as the system image during the next device startup.
- **image-2**—Specifies that image-2 is loaded as the system image during the next device startup.

Default Configuration

The default unit number is the master unit number.

Command Mode

Privileged EXEC mode

User Guidelines

Use the [show bootvar](#) command to display the active image.

Example

The following example specifies that **image-1** is the active system image file loaded by the device at startup. The results of this command is displayed in [show bootvar](#).

```
switchxxxxxx# boot system image-1
switchxxxxxx#show bootvar
Unit  Image  Filename  Version  Date                               Status
----  -
1     1     image-1  1.2.0.34  04-Jul-2011  15:03:07  Not active*
1     2     image-2  1.2.0.38  13-Jul-2011  17:51:53  Active
2     1     image-1  1.2.0.38  13-Jul-2011  17:51:53  Active*
2     2     image-2  1.2.0.34  04-Jul-2011  15:03:07  Not active
**" designates that the image was selected for the next boot
```

8.10 show running-config

Use the **show running-config** privileged EXEC command to display the contents of the currently running configuration file.

Syntax

show running-config



Parameters

N/A

Default Configuration

N/A

Command Mode

Privileged EXEC mode

Example

The following example displays the running configuration file contents.

```
switchxxxxxx# show running-config
no spanning-tree
interface range fe1/0/11-48
speed 1000
exit
no lldp run
interface vlan 1
ip address 1.1.1.1 255.0.0.0
exit
line console
exec-timeout 0
exit
switchxxxxxx#
```

8.11 show startup-config

Use the **show startup-config** Privileged EXEC mode command to display the Startup Configuration file contents.

Syntax

show startup-config

Parameters

N/A

Default Configuration

N/A

Command Mode

Privileged EXEC mode

Example

The following example displays the startup configuration file contents.

```
switchxxxxxx# show startup-config
no spanning-tree
interface range fe1/0/11-48
speed 1000
exit
no lldp run
interface vlan 1
ip address 1.1.1.1 255.0.0.0
exit
line console
exec-timeout 0
exit
switchxxxxxx#
```

8.12 show backup-config

Use the **show backup-config** Privileged EXEC mode command to display the Backup Configuration file contents.

Syntax

show backup-config

Parameters

N/A

Default Configuration

N/A

Command Mode

Privileged EXEC mode

Example

The following example displays the Backup Configuration file contents.

```
switchxxxxxx# show backup-config
software version 1.1
hostname device
interface fe1/0/11
ip address 176.242.100.100 255.255.255.0
duplex full
speed 1000
interface fe1/0/12
ip address 176.243.100.100 255.255.255.0
duplex full
speed 1000
```

8.13 show bootvar

Use the **show bootvar** EXEC mode command to display the active system image file that is loaded by the device at startup.

Syntax

show bootvar [*unit unit-id*]

Parameters

unit-id—Specifies the unit number. Range 1-8

Command Mode

EXEC mode

Example

The following example displays the active system image file that is loaded by the device at startup.

```
switchxxxxxx# show bootvar
```

Unit	Image	filename	Version	Date	Status
----	----	-----	-----	-----	-----
1	1	file1	3.1.31	23-Jul-2002	Active
1	2	file2	3.2.19	22-Jan-2003	Not active*
2	1	file1	3.1.31	23-Jul-2002	Not active
2	2	file2	3.2.19	22-Jan-2003 2	Active

***: Designates that the image was selected for the next boot.

9

Management ACL Commands

9.1 management access-list

The **management access-list** Global Configuration mode command configures a management access list (ACL) and enters the Management Access-List Configuration command mode. Use the **no** form of this command to delete an ACL.

Syntax

management access-list *name*

no management access-list *name*

Parameters

name—Specifies the ACL name. (Length: 1–32 characters)

Default Configuration

N/A

Command Mode

Global Configuration mode

User Guidelines

Use this command to configure a management access list. This command enters the Management Access-List Configuration mode, where the denied or permitted access conditions are defined with the **deny** and **permit** commands.

If no match criteria are defined, the default value is **deny**.

When re-entering the access-list context, the new rules are entered at the end of the access list.

Use the [management access-class](#) command to select the active access list.

The active management list cannot be updated or removed.

For IPv6 management traffic that is tunneled in IPv4 packets, the management ACL is applied first on the external IPv4 header (rules with the service field are ignored), and then again on the inner IPv6 header.

Example

Example 1 - The following example creates a management access list called **m1ist**, configures management `fe1/0/11` and `fe1/0/19`, and makes the new access list the active list.

```
switchxxxxxx(config)# management access-list m1ist
switchxxxxxx(config-macl)# permit fe1/0/11
switchxxxxxx(config-macl)# permit fe1/0/19
switchxxxxxx(config-macl)# exit
switchxxxxxx(config)# management access-class m1ist
```

Example 2 - The following example creates a management access list called 'mlist', configures all interfaces to be management interfaces except fe1/0/11 and 9, and makes the new access list the active list.

```
switchxxxxxx(config)# management access-list mlist
switchxxxxxx(config-macl)# deny fe1/0/11
switchxxxxxx(config-macl)# deny fe1/0/19
switchxxxxxx(config-macl)# permit
switchxxxxxx(config-macl)# exit
switchxxxxxx(config)# management access-class mlist
```

9.2 permit (Management)

The **permit** Management Access-List Configuration mode command sets permit rules (ACEs) for the management access list (ACL).

Syntax

permit [*interface-id*] [*service service*]

permit ip-source {*ipv4-address* | *ipv6-address*/*ipv6-prefix-length*} [*mask* {*mask* | *prefix-length*}] [*interface-id*] [*service service*]

Parameters

- **interface-id**:—Specify an interface ID. The interface ID can be one of the following types: Ethernet port, Port-channel or VLAN
- **service service** — Specifies the service type. Possible values are: Telnet, SSH, HTTP, HTTPS and SNMP.
- **ipv4-address**— Specifies the source IPv4 address.
- **ipv6-address/ipv6-prefix-length**— Specifies the source IPv6 address and source IPv6 address prefix length. The prefix length must be preceded by a forward slash (/). The parameter is optional.
- **mask mask** — Specifies the source IPv4 address network mask. This parameter is relevant only to IPv4 addresses.
- **mask prefix-length** — Specifies the number of bits that comprise the source IPv4 address prefix. The prefix length must be preceded by a forward slash (/). This parameter is relevant only to IPv4 addresses. (Range: 0–32)

Default Configuration

No rules are configured.

Command Mode

Management Access-List Configuration mode

User Guidelines

Rules with Ethernet, VLAN, and port-channel parameters are valid only if an IP address is defined on the appropriate interface.

Example

The following example permits all ports in the ACL called **mlist**

```
switchxxxxxx(config)# management access-list mlist
switchxxxxxx(config-macl)# permit
```

9.3 deny (Management)

The **deny** Management Access-List Configuration mode command sets permit rules (ACEs) for the management access list (ACL).

Syntax

deny [*interface-id*] [*service service*]

deny ip-source [*ipv4-address* | *ipv6-address/ipv6-prefix-length*] [*mask {mask | prefix-length}*]
[*interface-id*] [*service service*]

Parameters

- **interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port, Port-channel or VLAN
- **service service**—Specifies the service type. Possible values are: Telnet, SSH, HTTP, HTTPS and SNMP.
- **ipv4-address**—Specifies the source IPv4 address.
- **ipv6-address/ipv6-prefix-length**—Specifies the source IPv6 address and source IPv6 address prefix length. The prefix length must be preceded by a forward slash (/). The parameter is optional.
- **mask mask**—Specifies the source IPv4 address network mask. The parameter is relevant only to IPv4 addresses.
- **mask prefix-length**—Specifies the number of bits that comprise the source IPv4 address prefix. The prefix length must be preceded by a forward slash (/). The parameter is relevant only to IPv4 addresses. (Range: 0–32)

Default Configuration

No rules are configured.

Command Mode

Management Access-List Configuration mode

User Guidelines

Rules with ethernet, VLAN, and port-channel parameters are valid only if an IP address is defined on the appropriate interface.

Example

The following example denies all ports in the ACL called **mlist**.

```
switchxxxxxx(config)# management access-list mlist
switchxxxxxx(config-macl)# deny
```

9.4 management access-class

The **management access-class** Global Configuration mode command restricts management connections by defining the active management access list (ACL). To disable management connection restrictions, use the **no** form of this command.

Syntax

management access-class {-only | *name*}

no management access-class

Parameters

- **-only**—Specifies that the device can be managed only from the .
- **name**—Specifies the ACL name to be used. (Length: 1–32 characters)

Default Configuration

The default configuration is no management connection restrictions.

Command Mode

Global Configuration mode

Example

The following example defines an access list called **m1ist** as the active management access list.

```
switchxxxxxx(config)# management access-class m1ist
```

9.5 show management access-list

The **show management access-list** Privileged EXEC mode command displays management access lists (ACLs).

Syntax

show management access-list [*name*]

Parameters

name—Specifies the name of a management access list to be displayed. (Length: 1–32 characters)

Default Configuration

All management ACLs are displayed.

Command Mode

Privileged EXEC mode

Example

The following example displays the **m1ist** management ACL.

```
switchxxxxxx# show management access-list m1ist
```

```
-only
-----
deny
! (Note: all other access implicitly denied)
mlist
-----
permit fe1/0/11
permit fe1/0/19
! (Note: all other access implicitly denied)
switchxxxxxx#
```

9.6 show management access-class

The **show management access-class** Privileged EXEC mode command displays information about the active management access list (ACLs).

Syntax

show management access-class

Command Mode

Privileged EXEC mode

Example

The following example displays the active management ACL information.

```
switchxxxxxx# show management access-class
Management access-class is enabled, using access list mlist
```

10 Network Management Protocol (SNMP) Commands

10.1 snmp-server community

Use the **snmp-server community** Global Configuration mode command to set the community access string (password) that permits access to SNMP commands (v1 and v2). This is used for SNMP commands, such as GETs and SETs.

This command configures both SNMP v1 and v2.

Use the **no** form of this command to remove the specified community string.

Syntax

snmp-server community *community-string* [**ro** | **rw** | **su**] [*ip-address* | *ipv6-address*] [**mask** *mask* | **prefix** *prefix-length*] [**view** *view-name*]

snmp-server community-group *community-string* *group-name* [*ip-address* | *ipv6-address*] [**mask** *mask* | **prefix** *prefix-length*]

no snmp-server community *community-string* [*ip-address*]

Parameters

- **community-string**—Define the password that permits access to the SNMP protocol. (Range: 1–20 characters). This string is used as an input parameter to [snmp-server user](#) for SNMP v3.
- **ro**—Specifies read-only access (default)
- **rw**—Specifies read-write access
- **su**—Specifies SNMP administrator access
- **view** *view-name*—Specifies the name of a view configured using the command [snmp-server view](#) (no specific order of the command configurations is imposed on the user). The view defines the objects available to the community. It is not relevant for **su**, which has access to the whole MIB. If unspecified, all the objects, except the community-table and SNMPv3 user and access tables, are available. (Range: 1–30 characters)
- **ip-address**—Management station IP address. The default is all IP addresses. This can be an IPv4 address, IPv6 or IPv6z address. See [IPv6z Address Conventions](#).
- **mask**—Specifies the mask of the IPv4 address. This is not a network mask, but rather a mask that defines which bits of the packet's source address are compared to the configured IP address. If unspecified, it defaults to 255.255.255.255. The command returns an error if the mask is specified without an IPv4 address.
- **prefix-length**—Specifies the number of bits that comprise the IPv4 address prefix. If unspecified, it defaults to 32. The command returns an error if the prefix-length is specified without an IPv4 address.
- **group-name**—This is the name of a group configured using [snmp-server group](#) with v1 or v2 (no specific order of the two command configurations is imposed on the user). The group defines the objects available to the community. (Range: 1–30 characters)

Default Configuration

No community is defined

Command Mode

Global Configuration mode

User Guidelines

Use **snmp-server community-group** to configure access rights to a user group. The group must exist in order to be able to specify the access rights. Otherwise, the community-group will not be useful.

A *view-name* cannot be specified for **su**, which has access to the whole MIB tree.

The logical key of the command is the pair (community, ip-address). If ip-address is omitted then the key is (community, All-IPs). This means that there cannot be two commands with the same community, ip address pair.

The *view-name* is used to restrict the access rights of a community string. When a view-name is specified, the software:

- Generates an internal security-name.
- Maps the internal security-name for SNMPv1 and SNMPv2 security models to an internal group-name.
- Maps the internal group-name for SNMPv1 and SNMPv2 security models to view-name (read-view and notify-view always, and for rw for write-view also),

The *group-name* is used to restrict the access rights of a community string. When a group-name is specified, the software:

- Generates an internal security-name.
- Maps the internal security-name for SNMPv1 and SNMPv2 security models to the group-name.

Examples

Example 1 - Defines a password for administrator access to the management station at IP address 1.1.1.121 and mask 255.0.0.0.

```
switchxxxxxx(config)# snmp-server community abcd su 1.1.1.121 mask  
255.0.0.0
```

Example 2 - Defines a password *tom* for the group *abcd* that enables this group to access the management station 1.1.1.121 with prefix 8.

```
switchxxxxxx(config)# snmp-server community-group tom abcd 1.1.1.122  
prefix 8
```

10.2 snmp-server view

The **snmp-server view** Global Configuration mode command creates or updates an SNMP view. Use the **no** form of this command to remove an SNMP view.

Syntax

snmp-server view *view-name oid-tree {included | excluded}*

no snmp-server view *view-name [oid-tree]*

Parameters

- **view-name**—Specifies the name for the view that is being created or updated. (Length: 1–30 characters)

- **oid-tree**—Specifies the ASN.1 subtree object identifier to be included or excluded from the view. To identify the subtree, specify a text string consisting of numbers, such as 1.3.6.2.4, or a word, such as System and, optionally, a sequence of numbers. Replace a single sub-identifier with the asterisk (*) wildcard to specify a subtree family; for example 1.3.*.4. This parameter depends on the MIB being specified.
- **included**—Specifies that the view type is included.
- **excluded**—Specifies that the view type is excluded.

Default Configuration

The following views are created by default:

- **Default** - Contains all MIBs except for those that configure the SNMP parameters themselves.
- **DefaultSuper** - Contains all MIBs.

Command Mode

Global Configuration mode

User Guidelines

This command can be entered multiple times for the same view.

The command's logical key is the pair (view-name, oid-tree). Therefore there cannot be two commands with the same view-name and oid-tree.

The number of views is limited to 64.

Default and DefaultSuper views are reserved for internal software use and cannot be deleted or modified.

Example

The following example creates a view that includes all objects in the MIB-II system group except for sysServices (System 7) and all objects for interface 1 in the MIB-II interface group (this format is specified on the parameters specified in ifEntry).

```
switchxxxxxx(config)# snmp-server view user-view system included
switchxxxxxx(config)# snmp-server view user-view system.7 excluded
switchxxxxxx(config)# snmp-server view user-view ifEntry.*.1 included
```

10.3 show snmp views

Use the **show snmp views** Privileged EXEC mode command to display the SNMP views.

Syntax

show snmp views [viewname]

Parameters

viewname—Specifies the view name. (Length: 1–30 characters)

Default Configuration

If viewname is not specified, all views are displayed.

Command Mode

Privileged EXEC mode

Example

The following example displays the configured SNMP views.

```
switchxxxxxx# show snmp views
```

Name	OID Tree	Type
Default	iso	Included
Default	snmpNotificationMIB	Excluded
DefaultSuper	iso	Included

10.4 snmp-server group

Use the **snmp-server group** Global Configuration mode command to configure an SNMP group. Groups are used to map SNMP users to SNMP views (using [snmp-server user](#)). Use the **no** form of this command to remove an SNMP group.

Syntax

snmp-server group *groupname* {**v1** | **v2** | **v3** {**noauth** | **auth** | **priv**} [**notify** *notifyview*]} [**read** *readview*] [**write** *writeview*]

no snmp-server group *groupname* {**v1** | **v2** | **v3** [**noauth** | **auth** | **priv**]}

Parameters

- **group** *groupname*—Specifies the group name. (Length: 1–30 characters)
- **v1**—Specifies the SNMP Version 1 security model.
- **v2**—Specifies the SNMP Version 2 security model.
- **v3**—Specifies the SNMP Version 3 security model.
- **noauth**—Specifies that no packet authentication will be performed. Applicable only to the SNMP version 3 security model.
- **auth**—Specifies that packet authentication without encryption will be performed. Applicable only to the SNMP version 3 security model.
- **priv**—Specifies that packet authentication with encryption will be performed. Applicable only to the SNMP version 3 security model. Note that creation of SNMPv3 users with both authentication and privacy must be done in the GUI. All other users may be created in the CLI.
- **notify** *notifyview*—Specifies the view name that enables generating informs or a traps. An inform is a trap that requires acknowledgement. Applicable only to the SNMP version 3 security model. (Length: 1–30 characters)
- **read** *readview*—Specifies the view name that enables viewing only. (Length: 1–30 characters)
- **write** *writeview*—Specifies the view name that enables configuring the agent. (Length: 1–30 characters)

Default Configuration

No group entry exists.

If *notifyview* is not specified, the notify view is not defined.

If *readview* is not specified, all objects except for the community-table and SNMPv3 user and access tables are available for retrieval.

If *writeview* is not specified, the write view is not defined.

Command Mode

Global Configuration mode

User Guidelines

The group defined in this command is used in [snmp-server user](#) to map users to the group. These users are then automatically mapped to the views defined in this command.

The command logical key is (**groupname, snmp-version, security-level**). For snmp-version v1/v2 the security-level is always **noauth**.

Example

The following example attaches a group called *user-group* to SNMPv3, assigns the encrypted security level to the group, and limits the access rights of a view called *user-view* to read-only. User *tom* is then assigned to *user-group*. So that user *tom* has the rights assigned in *user-view*.

```
switchxxxxxx(config)# snmp-server group user-group v3 priv read
user-view
switchxxxxxx(config)# snmp-server user tom user-group v3
```

10.5 show snmp groups

Use the **show snmp groups** Privileged EXEC mode command to display the configured SNMP groups.

Syntax

show snmp groups [*groupname*]

Parameters

groupname—Specifies the group name. (Length: 1–30 characters)

Default Configuration

Display all groups.

Command Mode

Privileged EXEC mode

Example

The following example displays the configured SNMP groups.

```
switchxxxxxx# show snmp groups
```

Network Management Protocol (SNMP) Commands

Name	Security		Views		
	Model	Level	Read	Write	Notify
-----	-----	-----	-----	-----	-----
user-group	V3	priv	Default	""	""
managers-group	V3	priv	Default	Default	""

The following table describes significant fields shown above.

Field		Description
Name		Group name.
Security	Model	SNMP model in use (v1, v2 or v3).
Security	Level	Packet authentication with encryption. Applicable to SNMP v3 security only.
Views	Read	View name enabling viewing the agent contents. If unspecified, all objects except the community-table and SNMPv3 user and access tables are available.
	Write	View name enabling data entry and managing the agent contents.
	Notify	View name enabling specifying an inform or a trap.

10.6 snmp-server user

Use the **snmp-server user** Global Configuration mode command to configure a new SNMP Version user. Use the **no** form of the command to remove a user.

Syntax

```
snmp-server user username groupname {v1 | v2c | [remote host] v3[encrypted] [auth { md5 | sha} auth-password]}
```

```
no snmp-server user username [remote host]
```

Parameters

- **username**—Define the name of the user on the host that connects to the agent. (Range: Up to 20 characters). For SNMP v1 or v2c, this username must match the community string entered in [snmp-server host](#).
- **groupname**—The name of the group to which the user belongs. The group should be configured using the command [snmp-server group](#) with v1 or v2c parameters (no specific order of the 2 command configurations is imposed on the user). (Range: Up to 30 characters)
- **remote** *host*—IP address (IPv4, IPv6 or IPv6z) or host name of the remote SNMP host. See [IPv6z Address Conventions](#).
- **v1**—Specifies that the user is a v1 user.
- **v2c**—Specifies that the user is a v2c user..
- **v3**—Specifies that the user is a v3 user..
- **encrypted**—Specifies whether the password that follows appears in encrypted format. If it is in encrypted format, it serves as the key.
- **auth**—Specifies which authentication level is to be used.
- **md5**—Specifies the HMAC-MD5-96 authentication level.

- **Sha**—Specifies the HMAC-SHA-96 authentication level.

auth-password—Specifies the authentication password. Range: Up to 32 characters. **Default Configuration**

No group entry exists.

Command Mode

Global configuration

User Guidelines

For SNMP v1 and v2, this performs the same actions as **snmp-server community-group**, except that **snmp-server community-group** configures both v1 and v2 at the same time. With this command, you must perform it once for v1 and once for v2.

When you enter a **show running-config** command, you do not see a line for this SNMP user. To see if this user has been added to the configuration, type the **show snmp user** command.

An SNMP EngineID must be defined in order to add SNMPv3 users to the device (in the [snmp-server engineID local](#) or [snmp-server engineID remote](#) commands).

Changing or removing the value of **snmpEngineID** deletes the SNMPv3 users' database.

The logical key of the command is username.

Configuring a remote host is required in order to send informs to that host, because an inform is a trap that requires acknowledgement. A configured remote host is also able to manage the device (besides getting the informs)

To configure a remote user, specify the IP address for the remote SNMP agent of the device where the user resides. Also, before you configure remote users for a particular agent, configure the SNMP engine ID, using the [snmp-server engineID remote](#) command. The remote agent's SNMP engine ID is needed when computing the authentication and privacy digests from the password. If the remote engine ID is not configured first, the configuration command fails.

Since the same group may be defined several times, each time with different version or different access level (noauth, auth or auth & priv), when defining a user it is not sufficient to specify the group name, rather you must specify group name, version and access level for complete determination of how to handle packets from this user.

Example

This example assigns user *tom* to group *abcd* using SNMP v1 and v2c. The default is assigned as the engineID. User *tom* is assigned to group *abcd* using SNMP v1 and v2c

```
switchxxxxxx(config)# snmp-server user tom acbd v1
switchxxxxxx(config)# snmp-server user tom acbd v2c
switchxxxxxx(config)# snmp-server user tom acbd v3
```

10.7 show snmp users

Use the **show snmp users** Privileged EXEC mode command to display the configured SNMP users.

Syntax

show snmp users [*username*]

Parameters

username—Specifies the user name. (Length: 1–30 characters)

Default Configuration

Display all users.

Command Mode

Privileged EXEC mode

Example

The following example displays the configured SNMP users.

```
switchxxxxxx# show snmp users
```

Name	Group name	Auth Method	Remote
John	user-group	md5	
John	user-group	md5	08009009020C0B099C07-5879

10.8 snmp-server filter

The **snmp-server filter** Global Configuration mode command creates or updates an SNMP server notification filter. Use the **no** form of this command to remove a notification filter.

Syntax

snmp-server filter *filter-name oid-tree {included | excluded}*

no snmp-server filter *filter-name [oid-tree]*

Parameters

- **filter-name**—Specifies the label for the filter record that is being updated or created. The name is used to reference the filter in other commands. (Length: 1–30 characters)
- **oid-tree**—Specifies the ASN.1 subtree object identifier to be included or excluded from the view. To identify the subtree, specify a text string consisting of numbers, such as 1.3.6.2.4, or a word, such as System. Replace a single sub-identifier with the asterisk (*) wildcard to specify a subtree family; for example, 1.3.*.4.
- **included**—Specifies that the filter type is included.
- **excluded**—Specifies that the filter type is excluded.

Default Configuration

No view entry exists.

Command Mode

Global Configuration mode

User Guidelines

This command can be entered multiple times for the same filter. If an object identifier is included in two or more lines, later lines take precedence. The command's logical key is the pair (filter-name, oid-tree).

Example

The following example creates a filter that includes all objects in the MIB-II system group except for sysServices (System 7) and all objects for interface 1 in the MIB-II interfaces group (this format depends on the parameters define in ifEntry).

```
switchxxxxxx(config)# snmp-server filter f1 system included
switchxxxxxx(config)# snmp-server filter f2 system.7 excluded
switchxxxxxx(config)# snmp-server filter f3 ifEntry.*.1 included
```

10.9 show snmp filters

Use the **show snmp filters** Privileged EXEC mode command to display the defined SNMP filters.

Syntax

```
show snmp filters [filtername]
```

Parameters

filtername—Specifies the filter name. (Length: 1–30 characters)

Default Configuration

If filtername is not defined, all filters are displayed.

Command Mode

Privileged EXEC mode

Example

The following example displays the configured SNMP filters.

```
switchxxxxxx# show snmp filters user-filter

Name                OID Tree                Type
-----            -
user-filter         1.3.6.1.2.1.1          Included
user-filter         1.3.6.1.2.1.1.7        Excluded
user-filter         1.3.6.1.2.1.2.2.1.*.1  Included
```

10.10 snmp-server host

Use the **snmp-server host** Global Configuration mode command to configure the host for SNMP notifications: (traps/informs). Use the **no** form of this command to remove the specified host.

Syntax

snmp-server host {*host-ip* | *hostname*} [*traps* | *informs*] [*version* {1 | 2c | 3 [*auth* | *noauth* | *priv*]}] *community-string* [*udp-port* *port*] [*filter* *filtername*] [*timeout* *seconds*] [*retries* *retries*]

no snmp-server host {*ip-address* | *hostname*} [*traps* | *informs*] [*version* {1 | 2c | 3}]

Parameters

- **host-ip**—IP address of the host (the targeted recipient). The default is all IP addresses. This can be an IPv4 address, IPv6 or IPv6z address. See [IPv6z Address Conventions](#).
- **hostname**—Hostname of the host (the targeted recipient). (Range: 1–158 characters. Maximum label size of each part of the host name: 63)
- **trap**—Sends SNMP traps to this host (default).
- **informs**—Sends SNMP informs to this host. An inform is a trap that requires acknowledgement. Not applicable to SNMPv1.
- **1**—SNMPv1 traps are used.
- **2c**—SNMPv2 traps or informs are used
- **3**—SNMPv2 traps or informs are used
- **community-string**—Password-like community string sent with the notification operation. (Range: 1–20 characters). For v1 and v2, any community string can be entered here. For v3, the community string must match the user name defined in [snmp-server user](#) for v3.
- Authentication options are available for SNMP v3 only. The following options are available:
 - **noauth**—Specifies no authentication of a packet.
 - **auth**—Specifies authentication of a packet without encryption.
 - **priv**—Specifies authentication of a packet with encryption.
- **udp-port** *port*—UDP port of the host to use. The default is 162. (Range: 1–65535)
- **filter** *filtername*—Filter for this host. If unspecified, nothing is filtered. The filter is defined using [snmp-server filter](#) (no specific order of commands is imposed on the user). (Range: Up to 30 characters)
- **timeout** *seconds*—(For informs only) Number of seconds to wait for an acknowledgment before resending informs. The default is 15 seconds. (Range: 1–300)
- **retries** *retries*—(For informs only) Maximum number of times to resend an inform request, when a response is not received for a generated message. The default is 3. (Range: 0–255)

Default Configuration

Version: SNMP V1

Type of notification: Traps

udp-port: 162

If informs are specified, the default for retries: 3

Timeout: 15

Command Mode

Global Configuration mode

User Guidelines

The logical key of the command is the pair (ip-address/hostname, traps/informs, version).

When configuring SNMP v1 or v2 notifications recipient, the software automatically generates a notification view for that recipient for all MIBs.

For SNMPv3 the software does not automatically create a user or a notify view.

Use the commands `snmp-server user`, `snmp-server group` and `snmp-server view` to create a user, a group or a notification group, respectively.

Example

The following defines a host at the IP address displayed.

```
switchxxxxxx(config)# snmp-server host 1.1.1.121 abc
```

10.11 snmp-server engineID local

The `snmp-server engineID local` Global Configuration mode command specifies the SNMP engineID on the local device for SNMP v3. Use the `no` form of this command to remove this engine ID.

Syntax

`snmp-server engineID local {engineid-string | default}`

`no snmp-server engineID local`

Parameters

- **engineid-string**—Specifies a concatenated hexadecimal character string identifying the engine ID. Each byte in a hexadecimal character string is two hexadecimal digits. Bytes are separated by a period or colon. If an odd number of hexadecimal digits are entered, the system automatically prefixes the digit 0 to the string. (Length: 5–32 characters, 9–64 hexadecimal digits)
- **default**—Specifies that the engine ID is created automatically based on the device MAC address.

Default Configuration

The default engine ID is defined per standard as:

- First 4 octets: First bit = 1, the rest is IANA Enterprise number = 674.
- Fifth octet: Set to 3 to indicate the MAC address that follows.
- Last 6 octets: The device MAC address.

Command Mode

Global Configuration mode

User Guidelines

To use SNMPv3, an engine ID must be specified for the device. Any ID can be specified or the default string, which is generated using the device MAC address, can be used.

As the engineID should be unique within an administrative domain, the following guidelines are recommended:

- For standalone devices, use the default keyword to configure the Engine ID.
- For stackable systems, configure an EngineID, and verify that it is unique within the administrative domain.

Changing or removing the value of `snmpEngineID` deletes the SNMPv3 users database.

The SNMP EngineID cannot be all 0x0 or all 0xF or 0x00000001

Example

The following example enables SNMPv3 on the device and sets the device local engine ID to the default value.

```
switchxxxxxx(config)# snmp-server engineid local default
The engine-id must be unique within your administrative domain.
Do you wish to continue? [Y/N]Y
The SNMPv3 database will be erased. Do you wish to continue? [Y/N]Y
```

10.12 snmp-server engineID remote

To specify the SNMP engine ID of a remote SNMP device, use the **snmp-server engineID remote** Global Configuration mode command. Use the **no** form of this command to remove the configured engine ID.

Syntax

snmp-server engineID remote *{ip-address} engineid-string*

no snmp-server engineID remote *{ip-address}*

Parameters

- **ip-address**—IPv4, IPv6 or IPv6z address of the remote device. See [IPv6z Address Conventions](#).
- **engineid-string**—The character string that identifies the engine ID. The engine ID is a concatenated hexadecimal string. Each byte in hexadecimal character strings is two hexadecimal digits. Each byte can be separated by a period or colon. If the user enters an odd number of hexadecimal digits, the system automatically prefixes the hexadecimal string with a zero. (Range: engineid-string5–32 characters. 9–64 hexadecimal digits)

Default Configuration

The remote engineID is not configured by default.

Command Mode

Global Configuration mode

User Guidelines

A remote engine ID is required when an SNMP version 3 inform is configured. The remote engine ID is used to compute the security digest for authenticating and encrypting packets sent to a user on the remote host.

10.13 show snmp engineID

Use the **show snmp engineID** Privileged EXEC mode command to display the local SNMP engine ID.

Syntax

show snmp engineID

Parameters

N/A

Default Configuration

N/A

Command Mode

Privileged EXEC mode

Example

The following example displays the SNMP engine ID.

```
switchxxxxxx # show snmp engineID
Local SNMP engineID: 08009009020C0B099C075878
IP address          Remote SNMP engineID
-----
172.16.1.1          08009009020C0B099C075879
```

10.14 snmp-server enable traps

Use the **snmp-server enable traps** Global Configuration mode command to enable the device to send all SNMP traps. Use the **no** form of the command to disable all SNMP traps.

Syntax**snmp-server enable traps****no snmp-server enable traps****Default Configuration**

SNMP traps are enabled.

Command Mode

Global Configuration mode

User Guidelines

If **no snmp-server enable traps** has been entered, you can enable failure traps by using [snmp-server trap authentication](#) as shown in the example.

Example

The following example enables SNMP traps except for SNMP failure traps.

```
switchxxxxxx(config) # snmp-server enable traps
switchxxxxxx(config) # no snmp-server trap authentication
```

10.15 snmp-server trap authentication

Use the **snmp-server trap authentication** Global Configuration mode command to enable the device to send SNMP traps when authentication fails. Use the **no** form of this command to disable SNMP failed authentication traps.

Syntax

snmp-server trap authentication

no snmp-server trap authentication

Parameters

N/A

Default Configuration

SNMP failed authentication traps are enabled.

Command Mode

Global Configuration mode

User Guidelines

The command [snmp-server enable traps](#) enables all traps including failure traps. Therefore, if that command is enabled (it is enabled by default), this command is not necessary.

Example

The following example disables all SNMP traps and enables only failed authentication traps.

```
switchxxxxxx(config)# no snmp-server enable traps
switchxxxxxx(config)# snmp-server trap authentication
```

10.16 snmp-server contact

Use the **snmp-server contact** Global Configuration mode command to set the value of the system contact (sysContact) string. Use the **no** form of the command to remove the system contact information.

Syntax

snmp-server contact *text*

no snmp-server contact

Parameters

text—Specifies system contact information. (Length: 1–168 characters)

Default Configuration

N/A

Command Mode

Global Configuration mode

Example

The following example sets the system contact information to Technical_Support.

```
switchxxxxxx(config)# snmp-server contact Technical_Support
```

10.17 snmp-server location

Use the **snmp-server location** Global Configuration mode command to set the value of the system location string. Use the **no** form of this command to remove the location string.

Syntax

snmp-server location *text*

no snmp-server location

Parameters

text—Specifies the system location information. (Length: 1–160 characters)

Default Configuration

N/A

Command Mode

Global Configuration mode

Example

The following example sets the device location to New_York.

```
switchxxxxxx(config)# snmp-server location New_York
```

10.18 snmp-server set

Use the **snmp-server set** Global Configuration mode command to define SNMP MIB commands in the configuration file if a MIB performs an action for which there is no corresponding CLI command.

Syntax

snmp-server set *variable-name name value [name2 value2...]*

Parameters

- **variable-name**—Specifies an SNMP MIB variable name, which must be a valid string.
- **name value**—Specifies a list of names and value pairs. Each name and value must be a valid string. In the case of scalar MIBs, there is only a single name-value pair. In the case of an entry in a table, there is at least one name-value pair, followed by one or more fields.

Default Configuration

N/A

Command Mode

Global Configuration mode

User Guidelines

Although the CLI can set any required configuration, there might be a situation where an SNMP user sets a MIB variable that does not have an equivalent CLI command. To generate configuration files that support those situations, the system uses [snmp-server set](#). This command is not intended for the end user.

Example

The following example configures the scalar MIB sysName with the value TechSupp.

```
switchxxxxxx(config)# snmp-server set sysName sysname TechSupp
```

10.19 show snmp

Use the **show snmp** Privileged EXEC mode command to display the SNMP status.

Syntax

show snmp

Parameters

N/A

Default Configuration

N/A

Command Mode

Privileged EXEC mode

Example

The following example displays the SNMP communications status.

```
switchxxxxxx# show snmp
SNMP is enabled

Community-String      Community-Access      View name      IP Address      Mask
-----
public               read only             user-view      All
private              read write            Default        172.16.1.1/10
private              su                    DefaultSuper   172.16.1.1

Community-string      Group name            IP Address      Mask      Type
-----
public                user-group            All
                                     Router

Traps are enabled.
Authentication trap is enabled.
Version 1,2 notifications
```



```

Target Address      Type      Community      Version      UDP      Filter      TO      Retries
-----
192.122.173.42     Trap      public         2            162     -----
192.122.173.42     Inform    public         2            162     -----
Version 3 notifications
Target Address      Type      Username      Security      UDP      Filter      TO      Retries
-----
192.122.173.42     Inform    Bob           Priv          162     name        15     3
System Contact: Robert
System Location: Marketing

```

The following table describes the significant fields shown in the display.

Field	Description
Community-string	The community access string permitting access to SNMP.
Community-access	The permitted access type—read-only, read-write, super access.
IP Address	The management station IP Address.
Target Address	The IP address of the targeted recipient.
Version	The SNMP version for the sent trap.

11

RSA and Certificate Commands

11.1 crypto key generate dsa

The **crypto key generate dsa** Global Configuration mode command generates a public and private DSA key (DSA key pair).

Syntax

crypto key generate dsa

Parameters

N/A

Default Configuration

DSA key pairs do not exist.

Command Mode

Global Configuration mode

User Guidelines

DSA keys are generated in pairs - one public DSA key and one private DSA key.

If the device already has DSA keys, a warning is displayed with a prompt to replace the existing keys with new keys.

This command is not saved in the Running configuration file. However, the keys generated by this command are saved in a private configuration (which is never displayed to the user or backed up to another device).

Example

The following example generates a DSA key pair.

```
switchxxxxxx(config)# crypto key generate dsa
The SSH service is generating a private DSA key.
This may take a few minutes, depending on the key size.
.....
```

11.2 crypto key generate rsa

The **crypto key generate rsa** Global Configuration mode command generates RSA key pairs.

Syntax

crypto key generate rsa

Parameters

N/A

Default Configuration

RSA key paris do not exist.

Command Mode

Global Configuration mode

User Guidelines

RSA keys are generated in pairs - one public RSA key and one private RSA key.

If the device already has RSA keys, a warning is displayed with a prompt to replace the existing keys with new keys.

This command is not saved in the Running configuration file; however, the keys generated by this command are saved in a private configuration (which is never displayed to the user or backed up to another device).

Example

The following example generates RSA key pairs where a RSA key already exists.

```
switchxxxxxx(config)# crypto key generate rsa
Replace Existing RSA Key [y/n]? N
switchxxxxxx(config)#
```

11.3 show crypto key mypubkey

The **show crypto key mypubkey** Privileged EXEC mode command displays the device's SSH public keys.

Syntax

show crypto key mypubkey [*rsa* | *dsa*]

Parameters

- **rsa**—Displays the RSA key.
- **dsa**—Displays the DSA key.

Default Configuration

N/A

Command Mode

Privileged EXEC mode

Example

The following example displays the SSH public RSA keys on the device.

```
switchxxxxxx# show crypto key mypubkey dsa
dsa key data:
ssh-dss AAAAB3NzaC1kc3MAAACBAOY/PhBgItVP5tFgDS7PA6Sdsvg5zq6c
k0VoWb0Pckj5mXy86jPrUdCAFsdwHubfDVr1qJUSz+0e5LfQtu2Sf9mUoyRG
```

```

DeC8PYRurARrP0t90FNYk+PZazJRjgy/X4V+9YL2etj+OrYm3f3YqLES1zJS
6IIycU1fEGNcZXL5JqM7AAAAFQD3UDWQ/9dXAGhFWy+ulSEqv/6b4wAAAIAs
jjSG4hq0RFdK5ooMKfB8lHAIOf8pI1maywkaomVJcukzBJ0x+K7DQiRLYQ+r
mrc5rOCs+ZWK8n6qK6Nv1li36mrc5uNM/C/ZcT/T3xu5TpHoujgByaxR+EKA
HSg4lIJagCQjM6T1nhDyLQYpsKdV1yovpSavjhM/gHcGjnwUKwAAAIEAp4RE
oR9ylQwtDiZHQcNXZhkN8eyfV1mirxLfnGiQhX48FdHGLEQcZZBUFSkTvGr
Te0y3nh2mZwnmKKeu49B6oEFGGVIr/Df2uligxidHKTdhNqcpMjClZKk3roz
DI7/i4KhlRpaSByY4P7906k/QLDA6vcELMfUw1XH6FwNuNY=
Fingerprint (hex) : e5:2e:39:43:e6:a3:3b:8a:9d:c7:62:9f:fc:c6:86:d1
Fingerprint (bubbleBabble) :
xesit-mupyd-kihod-cuzem-cigot-zogyr-gafyn-vileg-kunen
-felac-kuxyx

```

11.4 crypto certificate generate

The **crypto certificate generate** Global Configuration mode command generates a self-signed certificate for HTTPS.

Syntax

crypto certificate number generate [*key-generate* [*length*]] [*passphrase string*] [*cn common-name*] [*ou organization-unit*] [*or organization*] [*loc location*] [*st state*] [*cu country*] [*duration days*]

Parameters

- **number**—Specifies the certificate number. (Range: 1–2)
- **key-generate length**—Regenerates SSL RSA key and specifies the SSL's RSA key length. (Range: 512–2048)
- **passphrase string**—Specifies the passphrase used for exporting the certificate in PKCS12 file format. (Length: 8–96 characters)
- The following elements can be associated with the key. When the key is displayed, they are also displayed.
 - **cn common-name**—Specifies the fully qualified device URL or IP address. (Length: 1–64 characters). If unspecified, defaults to the lowest IP address of the device (when the certificate is generated).
 - **ou organization-unit**—Specifies the organization-unit or department name. (Length: 1–64 characters)
 - **or organization**—Specifies the organization name. (Length: 1–64 characters)
 - **loc location**—Specifies the location or city name. (Length: 1–64 characters)
 - **st state**—Specifies the state or province name. (Length: 1–64 characters)
 - **cu country**—Specifies the country name. (Length: 2 characters)
- **duration days**—Specifies the number of days a certification is valid. (Range: 30–3650)

Default Configuration

The default SSL's RSA key length is 1024.

If **passphrase string** is not specified, the certificate is not exportable.

If **cn common-name** is not specified, it defaults to the device's lowest static IPv6 address (when the certificate is generated), or to the device's lowest static IPv4 address if there is no static IPv6 address, or to 0.0.0.0 if there is no static IP address.

If **duration** *days* is not specified, it defaults to 365 days.

Command Mode

Global Configuration mode

User Guidelines

This command is not saved in the Running configuration file. However, the certificate and keys generated by this command are saved in a private configuration (which is never displayed to the user or backed up to another device).

When exporting a RSA key pair to a PKCS#12 file, the RSA key pair is as secure as the passphrase. Keep the passphrase secure.

If the RSA key does not exist, you must use the parameter **key-generate**.

If both certificates 1 and 2 have been generated, use [ip https certificate](#) to active one of them.

Example

The following example generates a self-signed certificate for HTTPS whose length is 100 bytes.

```
switchxxxxxx# crypto certificate generate key-generate 100
```

11.5 crypto certificate request

The **crypto certificate request** Privileged EXEC mode command generates and displays a certificate request for HTTPS.

Syntax

crypto certificate *number* **request** [*cn common-name*] [*ou organization-unit*] [*or organization*] [*loc location*] [*st state*] [*cu country*]

Parameters

- **number**—Specifies the certificate number. (Range: 1–2)
- The following elements can be associated with the key. When the key is displayed, they are also displayed.
 - **cn common-name**—Specifies the fully qualified device URL or IP address. (Length: 1–64 characters). If unspecified, defaults to the lowest IP address of the device (when the certificate is generated).
 - **ou organization-unit**—Specifies the organization-unit or department name. (Length: 1–64 characters)
 - **or organization**—Specifies the organization name. (Length: 1–64 characters)
 - **loc location**—Specifies the location or city name. (Length: 1–64 characters)
 - **st state**—Specifies the state or province name. (Length: 1–64 characters)
 - **cu country**—Specifies the country name. (Length: 2 characters)

Default Configuration

If **cn common-name** is not specified, it defaults to the device's lowest static IPv6 address (when the certificate is generated), or to the device's lowest static IPv4 address if there is no static IPv6 address, or to 0.0.0.0 if there is no static IP address.

Command Mode

Privileged EXEC mode

User Guidelines

Use this command to export a certificate request to a Certification Authority. The certificate request is generated in Base64-encoded X.509 format.

Before generating a certificate request, first generate a self-signed certificate using the [crypto certificate generate](#) Global Configuration mode command to generate the keys. The certificate fields must be re-entered.

After receiving the certificate from the Certification Authority, use the [crypto certificate import](#) Global Configuration mode command to import the certificate into the device. This certificate replaces the self-signed certificate.

Example

The following example displays the certificate request for HTTPS.

```
switchxxxxx# crypto certificate 1 request
-----BEGIN CERTIFICATE REQUEST-----
MIwTCCASoCAQAwYjELMAkGA1UEBhMCUFAXCzAJBgNVBAgTAkNDMQswCQYDVQQH
EwRDEMMAoGA1UEChMDZGxkMQwwCgYDVQQLEwNkbGQxCzAJBgNVBAMTAmxkMRAw
DgKoZIhvcNAQkBFgFsMIGfMA0GCSqGSIb3DQEBAQUAA4GNADCBiQKBgQC8ecwQ
HdML0831i0fh/F0MV/Kib6Sz5p+3nUUenbfHp/igVPmFM+1nbqTDeKb2ymCu6K
aKvEbVLF9F2LmM7VPjDBb9bb4jnxkvwW/wzDLvW2rsy5NPmH1QV1+8Ubx3GyCm
/oW93BSOFwxwEsP58kf+sPYPy+/8wwmoNtDwIDAQABoB8wHQYJKoZIhvcNAQkH
MRDjEyMwgICCAgICAICAgaMA0GCSqGSIb3DQEBAQUAA4GBAGb8UgIx7rB05m+2
m5ZZPhIw18ARSPXwhVdJexFjbnmvcacqjPG8pIiRV6LkxryGF2bVU3jKEipcZa
g+uNpyTkDt3ZVU72pjz/fa8TF0n3
-----END CERTIFICATE REQUEST-----
CN= router.gm.com
O= General Motors
C= US
```

11.6 crypto certificate import

The **crypto certificate import** Global Configuration mode command imports a certificate signed by a Certification Authority for HTTPS.

Syntax

crypto certificate *number* **import**

Parameters

number—Specifies the certificate number. (Range: 1–2)

Default Configuration

N/A

Command Mode

Global Configuration mode

User Guidelines

To end the session (return to the command line to enter the next command), enter a blank line.

The imported certificate must be based on a certificate request created by the [crypto certificate request](#) privileged EXEC command.

If the public key found in the certificate does not match the device's SSL RSA key, the command fails.

This command is not saved in the Running configuration file. However, the certificate imported by this command is saved in the private configuration (which is never displayed to the user or backed up to another device).

Example

The following example imports a certificate signed by the Certification Authority for HTTPS.

```
switchxxxxxx(config)#exit
switchxxxxxx#crypto certificate
  <1-2>                Specifies the certificate number.
switchxxxxxx#crypto certificate 1 request
-----BEGIN CERTIFICATE REQUEST-----
MIIBkzCB/QIBADBUMQswCQYDVQQGEwIgdEIKMAgGA1UECBMBIDEKMAgGA1UEBxMB
IDEVMBMGA1UEAxMMMTAuNS4yMzQuMjA5MzQwCAYDVQQKEwEgMQowCAYDVQQLEwEg
MIGfMA0GCSqGSIb3DQEBAQUAA4GNADCBiQKBgQDK+beogIcke73sBSL7tC2DMZrY
0Og9XM1Axf0iqLlQJHd4xP+BHGZWwfKjKjUDBPzn52LxdDu1KrpB/h0+TZP0Fv38
7mIDqtnoF1NLsWxkVKRM5LPka0L/ha1pYxp7EWAt5iDBzSw5s04lv0bSN7oaGjFA
6t4SW2rrnDy8JbwjWQIDAQABAAwDQYJKoZIhvcNAQEEBQADgYEAuqYQinJst6hI
XFDxe7I8Od3Uyt3Dmf7KE/AmUV0Pif2yUluY/RuxRwKhDp/lGrK12tzLQz+s50x7
Klft/IcjzbBYXLvih45ASWG3TRv2WVKyWs89rPPXu5hKxggEeTvWqpuS+gXrIqjW
WVzd0n1fXhMacoflgnnEmweIzmrqXBs=
-----END CERTIFICATE REQUEST-----
switchxxxxxx(config)# crypto certificate 1 import
Please paste the input now, add a period (.) on a separate line after the
input, and press Enter.
-----BEGIN CERTIFICATE-----
MIIBkzCB/QIBADBUMQswCQYDVQQGEwIgdEIKMAgGA1UECBMBIDEKMAgGA1UEBxMB
IDEVMBMGA1UEAxMMMTAuNS4yMzQuMjA5MzQwCAYDVQQKEwEgMQowCAYDVQQLEwEg
MIGfMA0GCSqGSIb3DQEBAQUAA4GNADCBiQKBgQDK+beogIcke73sBSL7tC2DMZrY
0Og9XM1Axf0iqLlQJHd4xP+BHGZWwfKjKjUDBPzn52LxdDu1KrpB/h0+TZP0Fv38
7mIDqtnoF1NLsWxkVKRM5LPka0L/ha1pYxp7EWAt5iDBzSw5s04lv0bSN7oaGjFA
6t4SW2rrnDy8JbwjWQIDAQABAAwDQYJKoZIhvcNAQEEBQADgYEAuqYQinJst6hI
XFDxe7I8Od3Uyt3Dmf7KE/AmUV0Pif2yUluY/RuxRwKhDp/lGrK12tzLQz+s50x7
Klft/IcjzbBYXLvih45ASWG3TRv2WVKyWs89rPPXu5hKxggEeTvWqpuS+gXrIqjW
WVzd0n1fXhMacoflgnnEmweIzmrqXBs=
.
```

```

-----END CERTIFICATE-----
Certificate imported successfully.
Issued by : C= , ST= , L= , CN=0.0.0.0, O= , OU=
Valid From: Jan 24 18:41:24 2011 GMT
Valid to: Jan 24 18:41:24 2012 GMT
Subject: C=US , ST= , L= , CN=router.gm.com, O= General Motors, OU=
SHA1 Finger print: DC789788 DC88A988 127897BC BB789788
    
```

11.7 crypto certificate export pkcs12

The **crypto certificate export pkcs12** Privileged EXEC mode command exports the certificate and the RSA keys within a PKCS12 file.

Syntax

crypto certificate *number* **export pkcs12**

Parameters

number—Specifies the certificate number. (Range: 1–2)

Default Configuration

N/A

Command Mode

Privileged EXEC mode

User Guidelines

This command creates a PKCS 12 file that contains the certificate and an RSA key pair. This is used by [crypto certificate import pkcs12](#).

The passphrase for the export is determined when the key is generated.

The certificate and key pair are exported in a standard PEM-format PKCS12 file. This format can be converted to and from the binary PFX file used by Windows and Linux by using the **openssl** command-line tool. See an open source OpenSSL user manual (`man pkcs12`) for more information.

Example

The following example exports the certificate and the RSA keys within a PKCS12 file.

```

switchxxxxxx# crypto certificate 1 export pkcs12
Bag Attributes
localKeyID: 0C 75 81 77 5A 31 53 D1 FF 4E 26 BE 8D 4A FD 8B 22 9F 45 D4
subject=/C=us/ST= /L= /CN= /O= /OU=
issuer= /C=us/ST= /L= /CN= /O= /OU=
-----BEGIN CERTIFICATE-----
MIIBfDCCASYCAQAwdQYJKoZIhvcNAQEEBQAwSTELMAkGA1UEBhMCdXMxCjAIBgNV
BAGtTASAxCjAIBgNVBAAcTASAxCjAIBgNVBAMTASAxCjAIBgNVBAoTASAxCjAIBgNV
BASASAwHhcNMDQwMjA3MTU1NDQ4WhcNMDUwMjA2MTU1NDQ4WjBjBjMjQswCQYDVQQL
EwJlczEKMAgGA1UECBMBIDEKMAgGA1UEBxMBIDEKMAgGA1UEAxMBIDEKMAgGA1UE
    
```

```
ChMBIDEKMAgGA1UECxBMBIDBcMA0GCSqGSIb3DQEBAQUAA0sAMEgCQQCZXP/tk3e/
jrulFzw8q8T2oS5ymrEIES/sRJE8uahTBjQkU1VHqRYJR3VYa/03HSJ741w5MzPI
iuWZzrbbuXAxAgMBAAEwDQYJKoZIhvcNAQEEBQADQQBQ+GTLN1p1kARxI4C1fTU
efig3ffZ/tjW5qlt1r5F6zNv/GuXWw7rGzmRyoMXDcYp1TaA4gAIFQCpFGqiSbAx
-----END CERTIFICATE-----
Bag Attributes
localKeyID: 0C 75 81 77 5A 31 53 D1 FF 4E 26 BE 8D 4A FD 8B 22 9F 45 D4
Key Attributes: <No Attributes>
-----BEGIN RSA PRIVATE KEY-----
Proc-Type: 4, ENCRYPTED
DEK-Info: DES-EDE3-CBC, 085DCBF3A41D2669
dac0m9jqEp1DM50sIDb8Jq1jxW/1P0kqSxuMhc250dBE/1fPBg9VSvV1ARaYt16W
bX67UyJ8t7HHF3AowjcwZelQ5GJgSQ0VemsqsRQzjpCTb090rx+cNwVfIvjoedgQ
Mt15+fKIAcqsfEgEGJNXQ4jEzsXAkwfQLFfgt4703IpkUn0AxrQzutJDOcC28Uxp
raMVTVS1skJiVaPuXJxdZ279tDMwZffILBfKJGACT5V5/4WEqDkrF+uuF9/oxm2
5SVL8TvUmXB/3hX4UoaXtxAhuyOdhhlkyyZSpw9BPPR/8bc/wUYERh7+7JXLKHpd
ueeu3znfIX4dDeti8B3xYvvE8kGZjxFN1cC3zc3JsD0IVu1LkyiAa93P4LPEvAwG
Fw1LqmGiiqw9JM/tzc6kYkZXylFzCrSVf2exP+/tEvM=
-----END RSA PRIVATE KEY-----
```

11.8 crypto certificate import pkcs12

The **crypto certificate import pkcs12** Privileged EXEC mode command imports the certificate and the RSA keys within a PKCS12 file.

Syntax

crypto certificate *number* **import pkcs12** *passphrase*

Parameters

- **number**—Specifies the certificate number. (Range: 1–2)
- **passphrase**—Specifies the passphrase used to encrypt the PKCS12 file for export. (Length: 8–96 characters)

Default Configuration

N/A

Command Mode

Privileged EXEC mode

User Guidelines

This command enables using the passphrase that was exported by [crypto certificate export pkcs12](#). This passphrase must be saved for later exports.

Example

The following example imports the certificate and the RSA keys within a PKCS12 file.

```

switchxxxxx# crypto certificate 1 import pkcs12 encrypted_passphrase
Bag Attributes
localKeyID: 0C 75 81 77 5A 31 53 D1 FF 4E 26 BE 8D 4A FD 8B 22 9F 45 D4
subject=/C=us/ST= /L= /CN= /O= /OU=
issuer= /C=us/ST= /L= /CN= /O= /OU=
-----BEGIN CERTIFICATE-----
MIIBfDCCASYCAQAwDQYJKoZIhvcNAQEEBQAwSTELMAkGA1UEBhMCdXMxCjAIBgNV
BAGTASAxCjAIBgNVBACjAIBgNVBAMTASAxCjAIBgNVBAoTASAxCjAIBgNV
BAsTASAwHhcNMDQwMjA3MTU1NDQ4WhcNMDUwMjA2MTU1NDQ4WjBjMQswCQYD
VQQG
EwJ1czEKMAgGA1UECBMIDEKMAgGA1UEBxMBIDEKMAgGA1UEAxMBIDEKMAgGA1UE
ChMBIDEKMAgGA1UECxBMIDBcMA0GCSqGSIb3DQEBAQUAA0sAMEgCQQCZXP/tk3e/
jrulfZw8q8T2oS5ymrEIES/sRJE8uahTBjQKulVHqRYJR3VYa/03HSJ741w5MzPI
iuWZzrbbuXAxAgMBAAEwDQYJKoZIhvcNAQEEBQADQQBQ+GTLen1p1kARxI4C1fTU
efig3ffZ/tjW5q1t1r5F6zNv/GuXWw7rGzmRyoMXDcYp1TaA4gAIFQCPFGqiSbAx
-----END CERTIFICATE-----
Bag Attributes
localKeyID: 0C 75 81 77 5A 31 53 D1 FF 4E 26 BE 8D 4A FD 8B 22 9F 45 D4
Key Attributes: <No Attributes>
-----BEGIN RSA PRIVATE KEY-----
Proc-Type: 4, ENCRYPTED
DEK-Info: DES-EDE3-CBC, 085DCBF3A41D2669
dac0m9jqEp1DM50sIDb8Jq1jxW/1P0kqSxuMhc250dBE/1fPBg9VSvV1ARaYt16W
bx67UyJ8t7HHF3AowjcWzElQ5GJgSQ0VemsqsRQzjpCTb090rx+cNwVfIvjoedgQ
Mtl5+fKIAcqsEgEGJNXQ4jEzsXAkwfQLFfgt4703IpkUn0AxrQzutJDOcC28Uxp
raMVTVSlSkJivaPuXJxdZ279tDMwZffILBfKJGACT5V5/4WEqDkrF+uuF9/oxm2
5SVL8TvUmXB/3hX4UoaXtxAhuyOdhh1kyyZSpw9BPPR/8bc/wUYERh7+7JXLKHpd
ueeu3znfIX4dDeti8B3xYvvE8kGZjxFN1cC3zc3JsD0IVulLkyiAa93P4LPEvAwG
FwlLqmGiiqw9JM/tzc6kYkZXylFzCrSVf2exP+/tEvM=
-----END RSA PRIVATE KEY-----

```

11.9 show crypto certificate mycertificate

The **show crypto certificate mycertificate** Privileged EXEC mode command displays the device SSL certificates.

Syntax

show crypto certificate mycertificate [*number*]

Parameters

number—Specifies the certificate number. (Range: 1–3)

Default Configuration

Certificate number 1.

Command Mode

Privileged EXEC mode

**Example**

The following example displays SSL certificate # 1 present on the device.

```
switchxxxxxx# show crypto certificate mycertificate
-----BEGIN CERTIFICATE-----
dHmUgUm9vdCBDZXXJ0aWZpZXIwXDANBgkqhkiG9w0BAQEFAANLADBIAkEAp4HS
nnH/xQSGA2ffkRBwU2XIxb7n8VPsTm1xyJ1t11a1GaqchfMqqe0kmfhcoHSWr
yf1FpD0MWOTgDAwIDAQABo4IBojCCAZ4wEwYJKwYBBAGCNxQCBAYeBABDAEEw
CwR0PBAQDAgFGMA8GA1UdEwEB/wQFMAMBAf8wHQYDVR0OBBYEFAf4MT9BRD47
ZvKBAEL9Ggp+6MIIBNgYDVR0fBIIBLTCCASkwdKggc+ggcyGgclsZGFwOi8v
L0VByb3h5JTlWU29mdHdhcmU1MjBSb290JTlWQ2VydGlmaWVyLENOPXNlcnZl
-----END CERTIFICATE-----
Issued by: www.verisign.com
Valid from: 8/9/2003 to 8/9/2004
Subject: CN= router.gm.com, O= General Motors, C= US
Finger print: DC789788 DC88A988 127897BC BB789788
```

12 Web Server Commands

12.1 ip http server

Use the **ip http server** Global Configuration mode command to enable configuring and monitoring the device from a web browser. Use the **no** form of this command to disable this function.

Syntax

ip http server
no ip http server

Parameters

N/A

Default Configuration

HTTP server is enabled.

Command Mode

Global Configuration mode

Example

The following example enables configuring the device from a web browser.

```
switchxxxxxx(config)# ip http server
```

12.2 ip http port

The **ip http port** Global Configuration mode command specifies the TCP port used by the web browser interface. Use the **no** form of this command to restore the default configuration.

Syntax

ip http port *port-number*
no ip http port

Parameters

port *port-number*—For use by the HTTP server. (Range: 0–65534)

Default Configuration

The default port number is 80.

Command Mode

Global Configuration mode

Example

The following example configures the http port number as 100.

```
switchxxxxxx(config)# ip http port 100
```

12.3 ip http timeout-policy

Use the **ip http timeout-policy** Global Configuration mode command to set the interval for the system to wait for user input in http/https sessions before automatic logoff. Use the **no** form of this command to return to the default value.

Syntax

ip http timeout-policy *idle-seconds*

no ip http timeout-policy

Parameters

idle-seconds—Specifies the maximum number of seconds that a connection is kept open if no data is received or response data cannot be sent out. (Range: 0–86400)

Default Configuration

600 seconds

Command Mode

Global Configuration mode

User Guidelines

To specify no timeout, enter the **ip http timeout-policy 0** command.

Example

The following example configures the http timeout to be 1000 seconds.

```
switchxxxxxx(config)# ip http timeout-policy 1000
```

12.4 ip http secure-server

Use the **ip http secure-server** Global Configuration mode command to enable the device to be configured or monitored securely from a browser. Use the **no** form of this command to disable this function.

Syntax

ip http secure-server

no ip http secure-server

Parameters

N/A

Default Configuration

Disabled

Command Mode

Global Configuration mode

User Guidelines

After this command is used, you must generate a certificate using [crypto certificate generate](#). If no certificate is generated, this command has no effect.

Example

```
switchxxxxxx(config)# ip http secure-server
```

12.5 ip http secure-port

Use the **ip http secure-port** Global Configuration mode command to specify the TCP port to be used by the secure web browser. To use the default port, use the **no** form of this command.

Syntax

ip http secure-port *port-number*

no ip http secure-port

Parameters

port-number—Port number for use by the HTTPS server (Range: 0–65534)

Default Configuration

The default port number is 443.

Command Mode

Global Configuration mode

Example

```
switchxxxxxx(config)# ip http secure-port 1234
```

12.6 ip https certificate

Use the **ip https certificate** Global Configuration mode command to configure the active certificate for HTTPS. Use the **no** form of this command to restore the default configuration.

Syntax

ip https certificate *number*

no ip https certificate

Parameters

number—Specifies the certificate number. (Range: 1–2)

**Default Configuration**

The default certificate number is 1.

Command Mode

Global Configuration mode

User Guidelines

First, use [crypto certificate generate](#) to generate one or two HTTPS certificates. Then use this command to specify which is the active certificate.

Example

The following example configures the active certificate for HTTPS.

```
switchxxxxxx(config)# ip https certificate 2
```

12.7 show ip http

The **show ip http** EXEC mode command displays the HTTP server configuration.

Syntax

show ip http

Command Mode

EXEC mode

Example

The following example displays the HTTP server configuration.

```
switchxxxxxx# show ip http
HTTP server enabled
Port: 80
Interactive timeout: 10 minutes
```

12.8 show ip https

The **show ip https** Privileged EXEC mode command displays the HTTPS server configuration.

Syntax

show ip https

Command Mode

Privileged EXEC mode

Example

The following example displays the HTTPS server configuration.

```
switchxxxxxx# show ip https
HTTPS server enabled
Port: 443
Interactive timeout: Follows the HTTP interactive timeout (10 minutes)
Certificate 1 is active
Issued by: www.verisign.com
Valid from: 8/9/2003 to 8/9/2004
Subject: CN= router.gm.com, O= General Motors, C= US
Finger print: DC789788 DC88A988 127897BC BB789788
Certificate 2 is inactive
Issued by: self-signed
Valid from: 8/9/2003 to 8/9/2004
Subject: CN= router.gm.com, O= General Motors, C= US
Finger print: 1873B936 88DC3411 BC8932EF 782134BA
```



13 Teletype Network (Telnet), Secure Shell (SSH) and Secure Login (Slogin) Commands

13.1 ip telnet server

Use the **ip telnet server** Global Configuration mode command to enable the device to be configured from a Telnet server. Use the **no** form of this command to disable the device configuration from a Telnet server.

Syntax

ip telnet server

no ip telnet server

Default Configuration

Configuration from a Telnet server is Disabled by default.

Command Mode

Global Configuration mode

User Guidelines

The device can be configured from an SSH server or Telnet (or both). To control the device configuration by SSH, use the [ip ssh pubkey-auth](#) Global Configuration mode command.

Example

The following example enables the device to be configured from a Telnet server.

```
switchxxxxxx(config)# ip telnet server
```

13.2 ip ssh server

The **ip ssh server** Global Configuration mode command enables the device to be configured from an SSH server. Use the **no** form of this command to disable the device configuration from an SSH server.

Syntax

ip ssh server

no ip ssh server

Default Configuration

Device configuration from an SSH server is disabled.

Command Mode

Global Configuration mode

User Guidelines

The device can be configured from an SSH server or Telnet (or both). To control the device configuration by SSH, use the [ip telnet server](#) Global Configuration mode command

If encryption keys are not generated, the SSH server is in standby until the keys are generated. To generate SSH server keys, use the [crypto key generate dsa](#) and [crypto key generate rsa](#) Global Configuration mode commands.

Example

The following example enables configuring the device from an SSH server.

```
switchxxxxxx(config)# ip ssh server
```

13.3 ip ssh port

The **ip ssh port** Global Configuration mode command specifies the port used by the SSH server. Use the **no** form of this command to restore the default configuration.

Syntax

ip ssh port *port-number*

no ip ssh port

Parameters

port-number—Specifies the port number to be used by the SSH server. (Range: 1–65535)

Default Configuration

The default port number is 22.

Command Mode

Global Configuration mode

Example

The following example specifies that port number 8080 is used by the SSH server.

```
switchxxxxxx(config)# ip ssh port 8080
```

13.4 ip ssh pubkey-auth

Use the **ip ssh pubkey-auth** Global Configuration mode command to enable public key authentication of incoming SSH sessions. Use the **no** form of this command to disable this function.

Syntax

ip ssh pubkey-auth

no ip ssh pubkey-auth

Default Configuration

Public Key authentication of incoming SSH sessions is disabled.

Command Mode

Global Configuration mode

User Guidelines

This command enables encrypting information using the public key. AAA authentication is must be configured as usual.

Example

The following example configures authentication of the SSH client.

```
switchxxxxxx(config)# ip ssh pubkey-auth
switchxxxxxx(config)# crypto key pubkey-chain ssh
switchxxxxxx(config-pubkey-chain)# user-key bob
switchxxxxxx(config-pubkey-key)# key-string rsa
AAAAB3NzaC1yc2EAAAADAQABAAQACvTnRwPWl
Al4kpqIw9GBRonZQZxjHKcqKL6rMlQ+
ZNXfZSkvHG+QusIZ/76ILmFT34v7u7ChFAE+
Vu4GRfpSwoQUvV35LqJJK67IOU/zfwO11g
kTwm175QR9gHujS6KwGN2QWXgh3ub8gDjTSq
muSn/Wd05iDX2IExQWu08licg1k02LYciz
+Z4TrEU/9FJxwPiVQOjc+KBXuR0juNg5nFYsY
0ZCk0N/W9a/tnkmlshRE7Di71+w3fNiOA
6w9o44t6+AINEICBCCA4YcF6zMzaTlwefWwX6f+
Rmt5nhhqAtN/4oJfce166DqVX1gWmN
```

13.5 crypto key pubkey-chain ssh

The **crypto key pubkey-chain ssh** Global Configuration mode command enters the SSH Public Key-chain Configuration mode. This mode is used to manually specify device public keys, such as SSH client public keys.

Syntax

crypto key pubkey-chain ssh

Default Configuration

Keys do not exist.

Command Mode

Global Configuration mode

User Guidelines

Use this command when you want to manually specify SSH client's public keys.

Example

The following example enters the SSH Public Key-chain Configuration mode and manually configures the RSA key pair for SSH public key-chain to the user 'bob'.

```
switchxxxxxx(config)# crypto key pubkey-chain ssh
switchxxxxxx(config-pubkey-chain)# user-key bob
switchxxxxxx(config-pubkey-key)# key-string rsa
AAAAB3NzaC1yc2EAAAADAQABAAQACvTnRwPwL
Al4kpqIw9GBRonZQZxjHKcqKL6rMlQ+
ZNXfZSkvHG+QusIZ/76ILmFT34v7u7ChFAE+
Vu4GRfpSwoQUvV35LqJJK67IOU/zfwO11g
kTwm175QR9gHujS6KwGN2QWXgh3ub8gDjTSq
muSn/Wd05iDX2IExQWu08licg1k02LYciz
+Z4TrEU/9FJxwPiVQOjC+KBXuR0juNg5nFYsY
0ZCk0N/W9a/tnkm1shRE7Di71+w3fNiOA
6w9o44t6+AINEICBCCA4YcF6zMzaTlwefWwX6f+
Rmt5nhhqAtN/4oJfcel66DqVX1gWmN
zNR4DYDvSzg01DnwCAC8Qh
Fingerprint: a4:16:46:23:5a:8d:1d:b5:37:59:eb:44:13:b9:33:e9
```

13.6 user-key

The **user-key** SSH Public Key-string Configuration mode command associates a username with an SSH public key that was manually configured. Use the **no** form of this command to remove an SSH public key.

Syntax

user-key *username* {**rsa** | **dsa**}

no user-key *username*

Parameters

- **username**—Specifies the remote SSH client username. (Length: 1–48 characters)
- **rsa**—Specifies that the RSA key pair is manually configured.
- **dsa**—Specifies that the DSA key pair is manually configured.

Default Configuration

No SSH public keys exist.

Command Mode

SSH Public Key-string Configuration mode

User Guidelines

Follow this command with [key-string](#) to specify the key.

Note that after entering this command, the existing key is deleted even if no new key is defined by [key-string](#).

Example

The following example enables manually configuring an SSH public key for SSH public key-chain **bob**.

```
switchxxxxxx(config)# crypto key pubkey-chain ssh
switchxxxxxx(config-pubkey-chain)# user-key bob rsa
switchxxxxxx(config-pubkey-key)# key-string row
AAAAB3NzaC1yc2EAAAADAQABAAQACvTnRwPWl
```

13.7 key-string

The **key-string** SSH Public Key-string Configuration mode command manually specifies an SSH public key.

Syntax

key-string [*row key-string*]

Parameters

- **row**—Specifies the SSH public key row by row.
- **key-string**—Specifies the key in UU-encoded DER format. UU-encoded DER format is the same format as in the `authorized_keys` file used by OpenSSH. (Length:0–160)

Default Configuration

Keys do not exist.

Command Mode

SSH Public Key-string Configuration mode

User Guidelines

Use the **key-string** SSH Public Key-string Configuration mode command without the **row** parameter to specify which SSH public key is to be interactively configured next. Enter a row with no characters to complete the command.

Use the **key-string row** SSH Public Key-string Configuration mode command to specify the SSH public key, row by row. Each row must begin with a **key-string row** command.

The UU-encoded DER format is the same format as in the `authorized_keys` file used by OpenSSH.

Example

The following example enters public key strings for SSH public key client 'bob'.

```
switchxxxxxx(config)# crypto key pubkey-chain ssh
switchxxxxxx(config-pubkey-chain)# user-key bob rsa
switchxxxxxx(config-pubkey-key)# key-string
AAAAB3NzaC1yc2EAAAADAQABAAQACvTnRwPWl
Al4kpqIw9GBRonZQZxjHKcqKL6rMlQ+
ZNXfZSkvHG+QusIZ/76ILmFT34v7u7ChFAE+
Vu4GRfpSwoQUvV35LqJk67IOU/zfw011g
```

```
kTwm175QR9gHujS6KwGN2QWXgh3ub8gDjTSq
muSn/Wd05iDX2IExQWu08licg1k02LYciz
+Z4TrEU/9FJxwPiVQOjC+KBXuR0juNg5nFYsY
0ZCk0N/W9a/tnkm1shRE7Di71+w3fNiOA
6w9o44t6+AINEICBCCA4YcF6zMzaTlwefWwX6f+
Rmt5nhhqAtN/4oJfcel66DqVX1gWmN
zNR4DYDvSzg01DnwCAC8Qh
Fingerprint: a4:16:46:23:5a:8d:1d:b5:37:59:eb:44:13:b9:33:e9
switchxxxxxx(config)# crypto key pubkey-chain ssh
switchxxxxxx(config-pubkey-chain)# user-key bob rsa
switchxxxxxx(config-pubkey-key)# key-string row AAAAB3Nza
switchxxxxxx(config-pubkey-key)# key-string row Clc2
```

13.8 show ip ssh

The **show ip ssh** Privileged EXEC mode command displays the SSH server configuration.

Syntax

show ip ssh

Command Mode

Privileged EXEC mode

Example

The following example displays the SSH server configuration.

```
switchxxxxxx# show ip ssh
SSH server enabled. Port: 22
RSA key was generated.
DSA (DSS) key was generated.
SSH Public Key Authentication is enabled.
Active incoming sessions:

IP Address   SSH Username   Version         Cipher          Auth Code
-----
172.16.0.1   John Brown     1.5             3DES            HMAC-SHA1
```

The following table describes the significant fields shown in the display.

Field	Description
IP Address	The client address
SSH Username	The user name
Version	The SSH version number
Cipher	The encryption type (3DES, Blowfish, RC4)
Auth Code	The authentication Code (HMAC-MD5, HMAC-SHA1)

13.9 show crypto key pubkey-chain ssh

The **show crypto key pubkey-chain ssh** Privileged EXEC mode command displays SSH public keys stored on the device.

Syntax

show crypto key pubkey-chain ssh [*username username*] [*fingerprint {bubble-babble | hex}*]

Parameters

- **username** *username*—Specifies the remote SSH client username. (Length: 1–48 characters)
- **fingerprint** *{bubble-babble | hex}*—Specifies the fingerprint display format. The possible values are:
 - **bubble-babble**—Specifies that the fingerprint is displayed in Bubble Babble format.
 - **hex**—Specifies that the fingerprint is displayed in hexadecimal format.

Default Configuration

The default fingerprint format is hexadecimal.

Command Mode

Privileged EXEC mode

Example

The following examples display SSH public keys stored on the device.

```
switchxxxxxx# show crypto key pubkey-chain ssh
Username
-----
bob
john
Fingerprint
-----
9A:CC:01:C5:78:39:27:86:79:CC:23:C5:98:59:F1:86
98:F7:6E:28:F2:79:87:C8:18:F8:88:CC:F8:89:87:C8
switchxxxxxx# show crypto key pubkey-chain ssh username bob
Username: bob
Key: 005C300D 06092A86 4886F70D 01010105 00034B00 30480241 00C5E23B
55D6AB22 04AEF1BA A54028A6 9ACC01C5 129D99E4
Fingerprint: 9A:CC:01:C5:78:39:27:86:79:CC:23:C5:98:59:F1:86
```

14 Line Commands

14.1 line

The **line** Global Configuration mode command identifies a specific line for configuration and enters the Line Configuration command mode.

Syntax

line { | *telnet* | *ssh* }

Parameters

- —Enters the terminal line mode.
- **telnet**—Configures the device as a virtual terminal for remote access (Telnet).
- **ssh**—Configures the device as a virtual terminal for secured remote access (SSH).

Command Mode

Global Configuration mode

Example

The following example configures the device as a virtual terminal for remote (Telnet) access.

```
switchxxxxxx(config)# line telnet
switchxxxxxx(config-line)#
```

14.2 speed

The **speed** Line Configuration mode command sets the line baud rate. Use the **no** form of this command to restore the default configuration.

Syntax

speed *bps*

no speed

Parameters

bps—Specifies the baud rate in bits per second (bps). Possible values are 2400, 4800, 9600, 19200, 38400, 57600, and 115200.

Default Configuration

The default speed is 115200 bps.

Command Mode

Line Configuration mode

User Guidelines

The configured speed is applied when Autobaud is disabled. This configuration applies to the current session only.

Example

The following example configures the line baud rate as 9600 bits per second.

```
switchxxxxxx(config-line)# speed 9600
```

14.3 autobaud

The **autobaud** Line Configuration mode command sets the line for automatic baud rate detection (autobaud). Use the **no** form of this command to disable automatic baud rate detection.

Syntax

autobaud

no autobaud

Default Configuration

Automatic baud rate detection is enabled.

Command Mode

Line Configuration mode

User Guidelines

To start communication using Autobaud, press the **Enter** key twice.

Example

The following example enables autobaud.

```
switchxxxxxx(config)# line
switchxxxxxx(config-line)# autobaud
```

14.4 exec-timeout

The **exec-timeout** Line Configuration mode command sets the session idle time interval, during which the system waits for user input before automatic logoff. Use the **no** form of this command to restore the default configuration.

Syntax

exec-timeout *minutes* [*seconds*]

no exec-timeout

Parameters

- **minutes**—Specifies the number of minutes. (Range: 0-65535)
- **seconds**—Specifies the number of seconds. (Range: 0-59)

Default Configuration

The default idle time interval is 10 minutes.

Command Mode

Line Configuration mode

Example

The following example sets the HTTP session idle time interval before automatic logoff to 20 minutes and 10 seconds.

```
switchxxxxxx(config)# line
switchxxxxxx(config-line)# exec-timeout 20 10
```

14.5 show line

The **show line** EXEC mode command displays line parameters.

Syntax

show line [*| telnet | ssh*]

Parameters

- —Displays the configuration.
- **telnet**—Displays the Telnet configuration.
- **ssh**—Displays the SSH configuration.

Default Configuration

If the line is not specified, all line configuration parameters are displayed.

Command Mode

EXEC mode

Example

The following example displays the line configuration.

```
switchxxxxxx# show line
  configuration:
Interactive timeout: Disabled
History: 10
Baudrate: 9600
Databits: 8
Parity: none
Stopbits: 1
Telnet configuration:
Telnet is enabled.
Interactive timeout: 10 minutes 10 seconds
History: 10
```



```
SSH configuration:  
SSH is enabled.  
Interactive timeout: 10 minutes 10 seconds  
History: 10
```

15 Authentication, Authorization and Accounting (AAA) Commands

15.1 aaa authentication login

Use the **aaa authentication login** Global Configuration mode command to set one or more authentication methods to be applied during login. A list of authentication methods may be assigned a list name, and this list name can be used in [login authentication](#) . Use the **no** form of this command to restore the default authentication method.

Syntax

```
aaa authentication login {default | list-name} method1 [method2...]
```

```
aaa authentication login list-name method1 method2...
```

```
no aaa authentication login {default | list-name}
```

Parameters

- **default**—Uses the authentication methods that follow this argument as the default method list when a user logs in (this list is unnamed).
- **list-name**—Specifies a name of a list of authentication methods activated when a user logs in. (Length: 1–12 characters)
- **method1 [method2...]**—Specifies a list of methods that the authentication algorithm tries (in the given sequence). Each additional authentication method is used only if the previous method returns an error, not if it fails. To ensure that the authentication succeeds even if all methods return an error, specify **none** as the final method in the command line. Select one or more methods from the following list::

Keyword	Description
enable	Uses the enable password for authentication.
line	Uses the line password for authentication.
local	Uses the locally-defined usernames for authentication.
none	Uses no authentication.
radius	Uses the list of all RADIUS servers for authentication.
tacacs	Uses the list of all TACACS+ servers for authentication.

Default Configuration

If no methods are specified, the default are the locally-defined users and passwords. This is the same as entering the command **aaa authentication login local**.



Note

If no authentication method is defined, console users can log in without any authentication verification.

Command Mode

Global Configuration mode

User Guidelines

Create a list of authentication methods by entering this command with the *list-name* parameter where *list-name* is any character string. The method arguments identifies the list of methods that the authentication algorithm tries, in the given sequence.

The default and list names created with this command are used with [login authentication](#) .

no aaa authentication login list-name deletes a list-name only if it has not been referenced by another command.

Example

The following example sets the authentication login methods for the console.

```
switchxxxxxx (config)# aaa authentication login authen-list radius local none
switchxxxxxx (config)#line console
switchxxxxxx (config-line)#login authentication authen-list
```

15.2 aaa authentication enable

The **aaa authentication enable** Global Configuration mode command sets one or more authentication methods for accessing higher privilege levels. A user, who logons with a lower privilege level, must pass these authentication methods to access a higher level.

To restore the default authentication method, use the **no** form of this command.

Syntax

aaa authentication enable {default | list-name} method [method2...]

no aaa authentication enable {default | list-name}

Parameters

- **default**—Uses the listed authentication methods that follow this argument as the default method list, when accessing higher privilege levels.
- **list-name** —Specifies a name for the list of authentication methods activated when a user accesses higher privilege levels. (Length: 1–12 characters)
- **method [method2...]**—Specifies a list of methods that the authentication algorithm tries, in the given sequence. The additional authentication methods are used only if the previous method returns an error, not if it fails. Specify **none** as the final method in the command line to ensure that the authentication succeeds, even if all methods return an error. Select one or more methods from the following list:

Keyword	Description
enable	Uses the enable password for authentication.
line	Uses the line password for authentication.
none	Uses no authentication.

Keyword	Description
radius	Uses the list of all RADIUS servers for authentication. Uses username "\$enabx\$" where x is the privilege level.
tacacs	Uses the list of all TACACS servers for authentication. Uses username "\$enabx\$" where x is the privilege level.

Default Configuration

The `enable password` command defines the default authentication login method. This is the same as entering the command **aaa authentication enable default enable**.

On a console, the enable password is used if a password exists. If no password is set, authentication still succeeds. This is the same as entering the command **aaa authentication enable default enable none**.

Command Mode

Global Configuration mode

User Guidelines

Create a list by entering the **aaa authentication enable list-name method1 [method2...]** command where *list-name* is any character string used to name this list. The method argument identifies the list of methods that the authentication algorithm tries, in the given sequence.

The default and list names created by this command are used with `enable authentication`.

All **aaa authentication enable default** requests sent by the device to a RADIUS or TACACS+ server include the username **\$enabx\$**, where **x** is the requested privilege level.

The additional methods of authentication are used only if the previous method returns an error, not if it fails. Specify **none** as the final method in the command line to ensure that the authentication succeeds even if all methods return an error.

no aaa authentication enable list-name deletes list-name if it has not been referenced.

Example

The following example sets the enable password for authentication for accessing higher privilege levels.

```
switchxxxxxx(config)# aaa authentication enable enable-list radius none
switchxxxxxx(config)# line console
switchxxxxxx(config-line)# enable authentication enable-list
```

15.3 login authentication

The **login authentication** Line Configuration mode command specifies the login authentication method list for a remote Telnet or console session. Use the **no** form of this command to restore the default authentication method.

Syntax

login authentication {*default* | *list-name*}

no login authentication

Parameters

- **default**—Uses the default list created with the **aaa authentication login** command.
- **list-name**—Uses the specified list created with [aaa authentication login](#).

Default Configuration

The default is the [aaa authentication login](#) command default.

Command Mode

Line Configuration mode

Examples

Example 1 - The following example specifies the login authentication method as the default method for a console session.

```
switchxxxxxx(config)# line console
switchxxxxxx(config-line)# login authentication default
```

Example 2 - The following example sets the authentication login methods for the console as a list of methods.

```
switchxxxxxx (config)# aaa authentication login authen-list radius local
none
switchxxxxxx (config)#line console
switchxxxxxx (config-line)#login authentication authen-list
```

15.4 enable authentication

The **enable authentication** Line Configuration mode command specifies the authentication method for accessing a higher privilege level from a remote Telnet or console. Use the **no** form of this command to restore the default authentication method.

Syntax

enable authentication *{default | list-name}*

no enable authentication

Parameters

- **default**—Uses the default list created with the [aaa authentication enable](#) command.
- **list-name**—Uses the specified list created with the [aaa authentication enable](#) command.

Default Configuration

The default is the [aaa authentication enable](#) command default.

Command Mode

Line Configuration mode

Example

Example 1 - The following example specifies the authentication method as the default method when accessing a higher privilege level from a console.

```
switchxxxxxx(config)# line console
switchxxxxxx(config-line)# enable authentication default
```

Example 2 - The following example sets a list of authentication methods for accessing higher privilege levels.

```
switchxxxxxx(config)# aaa authentication enable enable-list radius none
switchxxxxxx(config)# line console
switchxxxxxx(config-line)# enable authentication enable-list
```

15.5 ip http authentication

The **ip http authentication** Global Configuration mode command specifies authentication methods for HTTP server access. Use the **no** form of this command to restore the default authentication method.

Syntax

ip http authentication aaa login-authentication *method1* [*method2...*]

no ip http authentication aaa login-authentication

Parameters

method [*method2...*]—Specifies a list of methods that the authentication algorithm tries, in the given sequence. The additional authentication methods are used only if the previous method returns an error, not if it fails. Specify **none** as the final method in the command line to ensure that the authentication succeeds, even if all methods return an error. Select one or more methods from the following list:

Keyword	Description
local	Uses the local username database for authentication.
none	Uses no authentication.
radius	Uses the list of all RADIUS servers for authentication.
tacacs	Uses the list of all TACACS+ servers for authentication.

Default Configuration

The local user database is the default authentication login method. This is the same as entering the **ip http authentication local** command.

Command Mode

Global Configuration mode

User Guidelines

The command is relevant for HTTP and HTTPS server users.

Example

The following example specifies the HTTP access authentication methods.

```
switchxxxxxx(config)# ip http authentication aaa login-authentication
radius local none
```

15.6 show authentication methods

The **show authentication methods** Privileged EXEC mode command displays information about the authentication methods.

Syntax

show authentication methods

Parameters

N/A

Default Configuration

N/A

Command Mode

Privileged EXEC mode

Example

The following example displays the authentication configuration.

```
switchxxxxxx# show authentication methods
Login Authentication Method Lists
-----
Default: Radius, Local, Line
Console_Login: Line, None
Enable Authentication Method Lists
-----
Default: Radius, Enable
Console_Enable: Enable, None

Line                Login Method List    Enable Method List
-----
Console             Console_Login        Console_Enable
Telnet              Default              Default
SSH                 Default              Default

HTTP: Radius, local
HTTPS: Radius, local
Dot1x: Radius
```

15.7 password

Use the **password** Line Configuration mode command to specify a password on a line (also known as an access method, such as a console or Telnet). Use the **no** form of this command to return to the default password.

Syntax

password *password* [*encrypted*]

no password

Parameters

- **password**—Specifies the password for this line. (Length: 0–159 characters)
- **encrypted**—Specifies that the password is encrypted and copied from another device configuration.

Default Configuration

No password is defined.

Command Mode

Line Configuration mode

Example

The following example specifies the password 'secret' on a console.

```
switchxxxxxx(config)# line console
switchxxxxxx(config-line)# password secret
```

15.8 enable password

Use the **enable password** Global Configuration mode command to set a local password to control access to normal and privilege levels. Use the **no** form of this command to return to the default password.

When the administrator configures a new **enable** password, this password is encrypted automatically and saved to the configuration file. No matter how the password was entered, it appears in the configuration file with the keyword **encrypted** and the encrypted value.

If the administrator wants to manually copy a password that was configured on one switch (for instance, switch B) to another switch (for instance, switch A), the administrator must add **encrypted** in front of this encrypted password when entering the **enable** command in switch A. In this way, the two switches will have the same password.

Syntax

enable password [*level privilege-level*] {*unencrypted-password* | **encrypted** *encrypted-password*}

no enable password [*level level*]

Parameters

- **level privilege-level**—Level for which the password applies. If not specified the level is 15. (Range: 1–15)

- **password** *unencrypted-password*—Password for this level. (Range: 0–159 chars)
- **password encrypted** *encrypted-password*—Specifies that the password is encrypted. Use this keyword to enter a password that is already encrypted (for instance that you copied from another the configuration file of another device). (Range: 1–40)

Default Configuration

Default for **level** is 15.

Passwords are encrypted by default.

Command Mode

Global Configuration mode

User Guidelines

Passwords are encrypted by default. You only are required to use the **encrypted** keyword when you are actually entering an encrypted keyword.

Example

The first command sets an unencrypted password for level 7 (it will be encrypted in the configuration file).

The second command sets a password that has already been encrypted. It will copied to the configuration file just as it is entered. To use it, the user must know its unencrypted form.

```
switchxxxxxx(config)# enable password level 7 let-me-in
switchxxxxxx(config)# enable password level 15 encrypted
4b529f21c93d4706090285b0c10172eb073ffebc4
```

15.9 username

Use the **username** Global Configuration mode command to establish a username-based authentication system. Use the **no** form to remove a user name.

Syntax

username *name* {**nopassword** | **password** *password* | **privilege** *privilege-level* | *unencrypted-password* | **encrypted** *encrypted-password*}

username *name*

no username *name*

Parameters

- **name**—The name of the user. (Range: 1–20 characters)
- **nopassword**—No password is required for this user to log in.
- **unencrypted-password**—The authentication password for the user. (Range: 1–159)
- **encrypted** *encrypted-password*—Specifies that the password is encrypted. Use this keyword to enter a password that is already encrypted (for instance that you copied from another the configuration file of another device). (Range: 1–40)
- **privilege** *privilege-level*—Privilege level for which the password applies. If not specified the level is 15. (Range: 1–15).

Default Configuration

No user is defined.

Command Mode

Global Configuration mode

Examples

Example 1 - Sets an unencrypted password for user tom (level 15). It will be encrypted in the configuration file.

```
switchxxxxxx(config)# username tom privilege 15 password 1234
```

Example 2 - Sets a password for user jerry (level 15) that has already been encrypted. It will be copied to the configuration file just as it is entered. To use it, the user must know its unencrypted form.

```
switchxxxxxx(config)# username jerry privilege 15 encrypted  
4b529f21c93d4706090285b0c10172eb073ffe4
```

15.10 show user accounts

The **show user accounts** Privileged EXEC mode command displays information about the users local database.

Syntax

show user accounts

Parameters

N/A

Default Configuration

N/A

Command Mode

Privileged EXEC mode

Example

The following example displays information about the users local database.

```
switchxxxxxx# show user accounts
```

```
Username      Privilege  
-----  
Bob           15  
Robert       15  
Smith        15
```

The following table describes the significant fields shown in the display:

Field	Description
Username	The user name.
Privilege	The user's privilege level.

15.11 aaa accounting login

Use the **aaa accounting login** command in Global Configuration mode to enable accounting of device management sessions. Use the **no** form of this command to disable accounting.

Syntax

aaa accounting login *start-stop group radius*

no aaa accounting login *start-stop group radius*

Parameters

N/A

Default Configuration

Disabled

Command Mode

Global Configuration mode

User Guidelines

This command enables the recording of device management sessions (Telnet, serial and WEB but not SNMP).

It records only users that were identified with a username (e.g. a user that was logged in with a line password is not recorded).

If accounting is activated, the device sends a "start"/"stop" messages to a Radius server when a user logs in / logs out respectively.

The device uses the configured priorities of the available Radius servers in order to select the Radius server.

The following table describes the supported Radius accounting attributes values, and when they are sent by the switch.

Name	Start	Stop	Description
User-Name (1)	Yes	Yes	User's identity.
NAS-IP-Address (4)	Yes	Yes	The switch IP address that is used for the session with the Radius server.
Class (25)	Yes	Yes	Arbitrary value is included in all accounting packets for a specific session.

Called-Station-ID (30)	Yes	Yes	The switch IP address that is used for the management session.
Calling-Station-ID (31)	Yes	Yes	The user IP address.
Acct-Session-ID (44)	Yes	Yes	A unique accounting identifier.
Acct-Authentic (45)	Yes	Yes	Indicates how the supplicant was authenticated.
Acct-Session-Time (46)	No	Yes	Indicates how long the user was logged in.
Acct-Terminate-Cause (49)	No	Yes	Reports why the session was terminated.

Example

```
switchxxxxxx(config)# aaa accounting login start-stop group radius
```

15.12 aaa accounting dot1x

To enable accounting of 802.1x sessions, use the **aaa accounting dot1x** Global Configuration mode command. Use the **no** form of this command to disable accounting.

Syntax

aaa accounting dot1x start-stop group radius

no aaa accounting dot1x start-stop group radius

Parameters

N/A

Default Configuration

Disabled

Command Mode

Global Configuration mode

User Guidelines

This command enables the recording of 802.1x sessions.

If accounting is activated, the device sends a “start”/“stop” messages to a Radius server when a user logs in / logs out to the network, respectively.

The device uses the configured priorities of the available Radius servers in order to select the Radius server.

If a new supplicant replaces an old supplicant (even if the port state remains authorized), the software sends a “stop” message for the old supplicant and a “start” message for the new supplicant.

In multiple sessions mode (dot1x multiple-hosts authentication), the software sends “start”/“stop” messages for each authenticated supplicant.

In multiple hosts mode (dot1x multiple-hosts), the software sends “start”/“stop” messages only for the supplicant that has been authenticated.

The software does not send “start”/“stop” messages if the port is force-authorized.

The software does not send “start”/“stop” messages for hosts that are sending traffic on the guest VLAN or on the unauthenticated VLANs.

The following table describes the supported Radius accounting Attributes Values and when they are sent by the switch.

Name	Start	Stop	Description
User-Name (1)	Yes	Yes	Supplicant’s identity.
NAS-IP-Address (4)	Yes	Yes	The switch IP address that is used for the session with the Radius server.
NAS-Port (5)	Yes	Yes	The switch port from where the supplicant has logged in.
Class (25)	Yes	Yes	Arbitrary value is included in all accounting packets for a specific session.
Called-Station-ID (30)	Yes	Yes	The switch MAC address.
Calling-Station-ID (31)	Yes	Yes	The supplicant MAC address.
Acct-Session-ID (44)	Yes	Yes	A unique accounting identifier.
Acct-Authentic (45)	Yes	Yes	Indicates how the supplicant was authenticated.
Acct-Session-Time (46)	No	Yes	Indicated how long the supplicant was logged in.
Acct-Terminate-Cause (49)	No	Yes	Reports why the session was terminated.
Nas-Port-Type (61)	Yes	Yes	Indicates the supplicant physical port type.

Example

```
switchxxxxxx(config)# aaa accounting dot1x start-stop group radius
```

15.13 show accounting

The **show accounting** EXEC mode command displays information about the accounting status.

Syntax

show accounting

Parameters

N/A

Default Configuration

N/A

Command Mode

EXEC mode

Example

The following example displays information about the accounting status.

```
switchxxxxxx# show accounting
Login: Radius
802.1x: Disabled
```

15.14 passwords complexity enable

Use the **passwords complexity enable** Global Configuration mode command to enforce minimum password complexity. The **no** form of this command disables enforcing password complexity.

Syntax

passwords complexity enable

no passwords complexity enable

Parameters

Parameters

N/A

Default Configuration

Disabled

Command Mode

Global Configuration mode

User Guidelines

If password complexity is enabled **by default**, the user is forced to enter a password that:

- Has a minimum length of 8 characters.
- Contains characters from at least 3 character classes (uppercase letters, lowercase letters, numbers, and special characters available on a standard keyboard).
- Are different from the current password.
- Contains no character that is repeated more than 3 times consecutively.
- Does not repeat or reverse the user name or any variant reached by changing the case of the characters.
- Does not repeat or reverse the manufacturer's name or any variant reached by changing the case of the characters.

You can control the above attributes of password complexity with specific commands described in this section.

If you have previously configured other complexity settings, then those settings are used. This command does not wipe out the other settings. It works only as a toggle.

Example

The following example configures requiring complex passwords that fulfill the minimum requirements specified in the User Guidelines above.

```
switchxxxxxx(config)# passwords complexity enable
switchxxxxxx#show passwords configuration
Passwords aging is enabled with aging time 180 days.
Passwords complexity is enabled with the following attributes:
Minimal length: 3 characters
Minimal classes: 3
New password must be different than the current: Enabled
Maximum consecutive same characters: 3
New password must be different than the user name: Enabled
New password must be different than the manufacturer name: Enabled
switchcc293e#
```

15.15 passwords complexity <attributes>

Use the **passwords complexity <attributes>** Global Configuration mode commands to control the minimum requirements from a password when password complexity is enabled. Use the **no** form of these commands to return to default.

Syntax

```
passwords complexity min-length number
no passwords complexity min-length
passwords complexity min-classes number
no passwords complexity min-classes
passwords complexity not-current
no passwords complexity not-current
passwords complexity no-repeat number
no password complexity no-repeat
passwords complexity not-username
no passwords complexity not-username
```

Parameters

- **min-length** *number*—Sets the minimal length of the password. (Range: 0–64)
- **min-classes** *number*—Sets the minimal character classes (uppercase letters, lowercase letters, numbers, and special characters available on a standard keyboard). (Range: 0–4)
- **not-current**—Specifies that the new password cannot be the same as the current password.

- **no-repeat *number***—Specifies the maximum number of characters in the new password that can be repeated consecutively. Zero specifies that there is no limit on repeated characters. (Range: 0–16)
- **not-username**—Specifies that the password cannot repeat or reverse the user name or any variant reached by changing the case of the characters.
- **not-manufacturer-name**—Specifies that the password cannot repeat or reverse the manufacturer's name or any variant reached by changing the case of the characters.

Default Configuration

The minimal length is 8.

The number of classes is 3.

The default for no-repeat is 3.

All the other controls are enabled by default.

Command Mode

Global Configuration mode

Example

The following example configures the minimal required password length to 8 characters.

```
switchxxxxxx (config)# passwords complexity min-length 8
```

15.16 passwords min-length

The **passwords min-length** Global Configuration mode command configures the minimal password length in the local database. Use the **no** form of this command to remove the restriction.

Syntax

passwords min-length *length*

no passwords min-length

Parameters

length—Specifies the minimal length required for passwords. (Range: 8-64)

Default Configuration

There is no minimal length requirement until this command is executed.

Command Mode

Global Configuration mode

User Guidelines

The setting is relevant to local user passwords, line passwords, and enable passwords.

The software checks the minimum length requirement when defining a password in an unencrypted format, or when a user tries to log in.

Note that if a password is inserted in encrypted format, the minimum length requirement is checked during user login only.

Passwords that were defined before defining the minimum length requirement are only checked during user login.

Example

The following example configures the minimal required password length to 8 characters.

```
switchxxxxxx (config)# passwords min-length 8
```

15.17 passwords aging

Use the **passwords aging** Global Configuration mode command to enforce password aging. Use the **no** form of this command to return to default.

Syntax

passwords aging *days*

no passwords aging

Parameters

days—Specifies the number of days before a password change is forced. You can use 0 to disable aging. (Range: 0–365)

Default Configuration

Disabled

Command Mode

Global Configuration mode

User Guidelines

Aging is relevant only to users of the local database with privilege level 15 and to “enable” a password of privilege level 15.

Example

The following example configures the aging time to be 24 days.

```
switchxxxxxx (config)# passwords aging 24
```

15.18 passwords history

The **passwords history** Global Configuration mode command configures the number of password changes required before a password can be reused. Use the **no** form of this command to remove the requirement.

Syntax

passwords history *number*

no passwords history

Parameters

number—Specifies the number of password changes required before a password can be reused. (Range: 1–8)

Default Configuration

Password history is disabled.

Command Mode

Global Configuration mode

User Guidelines

The setting is relevant to local users' passwords, line passwords and enable passwords.

Password history is not checked during a configuration download.

The password history is kept even if the password history check is disabled.

The password history for a user is kept as long as the user is defined.

Example

The following example sets the number of password changes required before a password can be reused to 10.

```
switchxxxxxx(config)# passwords history 10
```

15.19 show passwords configuration

The **show passwords configuration** Privileged EXEC mode command displays information about the password management configuration.

Syntax

show passwords configuration

Parameters

N/A

Default Configuration

N/A

Command Mode

Privileged EXEC mode

Example

```
switchxxxxxx#show passwords configuration
Passwords aging is enabled with aging time 180 days.
Passwords complexity is enabled with the following attributes:
Minimal length: 3 characters
Minimal classes: 3
```



New password must be different than the current: Enabled
Maximum consecutive same characters: 3
New password must be different than the user name: Enabled
New password must be different than the manufacturer name: Enabled
switchcc293e#

The following table describes the significant fields shown in the display:

Field	Description
Minimal length	The minimal length required for passwords in the local database.
Minimal character classes	The minimal number of different types of characters (special characters, integers and so on) required to be part of the password.
Maximum number of repeated characters	The maximum number of times a single character can be repeated in the password.
Level	The applied password privilege level.
Aging	The password aging time in days.

15.20 show users login-history

The **show users login-history** Privileged EXEC mode command displays information about the user's login history.

Syntax

show users login-history [*username name*]

Parameters

name—Name of the user. (Range: 1–20 characters)

Default Configuration

N/A

Command Mode

Privileged EXEC mode

Authentication, Authorization and Accounting (AAA) Commands

Example

The following example displays information about the users' login history.

```
switchxxxxx# show users login-history
File save: Enabled.

Login Time          Username    Protocol    Location
-----
Jan 18 2004 23:58:17 Robert     HTTP        172.16.1.8
Jan 19 2004 07:59:23 Robert     HTTP        172.16.0.8
Jan 19 2004 08:23:48 Bob        Serial
Jan 19 2004 08:29:29 Robert     HTTP        172.16.0.8
Jan 19 2004 08:42:31 John       SSH         172.16.0.1
Jan 19 2004 08:49:52 Betty     Telnet      172.16.1.7
```

16 Remote Authentication Dial-In User Service (RADIUS) Commands

16.1 radius-server host

Use the **radius-server host** Global Configuration mode command to configure a RADIUS server host. Use the no form of the command to delete the specified RADIUS server host.

Syntax

radius-server host {*ip-address* | *hostname*} [**auth-port** *auth-port-number*] [**acct-port** *acct-port-number*] [**timeout** *timeout*] [**retransmit** *retries*] [**deadtime** *deadtime*] [**key** *key-string*] [**source** {*source-ip*}] [**priority** *priority*] [**usage** {*login* | *802.1x* | *all*}]

no radius-server host {*ip-address* | *hostname*}

Parameters

- **ip-address**—Specifies the RADIUS server host IP address. The IP address can be an IPv4, IPv6 or IPv6z address. See [IPv6z Address Conventions](#)
- **hostname**—Specifies the RADIUS server host name. Translation to IPv4 addresses only is supported. (Length: 1–158 characters. Maximum label length of each part of the hostname: 63 characters)
- **auth-port** *auth-port-number*—Specifies the port number for authentication requests. If the port number is set to 0, the host is not used for authentication. (Range: 0–65535)
- **acct-port-number**—Port number for accounting requests. The host is not used for accountings if set to 0. If unspecified, the port number defaults to 1813.
- **timeout** *timeout*—Specifies the timeout value in seconds. (Range: 1–30)
- **retransmit** *retries*—Specifies the retransmit value. (Range: 1–10)
- **deadtime** *deadtime*—Specifies the length of time in minutes during which a RADIUS server is skipped over by transaction requests. (Range: 0–2000)
- **key** *key-string*—Specifies the authentication and encryption key for all RADIUS communications between the device and the RADIUS server. This key must match the encryption used on the RADIUS daemon. To specify an empty string, enter "". (Length: 0–128 characters)
- **source** *source-ip*—Specifies the source IPv4 or IPv6 address to use for communication. 0.0.0.0 is interpreted as a request to use the IP address of the outgoing IP interface.
- **priority** *priority*—Specifies the order in which servers are used, where 0 has the highest priority. (Range: 0–65535)
- **usage** {*login* | *802.1x* | *all*}—Specifies the RADIUS server usage type. The possible values are:
 - **login**—Specifies that the RADIUS server is used for user login parameters authentication.
 - **802.1x**—Specifies that the RADIUS server is used for 802.1x port authentication.
 - **all**—Specifies that the RADIUS server is used for user login authentication and 802.1x port authentication.

Default Configuration

The default authentication port number is 1812.

If **timeout** is not specified, the global value (set in [radius-server timeout](#)) is used.

If **retransmit** is not specified, the global value (set in [radius-server retransmit](#)) is used.

If **key-string** is not specified, the global value (set in [radius-server key](#)) is used.

If the **source** value is not specified, the global value (set in [radius-server source-ip](#) or [radius-server source-ipv6](#)) is used.

If a parameter was not set in one of the above commands, the default for that command is used. For example, if a timeout value was not set in the current command or in [radius-server timeout](#), the default timeout for [radius-server timeout](#) is used.

The default usage type is **all**.

Command Mode

Global Configuration mode

User Guidelines

To specify multiple hosts, this command is used for each host.

The **source** parameter address type (IPv4 or IPv6) must be the same as that of the **host** IP address type.

Example

The following example specifies a RADIUS server host with IP address 192.168.10.1, authentication request port number 20, and a 20-second timeout period.

```
switchxxxxxx(config)# radius-server host 192.168.10.1 auth-port 20
timeout 20
```

16.2 radius-server key

Use the **radius-server key** Global Configuration mode command to set the authentication and encryption key for RADIUS communications between the device and the RADIUS daemon. Use the **no** form of this command to restore the default configuration.

Syntax

radius-server key [*key-string*]

no radius-server key

Parameters

key-string—Specifies the authentication and encryption key for all RADIUS communications between the device and the RADIUS server. This key must match the encryption used on the RADIUS daemon. (Range: 0–128 characters)

Default Configuration

The key-string is an empty string.

Command Mode

Global Configuration mode

Example

The following example defines the authentication and encryption key for all RADIUS communications between the device and the RADIUS daemon.

```
switchxxxxxx(config)# radius-server key enterprise-server
```

16.3 radius-server retransmit

Use the **radius-server retransmit** Global Configuration mode command to specify the number of times the software searches the list of RADIUS server hosts. Use the no form of this command to restore the default configuration.

Syntax

radius-server retransmit *retries*

no radius-server retransmit

Parameters

retransmit *retries*—Specifies the retransmit value. (Range: 1–10)

Default Configuration

The software searches the list of RADIUS server hosts 3 times.

Command Mode

Global Configuration mode

Example

The following example configures the number of times the software searches all RADIUS server hosts as 5.

```
switchxxxxxx(config)# radius-server retransmit 5
```

16.4 radius-server source-ip

Use the **radius-server source-ip** Global Configuration mode command to specify the source IP address used for communication with RADIUS servers. Use the no form of this command to restore the default configuration.

Syntax

radius-server source-ip *{source-ip-address}*

no radius-server source-ip *{source-ip-address}*

Parameters

source-ip-address—Specifies the source IP address.

Default Configuration

The source IP address is the IP address of the outgoing IP interface.

Command Mode

Global Configuration mode

User Guidelines

If there is no available IP interface of the configured IP source address, an error message is issued when attempting to communicate with the IP address.

Example

The following example configures the source IP address used for communication with all RADIUS servers to 10.1.1.1.

```
switchxxxxxx(config)# radius-server source-ip 10.1.1.1
```

16.5 radius-server source-ipv6

Use the **radius-server source-ipv6** Global Configuration mode command to specify the source IPv6 address used for communication with RADIUS servers. Use the **no** form of this command to restore the default configuration.

Syntax

radius-server source-ipv6 {source}

no radius-server source-ipv6 {source}

Parameters

source—Specifies the source IPv6 address.

Default Configuration

The source IP address is the IP address of the outgoing IP interface.

Command Mode

Global Configuration mode

User Guidelines

If there is no available IP interface of the configured IP source address, an error message is issued when attempting to communicate with the IP address.

Example

The following example configures the source IP address used for communication with all RADIUS servers to 3ffe:1900:4545:3:200:f8ff:fe21:67cf.

```
switchxxxxxx(config)# radius-server source-ipv6  
3ffe:1900:4545:3:200:f8ff:fe21:67cf
```

16.6 radius-server timeout

Use the **radius-server timeout** Global Configuration mode command to set how long the device waits for a server host to reply. Use the **no** form of this command to restore the default configuration.

Syntax**radius-server timeout** *timeout-seconds***no radius-server timeout****Parameters****timeout** *timeout-seconds*—Specifies the timeout value in seconds. (Range: 1–30)**Default Configuration**

The default timeout value is 3 seconds.

Command Mode

Global Configuration mode

Example

The following example sets the timeout interval on all RADIUS servers to 5 seconds.

```
switchxxxxxx(config)# radius-server timeout 5
```

16.7 radius-server deadtime

Use the **radius-server deadtime** Global Configuration mode command to configure how long unavailable RADIUS servers are skipped over by transaction requests. This improves RADIUS response time when servers are unavailable. Use the **no** form of this command to restore the default configuration.

Syntax**radius-server deadtime** *deadtime***no radius-server deadtime****Parameters****deadtime**—Specifies the time interval in minutes during which a RADIUS server is skipped over by transaction requests. (Range: 0–2000)**Default Configuration**

The default deadtime interval is 0.

Command Mode

Global Configuration mode

Example

The following example sets all RADIUS server deadtimes to 10 minutes.

```
switchxxxxxx(config)# radius-server deadtime 10
```

16.8 show radius-servers

Use the **show radius-servers** Privileged EXEC mode command to display the RADIUS server settings.

Syntax

show radius-servers

Command Mode

Privileged EXEC mode

Example

The following example displays RADIUS server settings.

```
switchxxxxx# show radius-servers
```

IP address	Port Auth	Port Acct	Time Out	Retransmission	Dead time	Source IP	Priority	Usage
172.16.1.1	1812	1813	Global	Global	Global	Global	1	All
172.16.1.2	1812	1813	11	8	Global	Global	2	All

Global values

TimeOut: 3
Retransmit: 3
Deadtime: 0
Source IP: 172.16.8.1

17

Terminal Access Controller Access-Control System Plus (TACACS+) Commands

17.1 tacacs-server host

Use the **tacacs-server host** Global Configuration mode command to specify a TACACS+ host. Use the **no** form of this command to delete the specified TACACS+ host.

Syntax

tacacs-server host {*ip-address* | *hostname*} [*single-connection*] [**port** *port-number*] [**timeout** *timeout*] [**key** *key-string*] [**source** {*source-ip*}] [**priority** *priority*]

no tacacs-server host {*ip-address* | *hostname*}

Parameters

- **host** *ip-address*—Specifies the TACACS+ server host IP address.
- **host** *hostname*—Specifies the TACACS+ server host name. (Length: 1?158 characters. Maximum label length of each part of the host name: 63 characters)
- **single-connection**—Specifies that a single open connection is maintained between the device and the daemon, instead of the device opening and closing a TCP connection to the daemon each time it communicates.
- **port** *port-number*—Specifies the TACACS server TCP port number. If the port number is 0, the host is not used for authentication. (Range: 0-65535)
- **timeout** *timeout*—Specifies the timeout value in seconds. (Range: 1-30)
- **key** *key-string*—Specifies the authentication and encryption key for all TACACS+ communications between the device and the TACACS+ server. This key must match the encryption used on the TACACS+ daemon. To specify an empty string, enter "". (Length: 0-128 characters). This key is set in [tacacs-server key](#).
- **source** *source-ip*—Specifies the source IP address to use for the communication. 0.0.0.0 indicates a request to use the outgoing IP interface IP address.
- **priority** *priority*—Specifies the order in which the TACACS+ servers are used, where 0 is the highest priority. (Range: 0-65535)

Default Configuration

No TACACS+ host is specified.

The default **port-number** is 49.

The default authentication port number is 1812.

If **timeout** is not specified, the global value (set in [tacacs-server timeout](#)) is used.

If **key-string** is not specified, the global value (set in [tacacs-server key](#)) is used.

If the **source** value is not specified, the global value (set in [tacacs-server source-ip](#)) is used.

If a parameter was not set in one of the above commands, the default for that command is used. For example, if a timeout value was not set in the current command or in [tacacs-server timeout](#), the default timeout for [tacacs-server timeout](#) is used.

Command Mode

Global Configuration mode

User Guidelines

Multiple **tacacs-server host** commands can be used to specify multiple hosts.

Example

The following example specifies a TACACS+ host.

```
switchxxxxxx(config)# tacacs-server host 172.16.1.1
```

17.2 tacacs-server key

Use the **tacacs-server key** Global Configuration mode command to set the authentication encryption key used for all TACACS+ communications between the device and the TACACS+ daemon. Use the **no** form of this command to disable the key.

Syntax

tacacs-server key *key-string*

no tacacs-server key

Parameters

key-string—Specifies the authentication and encryption key for all TACACS+ communications between the device and the TACACS+ server. This key must match the encryption used on the TACACS+ daemon. (Length: 0–128 characters)

Default Configuration

The default key is an empty string.

Command Mode

Global Configuration mode

Example

The following example sets Enterprise as the authentication encryption key for all TACACS+ servers.

```
switchxxxxxx(config)# tacacs-server key enterprise
```

17.3 tacacs-server timeout

Use the **tacacs-server timeout** Global Configuration mode command to set the interval during which the device waits for a TACACS+ server to reply. Use the **no** form of this command to restore the default configuration.

Syntax

tacacs-server timeout *timeout*

no tacacs-server timeout

Parameters

timeout—Specifies the timeout value in seconds. (Range: 1-30)

Default Configuration

The default timeout value is 5 seconds.

Command Mode

Global Configuration mode

Example

The following example sets the timeout value to 30 for all TACACS+ servers.

```
switchxxxxxx(config)# tacacs-server timeout 30
```

17.4 tacacs-server source-ip

Use the **tacacs-server source-ip** Global Configuration mode command to configure the source IP address to be used for communication with TACACS+ servers. Use the no form of this command to restore the default configuration.

Syntax

tacacs-server source-ip {source}

no tacacs-server source-ip {source}

Parameters

source—Specifies the source IP address. (Range: Valid IP address)

Default Configuration

The default source IP address is the outgoing IP interface address.

Command Mode

Global Configuration mode

User Guidelines

If the configured IP source address has no available IP interface, an error message is issued when attempting to communicate with the IP address.

Example

The following example specifies the source IP address for all TACACS+ servers.

```
switchxxxxxx(config)# tacacs-server source-ip 172.16.8.1
```

17.5 show tacacs

Use the **show tacacs** Privileged EXEC mode command to display configuration and statistical information for a TACACS+ server.

Terminal Access Controller Access-Control System Plus (TACACS+) Commands

Syntax

show tacacs [*ip-address*]

Parameters

ip-address—Specifies the TACACS+ server name or IP address.

Default Configuration

If **ip-address** is not specified, information for all TACACS+ servers is displayed.

Command Mode

Privileged EXEC mode

Example

The following example displays configuration and statistical information for all TACACS+ servers.

```
switchxxxxxx# show tacacs
```

IP address	Status	Port	Single Connection	Time Out	Source IP	Priority
-----	-----	----	-----	-----	-----	-----
172.16.1.1	Connected	49	No	Global	Global	1

Global values

Time Out: 3
Source IP: 172.16.8.1

18 Syslog Commands

18.1 logging on

Use the **logging on** Global Configuration mode command to control error message logging. This command sends debug or error messages asynchronously to designated locations. Use the **no** form of this command to disable the logging.

Syntax

logging on

no logging on

Parameters

N/A

Default Configuration

Message logging is enabled.

Command Mode

Global Configuration mode

User Guidelines

The logging process controls the logging messages distribution at various destinations, such as the logging buffer, logging file or SYSLOG server. Logging on and off at these destinations can be individually configured using the [logging buffered](#), [logging file](#), and [logging on](#) Global Configuration mode commands. However, if the [logging on](#) command is disabled, no messages are sent to these destinations. Only the console receives messages.

Example

The following example enables logging error messages.

```
switchxxxxxx(config)# logging on
```

18.2 logging host

Use the **logging host** Global Configuration command to log messages to the specified SYSLOG server. Use the **no** form of this command to delete the SYSLOG server with the specified address from the list of SYSLOG servers.

Syntax

logging host *{ip-address | ipv6-address | hostname}* [**port** *port*] [**severity** *level*] [**facility** *facility*] [**description** *text*]

no logging host *{ipv4-address | ipv6-address | hostname}*

Parameters

- **ip-address**—IP address of the host to be used as a SYSLOG server. The IP address can be an IPv4, IPv6 or Ipv6z address. See [IPv6z Address Conventions](#).
- **hostname**—Hostname of the host to be used as a SYSLOG server. Only translation to IPv4 addresses is supported. (Range: 1–158 characters. Maximum label size for each part of the host name: 63)
- **port port**—Port number for SYSLOG messages. If unspecified, the port number defaults to 514. (Range: 1–65535)
- **severity level**—Limits the logging of messages to the SYSLOG servers to a specified level: emergencies, alerts, critical, errors, warnings, notifications, informational, debugging.
- **facility facility**—The facility that is indicated in the message. It can be one of the following values: local0, local1, local2, local3, local4, local5, local 6, local7. If unspecified, the port number defaults to local7.
- **description text**—Description of the SYSLOG server. (Range: Up to 64 characters)

Default Configuration

No messages are logged to a SYSLOG server.

if unspecified, the **severity level** defaults to Informational.

Command Mode

Global Configuration mode

User Guidelines

You can use multiple SYSLOG servers.

Examples

```
switchxxxxxx(config)# logging host 1.1.1.121
```

```
switchxxxxxx(config)# logging host 3000::100/SYSLOG1
```

18.3 logging console

Use the **logging console** Global Configuration mode command to limit messages logged to the console to messages to a specific severity level. Use the **no** form of this command to restore the default.

Syntax

logging console *level*

no logging console

Parameters

level—Specifies the severity level of logged messages displayed on the console. The possible values are: emergencies, alerts, critical, errors, warnings, notifications, informational and debugging.

Default Configuration

Informational.

Command Mode

Global Configuration mode

Example

The following example limits logging messages displayed on the console to messages with severity level **errors**.

```
switchxxxxxx(config)# logging console errors
```

18.4 logging buffered

Use the **logging buffered** Global Configuration mode command to limit the SYSLOG message display to messages with a specific severity level, and to define the buffer size (number of messages that can be stored). Use the **no** form of this command to cancel displaying the SYSLOG messages, and to return the buffer size to default.

Syntax

logging buffered [*buffer-size*] [*severity-level* | *severity-level-name*]

no logging buffered

Parameters

- **buffer-size**—Specifies the maximum number of messages stored in the history table. (Range: 20–400)
- **severity-level**—Specifies the severity level of messages logged in the buffer. The possible values are: 1-7.
- **severity-level-name**—Specifies the severity level of messages logged in the buffer. The possible values are: emergencies, alerts, critical, errors, warnings, notifications, informational and debugging.

Default Configuration

The default severity level is informational.

The default buffer size is 200.

Command Mode

Global Configuration mode

User Guidelines

All the SYSLOG messages are logged to the internal buffer. This command limits the messages displayed to the user.

Example

The following example shows two ways of limiting the SYSLOG message display from an internal buffer to messages with severity level **debugging**. In the second example, the buffer size is set to 100.

```
switchxxxxxx(config)# logging buffered debugging
switchxxxxxx(config)# logging buffered 100 7
```

18.5 clear logging

Use the **clear logging** Privileged EXEC mode command to clear messages from the internal logging buffer.

Syntax

clear logging

Parameters

N/A

Default Configuration

N/A

Command Mode

Privileged EXEC mode

Example

The following example clears messages from the internal logging buffer.

```
switchxxxxx# clear logging  
Clear logging buffer [confirm]
```

18.6 logging file

Use the **logging file** Global Configuration mode command to limit SYSLOG messages sent to the logging file to messages with a specific severity level. Use the **no** form of this command to cancel sending messages to the file.

Syntax

logging file *level*

no logging file

Parameters

level—Specifies the severity level of SYSLOG messages sent to the logging file. The possible values are: emergencies, alerts, critical, errors, warnings, notifications, informational and debugging.

Default Configuration

The default severity level is **errors**.

Command Mode

Global Configuration mode

Example

The following example limits SYSLOG messages sent to the logging file to messages with severity level **alerts**.

```
switchxxxxxx(config)# logging file alerts
```

18.7 clear logging file

Use the **clear logging file** Privileged EXEC mode command to clear messages from the logging file.

Syntax

clear logging file

Parameters

N/A

Default Configuration

N/A

Command Mode

Privileged EXEC mode

Example

The following example clears messages from the logging file.

```
switchxxxxxx# clear logging file  
Clear Logging File [y/n]
```

18.8 aaa logging

Use the **aaa logging** Global Configuration mode command to enable logging AAA logins. Use the **no** form of this command to disable logging AAA logins.

Syntax

aaa logging {login}

no aaa logging {login}

Parameters

login—Enables logging messages related to successful AAA login events, unsuccessful AAA login events and other AAA login-related events.

Default Configuration

Enabled.

Command Mode

Global Configuration mode

User Guidelines

This command enables logging messages related to successful login events, unsuccessful login events and other login-related events. Other types of AAA events are not subject to this command.

Example

The following example enables logging AAA login events.

```
switchxxxxxx(config)# aaa logging login
```

18.9 file-system logging

Use the **file-system logging** Global Configuration mode command to enable logging file system events. Use the **no** form of this command to disable logging file system events.

Syntax

file-system logging {*copy* | *delete-rename*}

no file-system logging {*copy* | *delete-rename*}

Parameters

- **copy**—Specifies logging messages related to file copy operations.
- **delete-rename**—Specifies logging messages related to file deletion and renaming operations.

Default Configuration

Enabled.

Command Mode

Global Configuration mode

Example

The following example enables logging messages related to file copy operations.

```
switchxxxxxx(config)# file-system logging copy
```

18.10 management logging

Use the **management logging** Global Configuration mode command to enable logging Management Access List (ACL) deny events (rejected logins). Use the **no** form of this command to disable logging management access list events.

Syntax

management logging {*deny*}

no management logging {*deny*}

Parameters

deny—Enables logging messages related to management ACL deny actions (rejected logins).

Default Configuration

Logging management ACL deny events is enabled.

Command Mode

Global Configuration mode

User Guidelines

Other management ACL events are not subject to this command.

Example

The following example enables logging messages related to management ACL deny actions.

```
switchxxxxxx(config)# management logging deny
```

18.11 logging aggregation on

Use the **logging aggregation on** Global Configuration mode command to control aggregation of SYSLOG messages. If aggregation is enabled, logging messages are displayed every time interval (according to the aging time specified by [logging aggregation aging-time](#)). Use the **no** form of this command to disable aggregation of SYSLOG messages.

Syntax

logging aggregation on

no logging aggregation on

Parameters

N/A

Default Configuration

Enabled.

Command Mode

Global Configuration mode

Example

To turn off aggregation of SYSLOG messages:

```
switchxxxxxx(config)# no logging aggregation on
```

18.12 logging aggregation aging-time

Use the **logging aggregation aging-time** Global Configuration mode command to configure the aging time of the aggregated SYSLOG messages. The SYSLOG messages are aggregated during the time interval set by the aging-time parameter. Use the **no** form of this command to return to the default.

Syntax**logging aggregation aging-time sec****no logging aggregation aging-time****Parameters****aging-time sec**—Aging time in seconds (Range: 15–3600)**Default Configuration**

300 seconds.

Command Mode

Global Configuration mode

Example

```
switchxxxxxx(config)# logging aggregation aging-time 300
```

18.13 show logging

Use the **show logging** Privileged EXEC mode command to display the logging status and SYSLOG messages stored in the internal buffer.

Syntax**show logging****Parameters**

N/A

Default Configuration

N/A

Command Mode

Privileged EXEC mode

Example

The following example displays the logging status and the SYSLOG messages stored in the internal buffer.

```
switchxxxxxx# show logging
Logging is enabled.
Console Logging: Level info. Console Messages: 0 Dropped.
Buffer Logging: Level info. Buffer Messages: 61 Logged, 61 Displayed, 200
Max.
File Logging: Level error. File Messages: 898 Logged, 64 Dropped.
4 messages were not logged
Application filtering control
```

```

Application          Event          Status
-----
AAA                  Login          Enabled
File system          Copy           Enabled
File system          Delete-Rename  Enabled
Management ACL       Deny           Enabled
Aggregation: Disabled.
Aggregation aging time: 300 Sec
01-Jan-2010 05:29:46 :%INIT-I-Startup: Warm Startup
01-Jan-2010 05:29:02 :%LINK-I-Up: Vlan 1
01-Jan-2010 05:29:02 :%LINK-I-Up: SYSLOG6
01-Jan-2010 05:29:02 :%LINK-I-Up: SYSLOG7
01-Jan-2010 05:29:00 :%LINK-W-Down: SYSLOG8

```

18.14 show logging file

Use the **show logging file** Privileged EXEC mode command to display the logging status and the SYSLOG messages stored in the logging file.

Syntax

show logging file

Parameters

N/A

Default Configuration

N/A

Command Mode

Privileged EXEC mode

Example

The following example displays the logging status and the SYSLOG messages stored in the logging file.

```

switchxxxxxx# show logging file
Logging is enabled.
Console Logging: Level info. Console Messages: 0 Dropped.
Buffer Logging: Level info. Buffer Messages: 61 Logged, 61 Displayed, 200
Max.
File Logging: Level error. File Messages: 898 Logged, 64 Dropped.
4 messages were not logged
Application filtering control
Application          Event          Status
-----
AAA                  Login          Enabled

```



```

File system          Copy          Enabled
File system          Delete-Rename Enabled
Management ACL      Deny          Enabled
Aggregation: Disabled.
Aggregation aging time: 300 Sec
01-Jan-2010 05:57:00 :%SSHD-E-ERROR: SSH error: key_read: type mismatch:
encoding error
01-Jan-2010 05:56:36 :%SSHD-E-ERROR: SSH error: key_read: type mismatch:
encoding error
01-Jan-2010 05:55:37 :%SSHD-E-ERROR: SSH error: key_read: type mismatch:
encoding error
01-Jan-2010 05:55:03 :%SSHD-E-ERROR: SSH error: key_read: key_from_blob
bgEgGnt9
z6NHgZwKI5xKqF7cBtdl1xmFgSEWuDhho5UedydAjVvKS5XR2... failed
01-Jan-2010 05:55:03 :%SSHD-E-ERROR: SSH error: key_from_blob: invalid key
type.
01-Jan-2010 05:56:34 :%SSHD-E-ERROR: SSH error: bad sigbloblen 58 !=
SIGBLOB_LEN
console#

```

18.15 show syslog-servers

Use the **show syslog-servers** Privileged EXEC mode command to display the SYSLOG server settings.

Syntax

show syslog-servers

Parameters

N/A

Default Configuration

N/A

Command Mode

Privileged EXEC mode

Example

The following example provides information about the SYSLOG servers.

```

switchxxxxxx# show syslog-servers
Device Configuration
IP address      Port  Facility Severity  Description
-----
1.1.1.121      514   local7   info
3000::100      514   local7   info

```

19 Remote Network Monitoring (RMON) Commands

19.1 show rmon statistics

Use the **show rmon statistics** EXEC mode command to display RMON Ethernet statistics.

Syntax

show rmon statistics *{interface-id}*

Parameters

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

Command Mode

EXEC mode

Example

The following example displays RMON Ethernet statistics for gigabitethernet port fe1/0/11.

```
switchxxxxxx# show rmon statistics fe1/0/11
Port fe1/0/11
Dropped: 0
Octets: 0                               Packets: 0
Broadcast: 0                             Multicast: 0
CRC Align Errors: 0                       Collisions: 0
Undersize Pkts: 0                         Oversize Pkts: 0
Fragments: 0                              Jabbers: 0
64 Octets: 0                              65 to 127 Octets: 1
128 to 255 Octets: 1                      256 to 511 Octets: 1
512 to 1023 Octets: 0                     1024 to max Octets: 0
```

The following table describes the significant fields displayed.

Field	Description
Dropped	Total number of events in which packets were dropped by the probe due to lack of resources. Note that this number is not necessarily the number of packets dropped. It is the number of times this condition was detected.
Octets	Total number of octets of data (including those in bad packets) received on the network (excluding framing bits but including FCS octets).
Packets	Total number of packets (including bad packets, broadcast packets, and multicast packets) received.

Remote Network Monitoring (RMON) Commands

Field	Description
Broadcast	Total number of good packets received and directed to the broadcast address. This does not include multicast packets.
Multicast	Total number of good packets received and directed to a multicast address. This number does not include packets directed to the broadcast address.
CRC Align Errors	Total number of packets received with a length (excluding framing bits, but including FCS octets) of between 64 and 1518 octets, inclusive, but with either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error).
Collisions	Best estimate of the total number of collisions on this Ethernet segment.
Undersize Pkts	Total number of packets received, less than 64 octets long (excluding framing bits, but including FCS octets) and otherwise well formed.
Oversize Pkts	Total number of packets received, longer than 1518 octets (excluding framing bits, but including FCS octets) and otherwise well formed.
Fragments	Total number of packets received, less than 64 octets in length (excluding framing bits but including FCS octets) and either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error).
Jabbers	Total number of packets received, longer than 1518 octets (excluding framing bits, but including FCS octets), and either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error).
64 Octets	Total number of packets (including bad packets) received that are 64 octets in length (excluding framing bits but including FCS octets).
65 to 127 Octets	Total number of packets (including bad packets) received that are between 65 and 127 octets in length inclusive (excluding framing bits but including FCS octets).
128 to 255 Octets	Total number of packets (including bad packets) received that are between 128 and 255 octets in length inclusive (excluding framing bits but including FCS octets).
256 to 511 Octets	Total number of packets (including bad packets) received that are between 256 and 511 octets in length inclusive (excluding framing bits but including FCS octets).
512 to 1023 Octets	Total number of packets (including bad packets) received that were between 512 and 1023 octets in length inclusive (excluding framing bits but including FCS octets).
1024 to max	Total number of packets (including bad packets) received that were between 1024 octets and the maximum frame size in length inclusive (excluding framing bits but including FCS octets).

19.2 rmon collection stats

Use the **rmon collection stats** Interface Configuration mode command to enable RMON MIB collecting history statistics (in groups) on an interface. Use the **no** form of this command to remove a specified RMON history group of statistics.

Syntax

rmon collection stats index [*owner ownername*] [*buckets bucket-number*] [*interval seconds*]

no rmon collection stats index

Parameters

- **index**—The requested group of statistics index.(Range: 1–65535)
- **owner ownername**—Records the name of the owner of the RMON group of statistics. If unspecified, the name is an empty string. (Range: Valid string)
- **buckets bucket-number**—A value associated with the number of buckets specified for the RMON collection history group of statistics. If unspecified, defaults to 50.(Range: 1–50)
- **interval seconds**—The number of seconds in each polling cycle. If unspecified, defaults to 1800 (Range: 1–3600).

Command Mode

Interface Configuration (Ethernet, Port-channel) mode. Cannot be configured for a range of interfaces (range context).

19.3 show rmon collection stats

Use the **show rmon collection stats** EXEC mode command to display the requested RMON history group statistics.

Syntax

show rmon collection stats [*interface-id*]

Parameters

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

Command Mode

EXEC mode

Example

The following example displays all RMON history group statistics.

```
switchxxxxxx# show rmon collection stats
```

Index	Interface	Interval	Requested Samples	Granted Samples	Owner
1	fe1/0/11	30	50	50	CLI
2	fe1/0/11	1800	50	50	Manager

The following table describes the significant fields shown in the display.

Field	Description
Index	An index that uniquely identifies the entry.
Interface	The sampled Ethernet interface.
Interval	The interval in seconds between samples.
Requested Samples	The requested number of samples to be saved.
Granted Samples	The granted number of samples to be saved.
Owner	The entity that configured this entry.

19.4 show rmon history

Use the **show rmon history** EXEC mode command to display RMON Ethernet history statistics.

Syntax

show rmon history *index* {*throughput* | *errors* | *other*} [*period seconds*]

Parameters

- **index**—Specifies the set of samples to display. (Range: 1–65535)
- **throughput**—Displays throughput counters.
- **errors**—Displays error counters.
- **other**—Displays drop and collision counters.
- **period seconds**—Specifies the period of time in seconds to display. (Range: 1–2147483647)

Command Mode

EXEC mode

Example

The following examples display RMON Ethernet history statistics for index 1

```
switchxxxxxx# show rmon history 1 throughput

Sample Set: 1                               Owner: CLI
Interface: fe1/0/11                         Interval: 1800
Requested samples: 50                       Granted samples: 50

Maximum table size: 500

Time                Octets      Packets    Broadcast  Multicast  Util
-----            -
Jan 18 2005 21:57:00 303595962  357568    3289       7287      19%
Jan 18 2005 21:57:30 287696304  275686    2789       5878      20%
```

```
switchxxxxxx# show rmon history 1 errors

Sample Set: 1                               Owner: Me
Interface: fe1/0/11                         Interval: 1800
Requested samples: 50                       Granted samples: 50
```

Maximum table size: 500 (800 after reset)

Time -----	CRC Align	Under size	Oversize	Fragments	Jabbers
Jan 18 2005 21:57:00	----- 1	----- 1	----- 0	----- 49	----- 0
Jan 18 2005 21:57:30	----- 1	----- 1	----- 0	----- 27	----- 0

switchxxxxxxx# **show rmon history 1 other**

Sample Set: 1 Owner: Me
 Interface: fe1/0/11 Interval: 1800
 Requested samples: 50 Granted samples: 50

Maximum table size: 500

Time -----	Dropped	Collisions
Jan 18 2005 21:57:00	----- 3	----- 0
Jan 18 2005 21:57:30	----- 3	----- 0

The following table describes significant fields shown in the display:

Field	Description
Time	Date and Time the entry is recorded.
Octets	Total number of octets of data (including those in bad packets and excluding framing bits but including FCS octets) received on the network.
Packets	Number of packets (including bad packets) received during this sampling interval.
Broadcast	Number of good packets received during this sampling interval that were directed to the broadcast address.
Multicast	Number of good packets received during this sampling interval that were directed to a multicast address. This number does not include packets addressed to the broadcast address.
Utilization	Best estimate of the mean physical layer network utilization on this interface during this sampling interval, in hundredths of a percent.
CRC Align	Number of packets received during this sampling interval that had a length (excluding framing bits but including FCS octets) between 64 and 1518 octets, inclusive, but had either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error).
Undersize	Number of packets received during this sampling interval that were less than 64 octets long (excluding framing bits but including FCS octets) and were otherwise well formed.

Field	Description
Oversize	Number of packets received during this sampling interval that were longer than 1518 octets (excluding framing bits but including FCS octets) but were otherwise well formed.
Fragments	Total number of packets received during this sampling interval that were less than 64 octets in length (excluding framing bits but including FCS octets) and had either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error), or a bad FCS with a non-integral number of octets (Alignment Error). It is normal for etherHistoryFragments to increment because it counts both runts (which are normal occurrences due to collisions) and noise hits.
Jabbers	Number of packets received during this sampling interval that were longer than 1518 octets (excluding framing bits but including FCS octets), and had either a bad Frame Check Sequence (FCS) with an integral number of octets (FCS Error) or a bad FCS with a non-integral number of octets (Alignment Error).
Dropped	Total number of events in which packets were dropped by the probe due to lack of resources during this sampling interval. This number is not necessarily the number of packets dropped, it is the number of times this condition has been detected.
Collisions	Best estimate of the total number of collisions on this Ethernet segment during this sampling interval.

19.5 rmon alarm

Use the **rmon alarm** Global Configuration mode command to configure alarm conditions. Use the **no** form of this command to remove an alarm.

Syntax

rmon alarm *index mib-object-id interval rising-threshold falling-threshold rising-event falling-event [type {absolute | delta}] [startup {rising | rising-falling | falling}] [owner name]*

no rmon alarm *index*

Parameters

- **index**—Specifies the alarm index. (Range: 1–65535)
- **mib-object-id**—Specifies the object identifier of the variable to be sampled. (Valid OID)
- **interval**—Specifies the interval in seconds during which the data is sampled and compared with rising and falling thresholds. (Range: 1–4294967295)
- **rising-threshold**—Specifies the rising threshold value. (Range: 0–4294967295)
- **falling-threshold**—Specifies the falling threshold value. (Range: 0–4294967295)
- **rising-event**—Specifies the index of the event triggered when a rising threshold is crossed. (Range: 0–65535)
- **falling-event**—Specifies the index of the event triggered when a falling threshold is crossed. (Range: 0–65535)
- **type {absolute | delta}**—Specifies the method used for sampling the selected variable and calculating the value to be compared against the thresholds. The possible values are:
 - **absolute**—Specifies that the selected variable value is compared directly with the thresholds at the end of the sampling interval.

- **delta**—Specifies that the selected variable value of the last sample is subtracted from the current value, and the difference is compared with the thresholds.
- **startup {rising | rising-falling | falling}**—Specifies the alarm that may be sent when this entry becomes valid. The possible values are:
 - **rising**—Specifies that if the first sample (after this entry becomes valid) is greater than or equal to **rising-threshold**, a single rising alarm is generated.
 - **rising-falling**—Specifies that if the first sample (after this entry becomes valid) is greater than or equal to **rising-threshold**, a single rising alarm is generated. If the first sample (after this entry becomes valid) is less than or equal to **falling-threshold**, a single falling alarm is generated.
 - **falling**—Specifies that if the first sample (after this entry becomes valid) is less than or equal to **falling-threshold**, a single falling alarm is generated.
- **owner name**—Specifies the name of the person who configured this alarm. (Valid string)

Default Configuration

The default method type is **absolute**.

The default **startup** direction is **rising-falling**.

If the owner **name** is not specified, it defaults to an empty string.

Command Mode

Global Configuration mode

Example

The following example configures an alarm with index 1000, MIB object ID D-Link, sampling interval 360000 seconds (100 hours), rising threshold value 1000000, falling threshold value 1000000, rising threshold event index 10, falling threshold event index 10, absolute method type and rising-falling alarm.

```
switchxxxxxx(config)# rmon alarm 1000 1.3.6.1.2.1.2.2.1.10.1 360000
1000000 1000000 10 20
```

19.6 show rmon alarm-table

Use the **show rmon alarm-table** EXEC mode command to display a summary of the alarms table.

Syntax

show rmon alarm-table

Command Mode

EXEC mode

Example

The following example displays the alarms table.

```
switchxxxxxx# show rmon alarm-table
Index      OID                               Owner
-----
1          1.3.6.1.2.1.2.2.1.10.1         CLI
2          1.3.6.1.2.1.2.2.1.10.1         Manager
3          1.3.6.1.2.1.2.2.1.10.9         CLI
```

The following table describes the significant fields shown in the display:

Field	Description
Index	An index that uniquely identifies the entry.
OID	Monitored variable OID.
Owner	The entity that configured this entry.

19.7 show rmon alarm

Use the **show rmon alarm** EXEC mode command to display alarm configuration.

Syntax

show rmon alarm *number*

Parameters

alarm *number*—Specifies the alarm index. (Range: 1–65535)

Command Mode

EXEC mode

Example

The following example displays RMON 1 alarms.

```
switchxxxxxx# show rmon alarm 1
Alarm 1
-----
OID: 1.3.6.1.2.1.2.2.1.10.1
Last sample Value: 878128
Interval: 30
Sample Type: delta
Startup Alarm: rising
Rising Threshold: 8700000
Falling Threshold: 78
Rising Event: 1
Falling Event: 1
```

Owner: CLI

The following table describes the significant fields shown in the display:

Field	Description
Alarm	Alarm index.
OID	Monitored variable OID.
Last Sample Value	Value of the statistic during the last sampling period. For example, if the sample type is delta , this value is the difference between the samples at the beginning and end of the period. If the sample type is absolute , this value is the sampled value at the end of the period.
Interval	Interval in seconds over which the data is sampled and compared with the rising and falling thresholds.
Sample Type	Method of sampling the variable and calculating the value compared against the thresholds. If the value is absolute , the variable value is compared directly with the thresholds at the end of the sampling interval. If the value is delta , the variable value at the last sample is subtracted from the current value, and the difference is compared with the thresholds.
Startup Alarm	Alarm that is sent when this entry is first set. If the first sample is greater than or equal to the rising threshold, and startup alarm is equal to rising or rising-falling, then a single rising alarm is generated. If the first sample is less than or equal to the falling threshold, and startup alarm is equal falling or rising-falling, then a single falling alarm is generated.
Rising Threshold	Sampled statistic rising threshold. When the current sampled value is greater than or equal to this threshold, and the value at the last sampling interval is less than this threshold, a single event is generated.
Falling Threshold	Sampled statistic falling threshold. When the current sampled value is less than or equal to this threshold, and the value at the last sampling interval is greater than this threshold, a single event is generated.
Rising Event	Event index used when a rising threshold is crossed.
Falling Event	Event index used when a falling threshold is crossed.
Owner	Entity that configured this entry.

19.8 rmon event

Use the **rmon event** Global Configuration mode command to configure an event. Use the **no** form of this command to remove an event.

Syntax

rmon event *index* {*none* | *log* | *trap* | *log-trap*} [*community text*] [*description text*] [*owner name*]

no rmon event *index*

Parameters

- **index**—Specifies the event index. (Range: 1–65535)
- **none**— Specifies that no notification is generated by the device for this event.
- **log**—Specifies that a notification entry is generated in the log table by the device for this event.
- **trap**—Specifies that an SNMP trap is sent to one or more management stations by the device for this event.
- **log-trap**—Specifies that an entry is generated in the log table and an SNMP trap is sent to one or more management stations by the device for this event.
- **community text**—Specifies the SNMP community (password) used when an SNMP trap is sent. (Octet string; length: 0–127 characters)
- **description text**—Specifies a comment describing this event. (Length: 0–127 characters)
- **owner name**—Specifies the name of the person who configured this event. (Valid string)

Default Configuration

If the owner name is not specified, it defaults to an empty string.

Command Mode

Global Configuration mode

Example

The following example configures an event identified as index 10, for which the device generates a notification in the log table.

```
switchxxxxxx(config)# rmon event 10 log
```

19.9 show rmon events

Use the **show rmon events** EXEC mode command to display the RMON event table.

Syntax

show rmon events

Command Mode

EXEC mode

Example

The following example displays the RMON event table.

```
switchxxxxxx# show rmon events
```

Index	Description	Type	Community	Owner	Last time sent
----	-----	-----	-----	-----	-----
1	Errors	Log	router	CLI	Jan 18 2006 23:58:17
2	High Broadcast	Log Trap		Manager	Jan 18 2006 23:59:48

The following table describes significant fields shown in the display:

Field	Description
Index	Unique index that identifies this event.
Description	Comment describing this event.
Type	Type of notification that the device generates about this event. Can have the following values: none , log , trap , log-trap . In the case of log, an entry is made in the log table for each event. In the case of trap, an SNMP trap is sent to one or more management stations.
Community	If an SNMP trap is to be sent, it is sent with the SNMP community string specified by this octet string.
Owner	The entity that configured this event.
Last time sent	The time this entry last generated an event. If this entry has not generated any events, this value is zero.

19.10 show rmon log

Use the **show rmon log** EXEC mode command to display the RMON log table.

Syntax

show rmon log [*event*]

Parameters

event—Specifies the event index. (Range: 0–65535)

Command Mode

EXEC mode

Example

The following example displays event 1 in the RMON log table.

```

switchxxxxxx# show rmon log 1
Maximum table size: 500 (800 after reset)

Event          Description                               Time
-----          -
1              MIB Var.:                               Jan 18 2006 23:48:19
              1.3.6.1.2.1.2.2.1.10.
              53, Delta, Rising,
              Actual Val: 800,
              Thres.Set: 100,
              Interval (sec):1
    
```

19.11 rmon table-size

Use the **rmon table-size** Global Configuration mode command to configure the maximum size of RMON tables. Use the **no** form of this command to return to the default size.

Syntax

rmon table-size *{history entries | log entries}*

no rmon table-size *{history | log}*

Parameters

- **history entries**—Specifies the maximum number of history table entries. (Range: 20–270)
- **log entries**—Specifies the maximum number of log table entries. (Range: 20–100)

Default Configuration

The default history table size is 270 entries.

The default log table size is 200 entries.

Command Mode

Global Configuration mode

User Guidelines

The configured table size takes effect after the device is rebooted.

Example

The following example configures the maximum size of RMON history tables to 100 entries.

```
switchxxxxxx(config)# rmon table-size history 100
```

20

802.1x Commands

20.1 aaa authentication dot1x

Use the **aaa authentication dot1x** Global Configuration mode command to specify how ports are authenticated when 802.1x is enabled. You can select either authentication by a RADIUS server, no authentication, or both methods. Use the **no** form of this command to restore the default configuration.

Syntax

aaa authentication dot1x default *method1* [*method2*]

no aaa authentication dot1x default

Parameters

method1 [**method2**]—Specify at least one method from the following:

- **radius** - Uses the list of all RADIUS servers for authentication
- **none** - Uses no authentication

Default Configuration

The default method is RADIUS.

Command Mode

Global Configuration mode

User Guidelines

You can select either authentication by a RADIUS server, no authentication (**none**), or both methods.

If you require that authentication succeeds even if the RADIUS server is not found or returns an error, specify **none** as the final method in the command line.

Example

The following example sets the 802.1X authentication mode to RADIUS server authentication. If no response is received, no authentication is performed.

```
switchxxxxxx(config)# aaa authentication dot1x default radius none
```

20.2 dot1x system-auth-control

Use the **dot1x system-auth-control** Global Configuration mode command to enable 802.1x globally. Use the **no** form of this command to restore the default configuration.

Syntax

dot1x system-auth-control

no dot1x system-auth-control

Parameters

N/A

Default Configuration

Disabled.

Command Mode

Global Configuration mode

Example

The following example enables 802.1x globally.

```
switchxxxxxx(config)# dot1x system-auth-control
```

20.3 dot1x port-control

Use the **dot1x port-control** Interface Configuration (Ethernet) mode command to enable manual control of the port authorization state. Use the **no** form of this command to restore the default configuration.

Syntax

dot1x port-control {*auto* | *force-authorized* | *force-unauthorized*}[*time-range* *time-range-name*]

no dot1x port-control

Parameters

- **auto**—Enables 802.1x authentication on the port and causes it to transition to the authorized or unauthorized state, based on the 802.1x authentication exchange between the device and the client.
- **force-authorized**—Disables 802.1x authentication on the interface and causes the port to transition to the authorized state without any authentication exchange required. The port resends and receives normal traffic without 802.1x-based client authentication.
- **force-unauthorized**—Denies all access through this port by forcing it to transition to the unauthorized state and ignoring all attempts by the client to authenticate. The device cannot provide authentication services to the client through this port.
- **time-range** *time-range-name*—Specifies a time range. When the Time Range is not in effect, the port state is Unauthorized. (Range: 1–32 characters)

Default Configuration

The port is in the force-authorized state.

Command Mode

Interface Configuration (Ethernet) mode

User Guidelines

It is recommended to disable spanning tree or to enable spanning-tree PortFast mode on 802.1x edge ports (ports in **auto** state that are connected to end stations), in order to proceed to the forwarding state immediately after successful authentication.

Example

The following example sets 802.1x authentication on `fe1/0/115` to `auto` mode.

```
switchxxxxxx(config)# interface fe1/0/115
switchxxxxxx(config-if)# dot1x port-control auto
```

20.4 dot1x reauthentication

Use the **dot1x reauthentication** Interface Configuration mode command to enable periodic re-authentication of the client. Use the **no** form of this command to return to the default setting.

Syntax

dot1x reauthentication

no dot1x reauthentication

Parameters

N/A

Default Configuration

Periodic re-authentication is disabled.

Command Mode

Interface configuration (Ethernet)

Example

```
switchxxxxxx(config)# interface fe1/0/11
switchxxxxxx(config-if)# dot1x reauthentication
```

20.5 dot1x timeout reauth-period

Use the **dot1x timeout reauth-period** Interface Configuration mode command to set the number of seconds between re-authentication attempts. Use the **no** form of this command to return to the default setting.

Syntax

dot1x timeout reauth-period *seconds*

no dot1x timeout reauth-period

Parameters

reauth-period *seconds*—Number of seconds between re-authentication attempts. (Range: 300-4294967295)

Default Configuration

3600

Command Mode

Interface Configuration (Ethernet) mode

Example

```
switchxxxxxx(config)# interface fe1/0/11  
switchxxxxxx(config-if)# dot1x timeout reauth-period 5000
```

20.6 dot1x re-authenticate

The **dot1x re-authenticate** Privileged EXEC mode command manually initiates re-authentication of all 802.1x-enabled ports or the specified 802.1x-enabled port.

Syntax**dot1x re-authenticate** [*interface-id*]**Parameters****interface-id**—Specifies an Ethernet port ID.**Default Configuration**

If no port is specified, command is applied to all ports.

Command Mode

Privileged EXEC mode

Example

The following command manually initiates re-authentication of 802.1x-enabled `fe1/0/115`.

```
switchxxxxxx# dot1x re-authenticate fe1/0/115
```

20.7 dot1x timeout quiet-period

Use the **dot1x timeout quiet-period** Interface Configuration (Ethernet) mode command to set the time interval that the device remains in a quiet state following a failed authentication exchange (for example, the client provided an invalid password). Use the **no** form of this command to restore the default configuration.

Syntax**dot1x timeout quiet-period** *seconds***no dot1x timeout quiet-period****Parameters****seconds**—Specifies the time interval in seconds that the device remains in a quiet state following a failed authentication exchange with the client. (Range: 0–65535 seconds)**Default Configuration**The default quiet period is 60 seconds.

Command Mode

Interface Configuration (Ethernet) mode

User Guidelines

During the quiet period, the device does not accept or initiate authentication requests.

The default value of this command should only be changed to adjust to unusual circumstances, such as unreliable links or specific behavioral problems with certain clients and authentication servers.

To provide faster response time to the user, a smaller number than the default value should be entered.

Example

The following example sets the time interval that the device remains in the quiet state following a failed authentication exchange to 10 seconds.

```
switchxxxxxx(config)# interface fe1/0/115
switchxxxxxx(config-if)# dot1x timeout quiet-period 10
```

20.8 dot1x timeout tx-period

Use the **dot1x timeout tx-period** Interface Configuration (Ethernet) mode command to set the time interval during which the device waits for a response to an Extensible Authentication Protocol (EAP) request/identity frame from the client before resending the request. Use the **no** form of this command to restore the default configuration.

Syntax

dot1x timeout tx-period *seconds*

no dot1x timeout tx-period

Parameters

seconds—Specifies the time interval in seconds during which the device waits for a response to an EAP-request/identity frame from the client before resending the request. (Range: 30–65535 seconds)

Default Configuration

The default timeout period is 30 seconds.

Command Mode

Interface Configuration (Ethernet) mode

User Guidelines

The default value of this command should be changed only to adjust to unusual circumstances, such as unreliable links or specific behavioral problems with certain clients and authentication servers.

Example

The following command sets the time interval during which the device waits for a response to an EAP request/identity frame to 60 seconds.

```
switchxxxxxx(config)# interface fe1/0/115  
switchxxxxxx(config-if)# dot1x timeout tx-period 60
```

20.9 dot1x max-req

Use the **dot1x max-req** Interface Configuration mode command to set the maximum number of times that the device sends an Extensible Authentication Protocol (EAP) request/identity frame (assuming that no response is received) to the client before restarting the authentication process. Use the **no** form of this command to restore the default configuration.

Syntax

dot1x max-req *count*

no dot1x max-req

Parameters

max-req *count*—Specifies the maximum number of times that the device sends an EAP request/identity frame before restarting the authentication process. (Range: 1–10)

Default Configuration

The default maximum number of attempts is 2.

Command Mode

Interface Configuration (Ethernet) mode

User Guidelines

The default value of this command should be changed only to adjust to unusual circumstances, such as unreliable links or specific behavioral problems with certain clients and authentication servers.

Example

The following example sets the maximum number of times that the device sends an EAP request/identity frame to 6

```
switchxxxxxx(config)# interface fe1/0/115  
switchxxxxxx(config-if)# dot1x max-req 6
```

20.10 dot1x timeout supp-timeout

Use the **dot1x timeout supp-timeout** Interface Configuration (Ethernet) mode command to set the time interval during which the device waits for a response to an Extensible Authentication Protocol (EAP) request frame from the client before resending the request. Use the **no** form of this command to restore the default configuration.

Syntax

dot1x timeout supp-timeout *seconds*

no dot1x timeout supp-timeout

Parameters

supp-timeout *seconds*—Specifies the time interval in seconds during which the device waits for a response to an EAP request frame from the client before resending the request. (Range: 1–65535 seconds)

Default Configuration

The default timeout period is 30 seconds.

Command Mode

Interface Configuration (Ethernet) mode

User Guidelines

The default value of this command should be changed only to adjust to unusual circumstances, such as unreliable links or specific behavioral problems with certain clients and authentication servers.

Example

The following example sets the time interval during which the device waits for a response to an EAP request frame from the client before resending the request to 3600 seconds.

```
switchxxxxxx(config)# interface fe1/0/115
switchxxxxxx(config-if)# dot1x timeout supp-timeout 3600
```

20.11 dot1x timeout server-timeout

Use the **dot1x timeout server-timeout** Interface Configuration (Ethernet) mode command to set the time interval during which the device waits for a response from the authentication server. Use the **no** form of this command to restore the default configuration.

Syntax

dot1x timeout server-timeout *seconds*

no dot1x timeout server-timeout

Parameters

server-timeout *seconds*—Specifies the time interval in seconds during which the device waits for a response from the authentication server. (Range: 1–65535 seconds)

Default Configuration

The default timeout period is 30 seconds.

Command Mode

Interface Configuration (Ethernet) mode

User Guidelines

The actual timeout period can be determined by comparing the value specified by the **dot1x timeout server-timeout** command to the result of multiplying the number of retries specified by the **radius-server retransmit** command by the timeout period specified by the **radius-server retransmit** command, and selecting the lower of the two values.

Example

The following example sets the time interval between retransmission of packets to the authentication server to 3600 seconds.

```
switchxxxxxx(config)# interface fe1/0/115  
switchxxxxxx(config-if)# dot1x timeout server-timeout 3600
```

20.12 show dot1x

Use the **show dot1x** Privileged EXEC mode command to display the 802.1x device or specified interface status.

Syntax

show dot1x [*interface interface-id*]

Parameters

interface-id—Specify an Ethernet port ID.

Default Configuration

Display for all ports.

Command Mode

Privileged EXEC mode



Examples

Example 1 - The following example displays the status of a single 802.1x-enabled Ethernet ports.

```

switchxxxxxx# show dot1x interface fe1/0/13
802.1x is enabled.

Port          Admin      Oper      Reauth    Reauth    Username
             Mode      Mode      Control   Period
-----
fe1/0/1      Auto      Unauthorized  Ena      3600      Clark
3

Time-range:          work-hours (Inactive now)
Quiet period:        60 Seconds
Tx period:           30 Seconds
Max req:             2
Supplicant timeout:  30 Seconds

Server timeout:      30 Seconds
Session Time (HH:MM:SS): 08:19:17
MAC Address:         00:08:78:32:98:78
Authentication Method: Remote
Termination Cause:  Supplicant logoff

Authenticator State Machine

State:               HELD

Backend State Machine

State:               IDLE
Authentication success: 9
Authentication fails:  1

```

Example 2 - The following example displays the status of all 802.1x-enabled Ethernet ports.

```

switchxxxxxx# show dot1x
802.1x is enabled

Port          Admin      Oper      Reauth    Reauth    Username
             Mode      Mode      Control   Period
-----
fe1/0/1      Auto      Authorized  Ena      3600      Bob
1            Auto      Authorized  Ena      3600      John
fe1/0/1      Auto      Unauthorized  Ena      3600      Clark
2            Force-auth  Authorized  Dis      3600      n/a
fe1/0/1      Force-auth  Unauthorized  Dis      3600      n/a
3
fe1/0/1
4
fe1/0/1
5

* Port is down or not present.

```

The following table describes the significant fields shown in the display.

Field	Description
Port	The port number.
Admin mode	The port administration (configured) mode. Possible values: Force-auth, Force-unauth, Auto.
Oper mode	The port operational (actual) mode. Possible values: Authorized, Unauthorized or Down.
Reauth Control	Reauthentication control.
Reauth Period	Reauthentication period.
Username	Username representing the supplicant identity. This field shows the username if the port control is auto. If the port is Authorized, it displays the username of the current user. If the port is Unauthorized, it displays the last user authenticated successfully.
Quiet period	Number of seconds that the device remains in the quiet state following a failed authentication exchange (for example, the client provided an invalid password).
Tx period	Number of seconds that the device waits for a response to an Extensible Authentication Protocol (EAP) request/identity frame from the client before resending the request.
Max req	Maximum number of times that the device sends an EAP request frame (assuming that no response is received) to the client before restarting the authentication process.
Supplicant timeout	Number of seconds that the device waits for a response to an EAP-request frame from the client before resending the request.
Server timeout	Number of seconds that the device waits for a response from the authentication server before resending the request.
Session Time	Amount of time (HH:MM:SS) that the user is logged in.
MAC address	Supplicant MAC address.
Authentication Method	Authentication method used to establish the session.
Termination Cause	Reason for the session termination.
State	Current value of the Authenticator PAE state machine and of the Backend state machine.
Authentication success	Number of times the state machine received a Success message from the Authentication Server.
Authentication fails	Number of times the state machine received a Failure message from the Authentication Server.

20.13 show dot1x users

Use the **show dot1x users** Privileged EXEC mode command to display active 802.1x authenticated users for the device.



Syntax

show dot1x users [*username username*]

Parameters

username—Specifies the supplicant username (Length: 1–160 characters)

Default Configuration

Display all users.

Command Mode

Privileged EXEC mode

Example

The following example displays 802.1x user with supplicant username Bob.

```
switchxxxxxx# show dot1x users username Bob
Port   Username   Session      Auth      MAC      VLAN
      Time      Method      Address
-----
fe1/0/11 Bob       1d 09:07:38 Remote    0008.3b79.8787  3
```

20.14 show dot1x statistics

Use the **show dot1x statistics** Privileged EXEC mode command to display 802.1x statistics for the specified port.

Syntax

show dot1x statistics interface *interface-id*

Parameters

interface-id—Specifies an Ethernet port ID.

Default Configuration

N/A

Command Mode

Privileged EXEC mode

Example

The following example displays 802.1x statistics for fe1/0/11.

```
switchxxxxxx# show dot1x statistics interface fe1/0/11
EapolFramesRx: 11
EapolFramesTx: 12
EapolStartFramesRx: 1
EapolLogoffFramesRx: 1
EapolRespIdFramesRx: 3
```

```

EapolRespFramesRx: 6
EapolReqIdFramesTx: 3
EapolReqFramesTx: 6
InvalidEapolFramesRx: 0
EapLengthErrorFramesRx: 0
LastEapolFrameVersion: 1
LastEapolFrameSource: 00:08:78:32:98:78

```

The following table describes the significant fields shown in the display:

Field	Description
EapolFramesRx	Number of valid EAPOL frames of any type that have been received by this Authenticator.
EapolFramesTx	Number of EAPOL frames of any type that have been transmitted by this Authenticator.
EapolStartFramesRx	Number of EAPOL Start frames that have been received by this Authenticator.
EapolLogoffFramesRx	Number of EAPOL Logoff frames that have been received by this Authenticator.
EapolRespIdFramesRx	Number of EAP Resp/Id frames that have been received by this Authenticator.
EapolRespFramesRx	Number of valid EAP Response frames (other than Resp/Id frames) that have been received by this Authenticator.
EapolReqIdFramesTx	Number of EAP Req/Id frames that have been transmitted by this Authenticator.
EapolReqFramesTx	Number of EAP Request frames (other than Req/Id frames) that have been transmitted by this Authenticator.
InvalidEapolFramesRx	Number of EAPOL frames that have been received by this Authenticator for which the frame type is not recognized.
EapLengthErrorFramesRx	Number of EAPOL frames that have been received by this Authenticator in which the Packet Body Length field is invalid.
LastEapolFrameVersion	Protocol version number carried in the most recently received EAPOL frame.
LastEapolFrameSource	Source MAC address carried in the most recently received EAPOL frame.

20.15 clear dot1x statistics

Use the **clear dot1x statistics** Privileged EXEC mode command to clear 802.1x statistics.

Syntax

clear dot1x statistics [*interface-id*]

Parameters

interface-id—Specify an Ethernet port ID.

Default Configuration

Statistics on all ports are cleared.

Command Mode

Privileged EXEC

User Guidelines

The command clears the statistics displayed in the [show dot1x statistics](#) command

Example

```
switchxxxxxx# clear dot1x statistics
```

20.16 dot1x host-mode

Use the **dot1x host-mode** Interface Configuration mode command to allow a single host (client) or multiple hosts on an IEEE 802.1x-authorized port. Use the **no** form of this command to return to the default setting.

Syntax

dot1x host-mode {*multi-host* | *single-host* | *multi-sessions*}

Parameters

- **multi-host**—Enable multiple-hosts mode.
- **single-host**—Enable single-hosts mode.
- **multi-sessions**—Enable multiple-sessions mode.

Default Configuration

Default mode is multi-host.

Command Mode

Interface Configuration (Ethernet) mode

User Guidelines

In multiple hosts mode only one of the attached hosts must be successfully authorized for all hosts to be granted network access. If the port becomes unauthorized, all attached clients are denied access to the network.

In multiple sessions mode each host must be successfully authorized in order to grant network access. Please note that packets are NOT encrypted, and after success full authentication filtering is based on the source MAC address only.

Port security on a port cannot be enabled in single-host mode and in multiple-sessions mode.

It is recommended to enable reauthentication when working in multiple-sessions mode in order to detect user logout for users that have not logged off.

In single host mode there is only one attached host and only this authenticated host can access the network.

Example

```
switchxxxxxx(config)# interface fe1/0/11
switchxxxxxx(config-if)# dot1x host-mode multi-host
switchxxxxxx(config-if)# dot1x host-mode single-host
switchxxxxxx(config-if)# dot1x host-mode multi-sessions
```

20.17 dot1x violation-mode

Use the **dot1x violation-mode** Interface Configuration (Ethernet) mode command to configure the action to be taken, when a station whose MAC address is not the supplicant MAC address, attempts to access the interface. Use the **no** form of this command to return to default.

Syntax

```
dot1x violation-mode {restrict | protect | shutdown} no dot1x violation-mode
```

Parameters

- **restrict**—Generates a trap when a station whose MAC address is not the supplicant MAC address, attempts to access the interface. The minimum time between the traps is 1 second. Those frames are forwarded but their source address are not learned.
- **protect**—Discard frames with source addresses not the supplicant address.
- **shutdown**—Discard frames with source addresses not the supplicant address and shutdown the port

Default Configuration

Protect

Command Mode

Interface Configuration (Ethernet) mode

User Guidelines

The command is relevant only for single-host mode.

BPDU message whose MAC address is not the supplicant MAC address wouldn't be discarded in the protect mode.

BPDU message whose MAC address is not the supplicant MAC address would cause a shutdown in the shutdown mode.

Example

```
switchxxxxxx(config)# interface fe1/0/11
switchxxxxxx(config-if)# dot1x violation-mode protect
```

20.18 dot1x guest-vlan

Use the **dot1x guest-vlan** Interface Configuration (VLAN) mode command to define a guest VLAN. Use the **no** form of this command to restore the default configuration.

Syntax

dot1x guest-vlan

no dot1x guest-vlan

Parameters

N/A

Default Configuration

No VLAN is defined as a guest VLAN.

Command Mode

Interface Configuration (VLAN) mode

User Guidelines

Use the **dot1x guest-vlan enable** Interface Configuration mode command to enable unauthorized users on an interface to access the guest VLAN.

If the guest VLAN is defined and enabled, the port automatically joins the guest VLAN when the port is unauthorized and leaves it when the port becomes authorized. To be able to join or leave the guest VLAN, the port should not be a static member of the guest VLAN.

Example

The following example defines VLAN 2 as a guest VLAN.

```
switchxxxxxx(config)# interface vlan 2
switchxxxxxx(config-if)# dot1x guest-vlan
```

20.19 dot1x guest-vlan timeout

Use the **dot1x guest-vlan timeout** Global Configuration mode command to set the time delay between enabling 802.1x (or port up) and adding a port to the guest VLAN. Use the **no** form of this command to restore the default configuration.

Syntax

dot1x guest-vlan timeout *timeout*

no dot1x guest-vlan timeout

Parameters

timeout—Specifies the time delay in seconds between enabling 802.1x (or port up) and adding the port to the guest VLAN. (Range: 30–180)

Default Configuration

The guest VLAN is applied immediately.

Command Mode

Global Configuration mode

User Guidelines

This command is relevant if the guest VLAN is enabled on the port. Configuring the timeout adds delay from enabling 802.1X (or port up) to the time the device adds the port to the guest VLAN.

Example

The following example sets the delay between enabling 802.1x and adding a port to a guest VLAN to 60 seconds.

```
switchxxxxxx(config)# dot1x guest-vlan timeout 60
```

20.20 dot1x guest-vlan enable

Use the **dot1x guest-vlan enable** Interface Configuration (Ethernet) mode command to enable unauthorized users on the interface access to the guest VLAN. Use the **no** form of this command to disable access.

Syntax

dot1x guest-vlan enable

no dot1x guest-vlan enable

Parameters

N/A

Default Configuration

The default configuration is disabled.

Command Mode

Interface Configuration (Ethernet) mode

User Guidelines

A device can have only one global guest VLAN. The guest VLAN is defined using the [dot1x guest-vlan](#) Interface Configuration mode command.

Example

The following example enables unauthorized users on fe1/0/11 to access the guest VLAN.

```
switchxxxxxx(config)# interface fe1/0/115
switchxxxxxx(config-if)# dot1x guest-vlan enable
```

20.21 dot1x mac-authentication

Use the **dot1x mac-authentication** Interface Configuration (Ethernet) mode command to enable authentication based on the station's MAC address. Use the **no** form of this command to disable this feature.

Syntax

dot1x mac-authentication {*mac-only* | *mac-and-802.1x*}

no dot1x mac-authentication

Parameters

- **mac-only**—Enables authentication based on the station's MAC address only. 802.1X frames are ignored.
- **mac-and-802.1x**—Enables 802.1X authentication and MAC address authentication on the interface.

Default Configuration

Authentication based on the station's MAC address is disabled.

Command Mode

Interface Configuration (Ethernet) mode

User Guidelines

The guest VLAN must be enabled when MAC authentication is enabled.

Static MAC addresses cannot be authorized. Do not change an authenticated MAC address to a static address.

It is not recommended to delete authenticated MAC addresses.

Reauthentication must be enabled when working in this mode.

Example

The following example enables authentication based on the station's MAC address on *fe1/0/11*.

```
switchxxxxxx(config)# interface fe1/0/11
switchxxxxxx(config-if)# dot1x mac-authentication mac-only
```

20.22 dot1x traps mac-authentication success

Use the **dot1x traps mac-authentication success** Global Configuration mode command to enable sending traps when a MAC address is successfully authenticated by the 802.1X MAC-authentication access control. Use the **no** form of this command to disable the traps.

Syntax

dot1x traps mac-authentication success

no dot1x traps mac-authentication success

Parameters

N/A

Default Configuration

Default is disabled.

Command Mode

Global Configuration mode

Example

The following example enables sending traps when a MAC address is successfully authenticated by the 802.1X MAC-authentication access control.

```
switchxxxxxx(config-if) # dot1x traps mac-authentication success
```

20.23 dot1x traps mac-authentication failure

Use the **dot1x traps mac-authentication failure** Global Configuration mode command to enable sending traps when MAC address was failed in authentication of the 802.1X MAC authentication access control. Use the **no** form of this command to disable the traps.

Syntax**dot1x traps mac-authentication failure****no dot1x traps mac-authentication failure****Parameters**

N/A

Default Configuration

Default is Enabled.

Command Mode

Global Configuration mode

Example

The following example enables sending traps when a MAC address fails to be authenticated by the 802.1X mac-authentication access control.

```
switchxxxxxx(config-if) # dot1x traps mac-authentication failure
```

20.24 dot1x radius-attributes vlan

Use the **dot1x radius-attributes vlan** Interface Configuration mode command, to enable user-based VLAN assignment. Use the **no** form of this command to disable user-based VLAN assignment.

Syntax**dot1x radius-attributes vlan****no dot1x radius-attributes vlan**

Parameters

N/A

Default Configuration

Disabled

Command Mode

Interface Configuration (Ethernet) mode

User Guidelines

The configuration of this command is allowed only when the port is Forced Authorized.

RADIUS attributes are supported only in the multiple sessions mode (multiple hosts with authentication)

When RADIUS attributes are enabled and the RADIUS Accept message does not contain the supplicant's VLAN as an attribute, then the supplicant is rejected.

Packets to the supplicant are sent untagged.

After successful authentication, the port remains a member in the unauthenticated VLANs and in the Guest VLAN. Other static VLAN configuration is not applied on the port. If the supplicant VLAN does not exist on the switch, the supplicant is rejected.

Example

```
switchxxxxxx(config)# interface fe1/0/11  
switchxxxxxx(config-if)# dot1x radius-attributes vlan
```

20.25 dot1x radius-attributes filter-id

Use the **dot1x radius-attributes filter-id** Interface Configuration mode command to enable user-based ACL/Qos-Policy assignment. Use the **no** form of this command to disable user-based ACL/Qos-Policy assignment.

Syntax

dot1x radius-attributes filter-id

no dot1x radius-attributes filter-id

Parameters

N/A

Default Configuration

Disabled

Command Mode

Interface Configuration (Ethernet) mode

User Guidelines

User based ACL/Qos-Policy assignment is supported only in 802.1x multiple sessions.

The configuration of the parameter is allowed only when the port is Forced Authorized or Forced Unauthorized.

Example

The following example enables user-based ACL/Qos-Policy assignment.

```
switchxxxxxx(config-if) # dot1x radius-attributes filter-id
```

20.26 dot1x radius-attributes errors

Use the **dot1x radius-attributes errors** Global Configuration mode command to specify error handling for the RADIUS attributes feature. Use the **no** form of this command to return to the default.

Syntax

dot1x radius-attributes errors filter-id resources {accept | reject}

no dot1x radius-attributes errors filter-id resources

Parameters

- **accept**—If the Filter-ID cannot be allocated for resource allocation reasons, the user is accepted. If the Filter-ID cannot be allocated for other reasons, the user is rejected.
- **reject**—If the Filter-ID cannot be assigned, the user is rejected.

Default Configuration

Reject

Command Mode

Global Configuration mode

Example

The following example accepts users who cannot be allocated.

```
switchxxxxxx(config-if) # dot1x radius-attributes errors filter-id resources accept
```

20.27 show dot1x advanced

Use the **show dot1x advanced** Privileged EXEC mode command to display 802.1x advanced features for the device or specified interface.

Syntax

show dot1x advanced [interface-id]

Parameters

interface-id—Specify an Ethernet port ID.

Command Mode

Privileged EXEC mode

Example

The following example displays 802.1x advanced features for the device.

```
switchxxxxxx# show dot1x advanced
Guest VLAN: 3978
Guest VLAN Timeout:
Unauthenticated VLANs: 91, 92
Interface Multiple Guest MAC VLAN Legacy- Policy
                Hosts VLAN Authentication Assignment sup Mode Assignment
-----
fel/0/11 Disabled Enabled MAC-and-802.1X Enabled Enable Disabled
fel/0/12 Enabled Disabled Disabled Enabled Enable Disabled
```

```
switchxxxxxx# show dot1x advanced fel/0/11
Interface Multiple Guest MAC VLAN Legacy- Policy
                Hosts VLAN Authentication Assignment sup Mode Assignment
-----
fel/0/11 Disabled Enabled MAC-and-802.1X Enabled Enable
Legacy-Supp mode is disabled
Policy assignment resource err handling: Accept
Single host parameters
Violation action: Discard
Trap: Enabledx
Status: Single-host locked
Violations since last trap: 9
```

21 Ethernet Configuration Commands

21.1 interface

Use the **interface** Global Configuration mode command to enter Interface configuration mode in order to configure an interface.

Syntax

interface *interface-id*

Parameters

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port, Port-channel, VLAN, range, IP interface or tunnel.

Default Configuration

N/A

Command Mode

Interface Configuration (Ethernet, Port-channel, VLAN, range, IP interface or tunnel) mode

Examples

Example 1 - For Gigabit Ethernet ports:

```
switchxxxxxx(config)# interface fe1/0/11
switchxxxxxx(config-if)#
```

Example 2 - For Fast Ethernet ports:

```
switchxxxxxx(config)# interface fa1
switchxxxxxx(config-if)#
```

Example 3 - For port channels (LAGs):

```
switchxxxxxx(config)# interface po1
switchxxxxxx(config-if)#
```

21.2 interface range

Use the **interface range** command to execute a command on multiple ports at the same time.

Syntax

interface range *interface-id-list*

Parameters

interface-id-list—Specify list of interface IDs. The interface ID can be one of the following types: Ethernet port, VLAN, or Port-channel

Default Configuration

N/A

Command Mode

Interface Configuration (Ethernet, Port-channel, or VLAN) mode

User Guidelines

Commands under the interface range context are executed independently on each interface in the range: If the command returns an error on one of the interfaces, it does not stop the execution of the command on other interfaces.

Example

```
switchxxxxxx(config)# interface range fe1/0/11-20
switchxxxxxx(config-if-range)#
```

21.3 shutdown

Use the **shutdown** Interface Configuration (Ethernet, Port-channel) mode command to disable an interface. Use the **no** form of this command to restart a disabled interface.

Syntax

shutdown

no shutdown

Parameters

N/A

Default Configuration

The interface is enabled.

Command Mode

Interface Configuration (Ethernet, Port-channel) mode

Example

Example 1 - The following example disables fe1/0/15 operations.

```
switchxxxxxx(config)# interface fe1/0/15
switchxxxxxx(config-if)# shutdown
switchxxxxxx(config-if)#
```

Example 2 - The following example restarts the disabled Ethernet port.

```
switchxxxxxx(config)# interface fe1/0/15
switchxxxxxx(config-if)# no shutdown
switchxxxxxx(config-if)
```

21.4 description

Use the **description** Interface Configuration (Ethernet, Port-channel) mode command to add a description to an interface. Use the **no** form of this command to remove the description.

Syntax

description *string*

no description

Parameters

string—Specifies a comment or a description of the port to assist the user. (Length: 1–64 characters).

Default Configuration

The interface does not have a description.

Command Mode

Interface Configuration (Ethernet, Port-channel) mode

Example

The following example adds the description 'SW#3' to fe1/0/15.

```
switchxxxxxx(config)# interface fe1/0/15
switchxxxxxx(config-if)# description SW#3
```

21.5 speed

Use the **speed** Interface Configuration (Ethernet, Port-channel) mode command to configure the speed of a given Ethernet interface when not using auto-negotiation. Use the **no** form of this command to restore the default configuration.

Syntax

speed {10 | 100 | 1000}

no speed

Parameters

- **10**—Forces 10 Mbps operation.
- **100**—Forces 100 Mbps operation.
- **1000**—Forces 1000 Mbps operation.

Default Configuration

The port operates at its maximum speed capability.

Command Mode

Interface Configuration (Ethernet, Port-channel) mode

User Guidelines

The **no speed** command in a port-channel context returns each port in the port-channel to its maximum capability.

Example

The following example configures the speed of `fe1/0/15` to 100 Mbps operation.

```
switchxxxxxx(config)# interface fe1/0/15
switchxxxxxx(config-if)# speed 100
```

21.6 duplex

Use the **duplex** Interface Configuration (Ethernet, Port-channel) mode command to configure the full/half duplex operation of a given Ethernet interface when not using auto-negotiation. Use the **no** form of this command to restore the default configuration.

Syntax

duplex {*half* | *full*}

no duplex

Parameters

- **half**—Forces half-duplex operation.
- **full**—Forces full-duplex operation.

Default Configuration

The interface operates in full duplex mode.

Command Mode

Interface Configuration (Port-channel) mode

Example

The following example configures `fe1/0/15` to operate in full duplex mode.

```
switchxxxxxx(config)# interface fe1/0/15
switchxxxxxx(config-if)# duplex full
```

21.7 negotiation

Use the **negotiation** Interface Configuration (Ethernet, Port-channel) mode command to enable auto-negotiation operation for the speed and duplex parameters of a given interface. Use the **no** form of this command to disable auto-negotiation.

Syntax**negotiation** [*capability* [*capability2*... *capability5*]]**no negotiation****Parameters****capability**—Specifies the capabilities to advertise. (Possible values: 10h, 10f, 100h, 100f, 1000f).

- **10h** - Advertise 10 half-duplex
- **10f** - Advertise 10 full-duplex
- **100h** - Advertise 100 half-duplex
- **100f** - Advertise 100 full-duplex
- **1000f** - Advertise 1000 full-duplex

Default ConfigurationIf **capability** is unspecified, defaults to list of all the capabilities of the port.**Command Mode**

Interface Configuration (Ethernet, Port-channel) mode

ExampleThe following example enables auto-negotiation on `fe1/0/15`.

```
switchxxxxxx(config)# interface fe1/0/15
switchxxxxxx(config-if)# negotiation
```

21.8 flowcontrol

Use the **flowcontrol** Interface Configuration (Ethernet, Port-channel) mode command to configure the flow control on a given interface. Use the **no** form of this command to disable flow control.**Syntax****flowcontrol** {*auto* | *on* | *off*}**no flowcontrol****Parameters**

- **auto**—Specifies auto-negotiation of flow control.
- **on**—Enables flow control.
- **off**—Disables flow control.

Default Configuration

Flow control is disabled.

Command Mode

Interface Configuration (Ethernet, Port-channel) mode

User GuidelinesUse the **negotiation** command to enable **flow control auto**.

Example

The following example enables flow control on port `fe1/0/11`

```
switchxxxxxx(config)# interface fe1/0/11
switchxxxxxx(config-if)# flowcontrol on
```

21.9 mdix

Use the **mdix** Interface Configuration (Ethernet) mode command to enable cable crossover on a given interface. Use the **no** form of this command to disable cable crossover.

Syntax

mdix {*on* | *auto*}

no mdix

Parameters

- **on**—Enables manual MDIX.
- **auto**—Enables automatic MDI/MDIX.

Default Configuration

The default setting is On.

Command Mode

Interface Configuration (Ethernet) mode

Example

The following example enables automatic crossover on port `fe1/0/15`.

```
switchxxxxxx(config)# interface fe1/0/15
switchxxxxxx(config-if)# mdix auto
```

21.10 back-pressure

Use the **back-pressure** Interface Configuration (Ethernet) mode command to enable back pressure on a specific interface. Use the **no** form of this command to disable back pressure.

Syntax

back-pressure

no back-pressure

Default Configuration

Back pressure is disabled.

Command Mode

Interface Configuration (Ethernet) mode

User Guidelines

Back-pressure cannot be enabled when EEE is enabled.

Example

The following example enables back pressure on port fe1/0/15.

```
switchxxxxxx(config)# interface fe1/0/15
switchxxxxxx(config-if)# back-pressure
```

21.11 port jumbo-frame

Use the **port jumbo-frame** Global Configuration mode command to enable jumbo frames on the device. Use the **no** form of this command to disable jumbo frames.

Syntax

port jumbo-frame

no port jumbo-frame

Default Configuration

Jumbo frames are disabled on the device.

Command Mode

Global Configuration mode

User Guidelines

This command takes effect only after resetting the device.

Example

The following example enables jumbo frames on the device.

```
switchxxxxxx(config)# port jumbo-frame
```

21.12 clear counters

Use the **clear counters** EXEC mode command to clear counters on all or on a specific interface.

Syntax

clear counters [*interface-id*]

Parameters

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

Default Configuration

All counters are cleared.

Command Mode

EXEC mode

Example

The following example clears the statistics counters for fe1/0/15.

```
switchxxxxxx# clear counters fe1/0/15.
```

21.13 set interface active

Use the **set interface active** EXEC mode command to reactivate an interface that was shut down.

Syntax

set interface active *{interface-id}*

Parameters

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

Command Mode

EXEC mode

User Guidelines

This command is used to activate interfaces that were configured to be active, but were shut down by the system.

Example

The following example reactivates fe1/0/11.

```
switchxxxxxx# set interface active fe1/0/11
```

21.14 errdisable recovery cause

Use the **errdisable recovery cause** Global Configuration mode command to enable automatic re-activation of an interface after Err-Disable shutdown. Use the **no** form of this command to disable automatic re-activation.

Syntax

errdisable recovery cause *{all | port-security | dot1x-src-address | acl-deny | stp-bpdu-guard | stp-loopback-guard}*

no errdisable recovery cause *{all | port-security | dot1x-src-address | acl-deny | stp-bpdu-guard | stp-loopback-guard}*

Parameters

all - Enables the error recovery mechanism for all the reasons

port-security - Enables the error recovery mechanism for the port security Err-Disable state.

dot1x-src-address - Enables the error recovery mechanism for the 802.1x Err-Disable state.

acl-deny - Enables the error recovery mechanism for the ACL Deny Err-Disable state.

stp-bpdu-guard - Enables the error recovery mechanism for the STP BPDU Guard Err-Disable state.

stp-loopback-guard - Enables the error recovery mechanism for the STP Loopback Guard Err-Disable state.

Default Configuration

Automatic re-activation is disabled.

Command Mode

Global Configuration mode

Example

The following example enables automatic re-activation of an interface after Loopback Detection Err-Disable shutdown.

```
switchxxxxxx(config)# errdisable recovery cause loopback-detection
```

21.15 errdisable recovery interval

Use the **errdisable recovery interval** Global Configuration mode command timeout interval to set the error recovery timeout interval. Use the **no** form of this command to return to the default configuration.

Syntax

errdisable recovery interval *seconds*

no errdisable recovery interval

Parameters

seconds—Specifies the error recovery timeout interval in seconds. (Range: 30–86400)

Default Configuration

The default error recovery timeout interval is 300 seconds.

Command Mode

Global Configuration mode

Example

The following example sets the error recovery timeout interval to 10 minutes.

```
switchxxxxxx(config)# errdisable recovery interval 600
```

21.16 show interfaces configuration

Use the **show interfaces configuration** EXEC mode command to display the configuration for all configured interfaces or for a specific interface.

Syntax

show interfaces configuration [*interface-id*]

Parameters

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

Default Configuration

Display all

Command Mode

EXEC mode

Example

The following example displays the configuration of all configured interfaces:

```
switchxxxxxx# show interfaces configuration
```

Port	Type	Duplex	Speed	Neg	Flow control	Admin State	Back Pressure	Mdix Mode
fe1/0/11	1G-Copper	Full	10000	Disabled	Off	Up	Disabled	Off
fe1/0/12	1G-Copper	Full	1000	Disabled	Off	Up	Disabled	Off

PO	Type	Speed	Neg	Flow Control	Admin State
Po1			Disabled	Off	Up

21.17 show interfaces status

Use the **show interfaces status** EXEC mode command to display the status of all interfaces or of a specific interface.

Syntax

show interfaces status [*interface-id*] [*detailed*]

Parameters

- **interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.
- **detailed**—Displays information for non-present ports in addition to present ports.

Command Mode

EXEC mode

Default Configuration

Display for all interfaces.

Example

The following example displays the status of all configured interfaces.

```
switchxxxxxx# show interfaces status
```

Port	Type	Duplex	Speed	Neg	Flow ctrl	Link State	Back Pressure	Mdix Mode
fel/0/11	1G-Copper	Full	1000	Disabled	Off	Up	Disabled	Off
fel/0/12	1G-Copper	--	--	--	--	Down	--	--

PO	Type	Duplex	Speed	Neg	Flow control	Link State
Po1	1G	Full	10000	Disabled	Off	Up

21.18 show interfaces advertise

Use the **show interfaces advertise** EXEC mode command to display auto-negotiation advertisement information for all configured interfaces or for a specific interface.

Syntax

show interfaces advertise [*interface-id* |

Parameters

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

Default Configuration

Display for all interfaces.

Command Mode

EXEC mode

Examples

The following examples display auto-negotiation information.

```
switchxxxxxx# show interfaces advertise
```

Port	Type	Neg	Operational Link Advertisement
fel/0/11	1G-Copper	Enable	1000f, 100f, 10f, 10h
fel/0/12	1G-Copper	Enable	1000f



```

switchxxxxxx# show interfaces advertise fel/0/11
Port: fel/0/11
Type: 1G-Copper
Link state: Up
Auto Negotiation: enabled

                                10h   10f   100h   100f   1000f
                                ---   ---   ----   ----   -----
Admin Local link Advertisement  yes   yes   yes   yes   yes
Oper Local link Advertisement  yes   yes   yes   yes   yes
Remote Local link               no    no    yes   yes   yes
Advertisement                    -    -    -    -    yes
Priority Resolution

switchxxxxxx# show interfaces advertise fel/0/11
Port: fel/0/11
Type: 1G-Copper
Link state: Up
Auto negotiation: disabled.

```

21.19 show interfaces description

Use the **show interfaces description** EXEC mode command to display the description for all configured interfaces or for a specific interface.

Syntax

show interfaces description [*interface-id*]

Parameters

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

Default Configuration

Display description for all interfaces.

Command Mode

EXEC mode

Example

The following example displays the description of all configured interfaces.

```
switchxxxxxx# show interfaces description
```

```

Port          Descriptions
-----
fel/0/11     -----
fel/0/12     Port that should be used for management only
fel/0/13
fel/0/14

PO           Description
-----
Po1         Output
    
```

21.20 show interfaces counters

Use the **show interfaces counters** EXEC mode command to display traffic seen by all the physical interfaces or by a specific interface.

Syntax

show interfaces counters [*interface-id*]

Parameters

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

Default Configuration

Display counters for all interfaces.

Command Mode

EXEC mode

Example

The following example displays traffic seen by all the physical interfaces.

```

switchxxxxxx# show interfaces counters fel/0/11
Port          InUcastPkts  InMcastPkts  InBcastPkts  InOctets
-----
fel/0/11      0            0            0            0
Port          OutUcastPkts  OutMcastPkts  OutBcastPkts  OutOctets
-----
fel/0/11      0            1            35           7051
Alignment Errors: 0
FCS Errors: 0
Single Collision Frames: 0
Multiple Collision Frames: 0
SQE Test Errors: 0
Deferred Transmissions: 0
Late Collisions: 0
Excessive Collisions: 0
    
```



```
Carrier Sense Errors: 0
Oversize Packets: 0
Internal MAC Rx Errors: 0
Symbol Errors: 0
Received Pause Frames: 0
Transmitted Pause Frames: 0
```


The following table describes the fields shown in the display.

Field	Description
InOctets	Number of received octets.
InUcastPkts	Number of received unicast packets.
InMcastPkts	Number of received multicast packets.
InBcastPkts	Number of received broadcast packets.
OutOctets	Number of transmitted octets.
OutUcastPkts	Number of transmitted unicast packets.
OutMcastPkts	Number of transmitted multicast packets.
OutBcastPkts	Number of transmitted broadcast packets.
FCS Errors	Number of frames received that are an integral number of octets in length but do not pass the FCS check.
Single Collision Frames	Number of frames that are involved in a single collision, and are subsequently transmitted successfully.
Multiple Collision Frames	Number of frames that are involved in more than one collision and are subsequently transmitted successfully.
SQE Test Errors	Number of times that the SQE TEST ERROR is received. The SQE TEST ERROR is set in accordance with the rules for verification of the SQE detection mechanism in the PLS Carrier Sense Function as described in IEEE Std. 802.3, 2000 Edition, section 7.2.4.6.
Deferred Transmissions	Number of frames for which the first transmission attempt is delayed because the medium is busy.
Late Collisions	Number of times that a collision is detected later than one slotTime into the transmission of a packet.
Excessive Collisions	Number of frames for which transmission fails due to excessive collisions.
Oversize Packets	Number of frames received that exceed the maximum permitted frame size.
Internal MAC Rx Errors	Number of frames for which reception fails due to an internal MAC sublayer receive error.
Received Pause Frames	Number of MAC Control frames received with an opcode indicating the PAUSE operation.
Transmitted Pause Frames	Number of MAC Control frames transmitted on this interface with an opcode indicating the PAUSE operation.

21.21 show ports jumbo-frame

Use the **show ports jumbo-frame** EXEC mode command to display the whether jumbo frames are enabled on the device.

Syntax

show port jumbo-frame

Parameters

N/A

Default Configuration

N/A

Command Mode

EXEC mode

Example

The following example displays whether jumbo frames are enabled on the device.

```
switchxxxxxx# show ports jumbo-frame
Jumbo frames are disabled
Jumbo frames will be enabled after reset
```

21.22 show errdisable recovery

Use the **show errdisable recovery** EXEC mode command to display the Err-Disable configuration of the device.

Syntax

show errdisable recovery

Parameters

N/A

Default Configuration

N/A

Command Mode

EXEC mode

Example

The following example displays the Err-Disable configuration.

```
switchxxxxxx# show errdisable recovery
Timer interval: 300 Seconds
```

Reason	Automatic Recovery
-----	-----
port-security	Disable
dot1x-src-address	Disable
acl-deny	Enable
stp-bpdu-guard	Disable
stp-loopback-guard	Disable

21.23 show errdisable interfaces

Use the **show errdisable interfaces** EXEC mode command to display the Err-Disable state of all interfaces or of a specific interface.

Syntax

show errdisable interfaces [*interface-id*]

Parameters

- **interface**—Interface number
- **port-channel-number**—Port channel index.

Default Configuration

Display for all interfaces.

Command Mode

EXEC mode

Example

The following example displays the Err-Disable state of all interfaces.

```
switchxxxxxx# show errdisable interfaces
Interface      Reason          Automatic Recovery
-----
fe1/0/11      port-security   No
fe1/0/112    acl-deny        Yes
```

21.24 storm-control broadcast enable

Use the **storm-control broadcast enable** Interface Configuration mode command to enable storm control on a port. Use the **no** form of this command to disable storm control.

Syntax

storm-control broadcast enable

no storm-control broadcast enable

**Parameters**

This command has no arguments or keywords.

Default Configuration

Disabled

Command Mode

Interface Configuration mode (Ethernet)

User Guidelines

Use the [storm-control include-multicast](#) Interface Configuration command to count Multicast packets and optionally unknown Unicast packets in the storm control calculation.

Example

```
switchxxxxxx(config)# interface fe1/0/11
switchxxxxxx(config-if)# storm-control broadcast enable
```

21.25 storm-control broadcast level kbps

Use the **storm-control broadcast level** Interface Configuration mode command to configure the maximum rate of broadcast on a port. Use the **no** form of this command to return to default.

Syntax

storm-control broadcast level kbps *kbps*

no storm-control broadcast level

Parameters

3500-10G

Default Configuration

1000

Command Mode

Interface Configuration mode (Ethernet)

User Guidelines

Use the **storm-control broadcast enable** Interface Configuration command to enable storm control.

The calculated rate includes the 20 bytes of Ethernet framing overhead (preamble+SFD+IPG).

Example

```
switchxxxxxx(config)# interface fe1/0/11
switchxxxxxx(config-if)# storm-control broadcast level kbps 12345
```

21.26 storm-control include-multicast

Use the **storm-control include-multicast** Interface Configuration mode command to count Multicast packets in a Broadcast storm control. Use the **no** form of this command to disable counting of Multicast packets in the Broadcast storm control.

Syntax

storm-control include-multicast [*unknown-unicast*]

no storm-control include-multicast

Parameters

unknown-unicast—Specifies also the count of unknown unicast packets.

Default Configuration

Disabled

Command Mode

Interface Configuration mode (Ethernet)

Example

```
switchxxxxxx(config)# interface fe1/0/11  
switchxxxxxx(config-if)# storm-control include-multicast
```

22 PHY Diagnostics Commands

22.1 test cable-diagnostics tdr

Use the **test cable-diagnostics tdr** Privileged EXEC mode command to use Time Domain Reflectometry (TDR) technology to diagnose the quality and characteristics of a copper cable attached to a port.

Syntax

test cable-diagnostics tdr interface *interface-id*

Parameters

interface-id—Specifies an Ethernet port ID.

Command Mode

Privileged EXEC mode

User Guidelines

The port to be tested should be shut down during the test, unless it is a combination port with fiber port active.

The maximum length of cable for the TDR test is 120 meters.

Example

The following examples test the copper cables attached to ports 7 and 8.

```
switchxxxxx# test cable-diagnostics tdr interface fe1/0/17
Cable is open at 64 meters
switchxxxxx# test cable-diagnostics tdr interface fe1/0/18
Can't perform the test on fiber ports
```

22.2 show cable-diagnostics tdr

Use the **show cable-diagnostics tdr** EXEC mode command to display information on the last Time Domain Reflectometry (TDR) test performed on all copper ports or on a specific copper port.

Syntax

show cable-diagnostics tdr [*interface interface-id*]

Parameters

interface-id—Specifies an Ethernet port ID.

Default Configuration

All ports are displayed.

Command Mode

EXEC mode

User Guidelines

The maximum length of cable for the TDR test is 120 meters.

Example

The following example displays information on the last TDR test performed on all copper ports.

```
switchxxxxxx# show cable-diagnostics tdr

Port      Result      Length      Date
----      -
          [meters]
          -----

fe1/0/11  OK
fe1/0/12  Short       50          13:32:00 23 July 2010
fe1/0/13  Test has not been performed
fe1/0/14  Open        64          13:32:00 23 July 2010
fe1/0/15  Fiber       -           -
```

22.3 show cable-diagnostics cable-length

Use the **show cable-diagnostics cable-length** EXEC mode command to display the estimated copper cable length attached to all ports or to a specific port.**Syntax****show cable-diagnostics cable-length** [*interface interface-id*]**Parameters****interface-id**—Specifies an Ethernet port ID.**Default Configuration**

All ports are displayed.

Command Mode

EXEC mode

User Guidelines

The port must be active and working at 100 M or 1000 M.

Example

The following example displays the estimated copper cable length attached to all ports.

```
switchxxxxxx# show cable-diagnostics cable-length

Port          Length [meters]
-----
fe1/0/11      < 50
fe1/0/12      Copper not active
fe1/0/13      110-140
fe1/0/14      Fiber
```

22.4 show fiber-ports optical-transceiver

Use the **show fiber-ports optical-transceiver** EXEC mode command to display the optical transceiver diagnostics.

Syntax

show fiber-ports optical-transceiver [*interface interface-id*] [*detailed*]

Parameters

- **interface-id**—Specifies an Ethernet port ID.
- **detailed**—Displays detailed diagnostics.

Command Mode

EXEC mode

Example

The following examples display the optical transceiver diagnostics results.

```
switchxxxxxx# show fiber-ports optical-transceiver

Port      Temp  Voltage Current  Output Input  LOS
          Power Power
-----
fe1/0/11   W     OK     OK     OK     OK     OK
fe1/0/12   OK    OK     OK     E     OK     OK

Temp      - Internally measured transceiver temperature
Voltage   - Internally measured supply voltage
Current   - Measured TX bias current
Output Power - Measured TX output power in milliWatts
Input Power - Measured RX received power in milliWatts
LOS       - Loss of signal
N/A - Not Available, N/S - Not Supported,
W - Warning, E - Error
```

```
switchxxxxxx# show fiber-ports optical-transceiver detailed
```

```
  Port      Temp  Voltage Current Output  Input  LOS
           [C]   [Volt]  [mA]   Power  Power
                   [mWatt] [mWatt]
-----
fe1/0/11    Copper
fe1/0/16    Copper
fe1/0/17    28    3.32   7.26   3.53   3.68   No
fe1/0/18    29    3.33   6.50   3.53   3.71   No
Temp        - Internally measured transceiver temperature
Voltage     - Internally measured supply voltage
Current     - Measured TX bias current
Output Power - Measured TX output power in milliWatts
Input Power - Measured RX received power in milliWatts
LOS         - Loss of signal
N/A - Not Available, N/S - Not Supported, W - Warning, E - Error
```



23 Green Ethernet

23.1 green-ethernet energy-detect (global)

Use the **green-ethernet energy-detect** Global Configuration mode command to enable Green-Ethernet Energy-Detect mode globally. Use the **no** form of this command to disabled it.

Syntax

green-ethernet energy-detect
no green-ethernet energy-detect

Parameters

N/A

Default Configuration

Enabled.

Command Mode

Global Configuration mode

Example

```
switchxxxxxx(config)# green-ethernet energy-detect
```

23.2 green-ethernet energy-detect (interface)

Use the **green-ethernet energy-detect** Interface configuration mode command to enable green-ethernet Energy-Detect mode on a port. Use the **no** form of this command, to disable it on a port.

Syntax

green-ethernet energy-detect
no green-ethernet energy-detect

Parameters

N/A

Default Configuration

Enabled

Command Mode

Interface configuration mode (Ethernet)

User Guidelines

Energy-Detect can work only when the port is a copper port. When a port is enabled for auto selection, copper/fiber Energy-Detect cannot work.

It takes the PHY ~5 seconds to fall into sleep mode when the link is lost after normal operation.

Example

```
switchxxxxxx(config)# interface fe1/0/11
switchxxxxxx(config-if)# green-ethernet energy-detect
```

23.3 green-ethernet short-reach (global)

Use the **green-ethernet short-reach** Global Configuration mode command to enable green-ethernet short-reach mode globally. Use the **no** form of this command to disabled it.

Syntax

green-ethernet short-reach

no green-ethernet short-reach

Parameters

N/A

Default Configuration

Disabled.

Command Mode

Global Configuration mode

Example

```
switchxxxxxx(config)# green-ethernet short-reach
```

23.4 green-ethernet short-reach (interface)

Use the **green-ethernet short-reach** Interface Configuration mode command to enable green-ethernet short-reach mode on a port. Use the **no** form of this command to disable it on a port.

Syntax

green-ethernet short-reach

no green-ethernet short-reach

Parameters

N/A

Default Configuration

Disabled.

Command Mode

Interface Configuration mode (Ethernet)

User Guidelines

When **Short-Reach** mode is enabled and is not forced, the VCT (Virtual Cable Tester) length check must be performed. The VCT length check can be performed only on a copper port operating at a speed of 1000 Mbps. If the media is not copper or the link speed is not 1000 Mbps and short-reach mode is not forced (by [green-ethernet short-reach force](#)), Short-Reach mode is not applied.

When the interface is set to enhanced mode, after the VCT length check has completed and set the power to low, an active monitoring for errors is done continuously. In the case of errors crossing a certain threshold, the PHY will be reverted to long reach.

Note that EEE cannot be enabled if the Short-Reach mode is enabled.

Example

```
switchxxxxxx(config)# interface fe1/0/11
switchxxxxxx(config-if)# green-ethernet short-reach
```

23.5 green-ethernet short-reach force

Use the **green-ethernet short-reach force** Interface Configuration mode command to force short-reach mode on a port. Use the **no** form of this command to return to default.

Syntax

green-ethernet short-reach force

no green-ethernet short-reach force

Parameters

N/A

Default Configuration

Short-reach mode is not forced.

Command Mode

Interface Configuration mode (Ethernet)

Example

```
switchxxxxxx(config)# interface fe1/0/11
switchxxxxxx(config-if)# green-ethernet short-reach force
```

23.6 green-ethernet short-reach threshold

Use the **green-ethernet short-reach threshold** Global Configuration mode command to set the maximum cable length for applying short-reach. Use the **no** form of this command to return to default.

Syntax**green-ethernet short-reach threshold** *cable-length***no green-ethernet short-reach threshold****Parameters****cable-length**—Specifies the maximum cable length (in meters) measured by VCT that allows applying short-reach mode (cable-length 0–70 meters)**Default Configuration**

The default length is 40 meters.

Command Mode

Global Configuration mode

User Guidelines

Note that the automatic cable length measurement accuracy is +/-10 meters. i.e. a cable with a real length of 30 m may be evaluated in the range of 20m–40m. Length performance depends on the link partner signal quality, cable quality and whether the link partner also operates in short-reach mode.

Marvell recommends a default of 50m for any cable type.

However, Marvell tests show that the link partner can operate error free with a cable length of up to 80 m (cat 5e).

The user may choose to change the threshold parameter under certain circumstances.

Setting the threshold to 0 meters, basically results in the short reach feature always being disabled, because the threshold is always exceeded.

Example

```
switchxxxxxx(config)# interface fe1/0/11
switchxxxxxx(config-if)# green-ethernet short-reach threshold 30
```

23.7 green-ethernet power-meter reset

Use the **green-ethernet power meter reset** Privileged EXEC mode command to reset the power save meter.

Syntax**green-ethernet power-meter reset****Parameters**

N/A

Default Configuration

N/A

Command Mode

Privileged EXEC mode.

Example

```
switchxxxxxx(config)# green-ethernet power-meter reset
```

23.8 show green-ethernet

Use the **show green-ethernet** Privileged EXEC mode command to display green-ethernet configuration and information.

Syntax

show green-ethernet [*interface-id*]

Parameters

interface-id—Specifies an Ethernet port.

Default Configuration

When no port is specified, information for all ports is displayed.

Command Mode

Privileged EXEC mode

User Guidelines

The following describes the reasons for non-operation displayed by this command.

If there are a several reasons, then only the highest priority reason is displayed.

Energy-detect Non-operational Reasons		
Priority	Reason	Description
1	NP	Port is not present
2	LT	Link Type is not supported (fiber, auto media select)
3	LU	Port Link is up – NA

Short-Reach Non-operational Reasons		
Priority	Reason	Description
1	NP	Port is not present
2	LT	Link Type is not supported (fiber)
3	LS	Link Speed Is not Supported (100M,10M,10G)
4	LL	Link Length received from VCT Test exceed threshold
6	LD	Port Link is Down – NA

Example

```
switchxxxxxx# show green-ethernet
Energy-Detect mode: Enabled
```

Short-Reach mode: Disabled

Power Consumption: 76% (3.31W out of maximum 4.33W)

Cumulative Energy Saved: 33 [Watt*Hour]

Short-Reach cable length threshold: 50m

Port	Energy-Detect		Short-Reach			VCT Cable Length
	Admin	Oper Reason	Admin	Force Oper	Reason	
-----	-----	-----	-----	-----	-----	-----
fel/0/11	on	on	off	off	off	
fel/0/12	on	off LU	on	off	off	< 50
fel/0/13	on	off LU	off	off	off	

24 Port Channel Commands

24.1 port-channel create

Use the **port-channel create** Global Configuration mode command to create a port channel. Use the **no** form of this command to remove the port-channel.

Syntax

port-channel create *port-channel*

no port-channel create *port-channel*

Parameters

port-channel—Specifies the port channel number. (Range: 1–64)

Default Configuration

No port channels exist.

Command Mode

Global Configuration mode

Example

The following example creates port-channel number 1.

```
switchxxxxxx(config)# port-channel create 1
```

24.2 channel-group

Use the **channel-group** Interface Configuration (Ethernet) mode command to associate a port with a port-channel. Use the **no** form of this command to remove a port from a port-channel.

Syntax

channel-group *port-channel mode {on | auto}*

no channel-group

Parameters

- **port-channel**—Specifies the port channel number for the current port to join.
- **mode**—Specifies the mode of joining the port channel. The possible values are:
 - **on**—Forces the port to join a channel without an LACP operation.
 - **auto**—Forces the port to join a channel as a result of an LACP operation.

Default Configuration

The port is not assigned to a port-channel.

Command Mode

Interface Configuration (Ethernet) mode

Default mode is **on**.

Example

The following example forces port `fe1/0/11` to join port-channel 1 without an LACP operation.

```
switchxxxxxx(config)# interface fe1/0/11
switchxxxxxx(config-if)# channel-group 1 mode on
```

24.3 port-channel load-balance

Use the **port-channel load-balance** Global Configuration mode command to configure the load balancing policy of the port channeling. Use the **no** form of this command to reset to default.

Syntax

port-channel load-balance {*src-dst-mac* | *src-dst-ip* | *src-dst-mac-ip*}

port-channel load-balance {*src-dst-mac* | *src-dst-ip* | *src-dst-mac-ip* | *src-dst-mac-ip-port*}

no port-channel load-balance

Parameters

- **src-dst-mac**—Port channel load balancing is based on the source and destination MAC address.
- **src-dst-mac-ip**—Port channel load balancing is based on the source and destination of MAC and IP addresses.
- **src-dst-mac-ip-port**—Port channel load balancing is based on the source and destination of MAC and IP addresses and on source and destination TCP/UDP port numbers.
- **src-dst-ip**—Port channel load balancing is based on the source and destination IP address.

Default Configuration

`src-dst-mac` is the default option.

Command Mode

Global Configuration mode

User Guidelines

In **src-dst-mac-ip-port** load balancing policy, fragmented packets might be reordered.

Example

```
switchxxxxxx(config)# port-channel load-balance src-dst-mac
switchxxxxxx(config)# port-channel load-balance src-dst-mac-ip
```

24.4 show interfaces port-channel

Use the **show interfaces port-channel** EXEC mode command to display port-channel information for all port channels or for a specific port channel.

Syntax

show interfaces port-channel [*interface-id*]

Parameters

interface-id—Specify an interface ID. The interface ID must be a Port Channel.

Command Mode

EXEC mode

Examples

Example 1 - The following example displays information on all port-channels.

```
switchxxxxxx# show interfaces port-channel
Load balancing: src-dst-mac.
Gathering information...
Channel  Ports
-----  -----
Po1      Active: fe1/0/11,Inactive: fe1/0/12-3
Po2      Active: fe1/0/15 Inactive: fe1/0/14
```

Example 2 - The following example displays information on port-channels containing port 1

```
switchxxxxxx# show interfaces switchport fe1/0/11
Gathering information...
Name: fe1/0/11
Switchport: enable
Administrative Mode: access
Operational Mode: down
Access Mode VLAN: 1
Access Multicast TV VLAN: none
Trunking Native Mode VLAN: 1
Trunking VLANs Enabled: 1
                        2-4094 (Inactive)
General PVID: 1
General VLANs Enabled: none
General Egress Tagged VLANs Enabled: none
General Forbidden VLANs: none
General Ingress Filtering: enabled
General Acceptable Frame Type: all
General GVRP status: disabled
Customer Mode VLAN: none
```

```
Private-vlan promiscuous-association primary VLAN: none
Private-vlan promiscuous-association Secondary VLANs Enabled: none
Private-vlan host-association primary VLAN: none
Private-vlan host-association Secondary VLAN Enabled: none
DVA: disable
```

25 Address Table Commands

25.1 bridge multicast filtering

Use the **bridge multicast filtering** Global Configuration mode command to enable the filtering of Multicast addresses. Use the **no** form of this command to disable Multicast address filtering.

Syntax

bridge multicast filtering

no bridge multicast filtering

Default Configuration

Multicast address filtering is disabled. All Multicast addresses are flooded to all ports.

Command Mode

Global Configuration mode

User Guidelines

When this feature is enabled, unregistered Multicast traffic (as opposed to registered) will still be flooded.

All registered Multicast addresses will be forwarded to the Multicast groups. There are two ways to manage Multicast groups, one is the IGMP Snooping feature, and the other is the [bridge multicast forward-all](#) command.

Example

The following example enables bridge Multicast filtering.

```
switchxxxxxx(config)# bridge multicast filtering
```

25.2 bridge multicast mode

Use the **bridge multicast mode** Interface Configuration (VLAN) mode command to configure the Multicast bridging mode. Use the **no** form of this command to return to the default configuration.

Syntax

bridge multicast mode {*mac-group* | *ip-group* | *ip-src-group*}

no bridge multicast mode

Parameters

- **mac-group**—Specifies that Multicast bridging is based on the packet's VLAN and MAC address.
- **ipv4-group**—Specifies that Multicast bridging is based on the packet's VLAN and MAC address for non-IPv4 packets, and on the packet's VLAN and IPv4 destination address for IPv4 packets.

- **ipv4-src-group**—Specifies that Multicast bridging is based on the packet's VLAN and MAC address for non-IPv4 packets, and on the packet's VLAN, IPv4 destination address and IPv4 source address for IPv4 packets.

Default Configuration

The default mode is mac-group.

Command Mode

Interface Configuration (VLAN) mode

User Guidelines

Use the mac-group option when using a network management system that uses a MIB based on the Multicast MAC address. Otherwise, it is recommended to use the ipv4-group or ipv4-src-group mode, because there is no overlapping of IPv4 Multicast addresses in these modes.

For each Forwarding Data Base (FDB) mode, use different CLI commands to configure static entries in the FDB, as described in the following table:

FDB Mode	CLI Commands	
mac-group	bridge multicast address	bridge multicast forbidden address
ipv4-group	bridge multicast ip-address	bridge multicast forbidden ip-addresss
ipv4-src-group	bridge multicast source group	bridge multicast forbidden source group

The following table describes the actual data that is written to the Forwarding Data Base (FDB) as a function of the IGMP version that is used in the network:

FDB mode	IGMP version 2	IGMP version 3
mac-group	MAC group address	MAC group address
ipv4-group	IP group address	IP group address
ipv4-src-group	(*)	IP source and group addresses

(*) Note that (*,G) cannot be written to the FDB if the mode is **ipv4-src-group**. In that case, no new FDB entry is created, but the port is added to the static (S,G) entries (if they exist) that belong to the requested group. It is recommended to set the FDB mode to ipv4-group or mac-group for IGMP version 2.

If an application on the device requests (*,G), the operating FDB mode is changed to ipv4-group.

Example

The following example configures the Multicast bridging mode as an ipv4-group on VLAN 2.

```
switchxxxxxx(config)# interface vlan 2
switchxxxxxx(config-if)# bridge multicast mode ipv4-group
```

25.3 bridge multicast address

Use the **bridge multicast address** Interface Configuration (VLAN) mode command to register a MAC-layer Multicast address in the bridge table and statically add or remove ports to or from the group. Use the **no** form of this command to unregister the MAC address.

Syntax

bridge multicast address {*mac-multicast-address* | *ipv4-multicast-address*} [*add* | *remove*]
{*ethernet interface-list* | *port-channel port-channel-list*}

no bridge multicast address {*mac-multicast-address*}

Parameters

- **mac-multicast-address** | **ipv4-multicast-address**—Specifies the group Multicast address.
- **add**—Adds ports to the group.
- **remove**—Removes ports from the group.
- **ethernet interface-list**—Specifies a list of Ethernet ports. Separate nonconsecutive Ethernet ports with a comma and no spaces. Use a hyphen to designate a range of ports.
- **port-channel port-channel-list**—Specifies a list of port channels. Separate nonconsecutive port-channels with a comma and no spaces; use a hyphen to designate a range of port channels.

Default Configuration

No Multicast addresses are defined.

If **ethernet interface-list** or **port-channel port-channel-list** is specified without specifying **add** or **remove**, the default option is **add**.

Command Mode

Interface Configuration (VLAN) mode

User Guidelines

To register the group in the bridge database without adding or removing ports or port channels, specify the **mac-multicast-address** parameter only.

Static Multicast addresses can be defined on static VLANs only.

You can execute the command before the VLAN is created.

Examples

Example 1 - The following example registers the MAC address to the bridge table:

```
switchxxxxxx(config)# interface vlan 8  
switchxxxxxx(config-if)# bridge multicast address 01:00:5e:02:02:03
```

Example 2 - The following example registers the MAC address and adds ports statically.

```
switchxxxxxx(config)# interface vlan 8  
switchxxxxxx(config-if)# bridge multicast address 01:00:5e:02:02:03 add  
fe1/0/11-2
```

25.4 bridge multicast forbidden address

Use the **bridge multicast forbidden address** Interface Configuration (VLAN) mode command to forbid adding or removing a specific Multicast address to or from specific ports. Use the **no** form of this command to restore the default configuration.

Syntax

bridge multicast forbidden address {*mac-multicast-address* | *ipv4-multicast-address*} {**add** | **remove**} {*ethernet interface-list* | **port-channel** *port-channel-list*}

no bridge multicast forbidden address {*mac-multicast-address*}

Parameters

- **mac-multicast-address** | **ipv4-multicast-address**—Specifies the group Multicast address.
- **add**—Forbids adding ports to the group.
- **remove**—Forbids removing ports from the group.
- **ethernet** *interface-list*—Specifies a list of Ethernet ports. Separate nonconsecutive Ethernet ports with a comma and no spaces. Use a hyphen to designate a range of ports.
- **port-channel** *port-channel-list*—Specifies a list of port channels. Separate nonconsecutive port-channels with a comma and no spaces. Use a hyphen to designate a range of port channels.

Default Configuration

No forbidden addresses are defined.

Default option is **add**.

Command Mode

Interface Configuration (VLAN) mode

User Guidelines

Before defining forbidden ports, the Multicast group should be registered, using [bridge multicast address](#).

You can execute the command before the VLAN is created.

Example

The following example forbids MAC address 0100.5e02.0203 on port fe1/0/19 within VLAN 8.

```
switchxxxxxx(config)# interface vlan 8
switchxxxxxx(config-if)# bridge multicast address 0100.5e02.0203
switchxxxxxx(config-if)# bridge multicast forbidden address
0100.5e02.0203 add fe1/0/19
```

25.5 bridge multicast ip-address

Use the **bridge multicast ip-address** Interface Configuration (VLAN) mode command to register IP-layer Multicast addresses to the bridge table, and statically add or remove ports to or from the group. Use the **no** form of this command to unregister the IP address.

Syntax

bridge multicast ip-address *ip-multicast-address* [[**add** | **remove**] {*ethernet interface-list* | *port-channel port-channel-list*}]

no bridge multicast ip-address *ip-multicast-address*

Parameters

- **ip-multicast-address**—Specifies the group IP Multicast address.
- **add**—Adds ports to the group.
- **remove**—Removes ports from the group.
- **ethernet interface-list**—Specifies a list of Ethernet ports. Separate nonconsecutive Ethernet ports with a comma and no spaces. Use a hyphen to designate a range of ports.
- **port-channel port-channel-list**—Specifies a list of port channels. Separate nonconsecutive port-channels with a comma and no spaces. Use a hyphen to designate a range of port channels.

Default Configuration

No Multicast addresses are defined.

Default option is **add**.

Command Mode

Interface Configuration (VLAN) mode

User Guidelines

To register the group in the bridge database without adding or removing ports or port channels, specify the **ip-multicast-address** parameter only.

Static Multicast addresses can be defined on static VLANs only.

You can execute the command before the VLAN is created.

Example

The following example registers the specified IP address to the bridge table:

```
switchxxxxxx(config)# interface vlan 8
switchxxxxxx(config-if)# bridge multicast ip-address 239.2.2.2
```

The following example registers the IP address and adds ports statically.

```
switchxxxxxx(config)# interface vlan 8
switchxxxxxx(config-if)# bridge multicast ip-address 239.2.2.2 add
fe1/0/19
```

25.6 bridge multicast forbidden ip-address

Use the **bridge multicast forbidden ip-address** Interface Configuration (VLAN) mode command to forbid adding or removing a specific IP Multicast address to or from specific ports. Use the no form of this command to restore the default configuration.

Syntax

bridge multicast forbidden ip-address *{ip-multicast-address}* **{add | remove}** **{ethernet interface-list | port-channel port-channel-list}**

no bridge multicast forbidden ip-address *{ip-multicast-address}*

Parameters

- **ip-multicast-address**—Specifies the group IP Multicast address.
- **add**—Forbids adding ports to the group.
- **remove**—Forbids removing ports from the group.
- **ethernet interface-list**—Specifies a list of Ethernet ports. Separate nonconsecutive Ethernet ports with a comma and no spaces. Use a hyphen to designate a range of ports.
- **port-channel port-channel-list**—Specifies a list of port channels. Separate nonconsecutive port-channels with a comma and no spaces. Use a hyphen to designate a range of port channels.

Default Configuration

No forbidden addresses are defined.

Command Mode

Interface Configuration (VLAN) mode

User Guidelines

Before defining forbidden ports, the Multicast group should be registered.

You can execute the command before the VLAN is created.

Example

The following example registers IP address 239.2.2.2, and forbids the IP address on port fe1/0/19 within VLAN 8.

```
switchxxxxxx(config)# interface vlan 8
switchxxxxxx(config-if)# bridge multicast ip-address 239.2.2.2
switchxxxxxx(config-if)# bridge multicast forbidden ip-address
239.2.2.2 add fe1/0/19
```

25.7 bridge multicast source group

Use the **bridge multicast source group** Interface Configuration (VLAN) mode command to register a source IP address - Multicast IP address pair to the bridge table, and statically add or remove ports to or from the source-group. Use the no form of this command to unregister the source-group-pair.

Syntax

bridge multicast source ip-address group ip-multicast-address **[[add | remove] {ethernet interface-list | port-channel port-channel-list}]**

no bridge multicast source ip-address group ip-multicast-address

Parameters

- **ip-address**—Specifies the source IP address.

- **ip-multicast-address**—Specifies the group IP Multicast address.
- **add**—Adds ports to the group for the specific source IP address.
- **remove**—Removes ports from the group for the specific source IP address.
- **ethernet interface-list**—Specifies a list of Ethernet ports. Separate nonconsecutive Ethernet ports with a comma and no spaces. Use a hyphen to designate a range of ports.
- **port-channel port-channel-list**—Specifies a list of port channels. Separate nonconsecutive port-channels with a comma and no spaces; use a hyphen to designate a range of port channels.

Default Configuration

No Multicast addresses are defined.

The default option is **add**.

Command Mode

Interface Configuration (VLAN) mode

User Guidelines

You can execute the command before the VLAN is created.

Example

The following example registers a source IP address - Multicast IP address pair to the bridge table:

```
switchxxxxxx(config)# interface vlan 8
switchxxxxxx(config-if)# bridge multicast source 13.16.1.1 group
239.2.2.2
```

25.8 bridge multicast forbidden source group

Use the **bridge multicast forbidden source group** Interface Configuration (VLAN) mode command to forbid adding or removing a specific IP source address - Multicast address pair to or from specific ports. Use the no form of this command to return to the default configuration.

Syntax

bridge multicast forbidden source *ip-address* **group** *ip-multicast-address* {**add** | **remove**}
{**ethernet interface-list** | **port-channel port-channel-list**}

no bridge multicast forbidden source *ip-address* **group** *ip-multicast-address*

Parameters

- **ip-address**—Specifies the source IP address.
- **ip-multicast-address**—Specifies the group IP Multicast address.
- **add**—Forbids adding ports to the group for the specific source IP address.
- **remove**—Forbids removing ports from the group for the specific source IP address.
- **ethernet interface-list**—Specifies a list of Ethernet ports. Separate nonconsecutive Ethernet ports with a comma and no spaces. Use a hyphen to designate a range of ports.
- **port-channel port-channel-list**—Specifies a list of port channels. Separate nonconsecutive port-channels with a comma and no spaces; use a hyphen to designate a range of port channels.

Default Configuration

No forbidden addresses are defined.

Command Mode

Interface Configuration (VLAN) mode

User Guidelines

Before defining forbidden ports, the Multicast group should be registered.

You can execute the command before the VLAN is created.

Example

The following example registers a source IP address - Multicast IP address pair to the bridge table, and forbids adding the pair to port `fe1/0/19` on VLAN 8:

```
switchxxxxxx(config)# interface vlan 8
switchxxxxxx(config-if)# bridge multicast source 13.16.1.1 group
239.2.2.2
switchxxxxxx(config-if)# bridge multicast forbidden source 13.16.1.1
group 239.2.2.2 add fe1/0/19
```

25.9 bridge multicast ipv6 mode

Use the **bridge multicast ipv6 mode** Interface Configuration (VLAN) mode command to configure the Multicast bridging mode for IPv6 Multicast packets. Use the no form of this command to return to the default configuration.

Syntax

bridge multicast ipv6 mode {*mac-group* | *ip-group* | *ip-src-group*}

no bridge multicast ipv6 mode

Parameters

- **mac-group**—Specifies that Multicast bridging is based on the packet's VLAN and MAC destination address.
- **ip-group**—Specifies that Multicast bridging is based on the packet's VLAN and IPv6 destination address for IPv6 packets.
- **ip-src-group**—Specifies that Multicast bridging is based on the packet's VLAN, IPv6 destination address and IPv6 source address for IPv6 packets.

Default Configuration

The default mode is **mac-group**.

Command Mode

Interface Configuration (VLAN) mode

User Guidelines

Use the **mac-group** mode when using a network management system that uses a MIB based on the Multicast MAC address.

For each Forwarding Data Base (FDB) mode, use different CLI commands to configure static entries for IPv6 Multicast addresses in the FDB, as described in the following table::

FDB Mode	CLI Commands	
mac-group	bridge multicast address	bridge multicast forbidden address
ipv6-group	bridge multicast ipv6 ip-address	bridge multicast ipv6 forbidden ip-address
ipv6-src-group	bridge multicast ipv6 source group	bridge multicast ipv6 forbidden source group

The following table describes the actual data that is written to the Forwarding Data Base (FDB) as a function of the MLD version that is used in the network:(*) Note that (*,G) cannot be written to the

FDB mode	MLD version 1	MLD version 2
mac-group	MAC group address	MAC group address
ipv6-group	IPv6 group address	IPv6 group address
ipv6-src-group	(*)	IPv6 source and group addresses

FDB if the mode is **ip-src-group**. In that case, no new FDB entry is created, but the port is added to the (S,G) entries (if they exist) that belong to the requested group. If an application on the device requests (*,G), the operating FDB mode is changed to **ip-group**.

You can execute the command before the VLAN is created.

Example

The following example configures the Multicast bridging mode as an **ip-group** on VLAN 2.

```
switchxxxxxx(config)# interface vlan 2
switchxxxxxx(config-if)# bridge multicast ipv6 mode ip-group
```

25.10 bridge multicast ipv6 ip-address

Use the **bridge multicast ipv6 ip-address** Interface Configuration (VLAN) mode command to register an IPv6 Multicast address to the bridge table, and statically add or remove ports to or from the group. Use the **no** form of this command to unregister the IPv6 address.

Syntax

bridge multicast ipv6 ip-address *ipv6-multicast-address* **[[add | remove] {ethernet interface-list | port-channel port-channel-list}]**

no bridge multicast ipv6 ip-address *ip-multicast-address*

Parameters

- **ipv6-multicast-address**—Specifies the group IPv6 multicast address.
- **add**—Adds ports to the group.
- **remove**—Removes ports from the group.

- **ethernet** *interface-list*—Specifies a list of Ethernet ports. Separate nonconsecutive Ethernet ports with a comma and no spaces; use a hyphen to designate a range of ports.
- **port-channel** *port-channel-list*—Specifies a list of port channels. Separate nonconsecutive port-channels with a comma and no spaces. Use a hyphen to designate a range of port channels.

Default Configuration

No Multicast addresses are defined.

The default option is **add**.

Command Mode

Interface Configuration (VLAN) mode

User Guidelines

To register the group in the bridge database without adding or removing ports or port channels, specify the **ipv6-multicast-address** parameter only.

Static Multicast addresses can be defined on static VLANs only.

You can execute the command before the VLAN is created.

Example

Example 1 - The following example registers the IPv6 address to the bridge table:

```
switchxxxxxx(config)# interface vlan 8
switchxxxxxx(config-if)# bridge multicast ipv6 ip-address
FF00:0:0:0:4:4:4:1
```

Example 2 - The following example registers the IPv6 address and adds ports statically.

```
switchxxxxxx(config)# interface vlan 8
switchxxxxxx(config-if)# bridge multicast ipv6 ip-address
FF00:0:0:0:4:4:4:1 add fe1/0/11-2
```

25.11 bridge multicast ipv6 forbidden ip-address

Use the **bridge multicast ipv6 forbidden ip-address** Interface Configuration (VLAN) mode command to forbid adding or removing a specific IPv6 Multicast address to or from specific ports. To restore the default configuration, use the **no** form of this command.

Syntax

bridge multicast ipv6 forbidden ip-address *{ipv6-multicast-address}* **{add | remove}** *{ethernet interface-list | port-channel port-channel-list}*

no bridge multicast ipv6 forbidden ip-address *{ipv6-multicast-address}*

Parameters

- **ipv6-multicast-address**—Specifies the group IPv6 Multicast address.
- **add**—Forbids adding ports to the group.

- **remove**—Forbids removing ports from the group.
- **ethernet interface-list**—Specifies a list of Ethernet ports. Separate nonconsecutive Ethernet ports with a comma and no spaces. Use a hyphen to designate a range of ports.
- **port-channel port-channel-list**—Specifies a list of port channels. Separate nonconsecutive port-channels with a comma and no spaces. Use a hyphen to designate a range of port channels.

Default Configuration

No forbidden addresses are defined.

The default option is **add**.

Command Mode

Interface Configuration (VLAN) mode

User Guidelines

Before defining forbidden ports, the Multicast group should be registered.

You can execute the command before the VLAN is created.

Example

The following example registers an IPv6 Multicast address, and forbids the IPv6 address on port fe1/0/19 within VLAN 8.

```
switchxxxxxx(config)# interface vlan 8
switchxxxxxx(config-if)# bridge multicast ipv6 ip-address
FF00:0:0:0:4:4:4:1
switchxxxxxx(config-if)# bridge multicast ipv6 forbidden ip-address
FF00:0:0:0:4:4:4:1 add fe1/0/19
```

25.12 bridge multicast ipv6 source group

Use the **bridge multicast ipv6 source group** Interface Configuration (VLAN) mode command to register a source IPv6 address - Multicast IPv6 address pair to the bridge table, and statically add or remove ports to or from the source-group. Use the **no** form of this command to unregister the source-group-pair.

Syntax

bridge multicast ipv6 source *ipv6-source-address* **group** *ipv6-multicast-address* [**add** | **remove**] *{ethernet interface-list | port-channel port-channel-list}*

no bridge multicast ipv6 source *ipv6-address* **group** *ipv6-multicast-address*

Parameters

- **ipv6-source-address**—Specifies the source IPv6 address.
- **ipv6-multicast-address**—Specifies the group IPv6 Multicast address.
- **add**—Adds ports to the group for the specific source IPv6 address.
- **remove**—Removes ports from the group for the specific source IPv6 address.
- **ethernet interface-list**—Specifies a list of Ethernet ports. Separate nonconsecutive Ethernet ports with a comma and no spaces. Use a hyphen to designate a range of ports.

- **port-channel** *port-channel-list*—Specifies a list of port channels. Separate nonconsecutive port-channels with a comma and no spaces. Use a hyphen to designate a range of port channels.

Default Configuration

No Multicast addresses are defined.

The default option is **add**.

Command Mode

Interface Configuration (VLAN) mode

Example

The following example registers a source IPv6 address - Multicast IPv6 address pair to the bridge table:

```
switchxxxxxx(config)# interface vlan 8
switchxxxxxx(config-if)# bridge multicast source 2001:0:0:0:4:4:4 group
FF00:0:0:0:4:4:4:1
```

25.13 bridge multicast ipv6 forbidden source group

Use the **bridge multicast ipv6 forbidden source group** Interface Configuration (VLAN) mode command to forbid adding or removing a specific IPv6 source address - Multicast address pair to or from specific ports. Use the **no** form of this command to return to the default configuration.

Syntax

bridge multicast ipv6 forbidden source *ipv6-source-address* **group** *ipv6-multicast-address* {**add** | **remove**} {**ethernet** *interface-list* | **port-channel** *port-channel-list*}

no bridge multicast ipv6 forbidden source *ipv6-address* **group** *ipv6-multicast-address*

Parameters

- **ipv6-source-address**—Specifies the source IPv6 address.
- **ipv6-multicast-address**—Specifies the group IPv6 multicast address.
- **add**—Forbids adding ports to the group for the specific source IPv6 address.
- **remove**—Forbids removing ports from the group for the specific source IPv6 address.
- **ethernet** *interface-list*—Specifies a list of Ethernet ports. Separate nonconsecutive Ethernet ports with a comma and no spaces. Use a hyphen to designate a range of ports.
- **port-channel** *port-channel-list*—Specifies a list of port channels. Separate nonconsecutive port-channels with a comma and no spaces; use a hyphen to designate a range of port channels.

Default Configuration

No forbidden addresses are defined.

Command Mode

Interface Configuration (VLAN) mode

User Guidelines

Before defining forbidden ports, the Multicast group should be registered.

You can execute the command before the VLAN is created.

Example

The following example registers a source IPv6 address - Multicast IPv6 address pair to the bridge table, and forbids adding the pair to fe1/0/19 on VLAN 8:

```
switchxxxxxx(config)# interface vlan 8
switchxxxxxx(config-if)# bridge multicast source 2001:0:0:0:4:4:4 group
FF00:0:0:0:4:4:4:1
switchxxxxxx(config-if)# bridge multicast forbidden source
2001:0:0:0:4:4:4:1 group FF00:0:0:0:4:4:4:1 add fe1/0/19
```

25.14 bridge multicast unregistered

Use the **bridge multicast unregistered** Interface Configuration (Ethernet, Port-Channel) mode command to configure forwarding unregistered Multicast addresses. Use the **no** form of this command to restore the default configuration.

Syntax

bridge multicast unregistered {*forwarding* | *filtering*}

no bridge multicast unregistered

Parameters

- **forwarding**—Forwards unregistered Multicast packets.
- **filtering**—Filters unregistered Multicast packets.

Default Configuration

Unregistered Multicast addresses are forwarded.

Command Mode

Interface Configuration (Ethernet, Port-Channel) mode

User Guidelines

Do not enable unregistered Multicast filtering on ports that are connected to routers, because the 224.0.0.x address range should not be filtered. Note that routers do not necessarily send IGMP reports for the 224.0.0.x range.

You can execute the command before the VLAN is created.

Example

The following example specifies that unregistered Multicast packets are filtered on fe1/0/11:

```
switchxxxxxx(config)# interface fe1/0/11
switchxxxxxx(config-if)# bridge multicast unregistered filtering
```

25.15 bridge multicast forward-all

Use the **bridge multicast forward-all** Interface Configuration (VLAN) mode command to enable forwarding all multicast packets for a range of ports or port channels. Use the **no** form of this command to restore the default configuration.

Syntax

bridge multicast forward-all {*add* | *remove*} {*ethernet interface-list* | *port-channel port-channel-list*}

no bridge multicast forward-all

Parameters

- **add**—Forces forwarding of all Multicast packets.
- **remove**—Does not force forwarding of all Multicast packets.
- **ethernet interface-list**—Specifies a list of Ethernet ports. Separate nonconsecutive Ethernet ports with a comma and no spaces. Use a hyphen to designate a range of ports.
- **port-channel port-channel-list**—Specifies a list of port channels. Separate nonconsecutive port-channels with a comma and no spaces. Use a hyphen to designate a range of port channels.

Default Configuration

Forwarding of all Multicast packets is disabled.

Command Mode

Interface Configuration (VLAN) mode

Example

The following example enables all Multicast packets on port fe1/0/18 to be forwarded.

```
switchxxxxxx(config)# interface vlan 2
switchxxxxxx(config-if)# bridge multicast forward-all add fe1/0/18
```

25.16 bridge multicast forbidden forward-all

Use the **bridge multicast forbidden forward-all** Interface Configuration (VLAN) mode command to forbid a port to dynamically join Multicast groups. Use the **no** form of this command to restore the default configuration.

Syntax

bridge multicast forbidden forward-all {*add* | *remove*} {*ethernet interface-list* | *port-channel port-channel-list*}

no bridge multicast forbidden forward-all

Parameters

- **add**—Forbids forwarding of all Multicast packets.
- **remove**—Does not forbid forwarding of all Multicast packets.

- **ethernet interface-list**—Specifies a list of Ethernet ports. Separate nonconsecutive Ethernet ports with a comma and no spaces. Use a hyphen to designate a range of ports.
- **port-channel port-channel-list**—Specifies a list of port channels. Separate nonconsecutive port-channels with a comma and no spaces; use a hyphen to designate a range of port channels.

Default Configuration

Ports are not forbidden to dynamically join Multicast groups.

The default option is **add**.

Command Mode

Interface Configuration (VLAN) mode

User Guidelines

Use this command to forbid a port to dynamically join (by IGMP, for example) a Multicast group.

The port can still be a Multicast router port.

Example

The following example forbids forwarding of all Multicast packets to fe1/0/11 within VLAN 2.

```
switchxxxxxx(config)# interface vlan 2
switchxxxxxx(config-if)# bridge multicast forbidden forward-all add
ethernet fe1/0/11
```

25.17 mac address-table static

Use the **mac address-table static** Global Configuration mode command to add a MAC-layer station source address to the MAC address table. Use the **no** form of this command to delete the MAC address.

Syntax

mac address-table static *mac-address* **vlan** *vlan-id* **interface** *interface-id* [**permanent** | **delete-on-reset** | **delete-on-timeout** | **secure**]

no mac address-table static [*mac-address*] **vlan** *vlan-id*

Parameters

- **mac-address**— MAC address (Range: Valid MAC address)
- **vlan-id**— Specify the VLAN
- **interface-id**— Specify an interface ID. The interface ID can be one of the following types: Ethernet port or port-channel (Range: valid ethernet port, valid port-channel)
- **permanent**— The permanent static MAC address. The keyword is applied by the default.
- **delete-on-reset**— The delete-on-reset static MAC address.
- **delete-on-timeout**— The delete-on-timeout static MAC address.
- **secure**—The secure MAC address. May be used only in a secure mode.

Default Configuration

No static addresses are defined. The default mode for an added address is permanent.

Command Mode

Global Configuration mode

User Guidelines

Use the command to add a static MAC address with given time-to-live in any mode or to add a secure MAC address in a secure mode.

Each MAC address in the MAC address table is assigned two attributes: **type** and **time-to-live**.

The following value of time-of-live is supported:

- **permanent**— a MAC address is saved until it is removed manually.
- **delete-on-reset**— a MAC address is saved until the next reboot.
- **delete-on-timeout**— a MAC address that may be removed by the aging timer.

The following types are supported:

- **static**— MAC address manually added by the command with the following keywords specifying its time-of-live:
 - **permanent**
 - **delete-on-reset**
 - **delete-on-timeout**

A static MAC address may be added in any port mode.

- **secure**— A MAC address added manually or learned in a secure mode. Use the **mac address-table static** command with the **secure** keyword to add a secure MAC address address. The MAC address cannot be relearned.

A secure MAC address may be added only in a secure port mode.

- **dynamic**— a MAC address learned by the switch in non secure mode. A value of its **time-to-live** attribute is **delete-on-timeout**.

Examples

Example 1 - The following example adds two permanent static MAC address:

```
switchxxxxxx(conf)#mac address-table static 00:3f:bd:45:5a:b1 vlan 1
fe1/0/11
switchxxxxxx(conf)mac address-table static 00:3f:bd:45:5a:b2 vlan 1
fe1/0/11 permanent
```

Example 2 - The following example adds a deleted-on-reset static MAC address:

```
switchxxxxxx(conf)mac address-table static 00:3f:bd:45:5a:b2 vlan 1
fe1/0/11 delete-on-reset
```

Example 3 - The following example adds a deleted-on-timeout static MAC address:

```
switchxxxxxx(conf)mac address-table static 00:3f:bd:45:5a:b2 vlan 1
fe1/0/11 delete-on-timeout
```

Example 4 - The following example adds a secure MAC address:

```
switchxxxxxx(conf)mac address-table static 00:3f:bd:45:5a:b2 vlan 1  
fe1/0/11 secure
```

25.18 clear mac address-table

Use the **clear mac address-table** Privileged EXEC command to remove learned or secure entries from the forwarding database (FDB).

Syntax

clear mac address-table dynamic [*interface interface-id*]

clear mac address-table secure interface *interface-id*

Parameters

- **dynamic interface** *interface-id*—Delete all dynamic (learned) addresses on the specified interface. The interface ID can be one of the following types: Ethernet port or port-channel. If interface ID is not supplied, all dynamic addresses are deleted.
- **secure interface** *interface-id*—Delete all the secure addresses learned on the specific interface. A secure address on a MAC address learned on ports on which port security is defined.

Default Configuration

For dynamic addresses, if interface-id is not supplied, all dynamic entries are deleted.

Command Mode

Privileged EXEC mode

Examples:

Example 1 - Delete all dynamic entries from the FDB.

```
switchxxxxxx# clear mac address-table dynamic
```

Example 2 - Delete all secure entries from the FDB learned on secure port gi1.

```
switchxxxxxx# clear mac address-table secure interface gi1
```

25.19 mac address-table aging-time

Use the **mac address-table aging-time** Global configuration command to set the aging time of the address table. Use the **no** form of this command to restore the default.

Syntax

mac address-table aging-time *seconds*

no mac address-table aging-time

Parameters

seconds—Time is number of seconds. (Range:10–300)

Default Configuration

300

Command Mode

Global Configuration mode

Example

```
switchxxxxxx(config)# mac address-table aging-time 600
```

25.20 port security

Use the **port security** Interface Configuration (Ethernet, Port-channel) mode command to enable port security learning mode on an interface. Use the **no** form of this command to disable port security learning mode on an interface.

Syntax

port security [**forward** | **discard** | **discard-shutdown**] [**trap seconds**]

no port security

Parameters

- **forward**—Forwards packets with unlearned source addresses, but does not learn the address.
- **discard**—Discards packets with unlearned source addresses.
- **discard-shutdown**—Discards packets with unlearned source addresses and shuts down the port.
- **trap seconds**—Sends SNMP traps and specifies the minimum time interval in seconds between consecutive traps. (Range: 1–1000000)

Default Configuration

The feature is disabled by default.

The default mode is **discard**.

The default number of seconds is zero, but if **traps** is entered, a number of seconds must also be entered.

Command Mode

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

The command may be used only when the interface is in the regular (non-secure with unlimited MAC learning) mode.

See the [mac address-table static](#) command for information about MAC address attributes (type and time-to-live) definitions.

When the **port security** command enables the **lock** mode on a port all dynamic addresses learned on the port are changed to **permanent secure** addresses.

When the **port security** command enables a mode on a port differing from the **lock** mode all dynamic addresses learned on the port are deleted.

When the **no port security** command cancels a secure mode on a port all secure addresses defined on the port are changed to **dynamic** addresses.

Additionally to set a mode, use the **port security** command to set an action that the switch should perform on a frame which source MAC address cannot be learned.

Example

The following example forwards all packets to port fe1/0/11 without learning addresses of packets from unknown sources and sends traps every 100 seconds, if a packet with an unknown source address is received.

```
switchxxxxxx(config) interface fe1/0/17
switchxxxxxx(config-if) port security mode lock
switchxxxxxx(config-if) port security forward trap 100
switchxxxxxx(config-if) exit
```

25.21 port security mode

Use the **port security mode** Interface Configuration (Ethernet, port-channel) mode command configures the port security learning mode. Use the **no** form of this command to restore the default configuration.

Syntax

Parameters

- **max-addresses**— Non secure mode with limited learning dynamic MAC addresses. The static MAC addresses may be added on the port manually by the [mac address-table static](#) command.
- **lock**— Secure mode without MAC learning. The static and secure MAC addresses may be added on the port manually by the [mac address-table static](#) command.

Default Configuration

The default port security mode is **lock**.

Command Mode

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

The default port mode is called regular. In this mode, the port allows unlimited learning of dynamic addresses. The static MAC addresses may be added on the port manually by the [mac address-table static](#) command.

The command may be used only when the interface in the regular (non-secure with unlimited MAC learning) mode.

Use the **port security mode** command to change the default mode before the [port security mode](#) command.

Example

The following example sets the port security mode to Lock for fe1/0/17.

```
switchxxxxxx(config) interface fe1/0/17
switchxxxxxx(config-if) port security mode lock
switchxxxxxx(config-if) port security
switchxxxxxx(config-if) exit
```

25.22 port security max

Use the **port security max** Interface Configuration (Ethernet, Port-channel) mode command to configure the maximum number of addresses that can be learned on the port while the port is in port, max-addresses or secure mode. Use the **no** form of this command to restore the default configuration.

Syntax

port security max *max-addr*

no port security max

Parameters

max-addr—Specifies the maximum number of addresses that can be learned on the port. (Range: 0–256)

Default Configuration

This default maximum number of addresses is 1.

Command Mode

Interface Configuration (Ethernet, Port-channel) mode

User Guidelines

The command may be used only when the interface is in the regular (non-secure with unlimited MAC learning) mode.

Use this command to change the default value before the [port security](#) command.

Example

The following example sets the port to limited learning mode:

```
switchxxxxxx(config) #interface gi7
switchxxxxxx(config-if) port security mode max
switchxxxxxx(config-if) port security max 20
switchxxxxxx(config-if) port security
switchxxxxxx(config-if) exit
```

25.23 port security routed secure-address

Use the **port security routed secure-address** Interface Configuration (Ethernet, Port-channel) mode command to add a MAC-layer secure address to a routed port. (port that has an IP address defined on it). Use the no form of this command to delete a MAC address from a routed port.

Syntax

port security routed secure-address *mac-address*

no port security routed secure-address [*mac-address*]

Parameters

mac-address—Specifies the MAC address.

Default Configuration

No addresses are defined.

Command Mode

Interface Configuration (Ethernet, port-channel) mode. It cannot be configured for a range of interfaces (range context).

User Guidelines

This command enables adding secure MAC addresses to a routed port in port security mode. The command is available when the port is a routed port and in port security mode. The address is deleted if the port exits the security mode or is not a routed port.

Example

The following example adds the MAC-layer address 00:66:66:66:66:66 to fe1/0/11.

```
switchxxxxxx(config)# interface fe1/0/11
switchxxxxxx(config-if)# port security routed secure-address
00:66:66:66:66:66
```

25.24 show mac address-table

Use the **show mac address-table** EXEC command to view entries in the MAC address table.

Syntax

show mac address-table [*dynamic* | *static* | *secure*] [*vlan vlan*] [*interface interface-id*] [*address mac-address*]

Parameters

- **dynamic**—Displays only dynamic MAC address table entries.
- **static**—Displays only static MAC address table entries.
- **secure**—Displays only secure MAC address table entries.
- **vlan**—Displays entries for a specific VLAN.
- **interface-id**—SDisplays entries for a specific interface ID. The interface ID can be one of the following types: Ethernet port or port-channel.

- **mac-address**—Displays entries for a specific MAC address.

Default Configuration

If no parameters are entered, the entire table is displayed.

Command Mode

EXEC mode

User Guidelines

Internal usage VLANs (VLANs that are automatically allocated on routed ports) are presented in the VLAN column by a port number and not by a VLAN ID.

Example

Example 1 - Displays entire address table.

```
switchxxxxx# show mac address-table
Aging time is 300 sec
VLAN          MAC Address          Port          Type
-----
1             00:00:26:08:13:23    0             self
1             00:3f:bd:45:5a:b1    fe1/0/11      static
1             00:a1:b0:69:63:f3    fe1/0/14      dynamic
2             00:a1:b0:69:63:f3    fe1/0/15      dynamic
```

Example 2 - Displays address table entries containing the specified MAC address.

```
switchxxxxx# show mac address-table 00:3f:bd:45:5a:b1
Aging time is 300 sec
VLAN          MAC Address          Port          Type
-----
1             00:3f:bd:45:5a:b1    static        fe1/0/19
```

25.25 show mac address-table count

Use the **show mac address-table count** EXEC mode command to display the number of addresses present in the Forwarding Database.

Syntax

show mac address-table count [*vlan vlan* | *interface interface-id*]

Parameters

- **vlan**—Specifies VLAN.
- **interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or port-channel.

Command Mode

EXEC mode

Example

```
switchxxxxxx# show mac address-table count
Capacity: 8192
Free: 8083
Used: 109
Secure : 0
Dynamic : 25
Static : 1
Internal : 0
```

25.26 show bridge multicast mode

Use the **show bridge multicast mode** EXEC mode command to display the Multicast bridging mode for all VLANs or for a specific VLAN.

Syntax

show bridge multicast mode [*vlan vlan-id*]

Parameters

vlan *vlan-id*—Specifies the VLAN ID.

Command Mode

EXEC mode

Example

The following example displays the Multicast bridging mode for all VLANs.

```
switchxxxxxx# show bridge multicast mode
VLAN          IPv4 Multicast Mode          IPv6 Multicast Mode
Admin         Oper         Admin         Oper
-----
1             MAC-GROUP   MAC-GROUP   MAC-GROUP   -MAC-GROUP
11            IPv4-GROUP  IPv4-GROUP  IPv6-GROUP  IPv6-GROUP
12            IPv4-SRC-   IPv4-SRC-   IPv6-SRC-   IPv6-SRC-
              GROUP      GROUP      GROUP      GROUP
```

25.27 show bridge multicast address-table

Use the **show bridge multicast address-table** EXEC mode command to display Multicast MAC addresses or IP Multicast address table information.

Syntax

show bridge multicast address-table [*vlan vlan-id*] [**address** {*mac-multicast-address* | *ipv4-multicast-address* | *ipv6-multicast-address*}] [**format** {*ip* | *mac*}] [**source** {*ipv4-source-address* | *ipv6-source-address*}]

Parameters

- **vlan-id**/*vlan-id*—Display entries for specified VLAN ID.
- **address** —Display entries for specified Multicast address. The possible values are:
 - **mac-multicast-address**—Specifies the MAC Multicast address.
 - **ipv4-multicast-address**—Specifies the IPv4 Multicast address.
 - **ipv6-multicast-address**—Specifies the IPv6 Multicast address.
- **format**—(this applies if picked mac-multicast-address). then i can display it either in mac or ip format) Display entries for specified Multicast address format. The possible values are:
 - **ip**—Specifies that the Multicast address is an IP address.
 - **mac**—Specifies that the Multicast address is a MAC address.
- **source {ipv4-source-address | ipv6-source-address}**—Specifies the source address. The possible values are:
 - **ipv4-address**—Specifies the source IPv4 address.
 - **ipv6-address**—Specifies the source IPv6 address.

Default Configuration

If the **format** is not specified, it defaults to **mac** (only if mac-multicast-address was entered).

If VLAN ID is not entered, entries for all VLANs are displayed.

If MAC or IP address is not supplied, entries for all addresses are displayed.

Command Mode

EXEC mode

User Guidelines

A MAC address can be displayed in IP format only if it is within the range 0100.5e00.0000 through 0100.5e7f.ffff.

Multicast router ports (defined statically or discovered dynamically) are members in all MAC groups.

Ports that were defined via the [bridge multicast forbidden forward-all](#) command are displayed in all forbidden MAC entries.

Changing the Multicast mode can move static Multicast addresses that are written in the device FDB to a shadow configuration because of FDB hash collisions.

Example

The following example displays bridge Multicast address information.

```
switchxxxxxx# show bridge multicast address-table
Multicast address table for VLANs in MAC-GROUP bridging mode:
Vlan    MAC Address          Type          Ports
----  -
8      01:00:5e:02:02:03   Static        1-2

Forbidden ports for Multicast addresses:
Vlan    MAC Address          Ports
----  -
8      01:00:5e:02:02:03   fe1/0/19
```



```

Multicast address table for VLANs in IPv4-GROUP bridging mode:
Vlan    MAC Address      Type           Ports
-----
1       224.0.0.251     Dynamic       fe1/0/12
Forbidden ports for Multicast addresses:
Vlan    MAC Address      Ports
-----
1       232.5.6.5
1       233.22.2.6
Multicast address table for VLANs in IPv4-SRC-GROUP bridging mode:
Vlan    Group Address    Source address  Type           Ports
-----
1       224.2.2.251     11.2.2.3      Dynamic       fe1/0/11
Forbidden ports for Multicast addresses:
Vlan    Group Address    Source Address  Ports
-----
8       239.2.2.2       *              fe1/0/19
8       239.2.2.2       1.1.1.11      fe1/0/19
Multicast address table for VLANs in IPv6-GROUP bridging mode:
VLAN    IP/MAC Address   Type           Ports
-----
8       ff02::4:4:4     Static        fe1/0/11-2, fe1/0/17, Po1
Forbidden ports for Multicast addresses:
VLAN    IP/MAC Address   Ports
-----
8       ff02::4:4:4     fe1/0/19
Multicast address table for VLANs in IPv6-SRC-GROUP bridging mode:
Vlan    Group Address    Source address  Type           Ports
-----
8       ff02::4:4:4     *              Static        fe1/0/11-2, fe1/0/17, Po1
8       ff02::4:4:4     fe80::200:7ff: fe00:200
Static
Forbidden ports for Multicast addresses:
Vlan    Group Address    Source address  Ports
-----
8       ff02::4:4:4     *              fe1/0/19
8       ff02::4:4:4     fe80::200:7ff:f e00:200
Static

```

25.28 show bridge multicast address-table static

Use the **show bridge multicast address-table static** EXEC mode command to display the statically configured Multicast addresses.

Syntax

```
show bridge multicast address-table static [vlan vlan-id] [address mac-multicast-address |
ipv4-multicast-address | ipv6-multicast-address] [source ipv4-source-address |
ipv6-source-address] [all | mac | ip]
```

Parameters

- **vlan vlan-id**—Specifies the VLAN ID.
- **address**—Specifies the Multicast address. The possible values are:
 - **mac-multicast-address**—Specifies the MAC Multicast address.
 - **ipv4-multicast-address**—Specifies the IPv4 Multicast address.
 - **ipv6-multicast-address**—Specifies the IPv6 Multicast address.
- **source**—Specifies the source address. The possible values are:
 - **ipv4-address**—Specifies the source IPv4 address.
 - **ipv6-address**—Specifies the source IPv6 address.

Default Configuration

When **all/mac/ip** is not specified, all entries (MAC and IP) will be displayed.

Command Mode

EXEC mode

User Guidelines

A MAC address can be displayed in IP format only if it is within the range 0100.5e00.0000—0100.5e7f.ffff.

Example

The following example displays the statically configured Multicast addresses.

```
switchxxxxx# show bridge multicast address-table static
MAC-GROUP table

Vlan      MAC Address      Ports
----      -
1         0100.9923.8787   fe1/0/11, fe1/0/12

Forbidden ports for multicast addresses:

Vlan      MAC Address      Ports
----      -
IPv4-GROUP Table

Vlan      IP Address       Ports
----      -
1         231.2.2.3        fe1/0/11, fe1/0/12
19        231.2.2.8        fe1/0/1-8
19        231.2.2.8        fe1/0/19-21

Forbidden ports for multicast addresses:
```



```

Vlan      IP Address      Ports
----      -
1         231.2.2.3       fe1/0/18
19        231.2.2.8       fe1/0/13
    
```

IPv4-SRC-GROUP Table:

```

Vlan      Group Address    Source          Ports
----      -
          -
          -
          -
    
```

Forbidden ports for multicast addresses:

```

Vlan      Group Address    Source          Ports
----      -
          -
          -
          -
    
```

IPv6-GROUP Table

```

Vlan      IP Address      Ports
----      -
191      -               fe1/0/11-8
          FF12::8
    
```

Forbidden ports for multicast addresses:

```

Vlan      IP Address      Ports
----      -
11        -               fe1/0/18
191      FF12::3         fe1/0/18
          FF12::8
    
```

IPv6-SRC-GROUP Table:

```

Vlan      Group Address    Source          Ports
----      -
          -
192      FF12::8         -----        fe1/0/11-8
          FE80::201:C9A9:FE40
          :8988
    
```

Forbidden ports for multicast addresses:

```

Vlan      Group Address    Source          Ports
----      -
          -
192      FF12::3         -----        fe1/0/18
          FE80::201:C9A9:FE40
          :8988
    
```

25.29 show bridge multicast filtering

Use the **show bridge multicast filtering** EXEC mode command to display the Multicast filtering configuration.

Syntax

show bridge multicast filtering *vlan-id*

Parameters

vlan-id—Specifies the VLAN ID. (Range: Valid VLAN)

Default Configuration

N/A

Command Mode

EXEC mode

Example

The following example displays the Multicast configuration for VLAN 1.

```
switchxxxxxx# show bridge multicast filtering 1
Filtering: Enabled
VLAN: 1

Port          Forward-All
-----      -
fe1/0/11      Static      Status
fe1/0/12      Forbidden   Filter
fe1/0/13      Forward     Forward(s)
-             -           Forward(d)
```

25.30 show bridge multicast unregistered

Use the **show bridge multicast unregistered** EXEC mode command to display the unregistered Multicast filtering configuration.

Syntax

show bridge multicast unregistered *[interface-id]*

Parameters

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

Default Configuration

Display for all interfaces.

Command Mode

EXEC mode

Example

The following example displays the unregistered Multicast configuration.

```
switchxxxxxx# show bridge multicast unregistered
Port          Unregistered
-----
fe1/0/11      Forward
fe1/0/12      Filter
fe1/0/13      Filter
```

25.31 show ports security

Use the **show ports security** Privileged EXEC mode command to display the port-lock status.

Syntax

```
show ports security [interface-id]
```

Parameters

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

Default Configuration

Display for all interfaces.

Command Mode

Privileged EXEC mode

Example

The following example displays the port-lock status of all ports.

```
switchxxxxxx# show ports security

Port   Status   Learning   Action   Maximum   Trap   Frequency
-----
fe1/0/11  Enabled  Max-      Discard  3         Enabled 100
          Addresses
fe1/0/12  Disabled Max-      -        28        -        -
          Addresses
fe1/0/13  Enabled  Lock      Discard, 8         Disabled -
          Shutdown
```


The following table describes the fields shown above.

Field	Description
Port	The port number.
Status	The port security status. The possible values are: Enabled or Disabled.
Action	The action taken on violation.
Maximum	The maximum number of addresses that can be associated on this port in the Max-Addresses mode.
Trap	The status of SNMP traps. The possible values are: Enable or Disable.
Frequency	The minimum time interval between consecutive traps.

25.32 show ports security addresses

Use the **show ports security addresses** Privileged EXEC mode command to display the current dynamic addresses in locked ports.

Syntax

show ports security addresses [*interface-id*]

Parameters

interface-id—Display addresses for the specified interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

Default Configuration

Display for all interfaces.

Command Mode

Privileged EXEC mode

Example

The following example displays dynamic addresses in all currently locked port:

```
Port   Status   Learning   Current   Maximum
-----
gi1    Disabled Lock        0         10
gi2    Disabled Lock        0         1
gi3    Disabled Lock        0         1
gi4    Disabled Lock        0         1
gi5    Disabled Lock        0         1
gi6    Disabled Lock        0         1
gi7    Disabled Lock        0         1
...
```

25.33 bridge multicast reserved-address

Use the **bridge multicast reserved-address** Global Configuration mode command to define the action on Multicast reserved-address packets. Use the **no** form of this command to revert to default.

Syntax

bridge multicast reserved-address *mac-multicast-address* [*ethernet-v2 ethtype* | *llc sap* | *llc-snap pid*] [*discard* | *bridge*]

no bridge multicast reserved-address *mac-multicast-address* [*ethernet-v2 ethtype* | *llc sap* | *llc-snap pid*]

Parameters

- **mac-multicast-address**—MAC Multicast address in the reserved MAC addresses range. (Range: 01-80-C2-00-00-00, 01-80-C2-00-00-02–01-80-C2-00-00-2F)
- **ethernet-v2 ethtype**—Specifies that the packet type is Ethernet v2 and the Ethernet type field (16 bits in hexadecimal format). (Range: 0x0600–0xFFFF)
- **llc sap**—Specifies that the packet type is LLC and the DSAP-SSAP field (16 bits in hexadecimal format). (Range: 0xFFFF)
- **llc-snap pid**—Specifies that the packet type is LLC-SNAP and the PID field (40 bits in hexadecimal format). (Range: 0x0000000000 - 0xFFFFFFFF)
- **discard**—Specifies discarding the packets.
- **bridge**—Specifies bridging (forwarding) the packets

Default Configuration

- If the user-supplied MAC Multicast address, ethertype and encapsulation (LLC) specifies a protocol supported on the device (called Peer), the default action (discard or bridge) is determined by the protocol.
- If not, the default action is as follows:
 - For MAC addresses in the range 01-80-C2-00-00-00, 01-80-C2-00-00-02–01-80-C2-00-00-0F, the default is **discard**.
 - For MAC addresses in the range 00-80-C2-00-00-10–01-80-C2-00-00-2F, the default is **bridge**.

Command Mode

Global Configuration mode

User Guidelines

If the packet/service type (ethertype/encapsulation) is not specified, the configuration is relevant to all the packets with the configured MAC address.

Specific configurations (that contain service type) have precedence over less specific configurations (contain only MAC address).

The packets that are bridged are subject to security ACLs.

The actions define by this command has precedence over forwarding rules defined by applications/protocols (STP, LLDP etc.) supported on the device.

Example

```
switchxxxxxx (conf) #bridge multicast reserved-address 00:3f:bd:45:5a:b1
```

25.34 show bridge multicast reserved-addresses

Use the **show bridge multicast reserved-addresses** EXEC mode command to display the Multicast reserved-address rules.

Syntax

show bridge multicast reserved-addresses

Command Mode

EXEC mode

Example

```
switchxxxxxx # show bridge multicast reserved-addresses
```

MAC Address	Frame Type	Protocol	Action
01-80-C2-00-00-00	LLC-SNAP	00-00-0C-01-29	Bridge

26 Port Monitor Commands

26.1 port monitor

Use the **port monitor** Interface Configuration (Ethernet) mode command to start a port monitoring session (mirroring). Use the **no** form of this command to stop a port monitoring session.

Syntax

port monitor *src-interface-id* [*rx* | *tx*]

no port monitor *src-interface-id*

port monitor *vlan* *vlan-id*

no port monitor *vlan* *vlan-id*

Parameters

- **rx**—Monitors received packets only. If no option is specified, it monitors both rx and tx.
- **tx**—Monitors transmitted packets only. If no option is specified, it monitors both rx and tx.
- **vlan** *vlan-id*—VLAN number
- **src-interface-id**—Specifies an interface ID. The interface ID must be an Ethernet port.

Default Configuration

Monitors both received and transmitted packets.

Command Mode

Interface Configuration (Ethernet) mode. It cannot be configured for a range of interfaces (range context).

User Guidelines

This command enables port copy between Source Port (*src-interface*) to a Destination Port (The port in context).

The analyzer port for port ingress traffic mirroring should be the same port for all mirrored ports.

The analyzer port for port egress traffic mirroring should be the same port for all mirrored ports.

The analyzer port for VLAN mirroring should be the same for all the mirrored VLANs, and should be the same port as the analyzer port for port ingress mirroring traffic.

The following restriction applies to ports that are configured to be source ports:

- The port cannot be a destination port.

The following restrictions apply to ports that are configured to be monitor ports:

- The port cannot be source port.
 - The port is not a member in port-channel.
 - IP interface is not configured on the port.
 - GVRP is not enabled on the port.
 - The port is not a member in any VLAN, except for the default VLAN (will be automatically removed from the default VLAN).
 - L2 protocols, such as: LLDP, CDP, LBD, STP, LACP, are not active on the destination port.
-

Notes:

1. In this mode some traffic duplication on the analyzer port may be observed. For example:
 - Port 2 is being egress monitored by port 4.
 - Port 2 & 4 are members in VLAN 3.
 - Unknown Unicast packet sent to VLAN 3 will egress from port 4 twice, one instance as normal forward and another instance as mirrored from port 2.
 - Moreover, if port 2 is an untagged member in VLAN 3 and port 4 is a tagged member then both instances will look different (one tagged and the other is not).
2. When the port is configured to 802.1X auto mode it will forward any mirrored traffic regardless of the .1X state. However, it will operate as a normal network port (forward traffic) only after authorization is done.
3. Mirrored traffic is exposed to STP state, i.e. if the port is in STP blocking, it will not egress any mirrored traffic.

Example

The following example copies traffic for both directions (Tx and Rx) from the source port fe1/0/12 to destination port fe1/0/11.

```
switchxxxxxx(config)# interface fe1/0/11
switchxxxxxx(config-if)# port monitor fe1/0/12
```

26.2 show ports monitor

Use the **show ports monitor** EXEC mode command to display the port monitoring status.

Syntax

show ports monitor

Command Mode

EXEC mode

Example

The following example displays the port monitoring status.

```
switchxxxxxx# show ports monitor
```

Source port	Destination Port	Type	Status
fe1/0/18	fe1/0/11		RX, TX Active
fe1/0/12	fe1/0/11		RX, TX Active
fe1/0/118	fe1/0/11	Rx	Active
VLAN 9	fe1/0/11	N/A	Active

26.3 port monitor mode

Use the **port monitor mode** Global Configuration mode command to define the monitoring mode. Use the **no** form of this command to return to default.

**Syntax**

port monitor mode {*monitor-only* | *network*}

no port monitor mode

Parameters

- **monitor-only**—Specifies that the monitor port acts only as a monitor port. Other network traffic is discarded at ingress and egress.
- **network**—Specifies that the monitor port acts also as a network port.

Default Configuration

The default is monitor-only.

Command Mode

Global Configuration mode

User Guidelines

Once the port monitor mode is defined, no changing between modes is allowed. Any mode change will have to first go through un-defining the monitor port.

Example

```
switchxxxxxx(config)# port monitor mode network
```

27 sFlow Commands

27.1 sflow receiver

Use the **sflow receiver** Global Configuration mode command to define sFlow collector. Use the **no** form of this command to remove the definition of the collector.

Syntax

sflow receiver *index* {*ipv4-address* | *ipv6-address* | *hostname*} [*port port*] [*max-datagram-size bytes*]

no sflow receiver *index*

Parameters

- **index**—The index of the receiver. (Range: 1–8)
- **ipv4-address**—Pv4 address of the host to be used as an sFlow Collector.
- **ipv6-address**—IPv6 address of the host to be used as an sFlow Collector. When the IPv6 address is a Link Local address (IPv6Z address), the outgoing interface name must be specified. Refer to the User Guidelines for the interface name syntax.
- **hostname**—Hostname of the host to be used as an sFlow Collector. Only translation to IPv4 addresses is supported.
- **port**—Port number for sflow messages. If unspecified, the port number defaults to 6343. The range is 1-65535.
- **bytes**—Specifies the maximum datagram size that can be sent. If unspecified, it defaults to 1400.

Default

No receiver is defined.

Command Mode

Global Configuration mode

User Guidelines

If the IP address of the sFlow receiver is set to 0.0.0.0, no sFlow datagrams are sent.

27.2 sflow flow-sampling

Use the **sflow flow-sampling** Interface Configuration mode command to enable sFlow Flow sampling and configure the average sampling rate of a specific port. Use the **no** form of this command to disable Flow sampling.

Syntax

sflow flow-sampling *rate receiver-index* [*max-header-size bytes*]

no sflow flow-sampling

Parameters

- **rate**—Specifies the average sampling rate (Range: 1, 1024–1073741823.)
- **receiver-index**—Index of the receiver/collector (Range: 1–8.)
- **bytes**—Specifies the maximum number of bytes that would be copied from the sampled packet. If unspecified, defaults to 128. (Range: 20–256.)

Default

Disabled

Command Mode

Interface Configuration (Ethernet) mode

User Guidelines

A new sampling rate configuration is not immediately loaded to the hardware. It will be loaded to the hardware only after the next packet is sampled (based on the current sampling rate).

27.3 sflow counters-sampling

Use the **sflow counters-sampling** Interface Configuration mode command to enable sFlow Counters sampling and to configure the maximum interval of a specific port. Use the **no** form of this command to disable sFlow Counters sampling.

Syntax

sflow counters-sampling *interval receiver-index*

no sflow counters-sampling

Parameters

- **interval**—Specifies the maximum number of seconds between successive samples of the interface counters. (Range: 1, 15–86400.)
- **receiver-index**—Index of the receiver/collector. (Range: 1–8.)

Default

Disabled

Command Mode

Interface Configuration (Ethernet) mode

27.4 clear sflow statistics

Use the **clear sFlow statistics** EXEC mode command to clear sFlow statistics.

Syntax

clear sflow statistics [*interface-id*]

Parameters

interface-id—Specifies an interface ID. The interface ID must be an Ethernet port.

Command Mode

EXEC mode

User Guidelines

If no interface is specified by the user, the command clears all the sFlow statistics counters (including datagrams sent). If an interface is specified by the user, the command clears only the counter of the specific interface.

27.5 show sflow configuration

Use the **show sflow configuration** EXEC mode command to display the sFlow configuration for ports that are enabled for Flow sampling or Counters sampling.

Syntax

show sflow configuration [*interface-id*]

Parameters

interface-id—Specifies an interface ID. The interface ID must be an Ethernet port.

Command Mode

EXEC mode

Example

Console # **show sflow configuration**

Receivers

Index	IP Address	Port	Max Datagram Size
1	0.0.0.0	6343	1400
2	172.16.1.2	6343	1400
3	0.0.0.0	6343	1400
4	0.0.0.0	6343	1400
5	0.0.0.0	6343	1400
6	0.0.0.0	6343	1400
7	0.0.0.0	6343	1400
8	0.0.0.0	6343	1400

Interfaces

Inter- face	Flow Sampling	Counters Sampling	Max Header Size	Flow Collector	Counters Index	Collector Index
fe1/0/11	1/2048	60 sec	128	1		1
fe1/0/12	1/4096	Disabled	128	0		2



27.6 show sflow statistics

Use the **show sflow statistics** EXEC mode command to display the sFlow statistics for ports that are enabled for Flow sampling or Counters sampling.

Syntax

show sflow statistics [*interface-id*]

Parameters

interface-id—Specifies an interface ID. The interface ID must be an Ethernet port.

Command Mode

EXEC mode

Example

```
Console # show sflow statistics  
Total sFlow datagrams sent to collectors: 100
```

Interface	Packets sampled	Datagrams sent to collector
-----	-----	-----
fe1/0/11	30	50
fe1/0/12	30	50
fe1/0/13	30	50

28 Link Layer Discovery Protocol (LLDP) Commands

28.1 `lldp run`

Use the `lldp run` Global Configuration mode command to enable LLDP. To disable LLDP, use the `no` form of this command.

Syntax

`lldp run`

`no lldp run`

Parameters

N/A.

Default Configuration

Enabled

Command Mode

Global Configuration mode

Example

```
console(config)# lldp run
```

28.2 `lldp transmit`

Use the `lldp transmit` Interface Configuration mode command to enable transmitting LLDP on an interface. Use the `no` form of this command to stop transmitting LLDP on an interface.

Syntax

`lldp transmit`

`no lldp transmit`

Parameters

N/A

Default Configuration

Enabled

Command Mode

Interface Configuration (Ethernet) mode

User Guidelines

LLDP manages LAG ports individually. LLDP sends separate advertisements on each port in a LAG. LLDP operation on a port is not dependent on the STP state of a port. I.e. LLDP frames are sent on blocked ports.

If a port is controlled by 802.1x, LLDP operates only if the port is authorized.

Example

```
console(config)# interface fe1/0/11
console(config-if)# lldp transmit
```

28.3 lldp receive

Use the **lldp receive** Interface Configuration mode command to enable receiving LLDP on an interface. Use the **no** form of this command to stop receiving LLDP on an interface.

Syntax

lldp receive

no lldp receive

Parameters

N/A

Default Configuration

Enabled

Command Mode

Interface Configuration (Ethernet) mode

User Guidelines

LLDP manages LAG ports individually. LLDP data received through LAG ports is stored individually per port.

LLDP operation on a port is not dependent on the STP state of a port. I.e. LLDP frames are received on blocked ports.

If a port is controlled by 802.1x, LLDP operates only if the port is authorized.

Example

```
console(config)# interface fe1/0/11
console(config-if)# lldp receive
```

28.4 lldp timer

Use the **lldp timer** Global Configuration mode command to specify how often the software sends LLDP updates. Use the **no** form of this command to restore the default configuration.

Syntax

lldp timer *seconds*

no lldp timer

Parameters

timer *seconds*—Specifies, in seconds, how often the software sends LLDP updates (range: 5-32768 seconds).

Default Configuration

30 seconds.

Command Mode

Global Configuration mode

Example

The following example sets the interval for sending LLDP updates to 60 seconds.

```
Console(config)# lldp timer 60
```

28.5 lldp hold-multiplier

Use the **lldp hold-multiplier** Global Configuration mode command to specify how long the receiving device holds a LLDP packet before discarding it. Use the **no** form of this command to restore the default configuration.

Syntax

lldp hold-multiplier *number*

no lldp hold-multiplier

Parameters

hold-multiplier *number*—Specifies the LLDP packet hold time interval as a multiple of the LLDP timer value (range: 2-10).

Default Configuration

The default LLDP hold multiplier is 4.

Command Mode

Global Configuration mode

User Guidelines

The actual Time-To-Live (TTL) value of LLDP frames is calculated by the following formula:

$$\text{TTL} = \min(65535, \text{LLDP-Timer} * \text{LLDP-hold-multiplier})$$

For example, if the value of the LLDP timer is 30 seconds, and the value of the LLDP hold multiplier is 4, then the value 120 is encoded in the TTL field of the LLDP header.

Example

The following example sets the LLDP packet hold time interval to 90 seconds.

```
Console(config)# lldp timer 30
Console(config)# lldp hold-multiplier 3
```

28.6 lldp reinit

Use the **lldp reinit** Global Configuration mode command to specify the minimum time an LLDP port waits before reinitializing LLDP transmission. Use the **no** form of this command to revert to the default setting.

Syntax

lldp reinit *seconds*

no lldp reinit

Parameters

reinit *seconds*—Specifies the minimum time in seconds an LLDP port waits before reinitializing LLDP transmission.(Range: 1–10)

Default Configuration

2 seconds

Command Mode

Global Configuration mode

Example

```
console(config)# lldp reinit 4
```

28.7 lldp tx-delay

Use the **lldp tx-delay** Global Configuration mode command to set the delay between successive LLDP frame transmissions initiated by value/status changes in the LLDP local systems MIB. Use the **no** form of this command to restore the default configuration.

Syntax

lldp tx-delay *seconds*

no lldp tx-delay

Parameters

tx-delay *seconds*—Specifies the delay in seconds between successive LLDP frame transmissions initiated by value/status changes in the LLDP local systems MIB (range: 1-8192 seconds).

Default Configuration

The default LLDP frame transmission delay is 2 seconds.

Command Mode

Global Configuration mode

User Guidelines

It is recommended that the tx-delay be less than 0.25 of the LLDP timer interval.

Example

The following example sets the LLDP transmission delay to 10 seconds.

```
Console(config)# lldp tx-delay 10
```

28.8 Ildp management-address

Use the **lldp management-address** Interface Configuration (Ethernet) mode command to specify the management address advertised by an interface. Use the **no** form of this command to stop advertising management address information.

Syntax

lldp management-address {*ip-address* | **none** | **automatic** [*interface-id*]}

no lldp management-address

Parameters

- **ip-address**—Specifies the static management address to advertise.
- **none**—Specifies that no address is advertised.
- **automatic**—Specifies that the software automatically selects a management address to advertise from all the IP addresses of the product. In case of multiple IP addresses, the software selects the lowest IP address among the dynamic IP addresses. If there are no dynamic addresses, the software selects the lowest IP address among the static IP addresses.
- **automatic interface-id**—(Available only when the device is in Layer 3 (router mode)). Specifies that the software automatically selects a management address to advertise from the IP addresses that are configured on the interface ID. In case of multiple IP addresses, the software selects the lowest IP address among the dynamic IP addresses of the interface. If there are no dynamic addresses, the software selects the lowest IP address among the static IP addresses of the interface. The interface ID can be one of the following types: Ethernet port, port-channel or VLAN. Note that if the port or port-channel are members in a VLAN that has an IP address, that address is not included because the address is associated with the VLAN.

Default Configuration

No IP address is advertised.

The default advertisement is **automatic**.

Command Mode

Interface Configuration (Ethernet) mode

User Guidelines

Each port can advertise one IP address.

Example

The following example sets the LLDP management address advertisement mode to **automatic** on fe1/0/12.

```
Console(config)# interface fe1/0/12
Console(config-if)# lldp management-address automatic
```

28.9 lldp notifications

Use the **lldp notifications** Interface Configuration (Ethernet) mode command to enable/disable sending LLDP notifications on an interface. Use the **no** form of this command to restore the default configuration.

Syntax

lldp notifications {*enable* | *disable*}

no lldp notifications

Parameters

- **enable**—Enables sending LLDP notifications.
- **disable**—Disables sending LLDP notifications.

Default Configuration

Disabled.

Command Mode

Interface Configuration (Ethernet) mode

Example

The following example enables sending LLDP notifications on fe1/0/15.

```
Console(config)# interface fe1/0/15
Console(config-if)# lldp notifications enable
```

28.10 lldp notifications interval

Use the **lldp notifications interval** Global Configuration mode command to configure the maximum transmission rate of LLDP notifications. Use the **no** form of this command to return to the default.

Syntax

lldp notifications interval *seconds*

no lldp notifications interval

Parameters

interval *seconds*—The device does not send more than a single notification in the indicated period (range: 5–3600).

Default Configuration

5 seconds

Command Mode

Global Configuration mode

Example

```
console(config)# lldp notifications interval 10
```

28.11 lldp optional-tlv 802.1

Use the **lldp optional-tlv** Interface Configuration mode command to specify which optional TLVs to transmit. Use the **no** form of this command to revert to the default setting.

Syntax

lldp optional-tlv 802.1 pvid - The PVID is advertised.

no lldp optional-tlv 802.1 pvid - The PVID is not advertised

lldp optional-tlv 802.1 ppvid add ppvid - The Protocol Port VLAN ID (PPVID) is advertised. The PPVID is the PVID that is used depending on the packet's protocol.

lldp optional-tlv 802.1 ppvid remove ppvid - The PPVID is not advertised.

lldp optional-tlv 802.1 vlan add vlan-id - This *vlan-id* is advertised.

lldp optional-tlv 802.1 vlan remove vlan-id - This *vlan-id* is not advertised.

lldp optional-tlv 802.1 protocol add {stp | rstp | mstp | pause | 802.1x | lacp | gvrp} - The protocols selected are advertised.

lldp optional-tlv 802.1 protocol remove {stp | rstp | mstp | pause | 802.1x | lacp | gvrp} - The protocols selected are not advertised.

Parameters

- **lldp optional-tlv 802.1 pvid**—Advertises the PVID of the port.
- **lldp optional-tlv 802.1 ppvid add/remove ppvid**—Adds/removes PPVID for advertising. (range: 0–4094). PPVID = 0 indicates that the port is not capable of supporting port and protocol VLANs and/or the port is not enabled with any protocol VLANs.
- **add/remove vlan-id**—Adds/removes VLAN for advertising (range: 0–4094).
- **add/remove {stp | rstp | mstp | pause | 802.1x | lacp | gvrp}**—Add specifies to advertise the specified protocols; remove specifies not to advertise the specified protocol.

Default Configuration

No optional TLV is transmitted.

Command Mode

Interface Configuration (Ethernet) mode

Example

```
console(config)# lldp optional-tlv 802.1 protocol add stp
```

28.12 Ildp Ildpdu

The **ildp ildpdu** Global Configuration mode command defines LLDP packet handling when LLDP is globally disabled. To restore the default configuration, use the **no** form of this command.

Syntax

ildp ildpdu {*filtering* | *flooding*}

no ildp ildpdu

Parameters

- **filtering** — Specifies that when LLDP is globally disabled, LLDP packets are filtered (deleted).
- **flooding** — Specifies that when LLDP is globally disabled, LLDP packets are flooded (forwarded to all interfaces).

Default Configuration

LLDP packets are filtered when LLDP is globally disabled.

Command Mode

Global Configuration mode

User Guidelines

If the STP mode is MSTP, the LLDP packet handling mode cannot be set to **flooding**.

The STP mode cannot be set to MSTP if the LLDP packet handling mode is **flooding**.

If LLDP is globally disabled, and the LLDP packet handling mode is **flooding**, LLDP packets are treated as data packets with the following exceptions:

- VLAN ingress rules are not applied to LLDP packets. The LLDP packets are trapped on all ports for which the STP state is Forwarding.
- Default "deny-all" rules are not applied to LLDP packets.
- VLAN egress rules are not applied to LLDP packets. The LLDP packets are flooded to all ports for which the STP state is Forwarding.
- LLDP packets are sent as untagged.

Example

The following example sets the LLDP packet handling mode to Flooding when LLDP is globally disabled.

```
Console(config)# ildp ildpdu flooding
```

28.13 Ildp med enable

Use the **ildp med enable** Interface Configuration (Ethernet) mode command to enable LLDP Media Endpoint Discovery (MED) on an interface. Use the **no** form of this command to disable LLDP MED on an interface.

Syntax

ildp med enable [*tlv* ... *tlv4*]

no lldp med enable

Parameters

tlv—Specifies the TLVs that should be included. Available TLVs are: network-policy, location, poe-pse, and inventory. The capabilities TLV is always included if LLDP-MED is enabled.

Default Configuration

LLDP MED is enabled.

Command Mode

Interface Configuration (Ethernet) mode

Example

The following example enables LLDP MED with the **location** TLV on `fe1/0/13`.

```
Console(config)# interface fe1/0/13
Console(config-if)# lldp med enable location
```

28.14 lldp med notifications topology-change

Use the **lldp med notifications topology-change** Interface Configuration (Ethernet) mode command to enable sending LLDP MED topology change notifications on a port. Use the **no** form of this command to restore the default configuration.

Syntax

lldp med notifications topology-change {*enable* | *disable*}

no lldp med notifications topology-change

Parameters

- **enable**—Enables sending LLDP MED topology change notifications.
- **disable**—Disables sending LLDP MED topology change notifications.

Default Configuration

Disable is the default.

Command Mode

Interface Configuration (Ethernet) mode

Example

The following example enables sending LLDP MED topology change notifications on `fe1/0/12`.

```
Console(config)# interface fe1/0/12
Console(config-if)# lldp med notifications topology-change enable
```

28.15 lldp med fast-start repeat-count

When a port comes up, LLDP can send packets more quickly than usual using its fast-start mechanism.

Use the **lldp med fast-start repeat-count** Global Configuration mode command to configure the number of packets that is sent during the activation of the fast start mechanism. Use the **no** form of this command return to default.

Syntax

lldp med fast-start repeat-count *number*

no lldp med fast-start repeat-count

Parameters

repeat-count *number*—Specifies the number of times the fast start LLDPDU is being sent during the activation of the fast start mechanism. The range is 1-10.

Default Configuration

3

Command Mode

Global Configuration mode

Example

```
console(config)# lldp med fast-start repeat-count 4
```

28.16 lldp med network-policy (global)

Use the **lldp med network-policy** Global Configuration mode command to define a LLDP MED network policy. For voice applications, it is simpler to use [lldp med network-policy voice auto](#).

The **lldp med network-policy** command creates the network policy, which is attached to a port by [lldp med network-policy \(interface\)](#).

The network policy defines how LLDP packets are constructed.

Use the **no** form of this command to remove LLDP MED network policy.

Syntax

lldp med network-policy *number application [vlan vlan-id] [vlan-type {tagged | untagged}] [up priority] [dscp value]*

no lldp med network-policy *number*

Parameters

- **number**—Network policy sequential number. The range is 1-32.
- **application**—The name or the number of the primary function of the application defined for this network policy. Available application names are:
 - voice
 - voice-signaling

- guest-voice
 - guest-voice-signaling
 - softphone-voice
 - video-conferencing
 - streaming-video
 - video-signaling.
- **vlan** *vlan-id*—VLAN identifier for the application.
 - **vlan-type**—Specifies if the application is using a tagged or an untagged VLAN.
 - **up priority**—User Priority (Layer 2 priority) to be used for the specified application.
 - **dscp value**—DSCP value to be used for the specified application.

Default Configuration

No network policy is defined.

Command Mode

Global Configuration mode

User Guidelines

Use the **lldp med network-policy** Interface Configuration command to attach a network policy to a port.

Up to 32 network policies can be defined.

Example

This example creates a network policy for the voice-signaling application and attaches it to port 1. LLDP packets sent on port 1 will contain the information defined in the network policy.

```
console(config)# lldp med network-policy 1 voice-signaling vlan 1
vlan-type untagged up 1 dscp 2
Console(config)# interface fe1/0/11
Console(config-if)# lldp med network-policy add 1
```

28.17 lldp med network-policy (interface)

Use the **lldp med network-policy** Interface Configuration (Ethernet) mode command to attach or remove an LLDP MED network policy on a port. Network policies are created in [lldp med network-policy \(global\)](#).

Use the **no** form of this command to remove all the LLDP MED network policies from the port.

Syntax

lldp med network-policy {*add* | *remove*} *number*

no lldp med network-policy *number*

Parameters

- **number**—Specifies the network policy sequential number. The range is 1-32
- **add/remove number**—Attaches/removes the specified network policy to the interface.

Default Configuration

No network policy is attached to the interface.

Command Mode

Interface Configuration (Ethernet) mode

User Guidelines

For each port, only one network policy per application (voice, voice-signaling, etc.) can be defined.

Example

This example creates a network policy for the voice-signally application and attaches it to port 1. LLDP packets sent on port 1 will contain the information defined in the network policy.

```
console(config)# lldp med network-policy 1 voice-signaling vlan 1
vlan-type untagged up 1 dscp 2
Console(config)# interface fe1/0/11
Console(config-if)# lldp med network-policy add 1
```

28.18 clear lldp table

Use the **clear lldp table** command in Privileged EXEC mode to clear the neighbors table for all ports or for a specific port.

Syntax

clear lldp table [*interface-id*]

Parameters

interface-id—Specifies a port ID.

Default Configuration

If no interface is specified, the default is to clear the LLDP table for all ports.

Command Mode

Privileged EXEC mode

Example

```
console# clear lldp table fe1/0/11
```

28.19 lldp med location

Use the **lldp med location** Interface Configuration (Ethernet) mode command to configure the location information for the LLDP Media Endpoint Discovery (MED) for a port. Use the **no** form of this command to delete location information for a port.

Syntax

lldp med location {{*coordinate data*} | {*civic-address data*} | {*ecs-elin data*}}

no lldp med location {*coordinate* | *civic-address* | *ecs-elin*}

Parameters

- **coordinate data**—Specifies the location data as coordinates in hexadecimal format.
- **civic-address data**—Specifies the location data as a civic address in hexadecimal format.
- **ecs-elin data**—Specifies the location data as an Emergency Call Service Emergency Location Identification Number (ECS ELIN) in hexadecimal format.
- **data**—Specifies the location data in the format defined in ANSI/TIA 1057: dotted hexadecimal data: Each byte in a hexadecimal character string is two hexadecimal digits. Bytes are separated by a period or colon. (Length: coordinate: 16 bytes. Civic-address: 6-160 bytes. Ecs-elin: 10-25 bytes)

Default Configuration

The location is not configured.

Command Mode

Interface Configuration (Ethernet) mode

Example

The following example configures the LLDP MED location information on fe1/0/12 as a civic address.

```
console(config)# interface fe1/0/12
console(config-if)# lldp med location civic-address 616263646566
```

28.20 show lldp configuration

Use the **show lldp configuration** Privileged EXEC mode command to display the LLDP configuration for all ports or for a specific port.

Syntax

show lldp configuration [*interface-id*]

Parameters

interface-id—Specifies the port ID.

Default Configuration

N/A

Command Mode

Privileged EXEC mode

Examples

Example 1 - Display LLDP configuration for all ports.

```
Switch# show lldp configuration
State: Enabled
```



```

Timer: 30 Seconds
Hold multiplier: 4
Reinit delay: 2 Seconds
Tx delay: 2 Seconds
Notifications interval: 5 seconds
LLDP packets handling: Filtering
Port      State  Optional TLVs      Address      Notifications
-----  -
fe1/0/11  RX,TX  PD, SN, SD, SC    172.16.1.1  Disabled
fe1/0/12  TX      PD, SN             172.16.1.1  Disabled
fe1/0/13  RX,TX  PD, SN, SD, SC    None         Disabled
fe1/0/15  RX,TX  D, SN, SD, SC     automatic    Disabled
fe1/0/16  RX,TX  PD, SN, SD, SC    auto vlan 1  Disabled
fe1/0/17  RX,TX  PD, SN, SD, SC    auto g1      Disabled
fe1/0/18  RX,TX  PD, SN, SD, SC    auto chl     Disabled
    
```

Example 2 - Display LLDP configuration for port 1.

```

Switch# show lldp configuration fe1/0/11
State: Enabled
Timer: 30 Seconds
Hold multiplier: 4
Reinit delay: 2 Seconds
Tx delay: 2 Seconds
Notifications interval: 5 seconds
LLDP packets handling: Filtering
Port State  Optional TLVs      Address      Notifications
-----  -
fe1/0/11  RX, TX  PD, SN, SD, SC    72.16.1.1  Disabled
802.3 optional TLVs: 802.3-mac-phy, 802.3-lag, 802.3-max-frame-size
802.1 optional TLVs
PVID: Enabled
PPVIDs: 0, 1, 92
VLANs: 1, 92
Protocols: 802.1x
    
```

The following table describes the significant fields shown in the display:

Field	Description
Timer	The time interval between LLDP updates.
Hold multiplier	The amount of time (as a multiple of the timer interval) that the receiving device holds a LLDP packet before discarding it.
Reinit timer	The minimum time interval an LLDP port waits before re-initializing an LLDP transmission.
Tx delay	The delay between successive LLDP frame transmissions initiated by value/status changes in the LLDP local systems MIB.

Field	Description
Port	The port number.
State	The port's LLDP state.
Optional TLVs	Optional TLVs that are advertised. Possible values are: PD - Port description SN - System name SD - System description SC - System capabilities
Address	The management address that is advertised.
Notifications	Indicates whether LLDP notifications are enabled or disabled.
PVID	Port VLAN ID advertised.
PPVID	Protocol Port VLAN ID advertised.
Protocols	Protocols advertised.

28.21 show lldp med configuration

Use the **show lldp med configuration** Privileged EXEC mode command to display the LLDP Media Endpoint Discovery (MED) configuration for all ports or for a specific port.

Syntax

show lldp med configuration [*interface-id*]

Parameters

interface-id—Specifies a port ID.

Default Configuration

If no port ID is entered, the command displays information for all ports.

Command Mode

Privileged EXEC mode

Examples

Example 1 - The following example displays the LLDP MED configuration for all interfaces.

```

console# show lldp med configuration
Fast Start Repeat Count: 4.
Network policy 1
-----
Application type: voiceSignaling
VLAN ID: 1 untagged
Layer 2 priority: 0
DSCP: 0
Port      Capabilities  Network Policy Location  Notifications  Inventory
-----
fel/0/11  Yes           Yes           Yes           Enabled        Yes

```

fe1/0/12	Yes	Yes	No	Enabled	No
fe1/0/13	No	No	No	Enabled	No

Example 2 - The following example displays the LLDP MED configuration for fe1/0/11.

```

console# show lldp med configuration fe1/0/11

Port      Capabilities  Network Policy  Location  Notifications  Inventory
-----
fe1/0/11  Yes           Yes             Yes       Enabled         Yes
Network policies:
Location:
Civic-address: 61:62:63:64:65:66
    
```

28.22 show lldp local tlvs-overloading

When an LLDP packet contains too much information for one packet, this is called overloading. Use the **show lldp local tlvs-overloading** EXEC mode command to display the status of TLVs overloading of the LLDP on all ports or on a specific port.

Syntax

show lldp local tlvs-overloading [*interface-id*]

Parameters

interface-id—Specifies a port ID.

Default Configuration

If no port ID is entered, the command displays information for all ports.

Command Mode

EXEC mode

User Guidelines

The command calculates the overloading status of the current LLDP configuration, and not for the last LLDP packet that was sent.

Example

```

Switch# show lldp local tlvs-overloading fe1/0/11

TLVs Group           Bytes      Status
-----
Mandatory            31         Transmitted
LLDP-MED Capabilities 9           Transmitted
LLDP-MED Location    200        Transmitted
802.1                 1360       Overloading
Total: 1600 bytes
    
```

Left: 100 bytes

28.23 show lldp local

Use the **show lldp local** Privileged EXEC mode command to display the LLDP information that is advertised from a specific port.

Syntax

show lldp local *interface-id*

Parameters

Interface-id—Specifies a port ID.

Default Configuration

If no port ID is entered, the command displays information for all ports.

Command Mode

Privileged EXEC mode

Example

The following examples display LLDP information that is advertised from `fe1/0/11` and `2`.

```
Switch# show lldp local fe1/0/11
Device ID: 0060.704C.73FF
Port ID: fe1/0/11
Capabilities: Bridge
System Name: ts-7800-1
System description:
Port description:
Management address: 172.16.1.8
802.3 MAC/PHY Configuration/Status
Auto-negotiation support: Supported
Auto-negotiation status: Enabled
Auto-negotiation Advertised Capabilities: 100BASE-TX full duplex,
1000BASE-T full duplex
Operational MAU type: 1000BaseTFD
802.3 Link Aggregation
Aggregation capability: Capable of being aggregated
Aggregation status: Not currently in aggregation
Aggregation port ID: 1
802.3 Maximum Frame Size: 1522
802.3 EEE
Local Tx: 30 usec
Local Rx: 25 usec
Remote Tx Echo: 30 usec
Remote Rx Echo: 25 usec
```



```
802.1 PVID: 1
802.1 PPVID: 2 supported, enabled
802.1 VLAN: 2 (VLAN2)
802.1 Protocol: 88 8E 01
LLDP-MED capabilities: Network Policy, Location Identification
LLDP-MED Device type: Network Connectivity
LLDP-MED Network policy
Application type: Voice
Flags: Tagged VLAN
VLAN ID: 2
Layer 2 priority: 0
DSCP: 0
LLDP-MED Power over Ethernet
Device Type: Power Sourcing Entity
Power source: Primary Power Source
Power priority: High
Power value: 9.6 Watts
LLDP-MED Location
Coordinates: 54:53:c1:f7:51:57:50:ba:5b:97:27:80:00:00:67:01
Hardware Revision: B1
Firmware Revision: A1
Software Revision: 3.8
Serial number: 7978399
Manufacturer name: Manufacturer
Model name: Model 1
Asset ID: Asset 123
Switch# show lldp local fe1/0/12
LLDP is disabled.
```

28.24 show lldp neighbors

Use the **show lldp neighbors** Privileged EXEC mode command to display information about neighboring devices discovered using LLDP. The information can be displayed for all ports or for a specific port.

Syntax

show lldp neighbors [*interface-id*]

Parameters

interface-id—Specifies a port ID.

Default Configuration

If no port ID is entered, the command displays information for all ports.

Command Mode

Privileged EXEC mode

User Guidelines

A TLV value that cannot be displayed as an ASCII string is displayed as a hexadecimal string.

Examples

Example 1 - The following example displays information about neighboring devices discovered using LLDP on all ports on which LLDP is enabled and who are up.

Location information, if it exists, is also displayed.

```
Switch# show lldp neighbors
Port  Device ID          Port ID  System Name  Capabilities  TTL
-----
fe1/0/11 00:00:00:11:11:11    fe1/0/11    ts-7800-2    B              90
fe1/0/11 00:00:00:11:11:11 D fe1/0/11    ts-7800-2    B              90
fe1/0/12 00:00:26:08:13:24    fe1/0/13    ts-7900-1    B, R          90
fe1/0/13 00:00:26:08:13:24    fe1/0/12    ts-7900-2    W              90
```

Example 2 - The following example displays information about neighboring devices discovered using LLDP on port 1.

```
Switch# show lldp neighbors fe1/0/11
Device ID: 00:00:00:11:11:11
Port ID: fe1/0/11
System Name: ts-7800-2
Capabilities: B
System description:
Port description:
Management address: 172.16.1.1
Time To Live: 90 seconds
802.3 MAC/PHY Configuration/Status
Auto-negotiation support: Supported.
Auto-negotiation status: Enabled.
Auto-negotiation Advertised Capabilities: 100BASE-TX full duplex,
1000BASE-T full duplex.
Operational MAU type: 1000BaseTFD
802.3 Power via MDI
MDI Power support Port Class: PD
PSE MDI Power Support: Not Supported
PSE MDI Power State: Not Enabled
PSE power pair control ability: Not supported.
PSE Power Pair: Signal
PSE Power class: 1
802.3 Link Aggregation
Aggregation capability: Capable of being aggregated
Aggregation status: Not currently in aggregation
Aggregation port ID: 1
```



```
802.3 Maximum Frame Size: 1522
802.3 EEE
Remote Tx: 25 usec
Remote Rx: 30 usec
Local Tx Echo: 30 usec
Local Rx Echo: 25 usec
802.1 PVID: 1
802.1 PPVID: 2 supported, enabled
802.1 VLAN: 2(VLAN2)
802.1 Protocol: 88 8E 01
LLDP-MED capabilities: Network Policy.
LLDP-MED Device type: Endpoint class 2.
LLDP-MED Network policy
Application type: Voice
Flags: Unknown policy
VLAN ID: 0
Layer 2 priority: 0
DSCP: 0
LLDP-MED Power over Ethernet
Device Type: Power Device
Power source: Primary power
Power priority: High
Power value: 9.6 Watts
Hardware revision: 2.1
Firmware revision: 2.3
Software revision: 2.7.1
Serial number: LM759846587
Manufacturer name: VP
Model name: TR12
Asset ID: 9
LLDP-MED Location
Coordinates: 54:53:c1:f7:51:57:50:ba:5b:97:27:80:00:00:67:01
```

The following table describes significant LLDP fields shown in the display:

Field	Description
Port	The port number.
Device ID	The neighbor device's configured ID (name) or MAC address.
Port ID	The neighbor device's port ID.
System name	The neighbor device's administratively assigned name.

Link Layer Discovery Protocol (LLDP) Commands

Field	Description
Capabilities	The capabilities discovered on the neighbor device. Possible values are: B - Bridge R - Router W - WLAN Access Point T - Telephone D - DOCSIS cable device H - Host r - Repeater O - Other
System description	The neighbor device's system description.
Port description	The neighbor device's port description.
Management address	The neighbor device's management address.
Auto-negotiation support	The auto-negotiation support status on the port. (supported or not supported)
Auto-negotiation status	The active status of auto-negotiation on the port. (enabled or disabled)
Auto-negotiation Advertised Capabilities	The port speed/duplex/flow-control capabilities advertised by the auto-negotiation.
Operational MAU type	The port MAU type.
LLDP MED	
Capabilities	The sender's LLDP-MED capabilities.
Device type	The device type. Indicates whether the sender is a Network Connectivity Device or Endpoint Device, and if an Endpoint, to which Endpoint Class it belongs.
LLDP MED - Network Policy	
Application type	The primary function of the application defined for this network policy.
Flags	Flags. The possible values are: Unknown policy: Policy is required by the device, but is currently unknown. Tagged VLAN: The specified application type is using a tagged VLAN. Untagged VLAN: The specified application type is using an Untagged VLAN.
VLAN ID	The VLAN identifier for the application.
Layer 2 priority	The Layer 2 priority used for the specified application.
DSCP	The DSCP value used for the specified application.
LLDP MED - Power Over Ethernet	
Power type	The device power type. The possible values are: Power Sourcing Entity (PSE) or Power Device (PD).

Field	Description
Power Source	The power source utilized by a PSE or PD device. A PSE device advertises its power capability. The possible values are: Primary power source and Backup power source. A PD device advertises its power source. The possible values are: Primary power, Local power, Primary and Local power.
Power priority	The PD device priority. A PSE device advertises the power priority configured for the port. A PD device advertises the power priority configured for the device. The possible values are: Critical, High and Low.
Power value	The total power in watts required by a PD device from a PSE device, or the total power a PSE device is capable of sourcing over a maximum length cable based on its current configuration.
LLDP MED - Location	
Coordinates, Civic address, ECS ELIN.	The location information raw data.

28.25 show lldp statistics

Use the `show lldp statistics` EXEC mode command to display LLDP statistics on all ports or a specific port.

Syntax

`show lldp statistics [interface-id]`

Parameters

interface-id—Specifies a port ID.

Default Configuration

If no port ID is entered, the command displays information for all ports.

Command Mode

EXEC mode

Example

```
Switch# show lldp statistics
console(config-if)# do show lldp statistics
Tables Last Change Time: 14-Oct-2010 32:08:18
Tables Inserts: 26
Tables Deletes: 2
Tables Dropped: 0
Tables Ageouts: 1
TX Frames      RX Frame      RX TLVs      RX Ageouts
```


Link Layer Discovery Protocol (LLDP) Commands

Port	Total	Total	Discarded	Errors	Discarded	Unrecognized	Total
-----	-----	-----	-----	-----	-----	-----	-----
fe1/0/11	730	850	0	0	0	0	0
fe1/0/12	0	0	0	0	0	0	0
fe1/0/13	730	0	0	0	0	0	0
fe1/0/14	0	0	0	0	0	0	0
fe1/0/15	0	0	0	0	0	0	0
fe1/0/16	8	7	0	0	0	0	1
fe1/0/17	0	0	0	0	0	0	0
fe1/0/18	0	0	0	0	0	0	0
fe1/0/19	730	0	0	0	0	0	0
fe1/0/110	0	0	0	0	0	0	0

29 Spanning-Tree Commands

29.1 spanning-tree

Use the **spanning-tree** Global Configuration mode command to enable spanning-tree functionality. Use the **no** form of this command to disable the spanning-tree functionality.

Syntax

spanning-tree

no spanning-tree

Parameters

N/A

Default Configuration

Spanning-tree is enabled.

Command Mode

Global Configuration mode

Example

The following example enables spanning-tree functionality.

```
switchxxxxxx(config)# spanning-tree
```

29.2 spanning-tree mode

Use the **spanning-tree mode** Global Configuration mode command to select which Spanning Tree Protocol (STP) protocol to run. Use the **no** form of this command to restore the default configuration.

Syntax

spanning-tree mode {stp | rstp | mst}

no spanning-tree mode

Parameters

- **stp**—Specifies that STP is enabled.
- **rstp**—Specifies that the Rapid STP is enabled.
- **mst**—Specifies that the Multiple STP is enabled.

Default Configuration

The default is RSTP.

Command Mode

Global Configuration mode

User Guidelines

In RSTP mode, the device uses STP when the neighbor device uses STP.

In MSTP mode, the device uses RSTP when the neighbor device uses RSTP, and uses STP when the neighbor device uses STP.

Example

The following example enables MSTP.

```
switchxxxxxx(config)# spanning-tree mode mstp
```

29.3 spanning-tree forward-time

Use the **spanning-tree forward-time** Global Configuration mode command to configure the spanning-tree bridge forward time, which is the amount of time a port remains in the listening and learning states before entering the forwarding state. Use the **no** form of this command to restore the default configuration.

Syntax

spanning-tree forward-time *seconds*

no spanning-tree forward-time

Parameters

seconds—Specifies the spanning-tree forward time in seconds. (Range: 4–30)

Default Configuration

15 seconds.

Command Mode

Global Configuration mode

User Guidelines

When configuring the forwarding time, the following relationship should be maintained:

$$2 * (\text{Forward-Time} - 1) \geq \text{Max-Age}$$

Example

The following example configures the spanning tree bridge forwarding time to 25 seconds.

```
switchxxxxxx(config)# spanning-tree forward-time 25
```

29.4 spanning-tree hello-time

Use the **spanning-tree hello-time** Global Configuration mode command to configure how often the device broadcasts Hello messages to other devices. Use the **no** form of this command to restore the default configuration.

Syntax**spanning-tree hello-time** *seconds***no spanning-tree hello-time****Parameters****seconds**—Specifies the spanning-tree Hello time in seconds. (Range: 1–10)**Default Configuration**

2 seconds.

Command Mode

Global Configuration mode

User Guidelines

When configuring the Hello time, the following relationship should be maintained:

$$\text{Max-Age} \geq 2 * (\text{Hello-Time} + 1)$$

Example

The following example configures the spanning-tree bridge hello time to 5 seconds.

```
switchxxxxxx(config)# spanning-tree hello-time 5
```

29.5 spanning-tree max-age

Use the **spanning-tree max-age** Global Configuration mode command to configure the STP maximum age. Use the **no** form of this command to restore the default configuration.**Syntax****spanning-tree max-age** *seconds***no spanning-tree max-age****Parameters****seconds**—Specifies the spanning-tree bridge maximum age in seconds. (Range: 6–40)**Default Configuration**

The default maximum age is 20 seconds.

Command Mode

Global Configuration mode

User Guidelines

When configuring the maximum age, the following relationships should be maintained:

$$2 * (\text{Forward-Time} - 1) \geq \text{Max-Age}$$

$$\text{Max-Age} \geq 2 * (\text{Hello-Time} + 1)$$

Example

The following example configures the spanning-tree bridge maximum age to 10 seconds.

```
switchxxxxxx(config)# spanning-tree max-age 10
```

29.6 spanning-tree priority

Use the **spanning-tree priority** Global Configuration mode command to configure the device STP priority, which is used to determine which bridge is selected as the root bridge. Use the **no** form of this command to restore the default device spanning-tree priority.

Syntax

spanning-tree priority *priority*

no spanning-tree priority

Parameters

priority—Specifies the bridge priority. (Range: 0–61440)

Default Configuration

Default priority = 32768.

Command Mode

Global Configuration mode

User Guidelines

The priority value must be a multiple of 4096.

The switch with the lowest priority is the root of the spanning tree. When more than one switch has the lowest priority, the switch with the lowest MAC address is selected as the root.

Example

The following example configures the spanning-tree priority to 12288.

```
switchxxxxxx(config)# spanning-tree priority 12288
```

29.7 spanning-tree disable

Use the **spanning-tree disable** Interface Configuration (Ethernet, port-channel) mode command to disable the spanning tree on a specific port. Use the **no** form of this command to enable the spanning tree on a port.

Syntax

spanning-tree disable

no spanning-tree disable

Parameters

N/A

Default Configuration

Spanning tree is enabled on all ports.

Command Mode

Interface Configuration (Ethernet, port-channel) mode

Example

The following example disables the spanning tree on fe1/0/15

```
switchxxxxxx(config)# interface fe1/0/15
switchxxxxxx(config-if)# spanning-tree disable
```

29.8 spanning-tree cost

Use the **spanning-tree cost** Interface Configuration (Ethernet, port-channel) mode command to configure the spanning-tree path cost for a port. Use the **no** form of this command to restore the default configuration.

Syntax

spanning-tree cost *cost*

no spanning-tree cost

Parameters

cost—Specifies the port path cost. (Range: 1–200000000)

Default Configuration

Default path cost is determined by port speed and path cost method (long or short) as shown below:

Interface	Long	Short
Port-channel	20,000	4
TenGigabit Ethernet (10000 Mbps)	2000	2
Gigabit Ethernet (1000 Mbps)	20,000	4
Fast Ethernet (100 Mbps)	200,000	19
Ethernet (10 Mbps)	2,000,000	100

Command Mode

Interface Configuration (Ethernet, port-channel) mode

Example

The following example configures the spanning-tree cost on fe1/0/115 to 35000.

```
switchxxxxxx(config)# interface fe1/0/115
switchxxxxxx(config-if)# spanning-tree cost 35000
```

29.9 spanning-tree port-priority

Use the **spanning-tree port-priority** Interface Configuration (Ethernet, port-channel) mode command to configure the port priority. Use the **no** form of this command to restore the default configuration.

Syntax

spanning-tree port-priority *priority*

no spanning-tree port-priority

Parameters

priority—Specifies the port priority. (Range: 0–240)

Default Configuration

The default port priority is 128.

Command Mode

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

The priority value must be a multiple of 16.

Example

The following example configures the spanning priority on `fe1/0/115` to 96

```
switchxxxxxx(config)# interface fe1/0/115
switchxxxxxx(config-if)# spanning-tree port-priority 96
```

29.10 spanning-tree portfast

Use the **spanning-tree portfast** Interface Configuration (Ethernet, port-channel) mode command to enable the PortFast mode. In PortFast mode, the interface is immediately put into the forwarding state upon linkup, without waiting for the standard forward time delay. Use the **no** form of this command to disable the PortFast mode.

Syntax

spanning-tree portfast [auto]

no spanning-tree portfast

Parameters

auto—Specifies that the software waits for 3 seconds (with no Bridge Protocol Data Units (BPDUs) received on the interface) before putting the interface into the PortFast mode.

Default Configuration

PortFast mode is disabled.

Command Mode

Interface Configuration (Ethernet, port-channel) mode

Example

The following example enables the PortFast mode on fe1/0/115.

```
switchxxxxxx(config)# interface fe1/0/115
switchxxxxxx(config-if)# spanning-tree portfast
```

29.11 spanning-tree link-type

Use the **spanning-tree link-type** Interface Configuration (Ethernet, port-channel) mode command to override the default link-type setting determined by the port duplex mode, and enable RSTP transitions to the Forwarding state. Use the **no** form of this command to restore the default configuration.

Syntax

spanning-tree link-type {*point-to-point* | *shared*}

no spanning-tree spanning-tree link-type

Parameters

- **point-to-point**—Specifies that the port link type is point-to-point.
- **shared**—Specifies that the port link type is shared.

Default Configuration

The device derives the port link type from the duplex mode. A full-duplex port is considered a point-to-point link and a half-duplex port is considered a shared link.

Command Mode

Interface Configuration (Ethernet, port-channel) mode

Example

The following example enables shared spanning-tree on fe1/0/115.

```
switchxxxxxx(config)# interface fe1/0/115
switchxxxxxx(config-if)# spanning-tree link-type shared
```

29.12 spanning-tree pathcost method

Use the **spanning-tree pathcost method** Global Configuration mode command to set the default path cost method. Use the **no** form of this command to return to the default configuration.

Syntax

spanning-tree pathcost method {*long* | *short*}

no spanning-tree pathcost method

Parameters

- **long**—Specifies that the default port path costs are within the range: 1–200,000,000.
- **short**—Specifies that the default port path costs are within the range: 1–65,535.

Default Configuration

Long path cost method.

Command Mode

Global Configuration mode

User Guidelines

This command applies to all the spanning tree instances on the switch.

- If the short method is selected, the switch calculates cost in the range 1 through 65,535.
- If the long method is selected, the switch calculates cost in the range 1 through 200,000,000.

Example

The following example sets the default path cost method to Long.

```
switchxxxxxx(config)# spanning-tree pathcost method long
```

29.13 spanning-tree bpdu (Global)

Use the **spanning-tree bpdu** Global Configuration mode command to define Bridge Protocol Data Unit (BPDU) handling when the spanning tree is disabled globally or on a single interface. Use the **no** form of this command to restore the default configuration.

Syntax

```
spanning-tree bpdu {filtering | flooding}
```

```
no spanning-tree bpdu
```

Parameters

- **filtering**—Specifies that BPDU packets are filtered when the spanning tree is disabled on an interface.
- **flooding**—Specifies that untagged BPDU packets are flooded unconditionally (without applying VLAN rules) to all ports with the spanning tree disabled and BPDU handling mode of flooding. Tagged BPDU packets are filtered.

Default Configuration

The default setting is **flooding**.

Command Mode

Global Configuration mode

User Guidelines

The **filtering** and **flooding** modes are relevant when the spanning tree is disabled globally or on a single interface.

Example

The following example defines the BPDU packet handling mode as **flooding** when the spanning tree is disabled on an interface.

```
switchxxxxxx(config)# spanning-tree bpdu flooding
```

29.14 spanning-tree bpdu (Interface)

Use the **spanning-tree bpdu** Interface Configuration (Ethernet, Port-channel) mode command to define BPDU handling when the spanning tree is disabled on a single interface. Use the **no** form of this command to restore the default configuration.

Syntax

spanning-tree bpdu {*filtering* | *flooding*}

no spanning-tree bpdu

Parameters

- **filtering**—Specifies that BPDU packets are filtered when the spanning tree is disabled on an interface.
- **flooding**—Specifies that untagged BPDU packets are flooded unconditionally (without applying VLAN rules) to ports with the spanning tree disabled and BPDU handling mode of flooding. Tagged BPDU packets are filtered.

Default Configuration

The [spanning-tree bpdu \(Global\)](#) command determines the default configuration.

Command Mode

Interface Configuration (Ethernet, Port-channel) mode

Example

The following example defines the BPDU packet as **flooding** when the spanning tree is disabled on fe1/0/13.

```
switchxxxxxx(config)# interface fe1/0/13
switchxxxxxx(config-if)# spanning-tree bpdu flooding
```

29.15 spanning-tree guard root

use the **spanning-tree guard root** Interface Configuration (Ethernet, Port-channel) mode command to enable Root Guard on all spanning-tree instances on the interface. Root guard prevents the interface from becoming the root port of the device. Use the **no** form of this command to disable the root guard on the interface.

Syntax

spanning-tree guard root

no spanning-tree guard root

Default Configuration

Root guard is disabled.

Command Mode

Interface Configuration (Ethernet, Port-channel) mode

User Guidelines

Root Guard can be enabled when the device operates in any mode (STP, RSTP and MSTP).

When Root Guard is enabled, the port changes to the alternate state if the spanning-tree calculations select the port as the root port.

Example

The following example prevents `fe1/0/11` from being the root port of the device.

```
switchxxxxxx(config)# interface fe1/0/11
switchxxxxxx(config-if)# spanning-tree guard root
```

29.16 spanning-tree bpduguard

Use the **spanning-tree bpduguard** Interface Configuration (Ethernet, port-channel) mode command to shut down an interface when it receives a Bridge Protocol Data Unit (BPDU). Use the **no** form of this command to restore the default configuration.

Syntax

spanning-tree bpduguard {*enable* | *disable*}

no spanning-tree bpduguard

Parameters

bpduguard enable—Enables BPDU Guard.

bpduguard disable—Disables BPDU Guard.

Default Configuration

BPDU Guard is disabled.

Command Mode

Interface Configuration (Ethernet, Port-channel) mode

User Guidelines

The command can be enabled when the spanning tree is enabled (useful when the port is in the PortFast mode) or disabled.

Example

The following example shuts down `fe1/0/15` when it receives a BPDU.

```
switchxxxxxx(config)# interface fe1/0/15
switchxxxxxx(config-if)# spanning-tree bpduguard enable
```

29.17 clear spanning-tree detected-protocols

Use the **clear spanning-tree detected-protocols** Privileged EXEC command to restart the STP migration process (force renegotiation with neighboring switches) on all interfaces or on the specified interface

Syntax

clear spanning-tree detected-protocols [*interface interface-id*]

Parameters

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

Default Configuration

All interfaces.

Command Mode

Privileged EXEC mode

User Guidelines

This feature can only be used when working in RSTP or MSTP mode.

Example

This restarts the STP migration process on all interfaces.

```
switchxxxxxx# clear spanning-tree detected-protocols
```

29.18 spanning-tree mst priority

Use the **spanning-tree mst priority** Global Configuration mode command to configure the device priority for the specified spanning-tree instance. Use the **no** form of this command to restore the default configuration.

Syntax

spanning-tree mst *instance-id* **priority** *priority*

no spanning-tree mst *instance-id* **priority**

Parameters

- **instance-id**—Specifies the spanning-tree instance ID. (Range:1–7)
- **priority**—Specifies the device priority for the specified spanning-tree instance. This setting determines the likelihood that the switch is selected as the root switch. A lower value increases the probability that the switch is selected as the root switch. (Range: 0–61440)

Default Configuration

The default priority is 32768.

Command Mode

Global Configuration mode

User Guidelines

The priority value must be a multiple of 4096.

The switch with the lowest priority is the root of the spanning tree.

Example

The following example configures the spanning tree priority of instance 1 to 4096.

```
switchxxxxxx(config)# spanning-tree mst 1 priority 4096
```

29.19 spanning-tree mst max-hops

Use the **spanning-tree mst max-hops** Global Configuration mode command to configure the number of hops in an MST region before the BPDU is discarded and the port information is aged out. Use the **no** form of this command to restore the default configuration.

Syntax

spanning-tree mst max-hops *hop-count*

no spanning-tree mst max-hops

Parameters

max-hops *hop-count*—Specifies the number of hops in an MST region before the BPDU is discarded. (Range: 1–40)

Default Configuration

The default number of hops is 20.

Command Mode

Global Configuration mode

Example

The following example configures the maximum number of hops that a packet travels in an MST region before it is discarded to 10.

```
switchxxxxxx(config)# spanning-tree mst max-hops 10
```

29.20 spanning-tree mst port-priority

Use the **spanning-tree mst port-priority** Interface Configuration (Ethernet, port-channel) mode command to configure the priority of a port. Use the **no** form of this command to restore the default configuration.

Syntax

spanning-tree mst *instance-id* **port-priority** *priority*

no spanning-tree mst *instance-id* port-priority

Parameters

- **instance-id**—Specifies the spanning tree instance ID. (Range: 1–15)
- **priority**—Specifies the port priority. (Range: 0–240 in multiples of 16)

Default Configuration

The default port priority is 128.

Command Mode

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

The priority value must be a multiple of 16.

Example

The following example configures the port priority of fe1/0/11 to 144.

```
switchxxxxxx(config)# interface fe1/0/11
switchxxxxxx(config-if)# spanning-tree mst 1 port-priority 144
```

29.21 spanning-tree mst cost

Use the **spanning-tree mst cost** Interface Configuration (Ethernet, Port-channel) mode command to configure the path cost for MST calculations. If a loop occurs, the spanning tree considers path cost when selecting an interface to put in the Forwarding state. Use the **no** form of this command to restore the default configuration.

Syntax

spanning-tree mst *instance-id* cost *cost*

no spanning-tree mst *instance-id* cost

Default Configuration

N/A

Parameters

- **instance-id**—Specifies the spanning-tree instance ID. (Range: 1–15)
- **cost**—Specifies the port path cost. (Range: 1–200000000)

Default Configuration

Default path cost is determined by the port speed and path cost method (long or short) as shown below:

Interface	Long	Short
Port-channel	20,000	4
TenGigabit Ethernet (10000 Mbps)	2000	2

Gigabit Ethernet (1000 Mbps)	20,000	4
Fast Ethernet (100 Mbps)	200,000	19
Ethernet (10 Mbps)	2,000,000	100

Command Mode

Interface Configuration (Ethernet, port-channel) mode

Example

The following example configures the MSTP instance 1 path cost for gigabitethernet port 9 to 4.

```
switchxxxxxx(config)# interface fe1/0/19
switchxxxxxx(config-if)# spanning-tree mst 1 cost 4
```

29.22 spanning-tree mst configuration

Use the **spanning-tree mst configuration** Global Configuration mode command to enable configuring an MST region by entering the MST mode.

Syntax

spanning-tree mst configuration

Command Mode

Global Configuration mode

User Guidelines

For two or more switches to be in the same MST region, they must contain the same VLAN mapping, the same configuration revision number, and the same name.

Example

The following example configures an MST region.

```
switchxxxxxx(config)# spanning-tree mst configuration
switchxxxxxx(config-mst)# instance 1 vlan 10-20
switchxxxxxx(config-mst)# name region1
switchxxxxxx(config-mst)# revision 1
```

29.23 instance (MST)

Use **instance** MST Configuration mode command to map VLANs to an MST instance. Use the **no** form of this command to restore the default mapping.

Syntax

instance *instance-id* **vlan** *vlan-range*

no instance *instance-id* **vlan** *vlan-range*

Parameters

- **instance-id**—MST instance (Range: 1–15)
- **vlan-range**—The specified range of VLANs is added to the existing ones. To specify a range, use a hyphen. To specify a series, use a comma. (Range: 1–4094)

Default Configuration

All VLANs are mapped to the common and internal spanning tree (CIST) instance (instance 0).

Command Mode

MST Configuration mode

User Guidelines

All VLANs that are not explicitly mapped to an MST instance are mapped to the common and internal spanning tree (CIST) instance (instance 0) and cannot be unmapped from the CIST.

For two or more devices to be in the same MST region, they must have the same VLAN mapping, the same configuration revision number, and the same name.

Example

The following example maps VLANs 10-20 to MST instance 1.

```
switchxxxxxx(config)# spanning-tree mst configuration
switchxxxxxx(config-mst)# instance 1 vlan 10-20
```

29.24 name (MST)

Use the **name** MST Configuration mode command to define the MST instance name. Use the **no** form of this command to restore the default setting.

Syntax

name *string*

no name

Parameters

string—Specifies the MST instance name. (Length: 1–32 characters)

Default Configuration

The default name is the bridge MAC address.

Command Mode

MST Configuration mode

Example

The following example defines the instance name as Region1.

```
switchxxxxxx(config)# spanning-tree mst configuration
switchxxxxxx(config-mst)# name region1
```

29.25 revision (MST)

Use the **revision** MST Configuration mode command to define the MST configuration revision number. Use the **no** form of this command to restore the default configuration.

Syntax

revision *value*

no revision

Parameters

value—Specifies the MST configuration revision number. (Range: 0–65535)

Default Configuration

The default configuration revision number is 0.

Command Mode

MST Configuration mode

Example

The following example sets the configuration revision to 1.

```
switchxxxxxx(config) # spanning-tree mst configuration
switchxxxxxx(config-mst) # revision 1
```

29.26 show (MST)

Use the **show** MST Configuration mode command to display the current or pending MST region configuration.

Syntax

show {*current* | *pending*}

Parameters

- **current**—Displays the current MST region configuration.
- **pending**—Displays the pending MST region configuration.

Default Configuration

N/A

Command Mode

MST Configuration mode

Example

The following example displays a pending MST region configuration

```
switchxxxxxx(config-mst)# show pending
Gathering information .....
```



```
Current MST configuration
Name: Region1
Revision: 1
Instance  VLANs Mapped          State
-----  -
0         1-4094                      Disabled
switchxxxxxx(config-mst) #
```

29.27 exit (MST)

Use the **exit** MST Configuration mode command to exit the MST region Configuration mode and apply all configuration changes.

Syntax

exit

Parameters

N/A

Default Configuration

N/A

Command Mode

MST Configuration mode

Example

The following example exits the MST Configuration mode and saves changes.

```
switchxxxxxx(config) # spanning-tree mst configuration
switchxxxxxx(config-mst) # exit
switchxxxxxx(config) #
```

29.28 abort (MST)

Use the **abort** MST Configuration mode command to exit the MST Configuration mode without applying the configuration changes.

Syntax

abort

Parameters

N/A

Default Configuration

N/A

Command Mode

MST Configuration mode

Example

The following example exits the MST Configuration mode without saving changes.

```
switchxxxxxx(config)# spanning-tree mst configuration  
switchxxxxxx(config-mst)# abort
```

29.29 show spanning-tree

Use the **show spanning-tree** Privileged EXEC mode command to display the spanning-tree configuration.

Syntax

show spanning-tree [*interface-id*] [*instance instance-id*]

show spanning-tree [*detail*] [*active | blockedports*] [*instance instance-id*]

show spanning-tree *mst-configuration*

Parameters

- **instance** *instance-id*—Specifies the spanning tree instance ID. (Range: 1–15)
- **detail**—Displays detailed information.
- **active**—Displays active ports only.
- **blockedports**—Displays blocked ports only.
- **mst-configuration**—Displays the MST configuration identifier.
- **interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

Default Configuration

If no interface is specified, the default is all interfaces.

Command Mode

Privileged EXEC mode

User Guidelines

This command only works when MST is enabled.



Example

The following examples display spanning-tree information in various configurations:

```
switchxxxxxx# show spanning-tree
Spanning tree enabled mode RSTP
Default port cost method: long
Loopback guard: Disabled

Root ID    Priority          32768
Address    00:01:42:97:e0:00
Cost       20000
Port       fe1/0/11

Hello Time 2 sec           Max Age 20 sec Forward Delay 15 sec

Bridge ID  Priority          36864
Address    00:02:4b:29:7a:00

Hello Time 2 sec           Max Age 20 sec Forward Delay 15 sec

Interfaces

Name      State   Prio. No   Cost   Sts   Role   PortFastType
-----  -
fe1/0/11  Enabled 128.1     20000  FWD   Root   No       P2p (RSTP)
fe1/0/12  Enabled 128.2     20000  FWD   Desg   No       Shared (STP)
fe1/0/13  Disabled 128.3     20000  -     -     -       -
fe1/0/14  Enabled 128.4     20000  BLK   Altn   No       Shared (STP)
fe1/0/15  Enabled 128.5     20000  DIS   -     -       -
```

```
switchxxxxxx# show spanning-tree
Spanning tree enabled mode RSTP
Default port cost method: long

Root ID    Priority          36864
Address    00:02:4b:29:7a:00

This switch is the Root.

Hello Time 2 sec           Max Age 20 sec Forward Delay 15 sec

Interfaces
```

Spanning-Tree Commands

Name	State	Prio.Nbr	Cost	Sts	Role	PortFast	Type
fel/0/11	Enabled	128.1	20000	FWD	Desg	-	P2p (RSTP)
fel/0/12	Enabled	128.2	20000	FWD	Desg	No	Shared (STP)
fel/0/13	Disabled	128.3	20000	-	-	No	-
fel/0/14	Enabled	128.4	20000	FWD	Desg	-	Shared (STP)
fel/0/15	Enabled	128.5	20000	DIS	-	No	-

switchxxxxxx# **show spanning-tree**

Spanning tree disabled (BPDU filtering) mode RSTP

Default port cost method: long

Root ID	Priority	N/A					
	Address	N/A					
	Path Cost	N/A					
	Root Port	N/A					
	Hello Time	N/A	Max Age	N/A	Forward Delay	N/A	

Bridge ID	Priority	36864					
	Address	00:02:4b:29:7a:00					
	Hello Time	2 sec	Max Age	20 sec	Forward Delay	15 sec	

Interfaces

Name	State	Prio.Nb	Cost	Sts	Role	PortFast	Type
fel/0/11	Enabled	128.1	20000	-	-	-	-
fel/0/12	Enabled	128.2	20000	-	-	-	-
fel/0/13	Disabled	128.3	20000	-	-	-	-
fel/0/14	Enabled	128.4	20000	-	-	-	-
fel/0/15	Enabled	128.5	20000	-	-	-	-

switchxxxxxx# **show spanning-tree active**

Spanning tree enabled mode RSTP

Default port cost method: long

Root ID	Priority	32768					
	Address	00:01:42:97:e0:00					
	Path Cost	20000					
	Root Port	fel/0/11					
	Hello Time	2 sec	Max Age	20 sec	Forward Delay	15 sec	

Bridge ID	Priority	36864					
	Address	00:02:4b:29:7a:00					
	Hello Time	2 sec	Max Age	20 sec	Forward Delay	15 sec	

Interfaces



Name	State	Prio.Nbr	Cost	Sts	Role	PortFast	Type
fe1/0/11	Enabled	128.1	20000	FWD	Root	-	P2p (RSTP)
fe1/0/12	Enabled	128.2	20000	FWD	Desg	No	Shared (STP)
fe1/0/14	Enabled	128.4	20000	BLK	Altn	No	Shared (STP)

switchxxxxxx# **show spanning-tree blockedports**

Spanning tree enabled mode RSTP
 Default port cost method: long

```

Root ID      Priority          32768
            Address          00:01:42:97:e0:00
            Path Cost       20000
            Root Port       fe1/0/11

            Hello Time 2 sec          Max Age 20 sec Forward Delay 15 sec
  
```

```

Bridge ID    Priority          36864
            Address          00:02:4b:29:7a:00

            Hello Time 2 sec          Max Age 20 sec Forward Delay 15 sec
  
```

Interfaces

Name	State	Prio.Nbr	Cost	Sts	Role	PortFast	Type
fe1/0/14	Enabled	128.4	19	BLK	Altn	No	Shared (STP)

switchxxxxxx# **show spanning-tree detail**

Spanning tree enabled mode RSTP
 Default port cost method: long

```

Root ID      Priority          32768
            Address          00:01:42:97:e0:00
            Path Cost       20000
            Root Port       fe1/0/11

            Hello Time 2 sec          Max Age 20 sec Forward Delay 15 sec
  
```

```

Bridge ID    Priority          36864
            Address          00:02:4b:29:7a:00

            Hello Time 2 sec          Max Age 20 sec Forward Delay 15 sec
  
```

Number of topology changes 2 last change occurred 2d18h ago

Times: hold 1, topology change 35, notification 2
 hello 2, max age 20, forward delay 15

Port 1 (fe1/0/11) enabled
State: Forwarding Role: Root
Port id: 128.1 Port cost: 20000
Type: P2p (configured: auto) RSTP Port Fast: No (configured:no)
Designated bridge Priority: 32768 Address: 00:01:42:97:e0:00
Designated port id: 128.25 Designated path cost: 0
Guard root: Disabled BPDU guard: Disabled

Number of transitions to forwarding state: 1
BPDU: sent 2, received 120638

Port 2 (fe1/0/12) enabled
State: Forwarding Role: Designated
Port id: 128.2 Port cost: 20000
Type: Shared (configured: auto) STP Port Fast: No (configured:no)
Designated bridge Priority: 32768 Address: 00:02:4b:29:7a:00
Designated port id: 128.2 Designated path cost: 20000
Guard root: Disabled BPDU guard: Disabled

Number of transitions to forwarding state: 1
BPDU: sent 2, received 170638

Port 3 (fe1/0/13) disabled
State: N/A Role: N/A
Port id: 128.3 Port cost: 20000
Type: N/A (configured: auto) Port Fast: N/A (configured:no)
Designated bridge Priority: N/A Address: N/A
Designated port id: N/A Designated path cost: N/A
Guard root: Disabled BPDU guard: Disabled

Number of transitions to forwarding state: N/A
BPDU: sent N/A, received N/A

Port 4 (fe1/0/14) enabled
State: Blocking Role: Alternate
Port id: 128.4 Port cost: 20000
Type: Shared (configured:auto) STP Port Fast: No (configured:no)
Designated bridge Priority: 28672 Address: 00:30:94:41:62:c8
Designated port id: 128.25 Designated path cost: 20000
Guard root: Disabled BPDU guard: Disabled

Number of transitions to forwarding state: 1
BPDU: sent 2, received 120638

Port 5 (fe1/0/15) enabled
State: Disabled Role: N/A
Port id: 128.5 Port cost: 20000
Type: N/A (configured: auto) Port Fast: N/A (configured:no)
Designated bridge Priority: N/A Address: N/A
Designated port id: N/A Designated path cost: N/A
Guard root: Disabled BPDU guard: Disabled

Number of transitions to forwarding state: N/A
BPDU: sent N/A, received N/A



```
switchxxxxxx# show spanning-tree ethernet fel/0/11
```

```
Port 1 (fel/0/11) enabled
State: Forwarding                Role: Root
Port id: 128.1                    Port cost: 20000
Type: P2p (configured: auto) RSTP  Port Fast: No (configured:no)
Designated bridge Priority: 32768  Address: 00:01:42:97:e0:00
Designated port id: 128.25        Designated path cost: 0
Guard root: Disabled              BPDU guard: Disabled
```

```
Number of transitions to forwarding state: 1
BPDU: sent 2, received 120638
```

```
switchxxxxxx# show spanning-tree mst-configuration
```

```
Name: Region1
Revision: 1
```

Instance	Vlans mapped	State
0	1-9, 21-4094	Enabled
1	10-20	Enabled

```
switchxxxxxx# show spanning-tree
```

```
Spanning tree enabled mode MSTP
Default port cost method: long
##### MST 0 Vlans Mapped: 1-9
```

```
CST Root ID      Priority    32768
Address          00:01:42:97:e0:00
Path Cost       20000
Root Port       fel/0/11

Hello Time 2 sec  Max Age 20 sec Forward Delay 15 sec
```

```
IST Master ID    Priority    32768
Address          00:02:4b:29:7a:00

This switch is the IST master.

Hello Time 2 sec  Max Age 20 sec Forward Delay 15 sec
Max hops 20
```

Interfaces

Name	State	Prio.Nbr	Cost	Sts	Role	PortFast	Type
fel/0/11	Enabled	128.1	20000	FWD	Root	No	P2p Bound
fel/0/12	Enabled	128.2	20000	FWD	Desg	No	(RSTP)
fel/0/13	Enabled	128.3	20000	FWD	Desg	No	Shared Bound
fel/0/14	Enabled	128.4	20000	FWD	Desg	No	(STP)
							P2p
							P2p

Spanning-Tree Commands

MST 1 Vlans Mapped: 10-20

Root ID Priority 24576
 Address 00:02:4b:29:89:76
 Path Cost 20000
 Root Port fe1/0/14
 Rem hops 19

Bridge ID Priority 32768
 Address 00:02:4b:29:7a:00

Interfaces

Name	State	Prio.Nbr	Cost	Sts	Role	PortFast	Type
----	-----	-----	-----	---	----	-----	-----
fe1/0/11	Enabled	128.1	20000	FWD	Boun	No	P2p Bound
fe1/0/12	Enabled	128.2	20000	FWD	Boun	No	(RSTP)
fe1/0/13	Enabled	128.3	20000	BLK	Altn	No	Shared Bound
fe1/0/14	Enabled	128.4	20000	FWD	Root	No	(STP)
							P2p
							P2p

switchxxxxxx# **show spanning-tree detail**

Spanning tree enabled mode MSTP

Default port cost method: long

MST 0 Vlans Mapped: 1-9

CST Root ID Priority 32768
 Address 00:01:42:97:e0:00
 Path Cost 20000
 Root Port fe1/0/11

 Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec

IST Master ID Priority 32768
 Address 00:02:4b:29:7a:00

 This switch is the IST master.

 Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec

 Max hops 20
 Number of topology changes 2 last change occurred 2d18h
 ago
 Times: hold 1, topology change 35, notification 2
 hello 2, max age 20, forward delay 15



Port 1 (fe1/0/11) enabled
State: Forwarding Role: Root
Port id: 128.1 Port cost: 20000
Type: P2p (configured: auto) Boundary RSTP Port Fast: No (configured:no)
Designated bridge Priority: 32768 Address: 00:01:42:97:e0:00
Designated port id: 128.25 Designated path cost: 0
Number of transitions to forwarding state: 1
BPDU: sent 2, received 120638

Port 2 (fe1/0/12) enabled
State: Forwarding Role: Designated
Port id: 128.2 Port cost: 20000
Type: Shared (configured: auto) Boundary STP Port Fast: No (configured:no)
Designated bridge Priority: 32768 Address: 00:02:4b:29:7a:00
Designated port id: 128.2 Designated path cost: 20000
Number of transitions to forwarding state: 1
BPDU: sent 2, received 170638

Port 3 (fe1/0/13) enabled
State: Forwarding Role: Designated
Port id: 128.3 Port cost: 20000
Type: Shared (configured: auto) Internal Port Fast: No (configured:no)
Designated bridge Priority: 32768 Address: 00:02:4b:29:7a:00
Designated port id: 128.3 Designated path cost: 20000
Number of transitions to forwarding state: 1
BPDU: sent 2, received 170638

Port 4 (fe1/0/14) enabled
State: Forwarding Role: Designated
Port id: 128.4 Port cost: 20000
Type: Shared (configured: auto) Internal Port Fast: No (configured:no)
Designated bridge Priority: 32768 Address: 00:02:4b:29:7a:00
Designated port id: 128.2 Designated path cost: 20000
Number of transitions to forwarding state: 1
BPDU: sent 2, received 170638

MST 1 Vlans Mapped: 10-20

Root ID	Priority	24576
	Address	00:02:4b:29:89:76
	Path Cost	20000
	Root Port	fe1/0/14
	Rem hops	19

Bridge ID	Priority	32768
	Address	00:02:4b:29:7a:00

Number of topology changes 2 last change occurred 1d9h ago

Spanning-Tree Commands

Times: hold 1, topology change 2, notification 2
hello 2, max age 20, forward delay 15

Port 1 (fe1/0/11) enabled
State: Forwarding Role: Boundary
Port id: 128.1 Port cost: 20000
Type: P2p (configured: auto) Boundary RSTP Port Fast: No (configured:no)
Designated bridge Priority: 32768 Address: 00:02:4b:29:7a:00
Designated port id: 128.1 Designated path cost: 20000
Number of transitions to forwarding state: 1
BPDU: sent 2, received 120638

Port 2 (fe1/0/12) enabled
State: Forwarding Role: Designated
Port id: 128.2 Port cost: 20000
Type: Shared (configured: auto) Boundary STP Port Fast: No (configured:no)
Designated bridge Priority: 32768 Address: 00:02:4b:29:7a:00
Designated port id: 128.2 Designated path cost: 20000
Number of transitions to forwarding state: 1
BPDU: sent 2, received 170638

Port 3 (fe1/0/13) disabled
State: Blocking Role: Alternate
Port id: 128.3 Port cost: 20000
Type: Shared (configured: auto) Internal Port Fast: No (configured:no)
Designated bridge Priority: 32768 Address: 00:02:4b:29:1a:19
Designated port id: 128.78 Designated path cost: 20000
Number of transitions to forwarding state: 1
BPDU: sent 2, received 170638

Port 4 (fe1/0/14) enabled
State: Forwarding Role: Designated
Port id: 128.4 Port cost: 20000
Type: Shared (configured: auto) Internal Port Fast: No (configured:no)
Designated bridge Priority: 32768 Address: 00:02:4b:29:7a:00
Designated port id: 128.2 Designated path cost: 20000
Number of transitions to forwarding state: 1
BPDU: sent 2, received 170638

switchxxxxxx# **show spanning-tree**

Spanning tree enabled mode MSTP
Default port cost method: long
MST 0 Vlans Mapped: 1-9

CST Root ID	Priority	32768
	Address	00:01:42:97:e0:00
	Path Cost	20000
	Root Port	fe1/0/11

```

Hello Time 2 sec   Max Age 20 sec Forward Delay 15 sec

IST Master ID      Priority    32768
Address            00:02:4b:19:7a:00
Path Cost         10000
Rem hops          19

Bridge ID          Priority    32768
Address            00:02:4b:29:7a:00

Hello Time 2 sec   Max Age 20 sec Forward Delay 15 sec
Max hops 20
```

```

switchxxxxxx# show spanning-tree
Spanning tree enabled mode MSTP
Default port cost method: long

##### MST 0 Vlans Mapped: 1-9

CST Root ID       Priority    32768
Address            00:01:42:97:e0:00

This switch is root for CST and IST master.

Root Port         fe1/0/11

Hello Time 2 sec   Max Age 20 sec Forward Delay 15 sec
Max hops 20
```

29.30 show spanning-tree bpdu

Use the **show spanning-tree bpdu** EXEC mode command to display the BPDU handling when spanning-tree is disabled.

Syntax

show spanning-tree bpdu [*interface-id*]

Parameters

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

Command Mode

EXEC mode

Example

The following examples display spanning-tree BPDU information:

```
switchxxxxxx# show spanning-tree bpdu
```

The following is the output if the global BPDU handling command is not supported.

Interface	Admin Mode	Oper Mode
-----	-----	-----
fe1/0/11	Filtering	Filtering
fe1/0/12	Filtering	Filtering
fe1/0/13	Filtering	Guard

The following is the output if both the global BPDU handling command and the per-interface BPDU handling command are supported.

Global: Flooding

Interface	Admin Mode	Oper Mode
-----	-----	-----
fe1/0/11	Global	Flooding
fe1/0/12	Global	STP
fe1/0/13	Flooding	STP

29.31 spanning-tree loopback-guard

Use the **spanning-tree loopback-guard global configuration** command to shut down an interface if it receives a loopback BPDU. Use the **no** form of this command to return the default setting.

Syntax

spanning-tree loopback-guard

no spanning-tree loopback-guard

Parameters

N/A

Default Configuration

N/A

Command Mode

Global

User Guidelines

This enables shutting down all interfaces if a loopback BPDU is received on it.



Example

```
switchxxxxxx(config)# spanning-tree loopback-guard
```

30 Virtual Local Area Network (VLAN) Commands

30.1 vlan database

Use the **vlan database** Global Configuration mode command to enter the VLAN Configuration mode. This mode is used to create VLAN(s) and define the default VLAN.

Use the **exit** command to return to Global Configuration mode.

Syntax

vlan database

Parameters

N/A

Default Configuration

VLAN 1 exists by default.

Command Mode

Global Configuration mode

Example

The following example enters the VLAN Configuration mode, creates VLAN 1972 and exits VLAN Configuration mode.

```
switchxxxxxx(config)# vlan database
switchxxxxxx(config-vlan)# vlan 1972
switchxxxxxx(config-vlan)# exit
switchxxxxxx(config)#
```

30.2 vlan

Use the **vlan** VLAN Configuration mode or Global Configuration mode command to create a VLAN and assign it a name (if only a single VLAN is being created). Use the **no** form of this command to delete the VLAN(s).

Syntax

vlan *vlan-range*

no vlan *vlan-range*

Parameters

- **vlan-range**—Specifies a list of VLAN IDs to add. Separate nonconsecutive VLAN IDs with a comma and no spaces. Use a hyphen to designate a range of IDs (range: 2-4094).

- **name**—Specifies the VLAN name. The option is only valid where only one VLAN is configured by the command (range: 1–32 characters).

Default Configuration

VLAN 1 exists by default.

Command Mode

Global Configuration mode

VLAN Configuration mode

Example

The following example creates VLAN number 1972 and assigns it the name Marketing.

```
switchxxxxxx(config)#vlan database
switchxxxxxx(config-vlan)#vlan 1972 Marketing
switchxxxxxx(config-vlan)#
```

30.3 show vlan

Use the **show vlan** Privileged EXEC mode command to display the following VLAN information for all VLANs or for a specific VLAN:

- VLAN ID
- VLAN name
- Ports on the VLAN
- Whether the VLAN was is dynamic or permanent
- Whether authorization is required on the VLAN

Syntax

show vlan [*tag vlan-id* | *name vlan-name*]

Parameters

- **tag** *vlan-id*—Specifies a VLAN ID.
- **name** *vlan-name*—Specifies a VLAN name string (length: 1–32 characters)

Default Configuration

All VLANs are displayed.

Command Mode

Privileged EXEC mode

Examples:

Example 1 - The following example displays information for all VLANs:

```
switchxxxxxx# show vlan
```

VLAN	Name	Ports	Type	Authorization
1	default	fe1/0/11-2	Default	Required
10	Marketing	fe1/0/13-14	Static	Required
11	VLAN0011	fe1/0/15-16	Static	Required
20	VLAN0020	fe1/0/17-18	Static	Required
21	VLAN0021		Static	Required
30	VLAN0030		Static	Required
31	VLAN0031		Static	Required
91	VLAN0091	fe1/0/12	Dynamic	Not Required
3978	Guest VLAN	fe1/0/17	Static	Guest

Example 2 - The following example displays information for the default VLAN (VLAN 1):

```
switchxxxxxx# show vlan tag default
```

VLAN	Name	Ports	Type	Authorization
1	default	fe1/0/11-2	Default	Required

Example 3 - The following example displays information for the VLAN named Marketing:

```
switchxxxxxx# show vlan name Marketing
```

VLAN	Name	Ports	Type	Authorization
1	Marketing	fe1/0/13-14	static	Required

30.4 show default-vlan-membership

Use the **show default-vlan-membership** privileged EXEC command to view the default VLAN membership.

Syntax

show default-vlan-membership [*interface-id*]

Parameters

interface-id—Specify an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel

Default Configuration

Membership in the default VLAN is displayed for all interfaces.

Command Mode

Privileged EXEC

Example

```
switchxxxxxx # show default-vlan-membership
```

Port	Forbidden	Membership
----	-----	-----
fe1/0/11	TRUE	FALSE
fe1/0/12	FALSE	TRUE
fe1/0/13	FALSE	FALSE

30.5 interface vlan

Use the **interface vlan** Global Configuration mode command to enter the Interface Configuration (VLAN) mode for a specific VLAN. After this command is entered, all commands configure this VLAN. To configure a range of VLANs, use [interface range vlan](#).

Syntax

```
interface vlan vlan-id
```

Parameters

vlan *vlan-id*—Specifies the VLAN to be configured.

Default Configuration

N/A

Command Mode

Global Configuration mode

User Guidelines

If the VLAN does not exist (ghost VLAN), some commands are not available under the interface VLAN context.

The commands that are supported for VLANs but do not exist for ghost VLANs are:

- IGMP snooping control commands
- Bridge Multicast configuration commands

Example

The following example configures VLAN 1 with IP address 131.108.1.27 and subnet mask 255.255.255.0.

```
switchxxxxxx (config)# interface vlan 1
switchxxxxxx (config-if)# ip address 131.108.1.27 255.255.255.0
```

30.6 interface range vlan

Use the **interface range vlan** Global Configuration mode command to configure multiple VLANs simultaneously.

Syntax

interface range vlan *vlan-range*

Parameters

vlan *vlan-range*—Specifies a list of VLANs. Separate nonconsecutive VLANs with a comma and no spaces. Use a hyphen to designate a range of VLANs.

Default Configuration

N/A

Command Mode

Global Configuration mode

User Guidelines

Commands under the interface VLAN range context are executed independently on each VLAN in the range. If the command returns an error on one of the VLANs, an error message is displayed, and the system attempts to configure the remaining VLANs.

If a VLAN does not exist (ghost VLAN), some commands are not available under the interface VLAN context. These are:

- IGMP snooping control commands
- Bridge Multicast configuration commands

Example

The following example groups VLANs 221 through 228 and 889 to receive the same command(s).

```
switchxxxxxx(config)# interface range vlan 221-228, vlan 889
switchxxxxxx(config-if)#
```

30.7 name

Use the **name** Interface Configuration (VLAN) mode command to name a VLAN. Use the **no** form of this command to remove the VLAN name.

Syntax

name *string*

no name

Parameters

string—Specifies a unique name associated with this VLAN. (Length: 1–32 characters)

Default Configuration

No name is defined.

Command Mode

Interface Configuration (VLAN) mode. It cannot be configured for a range of interfaces (range context).

User Guidelines

The VLAN name must be unique.

Example

The following example assigns VLAN 19 the name Marketing.

```
switchxxxxxx(config)# interface vlan 19
switchxxxxxx(config-if)# name Marketing
```

30.8 switchport protected-port

Use the **switchport protected-port** Interface Configuration mode command to isolate Unicast, Multicast, and Broadcast traffic at Layer 2 from other protected ports on the same switch. Use the **no** form of this command to disable protection on the port.

Syntax

switchport protected-port

no switchport protected-port

Parameters

N/A

Default Configuration

Unprotected

Command Mode

Interface configuration (Ethernet, port-channel)

User Guidelines

Note that packets are subject to all filtering rules and Filtering Database (FDB) decisions.

Use this command to isolate Unicast, Multicast, and Broadcast traffic at Layer 2 from other protected ports (that are not associated with the same community as the ingress interface) on the same switch. Please note that the packet is still subject to FDB decision and to all filtering rules. Use the **switchport community** Interface Configuration command to associate the interface with a community.

Example

```
switchxxxxxx(config)# interface fe1/0/11
switchxxxxxx(config-if)# switchport protected-port
```

30.9 show interfaces protected-ports

Use the **show interfaces protected-ports** EXEC mode command to display protected ports configuration.

Syntax

show interfaces protected-ports [*interface-id*]

Parameters

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

Default Configuration

Show all protected ports.

Command Mode

EXEC mode

Example

```
switchxxxxxx# show interfaces protected-ports
```

Interface	State	Community
fe1/0/11	Protected	1
fe1/0/12	Protected	Isolated
fe1/0/13	Unprotected	20
fe1/0/14	Unprotected	Isolated

Note: The Community column for unprotected ports is relevant only when the port state is changed to Protected.<gina - not clear why is there community for unprotected ports?>

30.10 switchport community

Use the **switchport community** Interface Configuration mode command to associate a protected port with a community. Use the **no** form of this command to return to the default.

Syntax

switchport community *community*

no switchport community

Parameters

community *community*—Specifies the community number. (range: 1 - 30)

Default Configuration

The port is not associated with a community.

Command Mode

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

The command is relevant only when the port is defined as a protected port. Use the **switchport protected-port** Interface Configuration command to define a port as a protected port.

Example

```
switchxxxxxx(config)# interface fe1/0/11
switchxxxxxx(config-if)# switchport community 1
```

30.11 switchport

Use the **switchport** Interface Configuration mode command to put an interface that is in Layer 3 mode into Layer 2 mode. Use the **no** form of this command to put an interface in Layer 3 mode.

Syntax

switchport

no switchport

Parameters

N/A

Default Configuration

Layer 2 mode

Command Mode

Interface Configuration (Ethernet, port-channel) mode

Examples:

Example 1 - The following example puts the port gi1 into Layer 2 mode.

```
switchxxxxxx(config)# interface gi1
switchxxxxxx(config-if)#switchport
```

Example 2 - The following example puts the port gi1 into Layer 3 mode.

```
switchxxxxxx(config)# interface gi1
```

```
switchxxxxxx(config-if) #no switchport
```

30.12 switchport mode

Use the **switchport mode** Interface Configuration (Ethernet, port-channel) mode command to configure the VLAN membership mode (access, trunk, general or customer) of a port. Use the **no** form of this command to restore the default configuration.

Syntax

switchport mode {*access* | *trunk* | *general* | *customer*}

no switchport mode

Parameters

- **access**—Specifies an untagged layer 2 VLAN port.
- **trunk**—Specifies a trunking layer 2 VLAN port.
- **general**—Specifies a full 802-1q-supported VLAN port.
- **customer**—Specifies that the port is connected to customer equipment. Used when the switch is in a provider network.

Default Configuration

Access mode.

Command Mode

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

- When the port's mode is changed, it receives the configuration corresponding to the mode.
- If the port mode is changed to access and the access VLAN does not exist, then the port does not belong to any VLAN.
- Trunk and general mode ports can be changed to access mode only if all VLANs (except for an untagged PVID) are first removed.

Example

The following example configures `fe1/0/11` as an access port (untagged layer 2) VLAN port.

```
switchxxxxxx(config) # interface fe1/0/11
switchxxxxxx(config-if) # switchport mode access
switchxxxxxx(config-if) # switchport access vlan 2
```

30.13 switchport access vlan

A port in access mode can be an untagged member of at most a single VLAN. The **switchport access vlan** Interface Configuration command reassigns an interface to a different VLAN than it currently belongs or assigns it to *none*, in which case it is not a member of any VLAN.

The **no** form of this command to restore the default configuration.

Syntax

switchport access vlan {*vlan-id* | *none*}

no switchport access vlan

Parameters

vlan *vlan-id*—Specifies the VLAN to which the port is configured.

vlan *none*—Specifies that the access port cannot belong to any VLAN.

Default Configuration

The interface belongs to the default VLAN.

Command Mode

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

When the port is assigned to a different VLAN, it is automatically removed from its previous VLAN and added to the new VLAN. If the port is assigned to *none*, it is removed from the previous VLAN and not assigned to any other VLAN.

Example

The following example assigns access port gi1 to VLAN 2 (and removes it from its previous VLAN).

```
switchxxxxxx(config)# interface fe1/0/12
switchxxxxxx(config-if)# switchport mode access
switchxxxxxx(config-if)# switchport access vlan 2
```

30.14 switchport trunk allowed vlan

A trunk interface is an untagged member of a single VLAN, and, in addition, it may be a tagged member of one or more VLANs. Use the **switchport trunk allowed vlan** Interface Configuration mode command to add/remove VLAN(s) to/from a trunk port.

Syntax

switchport trunk allowed vlan {*all* | *none* | **add** *vlan-list* | **remove** *vlan-list* | **except** *vlan-list*}

Parameters

all—Specifies all VLANs from 1 to 4094. At any time, the port belongs to all VLANs existing at the time. (range: 1–4094)

none—Specifies an empty VLAN list. The port does not belong to any VLAN.

add *vlan-list*—List of VLAN IDs to add to the port. Separate nonconsecutive VLAN IDs with a comma and no spaces. Use a hyphen to designate a range of IDs.

remove *vlan-list*—List of VLAN IDs to remove from a port. Separate nonconsecutive VLAN IDs with a comma and no spaces. Use a hyphen to designate a range of IDs.

except *vlan-list*—List of VLAN IDs is calculated by inverting the defined list of VLANs (the calculated list will include all VLANs from 1 - 4094 except VLANs from the this list).

Default Configuration

By default, trunk ports belongs to all created VLANs.

Command Mode

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

Inside **except** **except-vlan-list** is saved as **add ~ vlan-list**, where **~ vlan-list** is a list of all VLANs from 1 to 4094 minus the VLANs from **except-vlan-list**. The **show running/startup** command always uses the latter format.

The port must be in trunk mode before the command can take effect.

Example

To add VLANs 2,3 and 100 to trunk ports 1 to 13

```
switchxxxxxx(config)# interface range fe1/0/11-13
switchxxxxxx(config-if)# switchport mode trunk
switchxxxxxx(config-if)# switchport trunk allowed vlan add 2-3,100
switchxxxxxx(config-if)#
```

30.15 switchport trunk allowed vlan

A trunk interface is an untagged member of a single VLAN, and, in addition, it may be an tagged member of one or more VLANs. The **switchport trunk allowed vlan** Interface Configuration mode command adds/removes VLAN(s) to/from a trunk port.

Syntax

switchport trunk allowed vlan {**add** *vlan-list* | **remove** *vlan-list*}

Parameters

- **add** *vlan-list* — Specifies a list of VLAN IDs to add to a port. Separate nonconsecutive VLAN IDs with a comma and no spaces; use a hyphen to designate a range of IDs.
- **remove** *vlan-list* — Specifies a list of VLAN IDs to remove from a port. Separate nonconsecutive VLAN IDs with a comma and no spaces; use a hyphen to designate a range of IDs.

Default Configuration

By default, trunk ports belongs to all created VLANs.

Command Mode

Interface Configuration (Ethernet, port-channel) mode

Example

To add VLANs 2,3 and 100 to trunk ports 1 to 13:

```
switchxxxxxx(config)# interface range fe1/0/11-13
switchxxxxxx(config-if)# switchport mode trunk
```

```
switchxxxxxx(config-if) # switchport trunk allowed vlan add 2-3,100  
switchxxxxxx(config-if) #
```

30.16 switchport trunk native vlan

If an untagged packet arrives on a trunk port, it is directed to the port's native VLAN. Use the **switchport trunk native vlan** Interface Configuration (Ethernet, port-channel) mode command to define the native VLAN for a trunk interface. Use the **no** form of this command to restore the default native VLAN.

Syntax

switchport trunk native vlan {*vlan-id* | *none*}

no switchport trunk native vlan

Parameters

- **vlan-id**—Specifies the native VLAN ID.
- **none**—Specifies the access port cannot belong to any VLAN.

Default Configuration

If the default VLAN is enabled, the default native VLAN is 1. Otherwise, the default native VLAN is 4095.

Command Mode

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

The command adds the port as a member of the VLAN. If the port is already a member of the VLAN (not a native), it must first be removed from the VLAN.

Examples:

Example 1 - The following example:

- Defines VLAN 2 as native VLAN for port 1
- Removes VLAN 2 from port 1 and then sets it as the native VLAN

```
switchxxxxxx(config) # interface fe1/0/11  
switchxxxxxx(config-if) # switchport trunk native vlan 2  
Port 1: Port is Trunk in VLAN 2.  
switchxxxxxx(config-if) # switchport trunk allowed vlan remove 2  
switchxxxxxx(config-if) # switchport trunk native vlan 2  
switchxxxxxx(config-if) #
```

Example 2 - The following example sets packets on port as untagged on ingress and untagged on egress:

```
switchxxxxxx(config) # interface fe1/0/11  
switchxxxxxx(config-if) # switchport mode trunk
```

```
switchxxxxxx(config-if) # switchport trunk native vlan 2  
switchxxxxxx(config-if) #
```

Example 3 - The following example sets packets on port are tagged on ingress and tagged on egress:

```
switchxxxxxx(config) # interface fe1/0/11  
switchxxxxxx(config-if) # switchport mode trunk  
switchxxxxxx(config-if) # switchport trunk allowed vlan add 2  
switchxxxxxx(config-if) #
```

30.17 switchport general allowed vlan

General ports can receive tagged or untagged packets. Use the **switchport general allowed vlan** Interface Configuration mode command to add/remove VLANs to/from a general port and configure whether packets on the egress are tagged or untagged. Use the **no** form of this command to reset to the default.

Syntax

switchport general allowed vlan {add | remove} *vlan-list* [tagged | untagged]

no switchport general allowed vlan

Parameters

- **add *vlan-list***—List of VLAN IDs to add. Separate nonconsecutive VLAN IDs with a comma and no spaces. Use a hyphen to designate a range of IDs. (range: 1–4094)
- **remove *vlan-list***—List of VLAN IDs to remove. Separate nonconsecutive VLAN IDs with a comma and no spaces. Use a hyphen to designate a range of IDs.
- **tagged**—Specify that packets are transmitted tagged for the configured VLANs
- **untagged**—Specify that packets are transmitted untagged for the configured VLANs (this is the default)

Default Configuration

The port is not a member of any VLAN.

Packets are transmitted untagged.

Command Mode

Interface Configuration mode

Example

Sets port 1 to general mode and adds VLAN 2 and 3 to it. Packets are tagged on the egress.

```
switchxxxxxx(config) # interface fe1/0/11  
switchxxxxxx(config-if) # switchport mode general  
switchxxxxxx(config-if) # switchport general allowed vlan add 2-3 tagged
```

30.18 switchport general allowed vlan

General ports can receive tagged or untagged packets. Use the **switchport general allowed vlan** Interface Configuration mode command to add/remove VLANs to/from a general port and configure whether packets on the egress are tagged or untagged. Use the **no** form of this command to reset to the default.

Syntax

switchport general allowed vlan {[add *vlan-list* [*tagged* | *untagged*]] | [*remove vlan-list*]}

Parameters

- **add *vlan-list*** — Specifies the list of VLAN IDs to add. Separate nonconsecutive VLAN IDs with a comma and no spaces; use a hyphen to designate a range of IDs.
- **tagged** — Specifies that the port transmits tagged packets for the VLANs. This is the default value
- **untagged** — Specifies that the port transmits untagged packets for the VLANs.
- **remove *vlan-list*** — Specifies the list of VLAN IDs to remove. Separate nonconsecutive VLAN IDs with a comma and no spaces; use a hyphen to designate a range of IDs.

Default Configuration

The port is not member in any VLAN.

Packets are transmitted untagged.

Command Mode

Interface Configuration (Ethernet, Port-channel) mode

User Guidelines

You can change the egress rule (for example, from tagged to untagged) without first removing the VLAN from the list.

Example

Sets port 1 to general mode and adds VLAN 2 and 3 to it. Packets are tagged on the egress.

```
switchxxxxxx(config)# interface fe1/0/11
switchxxxxxx(config-if)# switchport mode general
switchxxxxxx(config-if)# switchport general allowed vlan add 2-3 tagged
```

30.19 switchport general pvid

The port VLAN ID (PVID) is the VLAN to which incoming untagged and priority-tagged frames are classified on a general port. Use the **switchport general pvid** Interface Configuration (Ethernet, Port-channel) mode command to configure the Port VLAN ID (PVID) of an interface when it is in general mode. Use the **no** form of this command to restore the default configuration.

Syntax

switchport general pvid *vlan-id*

no switchport general pvid

Parameters

pvid *vlan-id*—Specifies the Port VLAN ID (PVID).

Default Configuration

The default VLAN is the PVID.

Command Mode

Interface Configuration (Ethernet, Port-channel) mode

Example

Example 1 - The following example configures port 2 as a general port and sets its PVID to 234.

```
switchxxxxxx(config)# interface fe1/0/12
switchxxxxxx(config-if)# switchport mode general
switchxxxxxx(config-if)# switchport general pvid 234
```

Example 2 - Performs the following:

- Adds VLANs 2&3 as tagged, and VLAN 100 as untagged to general mode port 14
- Defines VID 100 as the PVID
- Reverts to the default PVID (VID=1)

```
switchxxxxxx(config)# interface fe1/0/114
switchxxxxxx(config-if)# switchport mode general
switchxxxxxx(config-if)# switchport general allowed vlan add 2-3
tagged
switchxxxxxx(config-if)# switchport general allowed vlan add 100
untagged
switchxxxxxx(config-if)# switchport general pvid 100
switchxxxxxx(config-if)# no switchport general pvid
switchxxxxxx(config-if)#
```

Example 3 - Configures VLAN on port 14 as untagged on input and untagged on output:

```
switchxxxxxx(config)# interface fe1/0/114
switchxxxxxx(config-if)# switchport mode general
switchxxxxxx(config-if)# switchport general pvid 2
switchxxxxxx(config-if)# switchport general allowed vlan add 2 untagged
switchxxxxxx(config-if)#
```

Example 4 - Configures VLAN on port 21 as untagged on input and tagged on output:

```
switchxxxxxx(config)# interface fe1/0/121
```

```
switchxxxxxx(config-if) # switchport mode general
switchxxxxxx(config-if) # switchport general pvid 2
switchxxxxxx(config-if) # switchport general allowed vlan add 2 tagged
switchxxxxxx(config-if) #
```

Example 5 - Configures VLAN on port 14 as tagged on input and tagged on output:

```
switchxxxxxx(config) # interface fe1/0/114
switchxxxxxx(config-if) # switchport mode general
switchxxxxxx(config-if) # switchport general allowed vlan add 2 tagged
switchxxxxxx(config-if) #
```

Example 6 - Configures VLAN on port 23 as tagged on input and untagged on output:

```
switchxxxxxx(config) # interface fe1/0/123
switchxxxxxx(config-if) # switchport mode general
switchxxxxxx(config-if) # switchport general allowed vlan add 2 tagged
switchxxxxxx(config-if) #
```

30.20 switchport general ingress-filtering disable

Use the **switchport general ingress-filtering disable** Interface Configuration (Ethernet, Port-channel) mode command to disable port ingress filtering (no packets are discarded at the ingress) on a general port. Use the no form of this command to restore the default configuration.

Syntax

switchport general ingress-filtering disable

no switchport general ingress-filtering disable

Parameters

N/A

Default Configuration

Ingress filtering is enabled.

Command Mode

Interface Configuration (Ethernet, port-channel) mode

Example

The following example disables port ingress filtering on fe1/0/11.

```
switchxxxxxx(config) # interface fe1/0/11
switchxxxxxx(config-if) # switchport mode general
switchxxxxxx(config-if) # switchport general ingress-filtering disable
```

30.21 switchport general acceptable-frame-type

The **switchport general acceptable-frame-type** Interface Configuration mode command configures the types of packets (tagged/untagged) that are filtered (discarded) on the interface. Use the **no** form of this command to return ingress filtering to the default.

Syntax

switchport general acceptable-frame-type {*tagged-only* | *untagged-only* | *all*}

no switchport general acceptable-frame-type

Parameters

- **tagged-only**—Ignore (discard) untagged packets and priority-tagged packets.
- **untagged-only**—Ignore (discard) VLAN-tagged packets (not including priority-tagged packets)
- **all**—Do not discard packets untagged or priority-tagged packets.

Default Configuration

All frame types are accepted at ingress (**all**).

Command Mode

Interface Configuration (Ethernet, port-channel) mode

Example

The following example configures port `fe1/0/13` to be in general mode and to discard untagged frames at ingress.

```
switchxxxxxx(config)# interface fe1/0/13
switchxxxxxx(config-if)# switchport mode general
switchxxxxxx(config-if)# switchport general acceptable-frame-type
tagged-only
```

30.22 switchport customer vlan

When a port is in customer mode it is in QinQ mode. This enables the user to use their own VLAN arrangements (PVID) across a provider network. The switch is in QinQ mode when it has one or more customer ports.

Use the **switchport customer vlan** Interface Configuration mode command to set the port's VLAN when the interface is in customer mode (set by [switchport mode](#)). Use the **no** form of this command to restore the default configuration.

Syntax

switchport customer vlan *vlan-id*

no switchport customer vlan

Parameters

vlan *vlan-id*—Specifies the customer VLAN.

Default Configuration

No VLAN is configured as customer.

Command Mode

Interface Configuration (Ethernet, Port-channel) mode

Example

The following example defines `fe1/0/15` as a member of customer VLAN 5.

```
switchxxxxxx(config)# interface fe1/0/15
switchxxxxxx(config-if)# switchport mode customer
switchxxxxxx(config-if)# switchport customer vlan 5
```

30.23 map protocol protocols-group

Forwarding of packets based on their protocol requires setting up groups of protocols and then mapping these groups to VLANs. Use the **map protocol protocols-group** VLAN Configuration mode command to map a protocol to a group of protocols. This protocol group can then be used in [switchport general map protocols-group vlan](#). Use the **no** form of this command to delete a protocol from a group.

Syntax

map protocol *protocol* [*encapsulation*] **protocols-group** *group*

no map protocol *protocol* [*encapsulation*]

Parameters

- **protocol**—Specifies a 16-bit protocol number or one of the reserved names listed in the User Guidelines. (range: 0x0600–0xFFFF)
- **encapsulation**—Specifies one of the following values: Ethernet, rfc1042, llcOther.
- **protocols-group** *group*—Specifies the group number of the group of protocols (range: 1–2147483647).

Default Configuration

The default encapsulation is Ethernet.

Command Mode

VLAN Configuration mode

User Guidelines

The value 0x8100 is not valid as the protocol number for Ethernet encapsulation.

The following protocol names are reserved for Ethernet Encapsulation:

- ip
- arp
- ipv6
- ipx

Example

The following example maps the IP protocol to protocol group number 213.

```
switchxxxxxx(config)# vlan database  
switchxxxxxx(config-vlan)# map protocol ip protocols-group 213
```

30.24 switchport general map protocols-group vlan

Use the **switchport general map protocols-group vlan** Interface Configuration (Ethernet, Port-channel) mode command to forward packets based on their protocol, otherwise known as setting up a classifying rule. This command forwards packets arriving on an interface containing a specific protocol to a specific VLAN.

Use the no form of this command to stop forwarding packets based on their protocol.

Syntax

switchport general map protocols-group *group* **vlan** *vlan-id*

no switchport general map protocols-group *group*

Parameters

- **group**—Specifies the group number as defined in [map protocol protocols-group](#) (range: 1–65535).
- **vlan** *vlan-id*—Defines the VLAN ID in the classifying rule.

Default Configuration

N/A

Command Mode

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

The VLAN classification rule priorities are:

4. MAC-based VLAN (best match among the rules)
5. Subnet-based VLAN (best match among the rules)
6. Protocol-based VLAN
7. PVID

Example

The following example forwards packets with protocols belong to protocol-group 1 to VLAN 8.

```
switchxxxxxx(config-if)# switchport general map protocols-group 1 vlan  
8
```

30.25 show vlan protocols-groups

Use the **show vlan protocols-groups** EXEC mode command to display the protocols that belong to the defined protocols-groups.

Syntax

show vlan protocols-groups

Parameters

N/A

Default Configuration

N/A

Command Mode

EXEC mode

Example

The following example displays protocols-groups information.

```
switchxxxxxx# show vlan protocols-groups
```

Protocol	Encapsulation	Group
-----	-----	-----
0x800 (IP)	Ethernet	1
0x806 (ARP)	Ethernet	1
0x86dd (IPv6)	Ethernet	2
0x8898	Ethernet	3

30.26 map mac macs-group

Forwarding of packets based on their MAC address requires setting up groups of MAC addresses and then mapping these groups to VLANs.

Use the **map mac macs-group** VLAN Configuration mode command to map a MAC address or range of MAC addresses to a group of MAC addresses, which is then used in [switchport general map macs-group vlan](#). Use the **no** form of this command to delete the mapping.

This command can only be used when the device is in Layer 2 mode.

Syntax

map mac mac-address {*prefix-mask* | *host*} **macs-group** *group*

no map mac mac-address {*prefix-mask* | *host*}

Parameters

- **mac mac-address**—Specifies the MAC address to be mapped to the group of MAC addresses.
- **prefix-mask**—Specifies the number of ones in the mask.
- **host**—Specifies that the mask is comprised of all 1s.
- **macs-group group**—Specifies the group number (range: 1–2147483647)

Default Configuration

N/A

Command Mode

VLAN Configuration mode

Example

The following example creates two groups of MAC addresses, sets a port to general mode and maps the groups of MAC addresses to specific VLANs.

```
switchxxxxxx(config)# vlan database
switchxxxxxx(config-vlan)# map mac 0000.1111.0000 32 macs-group 1
switchxxxxxx(config-vlan)# map mac 0000.0000.2222 host macs-group 2
switchxxxxxx(config-vlan)# exit
switchxxxxxx(config)# interface fe1/0/111
switchxxxxxx(config-if)# switchport mode general
switchxxxxxx(config-if)# switchport general map macs-group 1 vlan 2
switchxxxxxx(config-if)# switchport general map macs-group 2 vlan 3
```

30.27 switchport general map macs-group vlan

After groups of MAC addresses have been created (see [map mac macs-group](#)), they can be mapped to specific VLANs.

Use the **switchport general map macs-group vlan** Interface Configuration (Ethernet, Port-channel) mode command to set a MAC-based classification rule. Use the no form of this command to delete a classification rule.

Syntax

switchport general map macs-group *group* **vlan** *vlan-id*

no switchport general map macs-group *group*

Parameters

- **macs-group** *group*—Specifies the group number (range: 1–2147483647)
- **vlan** *vlan-id*—Defines the VLAN ID associated with the rule.

Default Configuration

N/A

Command Mode

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

MAC-based VLAN rules cannot contain overlapping ranges on the same interface.

The VLAN classification rule priorities are:

1. MAC-based VLAN (Best match among the rules).
2. Subnet-based VLAN (Best match among the rules).
3. Protocol-based VLAN.
4. PVID.

**Example**

The following example creates two groups of MAC addresses, sets a port to general mode and maps the groups of MAC addresses to specific VLANs.

```
switchxxxxxx(config)# vlan database
switchxxxxxx(config-vlan)# map mac 0000.1111.0000 32 macs-group 1
switchxxxxxx(config-vlan)# map mac 0000.0000.2222 host macs-group 2
switchxxxxxx(config-vlan)# exit
switchxxxxxx(config)# interface fe1/0/111
switchxxxxxx(config-if)# switchport mode general
switchxxxxxx(config-if)# switchport general map macs-group 1 vlan 2
switchxxxxxx(config-if)# switchport general map macs-group 2 vlan 3
```

30.28 show vlan macs-groups

Use the **show vlan macs-groups** EXEC mode command to display the MAC addresses that belong to the defined MACs-groups.

Syntax

show vlan macs-groups

Parameters

N/A

Default Configuration

N/A

Command Mode

EXEC mode

Example

The following example displays macs-groups information.

```
switchxxxxxx# show vlan macs-groups
```

MAC Address	Mask	Group ID
00:12:34:56:78:90	20	22
00:60:70:4c:73:ff	40	1

30.29 map subnet subnets-group

Forwarding of packets based on their IP subnet requires setting up groups of IP subnets and then mapping these groups to VLANs. Use the **map subnet subnets-group** VLAN Configuration mode command to map an IP subnet to a group of IP subnets. Use the **no** form of this command to delete the map.

Syntax

map subnet *ip-address prefix-mask subnets-group group*

no map subnet *ip-address prefix-mask*

Parameters

- **ip-address**—Specifies the IP address prefix of the subnet to be mapped to the group.
- **prefix-mask**—Specifies the number of 1s in the mask.
- **subnets-group group**—Specifies the group number. (range: 1–2147483647)

Default Configuration

N/A

Command Mode

VLAN Configuration mode

Example

The following example maps an IP subnet to the group of IP subnets 4. It then maps this group of IP subnets to VLAN 8

```
switchxxxxxx(config)#vlan database
switchxxxxxx(config-vlan)# map subnet 172.16.1.1 24 subnets-group 4
switchxxxxxx(config-if)# switchport general map subnets-group 4 vlan 8
```

30.30 switchport general map subnets-group vlan

Use the **switchport general map subnets-group vlan** Interface Configuration (Ethernet, Port-channel) mode command to set a subnet-based classification rule. Use the **no** form of this command to delete a subnet-based classification rule.

Syntax

switchport general map subnets-group group vlan *vlan-id*

no switchport general map subnets-group group

Parameters

- **group**—Specifies the group number. (range: 1–2147483647)
- **vlan-id**—Defines the VLAN ID associated with the rule.

Default Configuration

N/A

Command Mode

Interface Configuration (Ethernet, Port-channel) mode

User Guidelines

The VLAN classification rule priorities are:

1. MAC-based VLAN (Best match among the rules)

2. Subnet-based VLAN (Best match among the rules)
3. Protocol-based VLAN
4. PVID

Example

The following example maps an IP subnet to the group of IP subnets 4. It then maps this group of IP subnets to VLAN 8

```
switchxxxxxx(config)#vlan database
switchxxxxxx(config-vlan)# map subnet 172.16.1.1 24 subnets-group 4
switchxxxxxx(config-if)# switchport general map subnets-group 4 vlan 8
```

30.31 show vlan subnets-groups

Use the **show vlan subnets-groups** EXEC mode command to display subnets-groups information.

Syntax

show vlan subnets-groups

Parameters

N/A

Default Configuration

N/A

Command Mode

EXEC mode

Example

The following example displays subnets-groups information.

```
switchxxxxxx# show vlan subnets-groups
```

IP Subnet Address	Mask	Group ID
1.1.1.1	32	1
172.16.2.0	24	2

30.32 switchport forbidden default-vlan

Use the **switchport forbidden default-vlan** Interface Configuration command to forbid a port from being added to the default VLAN. Use the no form of this command to revert to default.

Syntax

switchport forbidden default-vlan

no switchport forbidden default-vlan

Parameters

N/A

Default Configuration

Membership in the default VLAN is allowed.

Command Mode

Interface and Interface range configuration (Ethernet, port-channel)

User Guidelines

The command may be used at any time regardless of whether the port belongs to the default VLAN.

The **no** command does not add the port to the default VLAN, it only defines an interface as permitted to be a member of the default VLAN, and the port will be added only when conditions are met.

Example

The following example forbids the port gi1 from being added to the default VLAN.

```
switchxxxxxx(config)#interface gi1
switchxxxxxx(config-if)# switchport forbidden default-vlan
```

30.33 switchport forbidden vlan

The **switchport forbidden vlan** Interface Configuration (Ethernet, Port-channel) mode command forbids adding or removing specific VLANs to or from a port. To restore the default configuration, use the **no** form of this command.

Syntax

switchport forbidden vlan {**add** *vlan-list* | **remove** *vlan-list*}

no switchport forbidden vlan {**add** *vlan-list* | **remove** *vlan-list*}

Parameters

- **add** *vlan-list* — Specifies a list of VLAN IDs to add. Separate nonconsecutive VLAN IDs with a comma and no spaces; use a hyphen designate a range of IDs.
- **remove** *vlan-list* — Specifies a list of VLAN IDs to remove. Separate nonconsecutive VLAN IDs with a comma and no spaces; use a hyphen designate a range of IDs.

Default Configuration

All VLANs are allowed.

Command Mode

Interface Configuration (Ethernet, Port-channel) mode

Example

The following example forbids adding VLAN IDs 234 to 256 to fe1/0/17.

```
switchxxxxxx(config)# interface fe1/0/17
```

```
switchxxxxxx(config-if) # switchport mode trunk  
switchxxxxxx(config-if) # switchport forbidden vlan add 234-256
```

30.34 switchport default-vlan tagged

Use the **switchport default-vlan tagged** Interface Configuration command to configure the port as a tagged port in the default VLAN. Use the **no** form of the command to return the port to an untagged port.

Syntax

switchport default-vlan tagged
no switchport default-vlan tagged

Parameters

N/A

Default Configuration

If the port is a member in the default VLAN, by default, it is a member as an untagged port.

Command Mode

Interface configuration (Ethernet, port-channel)

User Guidelines

The command adds a port to the default VLAN as a tagged port.

The command is available only if the port mode is trunk or general.

When a trunk port is a member in the default VLAN as a tagged port then:

- The native VLAN cannot be the default VLAN
- The default of the native VLAN is 4095

Note: If the native VLAN of a port is the default VLAN when the port is added to the default VLAN as tagged, the native VLAN is set by the system to 4095.

When a general port is a member in the default VLAN as a tagged port then:

- The PVID can be the default VLAN.
- The default PVID is the default VLAN.

Note: The PVID is not changed when the port is added to the default VLAN as a tagged.

When executing the **switchport default-vlan tagged** command, the port is added (automatically by the system) to the default VLAN when the following conditions no longer exist:

- The port is a member in a LAG.
- The port is 802.1X unauthorized.
- An IP address is defined on the port.
- The port is a destination port of port mirroring.
- An IP address is defined on the default VLAN and the port is a PVE protected port.

The **no switchport default-vlan tagged** command removes the port from the default VLAN, and returns the default VLAN mode to untagged.

Note:

- If the native VLAN of a trunk port is 4095 when the port is removed from the default VLAN (as a tagged), the native VLAN is set by the system to the default VLAN.

- The PVID of a general port is not changed when the port is removed from the default VLAN (as a tagged). If the PVID is the default VLAN, the port is added by the system to the default VLAN as an untagged.

Example

The following example configures the port fe1/0/11 as a tagged port in the default VLAN.

```
switchxxxxxx(config)#interface gi1
switchxxxxxx(config-if)# switchport mode trunk
switchxxxxxx(config-if)#switchport default-vlan tagged
```

30.35 show interfaces switchport

Use the **show interfaces switchport** Privileged EXEC command to display the administrative and operational status of all interfaces or a specific interface.

Syntax

show interfaces switchport [*interface-id*]

Parameters

interface-id—Specify an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel

Default Configuration

Displays information for all interfaces.

Command Mode

EXEC mode

Examples:

Example 1 - The following example displays the the command output for a trunk port:

```
switchxxxxxx# show interfaces switchport fe1/0/11
Port fe1/0/11:
Port Mode: Trunk
Gvrp Status: disabled
Ingress Filtering: true
Acceptable Frame Type: admitAll
Ingress UnTagged VLAN ( NATIVE ): 2
Protected: Enabled, Uplink is fe1/0/19.
Port fe1/0/11 is member in:
  VLAN   Name           Egress Rule  Type
  ----   -
  1      default        untagged     System
  8      VLAN008        tagged       Dynamic
```



```

11      VLAN0011      tagged      Static
19      IPv6VLAN      untagged    Static
72      VLAN0072      untagged    Static
Forbidden VLANs:
VLAN    Name
----    -
73      Out
Classification rules:
Mac based VLANs:
Group ID  Vlan ID

```

Example 2 - The following example displays the output for a general port:

```

switchxxxxx# show interfaces switchport fe1/0/12
Port fe1/0/12:
VLAN Membership mode: General
Operating Parameters:
PVID: 4095 (discard vlan)
Ingress Filtering: Enabled
Acceptable Frame Type: All
GVRP status: Enabled
Protected: Disabled
Port fe1/0/11 is member in:
VLAN  Name          Egress Rule Type
----  -
91    IP Telephony    tagged      Static
Protected: Disabled
Port fe1/0/12 is statically configured to:
VLAN  Name          Egress Rule Type
----  -
8     VLAN0072      untagged
91    IP Telephony    tagged
Forbidden VLANs:
VLAN  Name
----  -
73    Out

```

Example 3 - The following example displays the command output for an access port:

```

switchxxxxx# show interfaces switchport fe1/0/12
Port fe1/0/12:
Port Mode: Access

```

```
Gvrp Status: disabled
Ingress Filtering: true
Acceptable Frame Type: admitAll
Ingress UnTagged VLAN ( NATIVE ): 1
Port is member in:
Vlan          Name          Egress Rule Port Membership Type
-----
1             1             Untagged     System
Forbidden VLANS:
Vlan          Name
-----
Classification rules:
Mac based VLANs:
```

30.36 show interfaces switchport

Use the **show interfaces switchport** Privileged EXEC command to display the administrative and operational status of all interfaces or a specific interface.

Syntax

```
show interfaces switchport [interface-id]
```

Parameters

Interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

Command Mode

Privileged EXEC mode

Default

Displays the status of all interfaces.

Example

```
switchxxxxxx# show interfaces switchport fe1/0/11
```

```
Protected: Enabled, Uplink is fe1/0/11
Classification rules:
Classification Type  Group ID  VLAN ID
-----
Protocol             1         19
Protocol             1         20
Protocol             2         72
Subnet               1         15
MAC                  6         11
```

30.37 ip internal-usage-vlan

The system assigns a VLAN to every IP address. In rare cases, this might conflict with a user requirement for that VLAN. In this case, use the **ip internal-usage-vlan** Interface Configuration (Ethernet, Port-channel) mode command to reserve a different VLAN as the internal usage VLAN of an interface. Use the **no** form of this command to restore the default configuration.

Syntax

ip internal-usage-vlan *vlan-id*

no ip internal-usage-vlan

Parameters

vlan-id—Specifies the internal usage VLAN ID.

Default Configuration

No VLAN is reserved as an internal usage VLAN by default (using this command).

Command Mode

Interface Configuration (Ethernet, Port-channel) mode. It cannot be configured for a range of interfaces (range context).

User Guidelines

An internal usage VLAN is assigned by the system when an IP interface is defined on an Ethernet port or port-channel.

If an internal usage VLAN is not defined for a port, the software selects one of the unused VLANs.

If a VLAN was chosen by the software for internal usage, but you want to use that VLAN for a static or dynamic VLAN, do one of the following:

- Remove the IP address from the interface (this releases the internal usage VLAN).
- Recreate the VLAN on the required interface (now it will be assigned to the interface and not be used as an internal usage VLAN)
- Recreate the IP interface (another internal usage VLAN is assigned to this IP interface) or use this command to explicitly define the internal usage VLAN.

Example

The following example reserves unused VLAN 200 as the internal usage VLAN of fe1/0/13.

```
switchxxxxxx(config)# interface fe1/0/13
switchxxxxxx(config-if)# ip internal-usage-vlan 200
```

30.38 show vlan internal usage

Use the **show vlan internal usage** Privileged EXEC mode command to display a list of VLANs used internally by the device (defined by the user).

Syntax

show vlan internal usage

Parameters

N/A

Default Configuration

N/A

Command Mode

Privileged EXEC mode

Example

The following example displays VLANs used internally by the device.

```
switchxxxxxxx# show vlan internal usage

Usage          VLAN          Reserved      IP address
-----
fe1/0/121     1007          No            Active
fe1/0/122     1008          Yes           Inactive
fe1/0/123     1009          Yes           Active
```

30.39 switchport access multicast-tv vlan

Use the **switchport access multicast-tv vlan** Interface Configuration (Ethernet, Port-channel) mode command to enable receiving Multicast transmissions on an interface that is not the access port VLAN, while keeping the L2 segregation with subscribers on different access port VLANs. Use the **no** form of this command to disable receiving Multicast transmissions.

Syntax**switchport access multicast-tv vlan** *vlan-id***no switchport access multicast-tv vlan****Parameters****vlan-id**—Specifies the Multicast TV VLAN ID.**Default Configuration**

Receiving Multicast transmissions is disabled.

Command Mode

Interface Configuration (Ethernet, Port-channel) mode

User Guidelines

The user cannot transmit Multicast transmissions on the Multicast TV VLAN.

A Multicast TV VLAN cannot be enabled if a Guest VLAN is enabled on the interface.

Example

The following example enables `fe1/0/15` to receive Multicast transmissions from VLAN 11.

```
switchxxxxxx(config)# interface fe1/0/15  
switchxxxxxx(config-if)# switchport access multicast-tv vlan 11
```

30.40 switchport customer multicast-tv vlan

Use the **switchport customer multicast-tv vlan** Interface Configuration mode command to enable receiving Multicast transmissions from a VLAN that is not the customer port's VLAN, while keeping the L2 segregation with subscribers on different customer port VLANs.

Syntax

switchport customer multicast-tv vlan {*add vlan-list* | *remove vlan-list*}

Parameters

- **add *vlan-list***—Specifies a list of Multicast TV VLANs to add to interface.
- **remove *vlan-list***—Specifies a list of Multicast TV VLANs to remove from interface.

Default Configuration

The port is not a member in any Multicast TV VLAN.

Command Mode

Interface Configuration (Ethernet, port-channel) mode

User Guidelines

The user cannot transmit Multicast transmissions on Multicast TV VLANs.

A Multicast TV VLAN cannot be enabled if a Guest VLAN is enabled on the interface.

Example

The following example enables *fe1/0/15* to receive Multicast transmissions from VLANs 5, 6, 7.

```
switchxxxxxx(config)# interface fe1/0/15  
switchxxxxxx(config-if)# switchport customer multicast-tv vlan add 5-7
```

30.41 show vlan multicast-tv

Use the **show vlan Multicast-tv** EXEC mode command to display the source and receiver ports of Multicast-TV VLAN. Source ports can transmit and receive traffic to/from the VLAN, while receiver ports can only receive traffic from the VLAN.

Syntax

show vlan Multicast-tv vlan *vlan-id*

Parameters

vlan-id—Specifies the VLAN ID.

Default Configuration

N/A

Command Mode

EXEC mode

Example

The following example displays information on the source and receiver ports of Multicast-TV VLAN 1000.

```
switchxxxxxx# show vlan multicast-tv vlan 1000

Source Ports      Receiver Ports
-----
fe1/0/18,        fe1/0/11-18
fe1/0/19
```

31 Internet Group Management Protocol (IGMP) Snooping Commands

31.1 ip igmp snooping (Global)

Use the **ip igmp snooping** Global Configuration mode command to enable Internet Group Management Protocol (IGMP) snooping. Use the **no** form of this command to disable IGMP snooping.

Syntax

ip igmp snooping

no ip igmp snooping

Default Configuration

Disabled.

Command Mode

Global Configuration mode

Example

The following example enables IGMP snooping.

```
switchxxxxxx(config)# ip igmp snooping
```

31.2 ip igmp snooping vlan

Use the **ip igmp snooping vlan** Global Configuration mode command to enable IGMP snooping on a specific VLAN. Use the **no** form of this command to disable IGMP snooping on a VLAN interface.

Syntax

ip igmp snooping vlan *vlan-id*

no ip igmp snooping vlan *vlan-id*

Parameters

vlan *vlan-id*—Specifies the VLAN.

Default Configuration

Disabled

Command Mode

Global Configuration mode

User Guidelines

IGMP snooping can be enabled only on static VLANs.

IGMPv1, IGMPv2 and IGMPv3 are supported.

To activate IGMP snooping, the [bridge multicast filtering](#) should be enabled.

The user guidelines of the [bridge multicast mode](#) Interface VLAN Configuration command describes the configuration that is written into the FDB as a function of the FDB mode and the IGMP version that is used in the network.

Example

```
switchxxxxxx(config)# ip igmp snooping vlan 2
```

31.3 ip igmp snooping vlan mrouter

Use the **ip igmp snooping mrouter** Global Configuration mode command to enable automatic learning of Multicast router ports on a VLAN. Use the **no** form of this command to remove the configuration.

Syntax

ip igmp snooping vlan *vlan-id* mrouter learn pim-dvmrp

no ip igmp snooping vlan *vlan-id* mrouter learn pim-dvmrp

Parameters

vlan *vlan-id*—Specifies the VLAN.

Default Configuration

Learning pim-dvmrp is enabled.

Command Mode

Global Configuration mode

User Guidelines

Multicast router ports are learned according to:

- Queries received on the port
- PIM/PIMv2 received on the port
- DVMRP received on the port
- MRDISC received on the port
- MOSPF received on the port

You can execute the command before the VLAN is created.

Example

```
switchxxxxxx(config)# ip igmp snooping vlan 1 mrouter learn pim-dvmrp
```

31.4 ip igmp snooping vlan mrouter interface

Use the **ip igmp snooping mrouter interface** Global Configuration mode command to define a port that is connected to a Multicast router port. Use the **no** form of this command to remove the configuration.

Syntax

ip igmp snooping vlan *vlan-id* **mrouter interface** *interface-list*

no ip igmp snooping vlan *vlan-id* **mrouter interface** *interface-list*

Parameters

- **vlan** *vlan-id*—Specifies the VLAN.
- **interface** *interface-list*—Specifies the list of interfaces. The interfaces can be one of the following types: Ethernet port or Port-channel.

Default Configuration

No ports defined

Command Mode

Global Configuration mode

User Guidelines

A port that is defined as a Multicast router port receives all IGMP packets (reports and queries) as well as all Multicast data.

You can execute the command before the VLAN is created.

Example

```
switchxxxxxx(config)# ip igmp snooping vlan 1 mrouter interface fe1/0/11
```

31.5 ip igmp snooping vlan forbidden mrouter interface

Use the **ip igmp snooping forbidden mrouter interface** Global Configuration mode command to forbid a port from being defined as a Multicast router port by static configuration or by automatic learning. Use the **no** form of this command to remove the configuration.

Syntax

ip igmp snooping vlan *vlan-id* **forbidden mrouter interface** *interface-list*

no ip igmp snooping vlan *vlan-id* **forbidden mrouter interface** *interface-list*

Parameters

- **vlan** *vlan-id*—Specifies the VLAN.
- **interface** *interface-list*—Specifies a list of interfaces. The interfaces can be from one of the following types: Ethernet port or Port-channel.

Default Configuration

No ports defined.

Command Mode

Global Configuration mode

User Guidelines

A port that is a forbidden mrouter port cannot be a Multicast router port (i.e. cannot be learned dynamically or assigned statically).

You can execute the command before the VLAN is created.

Example

```
switchxxxxxx(config)# ip igmp snooping vlan 1 forbidden mrouter
interface fe1/0/11
```

31.6 ip igmp snooping vlan static

Use the **ip igmp snooping vlan static** Global Configuration mode command to register an IP-layer Multicast address to the bridge table, and to add static ports to the group defined by this address. Use the **no** form of this command to remove ports specified as members of a static Multicast group.

Syntax

ip igmp snooping vlan *vlan-id* **static** *ip-address* [**interface** *interface-list*]

no ip igmp snooping vlan *vlan-id* **static** *ip-address* [**interface** *interface-list*]

Parameter

- **vlan** *vlan-id*—Specifies the VLAN.
- **static** *ip-address*—Specifies the IP Multicast address.
- **interface** *interface-list*—Specifies a list of interfaces. The interfaces can be from one of the following types: Ethernet port or Port-channel.

Default Configuration

No Multicast addresses are defined.

Command Mode

Global Configuration mode

User Guidelines

Static Multicast addresses can only be defined on static VLANs.

You can execute the command before the VLAN is created.

You can register an entry without specifying an interface.

Using the **no** command without a port-list removes the entry.

Example

```
switchxxxxxx(config)# ip igmp snooping vlan 1 static 239.2.2.2 interface  
fe1/0/11
```

31.7 ip igmp snooping vlan multicast-tv

Use the **ip igmp snooping vlan multicast-tv** Global Configuration mode command to define the Multicast IP addresses that are associated with a Multicast TV VLAN. Use the **no** form of this command to remove all associations.

Syntax

ip igmp snooping vlan *vlan-id* **multicast-tv** *ip-multicast-address* [*count number*]

no ip igmp snooping vlan *vlan-id* **multicast-tv** *ip-multicast-address* [*count number*]

Parameters

- **vlan-id**—Specifies the VLAN
- **count number**—Configures multiple contiguous Multicast IP addresses. If not specified, the default is 1. (Range: 1–256)

Default Configuration

No Multicast IP address is associated.

Command Mode

Global Configuration mode

User Guidelines

Use this command to define the Multicast transmissions on a Multicast-TV VLAN. The configuration is only relevant for an Access port that is a member in the configured VLAN as a Multicast-TV VLAN.

If an IGMP message is received on such an Access port, it is associated with the Multicast-TV VLAN only if it is for one of the Multicast IP addresses that are associated with the Multicast-TV VLAN.

Up to 256 VLANs can be configured.

Example

```
switchxxxxxx(config)# ip igmp snooping vlan 1 multicast-tv 239.2.2.2  
count 3
```

31.8 ip igmp snooping map cpe vlan

The **ip igmp snooping map cpe vlan** Global Configuration mode command maps CPE VLANs to Multicast-TV VLANs. Use the **no** form of this command to remove the mapping.

Syntax

ip igmp snooping map cpe vlan *vlan-id* **multicast-tv** *vlan* *vlan-id*

no ip igmp snooping map cpe vlan *vlan-id*

Parameters

- **cpe vlan** *vlan-id*—Specifies the CPE VLAN ID.

- **multicast-tv vlan** *vlan-id*—Specifies the Multicast-TV VLAN ID.

Default Configuration

No mapping exists.

Command Mode

Global Configuration mode

User Guidelines

Use this command to associate the CPE VLAN with a Multicast-TV VLAN.

If an IGMP message is received on a customer port tagged with a CPE VLAN, and there is mapping from that CPE VLAN to a Multicast-TV VLAN, the IGMP message is associated with the Multicast-TV VLAN.

Example

The following example maps CPE VLAN 2 to Multicast-TV VLAN 31.

```
switchxxxxxx(config)# ip igmp snooping map cpe vlan 2 multicast-tv vlan
31
```

31.9 ip igmp snooping vlan querier

Use the **ip igmp snooping vlan querier** Global Configuration mode command to enable the Internet Group Management Protocol (IGMP) querier on a specific VLAN. Use the **no** form of this command to disable the IGMP querier on a VLAN interface.

Syntax

ip igmp snooping vlan *vlan-id* **querier**

no ip igmp snooping vlan *vlan-id* **querier**

Parameters

vlan *vlan-id*—Specifies the VLAN

Default Configuration

Disabled

Command Mode

Global Configuration mode

User Guidelines

The IGMP snooping querier can be enabled on a VLAN only if IGMP snooping is enabled for that VLAN.

At most one switch can be configured as an IGMP Querier for a VLAN.

When the IGMP snooping querier is enabled, it starts after a host-time-out/2 with no IGMP traffic being detected from a Multicast router.

The IGMP Snooping Querier disables itself if it detects IGMP traffic from a Multicast router. It restarts automatically after host-time-out/2.

Example

```
switchxxxxxx(config)# ip igmp snooping vlan 1 querier
```

31.10 ip igmp snooping vlan querier address

Use the **ip igmp snooping vlan querier address** Global Configuration mode command to define the source IP address that the IGMP snooping querier uses. Use the **no** form of this command to return to default.

Syntax

ip igmp snooping vlan *vlan-id* **querier address** *ip-address*

no ip igmp snooping vlan *vlan-id* **querier address**

Parameters

- **vlan** *vlan-id*—Specifies the VLAN.
- **querier address** *ip-address*—Source IP address.

Default Configuration

If an IP address is configured for the VLAN, it is used as the source address of the IGMP snooping querier. If there are multiple IP addresses, the minimum IP address defined on the VLAN is used.

Command Mode

Global Configuration mode

User Guidelines

If an IP address is not configured by this command, and no IP address is configured for the querier's VLAN, the querier is disabled.

Example

```
switchxxxxxx(config)# ip igmp snooping vlan 1 querier address  
10.5.234.205
```

31.11 ip igmp snooping vlan querier version

Use the **ip igmp snooping vlan querier version** Global Configuration mode command to configure the IGMP version of an IGMP querier on a specific VLAN. Use the **no** form of this command to return to the default version.

Syntax

ip igmp snooping vlan *vlan-id* **querier version** {2 | 3}

no ip igmp snooping vlan *vlan-id* **querier version**

Parameters

- **vlan** *vlan-id*—Specifies the VLAN.
- **querier version** 2—Specifies that the IGMP version would be IGMPv2.

- **querier version 3**—Specifies that the IGMP version would be IGMPv3.

Default Configuration

IGMPv2.

Command Mode

Global Configuration mode

Example

```
switchxxxxxx(config)# ip igmp snooping vlan 1 querier version 3
```

31.12 ip igmp robustness

Use the **ip igmp robustness** Interface Configuration (VLAN) mode command to set the IGMP robustness variable on a VLAN. Use the **no** format of the command to return to default.

Syntax

ip igmp robustness *count*

no ip igmp robustness

Parameters

count—The number of expected packet loss on a link. Parameter range. (Range: 1–7)

Default Configuration

2

Command Mode

Interface Configuration (VLAN) mode

User Guidelines

You can execute the command before the VLAN is created, but you must enter the command in Interface VLAN mode.

Example

```
switchxxxxxx(config)# interface vlan 1  
switchxxxxxx(config-if)# ip igmp robustness 3
```

31.13 ip igmp query-interval

Use the **ip igmp query-interval** Interface Configuration (VLAN) mode command to configure the Query interval on a VLAN. Use the **no** format of the command to return to default.

Syntax

ip igmp query-interval *seconds*

no ip igmp query-interval

Parameters

seconds—Frequency, in seconds, at which IGMP query messages are sent on the interface. (Range: 30–18000)

Default Configuration

125

Command Mode

Interface Configuration (VLAN) mode

User Guidelines

You can execute the command before the VLAN is created.

Example

```
switchxxxxxx(config)# interface vlan 1
switchxxxxxx(config-if)# ip igmp query-interval 200
```

31.14 ip igmp query-max-response-time

Use the **ip igmp query-max-response-time** Interface Configuration (VLAN) mode command to configure the Query Maximum Response time on a VLAN. Use the **no** format of the command to return to default.

Syntax

ip igmp query-max-response-time *seconds*

no ip igmp query-max-response-time

Parameters

seconds—Maximum response time, in seconds, advertised in IGMP queries. (Range: 5–20)

Default Configuration

10

Command Mode

Interface Configuration (VLAN) mode

User Guidelines

You can execute the command before the VLAN is created.

Example

```
switchxxxxxx(config)# interface vlan 1
switchxxxxxx(config-if)# ip igmp query-max-response-time 20
```

31.15 ip igmp last-member-query-count

Use the **ip igmp last-member-query-count** Interface Configuration (VLAN) mode command to configure the Last Member Query Counter on a VLAN. Use the **no** format of the command to return to default.

Syntax

ip igmp last-member-query-count *count*

no ip igmp last-member-query-count

Parameter

count—The number of times that group- or group-source-specific queries are sent upon receipt of a message indicating a leave. (Range: 1–7)

Default Configuration

A value of Robustness variable

Command Mode

Interface Configuration (VLAN) mode

User Guidelines

You can execute the command before the VLAN is created.

Example

```
switchxxxxxx(config)# interface vlan 1  
switchxxxxxx(config-if)# ip igmp last-member-query-count 7
```

31.16 ip igmp last-member-query-interval

Use the **ip igmp last-member-query-interval** Interface Configuration (VLAN) mode command to configure the Last Member Query interval on a VLAN. Use the **no** format of the command to return to default.

Syntax

ip igmp last-member-query-interval *milliseconds*

no ip igmp last-member-query-interval

Parameters

milliseconds—Interval, in milliseconds, at which IGMP group-specific host query messages are sent on the interface. (Range: 100–25500)

Default Configuration

1000

Command Mode

Interface Configuration (VLAN) mode

User Guidelines

You can execute the command before the VLAN is created.

Example

```
switchxxxxxx(config)# interface vlan 1
switchxxxxxx(config-if)# ip igmp last-member-query-interval 2000
```

31.17 ip igmp snooping vlan immediate-leave

Use the **ip igmp snooping vlan immediate-leave** Global Configuration mode command to enable the IGMP Snooping Immediate-Leave processing on a VLAN. Use the **no** format of the command to disable IGMP Snooping Immediate-Leave processing.

Syntax

ip igmp snooping vlan *vlan-id* **immediate-leave**

no ip igmp snooping vlan *vlan-id* **immediate-leave**

Parameters

vlan *vlan-id*—Specifies the VLAN ID value. (Range: 1–4094)

Default Configuration

Disabled

Command Mode

Global Configuration mode

User Guidelines

You can execute the command before the VLAN is created.

Example

The following example enables IGMP snooping immediate-leave feature on VLAN 1.

```
switchxxxxxx(config)# ip igmp snooping vlan 1 immediate-leave
```

31.18 show ip igmp snooping mrouter

The **show ip igmp snooping mrouter** EXEC mode command displays information on dynamically learned Multicast router interfaces for all VLANs or for a specific VLAN.

Syntax

show ip igmp snooping mrouter [**interface** *vlan-id*]

Parameters

interface *vlan-id*—Specifies the VLAN ID.

Command Mode

EXEC mode

Example

The following example displays information on dynamically learned Multicast router interfaces for VLAN 1000.

```
switchxxxxxx# show ip igmp snooping mrouter interface
1000
```

VLAN	Dynamic	Static	Forbidden
----	-----	-----	-----
1000	fe1/0/11	fe1/0/12	fe1/0/13-23

31.19 show ip igmp snooping interface

The **show ip igmp snooping interface** EXEC mode command displays the IGMP snooping configuration for a specific VLAN.

Syntax

show ip igmp snooping interface *vlan-id*

Parameters

interface *vlan-id*—Specifies the VLAN ID.

Command Mode

EXEC mode

Example

The following example displays the IGMP snooping configuration for VLAN 1000

```
switchxxxxxx# show ip igmp snooping interface 1000
IGMP Snooping is globally enabled
IGMP Snooping admin: Enabled
IGMP Snooping oper: Enabled
Routers IGMP version: 3
Groups that are in IGMP version 2 compatibility mode:
231.2.2.3, 231.2.2.3
Groups that are in IGMP version 1 compatibility mode:
IGMP snooping querier admin: Enabled
IGMP snooping querier oper: Enabled
IGMP snooping querier address admin:
IGMP snooping querier address oper: 172.16.1.1
IGMP snooping querier version admin: 3
IGMP snooping robustness: admin 2 oper 2
IGMP snooping query interval: admin 125 sec oper 125 sec
```

```
IGMP snooping query maximum response: admin 10 sec oper 10 sec
IGMP snooping last member query counter: admin 2 oper 2
IGMP snooping last member query interval: admin 1000 msec oper 500 msec
IGMP snooping last immediate leave: enable
Automatic learning of Multicast router ports is enabled
```

31.20 show ip igmp snooping groups

The **show ip igmp snooping groups** EXEC mode command displays the Multicast groups learned by the IGMP snooping.

Syntax

show ip igmp snooping groups [vlan *vlan-id*] [address *ip-multicast-address*] [source *ip-address*]

Parameters

vlan *vlan-id*—Specifies the VLAN ID.

address *ip-multicast-address*—Specifies the IP multicast address.

source *ip-address*—Specifies the IP source address.

Command Mode

EXEC mode

User Guidelines

To see all Multicast groups learned by IGMP snooping, use the **show ip igmp snooping groups** command without parameters.

Use the **show ip igmp snooping groups** command with parameters to see a needed subset of all Multicast groups learned by IGMP snooping

To see the full Multicast address table (including static addresses), use the **show bridge multicast address-table** command.

Example

The following example shows sample output for IGMP version 2.

```
switchxxxxxx# show ip igmp snooping groups
```

Vlan	Group Address	Source Address	Include Ports	Exclude Ports	Comp-Mode
1	239.255.255.250	*	gil		v3

31.21 show ip igmp snooping multicast-tv

The **show ip igmp snooping multicast-tv** EXEC mode command displays the IP addresses associated with Multicast TV VLANs.

Syntax

show ip igmp snooping multicast-tv [vlan *vlan-id*]

Parameters

vlan *vlan-id*—Specifies the VLAN ID.

Command Mode

EXEC mode

Example

The following example displays the IP addresses associated with all Multicast TV VLANs.

```
switchxxxxxx# show ip igmp snooping multicast-tv
VLAN IP Address
----
1000 239.255.0.0
1000 239.255.0.1
1000 239.255.0.2
1000 239.255.0.3
1000 239.255.0.4
1000 239.255.0.5
1000 239.255.0.6
1000 239.255.0.7
```

31.22 show ip igmp snooping cpe vlans

The **show ip igmp snooping cpe vlans** EXEC mode command displays the CPE VLAN to Multicast TV VLAN mappings.

Syntax

show ip igmp snooping cpe vlans [*vlan vlan-id*]

Parameters

vlan *vlan-id* —Specifies the CPE VLAN ID.

Command Mode

EXEC mode

Example

The following example displays the CPE VLAN to Multicast TV VLAN mappings.

```
switchxxxxxx# show ip igmp snooping cpe vlans
CPE VLAN  Multicast-TV VLAN
-----
2          1118
3          1119
```

32 IPv6 MLD Snooping Commands

32.1 ipv6 mld snooping (Global)

The **ipv6 mld snooping** Global Configuration mode command enables IPv6 Multicast Listener Discovery (MLD) snooping. To disable IPv6 MLD snooping, use the **no** form of this command.

Syntax

ipv6 mld snooping
no ipv6 mld snooping

Parameters

N/A

Default Configuration

IPv6 MLD snooping is disabled.

Command Mode

Global Configuration mode

Example

The following example enables IPv6 MLD snooping.

```
switchxxxxxx(config)# ipv6 mld snooping
```

32.2 ipv6 mld snooping vlan

Use the **ipv6 mld snooping vlan** Global Configuration mode command to enable MLD snooping on a specific VLAN. Use the **no** form of this command to disable MLD snooping on a VLAN interface.

Syntax

ipv6 mld snooping vlan *vlan-id*
no ipv6 mld snooping vlan *vlan-id*

Parameters

vlan-id—Specifies the VLAN.

Default Configuration

Disabled

Command Mode

Global Configuration mode

User Guidelines

MLD snooping can only be enabled on static VLANs.

MLDv1 and MLDv2 are supported.

To activate MLD snooping, the Bridge Multicast Filtering command must be enabled.

The user guidelines of the [bridge multicast ipv6 mode](#) Interface VLAN Configuration command describe the configuration that can be written into the FDB as a function of the FDB mode, and the MLD version that is used in the network.

Example

```
switchxxxxxx(config)# ipv6 mld snooping vlan 2
```

32.3 ipv6 mld robustness

Use the **ipv6 mld robustness** interface Configuration mode command to change a value of MLD robustness. Use the **no** format of the command to return to default.

Syntax

ipv6 mld robustness *count*

no ipv6 mld robustness

Parameters

count - The number of expected packet losses on a link. (Range: 1–7)

Default Configuration

2

Command Mode

Interface Configuration (VLAN) mode

User Guidelines

You can execute the command before the VLAN is created.

Example

```
switchxxxxxx(config)# interface vlan 1  
switchxxxxxx(config-if)# ipv6 mld robustness 3
```

32.4 ipv6 mld snooping mrouter

Use the **ipv6 mld snooping mrouter** Global Configuration mode command to enable automatic learning of Multicast router ports. Use the **no** form of this command to remove the configuration.

Syntax

ipv6 mld snooping vlan *vlan-id* **mrouter learn** *pim-dvmrp*

no ipv6 mld snooping vlan *vlan-id* **mrouter learn** *pim-dvmrp*

Parameters

- **vlan-id**—Specifies the VLAN.

- **pim-dvmrp**—Learn Multicast router port by PIM, DVMRP and MLD messages.

Default Configuration

Learning **pim-dvmrp** is enabled.

Command Mode

Global Configuration mode

User Guidelines

Multicast router ports can be configured statically with the [bridge multicast forward-all](#) command.

You can execute the command before the VLAN is created.

Example

```
switchxxxxxx(config)# ipv6 mld snooping vlan 1 mrouter learn pim-dvmrp
```

32.5 ipv6 mld snooping mrouter interface

Use the **ipv6 mld snooping mrouter interface** Global Configuration mode command to define a port that is connected to a Multicast router port. Use the **no** form of this command to remove the configuration.

Syntax

ipv6 mld snooping *vlan* *vlan-id* mrouter interface *interface-list*

no ipv6 mld snooping *vlan* *vlan-id* mrouter interface *interface-list*

Parameters

- **vlan-id**—Specifies the VLAN.
- **interface-list**—Specifies a list of interfaces. The interfaces can be from one of the following types: port or port-channel.

Default Configuration

No ports defined

Command Mode

Global Configuration mode

User Guidelines

This command may be used in conjunction with the [bridge multicast forward-all](#) command, which is used in older versions to statically configure a port as a Multicast router.

A port that is defined as a Multicast router port receives all MLD packets (reports and queries) as well as all Multicast data.

You can execute the command before the VLAN is created.

Example

```
switchxxxxxx(config)# ipv6 mld snooping vlan 1 mrouter interface  
fe1/0/11
```

32.6 ipv6 mld snooping forbidden mrouter interface

Use the **ipv6 mld snooping forbidden mrouter interface** Global Configuration mode command to forbid a port from being defined as a Multicast router port by static configuration or by automatic learning. Use the **no** form of this command to remove the configuration.

Syntax

ipv6 mld snooping *vlan* *vlan-id* **forbidden mrouter** *interface* *interface-list*

no ipv6 mld snooping *vlan* *vlan-id* **forbidden mrouter** *interface* *interface-list*

Parameters

- **vlan-id**—Specifies the VLAN.
- **interface-list**—Specifies list of interfaces. The interfaces can be from one of the following types: Ethernet port or Port-channel.

Default Configuration

No forbidden ports by default

Command Mode

Global Configuration mode

User Guidelines

A port that is forbidden to be defined as a Multicast router port (mrouter port) cannot be learned dynamically or assigned statically.

The [bridge multicast forbidden forward-all](#) command was used in older versions to forbid dynamic learning of Multicast router ports.

You can execute the command before the VLAN is created.

Example

```
switchxxxxxx(config)# ipv6 mld snooping vlan 1 forbidden mrouter  
interface fe1/0/11
```

32.7 ipv6 mld snooping static

Use the **ipv6 mld snooping static** Global Configuration mode command to register a IPv6-layer Multicast address to the bridge table, and to add statically ports to the group. Use the **no** form of this command to remove ports specified as members of a static Multicast group.

Syntax

ipv6 mld snooping *vlan* *vlan-id* **static** *ipv6-address* *interface* [*interface-list*]

no ipv6 mld snooping *vlan* *vlan-id* **static** *ipv6-address* *interface* [*interface-list*]

Parameters

- **vlan-id**—Specifies the VLAN.
- **ipv6-address**—Specifies the IP multicast address

- **interface-list**—Specifies list of interfaces. The interfaces can be from one of the following types: Ethernet port or Port-channel.

Default Configuration

No Multicast addresses are defined.

Command Mode

Global configuration mode

User Guidelines

Static multicast addresses can only be defined on static VLANs.

You can execute the command before the VLAN is created.

You can register an entry without specifying an interface.

Using the **no** command without a port-list removes the entry.

Example

```
switchxxxxxx(config)# ipv6 mld snooping vlan 1 static 239.2.2.2 fe1/0/11
```

32.8 ipv6 mld query-interval

Use the **ipv6 mld query-interval** Interface Configuration mode command to configure the Query interval. Use the **no** format of the command to return to default.

Syntax

ipv6 mld query-interval *seconds*

ipv6 mld query-interval

Parameters

seconds—Frequency, in seconds, at which MLD query messages are sent on the interface. (Range: 30–18000)

Default Configuration

125

Command Mode

Interface Configuration (VLAN) mode

User Guidelines

This command provides the frequency value if this value is not received in [MLD general query messages](#). A field for this value is present in [MLDv2 general query messages](#), but this field may be blank. There is no field for this value in [MLDv1 general query messages](#).

Example

```
switchxxxxxx(config)# interface vlan 1  
switchxxxxxx(config-if)# ipv6 mld query-interval 3000
```

32.9 ipv6 mld query-max-response-time

Use the **ipv6 mld query-max-response-time** Interface Configuration mode command to configure the Query Maximum Response time. Use the **no** format of the command to return to default.

Syntax

ipv6 mld query-max-response-time *seconds*

no ipv6 mld query-max-response-time

Parameter

seconds—Maximum response time, in seconds, advertised in MLD queries. (Range: 5–20)

Default Configuration

10

Command Mode

Interface Configuration (VLAN) mode

User Guidelines

This command provides the maximum response time value if this value is not received in [MLD general query messages](#). A field for this value is present in [MLDv2 general query messages](#), but this field may be blank. There is no field for this value in [MLDv1 general query messages](#).

Example

```
switchxxxxxx(config)# interface vlan 1
switchxxxxxx(config-if)# ipv6 mld query-max-response-time 5
```

32.10 ipv6 mld last-member-query-count

Use the **ipv6 mld last-member-query-count** Interface Configuration mode command to configure the Last Member Query Count. This is the number of Multicast address specific queries sent before the router assumes there are no local listeners. The Last Listener Query Count is also the number of Multicast Address and Source Specific Queries sent before the router assumes there are no listeners for a particular source.

Use the **no** format of the command to return to default.

Syntax

ipv6 mld last-member-query-count *count*

no ipv6 mld last-member-query-count

Parameters

count—The number of times that group- or group-source-specific queries are sent upon receipt of a Leave message. (Range: 1–7)

Default Configuration

The value of the Robustness variable.

Command Mode

Interface Configuration (VLAN) mode

User Guidelines

This command provides this value if it is not received in [MLD general query messages](#). A field for this value is present in [MLDv2 general query messages](#), but this field may be blank. There is no field for this value in [MLDv1 general query messages](#).

Example

```
switchxxxxxx(config)# interface vlan 1
switchxxxxxx(config-if)# ipv6 mld last-member-query-count 3
```

32.11 ipv6 mld last-member-query-interval

Use the **ipv6 mld last-member-query-interval** interface configuration command to configure the Last Member Query Interval. Use the **no** format of the command to return to default.

Syntax**ipv6 mld last-member-query-interval** *milliseconds***no ipv6 mld last-member-query-interval****Parameter**

milliseconds—Interval, in milliseconds, at which MLD group-specific host query messages are sent on the interface. (Range: 100–64512).

Default Configuration

1000

Command Mode

Interface Configuration (VLAN) mode

User Guidelines

This command provides this value if it is not received in [MLD general query messages](#). A field for this value is present in [MLDv2 general query messages](#), but this field may be blank. There is no field for this value in [MLDv1 general query messages](#).

Example

```
switchxxxxxx(config)# interface vlan 1
switchxxxxxx(config-if)# ipv6 mld last-member-query-interval 2000
```

32.12 ipv6 mld snooping vlan immediate-leave

Use the **ipv6 mld snooping vlan immediate-leave** Global Configuration mode command to enable MLD Snooping Immediate-Leave processing on a VLAN. When an MLD Leave Group message is received from a host, the system removes the host port from the table entry. After it relays the MLD

queries from the Multicast router, it deletes entries periodically if it does not receive any MLD membership reports from the Multicast clients.

MLD snooping Immediate-Leave processing allows the switch to remove an interface that sends a leave message from the forwarding table without first sending out MAC-based general queries to the interface.

Use the **no** format of the command to return to disable MLD Snooping Immediate-Leave processing.

Syntax

ipv6 mld snooping vlan *vlan-id* immediate-leave

no ipv6 mld snooping vlan *vlan-id* immediate-leave

Parameters

vlan-id—Specifies the VLAN ID value. (Range: 1–4094)

Default Configuration

Disabled

Command Mode

Global Configuration mode

User Guidelines

You can execute the command before the VLAN is created.

Example

```
switchxxxxxx(config)# ipv6 mld snooping vlan 1 immediate-leave
```

32.13 show ipv6 mld snooping mrouter

The **show ipv6 mld snooping mrouter** EXEC mode command displays information on dynamically learned Multicast router interfaces for all VLANs or for a specific VLAN.

Syntax

show ipv6 mld snooping mrouter [*interface* *vlan-id*]

Parameters

interface *vlan-id*—Specifies the VLAN ID.

Default Configuration

Display information for all VLANs.

Command Mode

EXEC mode

Example

The following example displays information on dynamically learned Multicast router interfaces for VLAN 1000

```
switchxxxxxx# show ipv6 mld snooping mrouter interface 1000
VLAN   Static   Dynamic   Forbidden
----   -
1000   fe1/0/11 fe1/0/12   fe1/0/13-23
```

32.14 show ipv6 mld snooping interface

The **show ipv6 mld snooping interface** EXEC mode command displays the IPv6 MLD snooping configuration for a specific VLAN.

Syntax

show ipv6 mld snooping interface *vlan-id*

Parameters

vlan-id—Specifies the VLAN ID.

Default Configuration

Display information for all VLANs.

Command Mode

EXEC mode

Example

The following example displays the MLD snooping configuration for VLAN 1000.

```
switchxxxxxx# show ipv6 mld snooping interface 1000
MLD Snooping is globally enabled
MLD Snooping admin: Enabled
MLD snooping oper mode: Enabled
Routers MLD version: 2
Groups that are in MLD version 1 compatibility mode:
FF12::3, FF12::8
MLD snooping robustness:admin 2 oper 2
MLD snooping query interval: admin 125 sec oper 125 sec
MLD snooping query maximum response: admin 10 sec oper 10 sec
MLD snooping last member query counter: admin 2 oper 2
MLD snooping last member query interval: admin 1000 msec oper 600 msec
MLD snooping last immediate leave: enable
Automatic learning of multicast router ports is enabled
```

32.15 show ipv6 mld snooping groups

The **show ipv6 mld snooping groups** EXEC mode command displays the multicast groups learned by the MLD snooping.

Syntax

show ipv6 mld snooping groups [*vlan vlan-id*] [*address ipv6-multicast-address*] [*source ipv6-address*]

Parameters

- **vlan vlan-id**—Specifies the VLAN ID.
- **address ipv6-multicast-address**—Specifies the IPv6 multicast address.
- **source ipv6-address**—Specifies the IPv6 source address.

Command Mode

EXEC mode

Default Configuration

Display information for all VLANs and addresses defined on them.

User Guidelines

To see the full multicast address table (including static addresses), use the **show bridge multicast address-table** command.

The Include list contains the ports which are in a forwarding state for this group according to the snooping database. In general, the Exclude list contains the ports which have issued an explicit Exclude for that specific source in a multicast group.

The Reporters That Are Forbidden Statically list contains the list of ports which have asked to receive a multicast flow but were defined as forbidden for that multicast group in a multicast bridge.

Note: Under certain circumstances, the Exclude list may not contain accurate information; for example, in the case when two Exclude reports were received on the same port for the same group but for different sources, the port will not be in the Exclude list but rather in the Include list

Example

The following example shows the output for IPv6 MLD version 2.

```
switchxxxxxxx# show ipv6 mld snooping groups
```

VLAN	Group Address	Source Address	Include Ports	Exclude Ports	Compatibility Mode
1	FF12::3	FE80::201:C9FF:FE40:8001	fe1/0/11		1
1	FF12::3	FE80::201:C9FF:FE40:8002	fe1/0/12		1
19	FF12::8	FE80::201:C9FF:FE40:8003	fe1/0/19		2
19	FF12::8	FE80::201:C9FF:FE40:8004	fe1/0/11		2
19	FF12::8	FE80::201:C9FF:FE40:8005	fe1/0/110- 11	fe1/0/12 fe1/0/13	2



MLD Reporters that are forbidden statically:

VLAN	Group Address	Source Address	Ports
1	FF12::3	FE80::201:C9FF:FE40:8001	fe1/0/18
19	FF12::8	FE80::201:C9FF:FE40:8001	fe1/0/19

33 Link Aggregation Control Protocol (LACP) Commands

33.1 lacp system-priority

Use the **lacp system-priority** Global Configuration mode command to set the system priority. Use the **no** form of this command to restore the default configuration.

Syntax

lacp system-priority *value*

no lacp system-priority

Parameters

value—Specifies the system priority value. (Range: 1–65535)

Default Configuration

The default system priority is 1.

Command Mode

Global Configuration mode

Example

The following example sets the system priority to 120.

```
switchxxxxxx(config)# lacp system-priority 120
```

33.2 lacp port-priority

Use the **lacp port-priority** Interface Configuration (Ethernet) mode command to set the physical port priority. Use the **no** form of this command to restore the default configuration.

Syntax

lacp port-priority *value*

no lacp port-priority

Parameters

value—Specifies the port priority. (Range: 1use the **no** form of this command65535)

Default Configuration

The default port priority is 1.

Command Mode

Interface Configuration (Ethernet) mode

Example

The following example sets the priority of fe1/0/16.

```
switchxxxxxx(config)# interface fe1/0/16
switchxxxxxx(config-if)# lACP port-priority 247
```

33.3 lACP timeout

Use the **lACP timeout** Interface Configuration (Ethernet) mode command to assign an administrative LACP timeout to an interface. Use the **no** form of this command to restore the default configuration.

Syntax

lACP timeout {*long* | *short*}

no lACP timeout

Parameters

- **long**—Specifies the long timeout value.
- **short**—Specifies the short timeout value.

Default Configuration

The default port timeout value is Long.

Command Mode

Interface Configuration (Ethernet) mode

Example

The following example assigns a long administrative LACP timeout to fe1/0/16.

```
switchxxxxxx(config)# interface fe1/0/16
switchxxxxxx(config-if)# lACP timeout long
```

33.4 show lACP

Use the **show lACP** EXEC mode command to display LACP information for all Ethernet ports or for a specific Ethernet port.

Syntax

show lACP *interface-id* [*parameters* | *statistics* | *protocol-state*]

Parameters

- **interface-id** —Specify an interface ID. The interface ID must be an Ethernet port
- **parameters**—Displays parameters only.
- **statistics**—Displays statistics only.
- **protocol-state**—Displays protocol state only.

Command Mode

EXEC mode

Example

The following example displays LACP information for fe1/0/11.

```
switchxxxxxx# show lacp ethernet fe1/0/11
Port fe1/0/11 LACP parameters:
  Actor
    system priority:          1
    system mac addr:         00:00:12:34:56:78
    port Admin key:          30
    port Oper key:           30
    port Oper number:        21
    port Admin priority:     1
    port Oper priority:      1
    port Admin timeout:      LONG
    port Oper timeout:       LONG
    LACP Activity:           ACTIVE
    Aggregation:             AGGREGATABLE
    synchronization:         FALSE
    collecting:               FALSE
    distributing:            FALSE
    expired:                  FALSE
  Partner
    system priority:          0
    system mac addr:         00:00:00:00:00:00
    port Admin key:          0
    port Oper key:           0
    port Oper number:        0
    port Admin priority:     0
    port Oper priority:      0
    port Admin timeout:      LONG
    port Oper timeout:       LONG
    LACP Activity:           PASSIVE
    Aggregation:             AGGREGATABLE
    synchronization:         FALSE
    collecting:               FALSE
    distributing:            FALSE
    expired:                  FALSE
Port fe1/0/11 LACP Statistics:
LACP PDUs sent:              2
LACP PDUs received:         2
Port fe1/0/11 LACP Protocol State:
  LACP State Machines:
    Receive FSM:              Port Disabled State
    Mux FSM:                  Detached State
  Control Variables:
```

```

BEGIN:                FALSE
LACP_Enabled:         TRUE
Ready_N:              FALSE
Selected:             UNSELECTED
Port_moved:           FALSE
NNT:                  FALSE
Port_enabled:         FALSE

```

Timer counters:

```

periodic tx timer:    0
current while timer:  0
wait while timer:    0

```

33.5 show lacp port-channel

Use the **show lacp port-channel** EXEC mode command to display LACP information for a port-channel.

Syntax

show lacp port-channel [*port_channel_number*]

Parameters

port_channel_number—Specifies the port-channel number.

Command Mode

EXEC mode

Example

The following example displays LACP information about port-channel 1.

```
switchxxxxxx# show lacp port-channel 1
```

```
Port-Channel 1:Port Type 1000 Ethernet
```

Actor

```

System          1
Priority:        000285:0E1C00
MAC Address:    29
Admin Key:      29
Oper Key:

```

Partner

```

System          0
Priority:        00:00:00:00:00:00
MAC Address:    14
Oper Key:

```




34 GARP VLAN Registration Protocol (GVRP) Commands

34.1 gvrp enable (Global)

Use the **gvrp enable** Global Configuration mode command to enable the Generic Attribute Registration Protocol (GARP) VLAN Registration Protocol (GVRP) globally. Use the **no** form of this command to disable GVRP on the device.

Syntax

gvrp enable

no gvrp enable

Parameters

N/A

Default Configuration

GVRP is globally disabled.

Command Mode

Global Configuration mode

Example

The following example enables GVRP globally on the device.

```
switchxxxxxx(config)# gvrp enable
```

34.2 gvrp enable (Interface)

Use the **gvrp enable** Interface Configuration (Ethernet, Port-channel) mode command to enable GVRP on an interface. Use the **no** form of this command to disable GVRP on an interface.

Syntax

gvrp enable

no gvrp enable

Default Configuration

GVRP is disabled on all interfaces.

Command Mode

Interface Configuration (Ethernet, Port-channel) mode

User Guidelines

An access port does not dynamically join a VLAN because it is always a member of a single VLAN only. Membership in an untagged VLAN is propagated in the same way as in a tagged VLAN. That is, the PVID must be manually defined as the untagged VLAN ID.

Example

The following example enables GVRP on `fe1/0/16`.

```
switchxxxxxx(config)# interface fe1/0/16
switchxxxxxx(config-if)# gvrp enable
```

34.3 garp timer

Use the **garp timer** Interface Configuration mode command to adjust the values of the join, leave and leaveall timers of GARP applications, such as GVRP. Use the **no** form of this command to restore the default configuration.

Syntax

garp timer {*join* | *leave* | *leaveall*} *timer-value*

no garp timer

Parameters

- The following specify the type of timer. The possible values are:
 - **join**—Specifies the GARP join timer. The timer value for this type of timer specifies the time interval between the two join messages sent by the GARP application.
 - **leave**—Specifies the GARP leave timer. The timer value for this type of timer specifies the time interval for a GARP application to wait for a join message after receiving a leave message for a GARP attribute, before it de-registers the GARP attribute.
 - **leaveall**—Specifies the GARP leaveall timer. The timer value for this type of timer specifies the time interval between leaveall messages for a GARP entity, which prompt other GARP entities to re-register all attribute information on this entity.
- **timer-value**—Specifies the timer value in milliseconds in multiples of 10. (Range: 10–2147483640)

Default Configuration

The following are the default timer values:

- **Join timer**—200 milliseconds
- **Leave timer**—600 milliseconds
- **Leaveall timer**—10000 milliseconds

Command Mode

Interface Configuration (Ethernet, Port-channel) mode

User Guidelines

The **timer-value** must be a multiple of 10.

The following relationship must be maintained between the timers:

- The leave timer value must be greater than or equal to three times the join timer.

- The leave-all timer value must be greater than the leave timer.

Set the same GARP timer values on all Layer 2-connected devices to ensure proper operation of the GARP application.

Example

The following example sets the leave timer for `fe1/0/16` to 900 milliseconds.

```
switchxxxxxx(config)# interface fe1/0/16
switchxxxxxx(config-if)# garp timer leave 900
```

34.4 gvrp vlan-creation-forbid

Use the **gvrp vlan-creation-forbid** Interface Configuration mode command to disable dynamic VLAN creation or modification. Use the **no** form of this command to enable dynamic VLAN creation or modification.

Syntax

gvrp vlan-creation-forbid

no gvrp vlan-creation-forbid

Default Configuration

Enabled.

Command Mode

Interface Configuration (Ethernet, Port-channel) mode

Example

The following example disables dynamic VLAN creation on `fe1/0/13`.

```
switchxxxxxx(config)# interface fe1/0/13
switchxxxxxx(config-if)# gvrp vlan-creation-forbid
```

34.5 gvrp registration-forbid

Use the **gvrp registration-forbid** Interface Configuration mode command to deregister all dynamic VLANs on a port and prevent VLAN creation or registration on the port. Use the **no** form of this command to allow dynamic registration of VLANs on a port.

Syntax

gvrp registration-forbid

no gvrp registration-forbid

Default Configuration

Dynamic registration of VLANs on the port is allowed.

Command Mode

Interface Configuration (Ethernet, Port-channel) mode

Example

The following example forbids dynamic registration of VLANs on `fe1/0/12`.

```
switchxxxxxx(config)# interface fe1/0/12
switchxxxxxx(config-if)# gvrp registration-forbid
```

34.6 clear gvrp statistics

Use the **clear gvrp statistics** Privileged EXEC mode command to clear GVRP statistical information for all interfaces or for a specific interface.

Syntax

clear gvrp statistics [*interface-id*]

Parameters

Interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

Default Configuration

All GVRP statistics are cleared.

Command Mode

Privileged EXEC mode

Example

The following example clears all GVRP statistical information on `fe1/0/15`.

```
switchxxxxxx# clear gvrp statistics fe1/0/15
```

34.7 show gvrp configuration

Use the **show gvrp configuration** EXEC mode command to display GVRP configuration information, including timer values, whether GVRP and dynamic VLAN creation are enabled, and which ports are running GVRP.

Syntax

show gvrp configuration [*interface-id*]

Parameters

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

Default Configuration

All GVRP statistics are displayed.



Command Mode

EXEC mode

Example

The following example displays GVRP configuration.

```
switchxxxxx# show gvrp configuration
GVRP Feature is currently Enabled on the device.
Maximum VLANs: 4094
Port GVRP-Status Regist-      Dynamic      Timers (ms)
          ration      VLAN Creation      Leave   Join   Leave All
-----
fel/0/11  Enabled      Forbidden Disabled      200    600    10000
fel/0/12  Enabled      Normal   Enabled      400    1200   20000
```

34.8 show gvrp statistics

Use the **show gvrp statistics** EXEC mode command to display GVRP statistics for all interfaces or for a specific interface.

Syntax

show gvrp statistics [*interface-id*]

Parameters

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

Default Configuration

All GVRP statistics are displayed.

Command Mode

EXEC mode

Example

The following example displays GVRP statistical information.

```
switchxxxxx# show gvrp statistics
GVRP statistics:
-----
Legend:
rJE :   Join Empty Received      rJIn: Join In Received
rEmp:   Empty Received           rLIn: Leave In Received
rLE :   Leave Empty Received     rLA : Leave All Received
sJE :   Join Empty Sent         sJIn: Join In Sent
sEmp:   Empty Sent              sLIn: Leave In Sent
sLE :   Leave Empty Sent        sLA : Leave All Sent
```

Port	rJE	rJIn	rEmp	rLIn	rLE	rLA	sJE	sJIn	sEmp	sLIn	sLE	sLA
----	----	----	----	----	----	----	----	----	----	----	----	----
fe1/0/11	0	0	0	0	0	0	0	0	0	0	0	0
fe1/0/12	0	0	0	0	0	0	0	0	0	0	0	0
fe1/0/13	0	0	0	0	0	0	0	0	0	0	0	0
fe1/0/14	0	0	0	0	0	0	0	0	0	0	0	0
fe1/0/15	0	0	0	0	0	0	0	0	0	0	0	0
fe1/0/16	0	0	0	0	0	0	0	0	0	0	0	0
fe1/0/17	0	0	0	0	0	0	0	0	0	0	0	0
fe1/0/18	0	0	0	0	0	0	0	0	0	0	0	0

34.9 show gvrp error-statistics

Use the **show gvrp error-statistics** EXEC mode command to display GVRP error statistics for all interfaces or for a specific interface.

Syntax

show gvrp error-statistics [*interface-id*]

Parameters

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

Default Configuration

All GVRP error statistics are displayed.

Command Mode

EXEC mode

Example

The following example displays GVRP error statistics.

```

switchxxxxxx# show gvrp error-statistics
GVRP Error Statistics:
-----
Legend:
  INVPROT  : Invalid Protocol Id
  INVATYP  : Invalid Attribute Type  INVALEN  : Invalid Attribute Length
  INVAVAL  : Invalid Attribute Value INVEVENT: Invalid Event
  Port    INVPROT INVATYP INVAVAL INVALEN INVEVENT
-----
fe1/0/11      0      0      0      0      0
fe1/0/12      0      0      0      0      0
fe1/0/13      0      0      0      0      0
fe1/0/14      0      0      0      0      0
fe1/0/15      0      0      0      0      0
fe1/0/16      0      0      0      0      0
  
```



fe1/0/17	0	0	0	0	0
fe1/0/18	0	0	0	0	0

35 Voice VLAN Commands

Use the **voice vlan id** Global Configuration mode command to statically configure the VLAN identifier of the voice VLAN. The **no** format of the command returns the voice VLAN to the default VLAN (1).

Syntax

voice vlan id *vlan-id*

no voice vlan id

Parameters

vlan id *vlan-id*—Specifies the voice VLAN (range 1-4094).

Default Configuration

VLAN ID 1.

Command Mode

Global Configuration mode

User Guidelines

If the Voice VLAN does not exist, it is created automatically. It will not be removed automatically by the **no** version of this command.

Example

The following example enables VLAN 104 as the voice VLAN on the device.

```
switchxxxxxx(config)# voice vlan id 35
For Auto Voice VLAN, changes in the voice VLAN ID, CoS/802.1p, and/or DSCP
will cause the switch to advertise the administrative voice VLAN as static
voice VLAN which has higher priority than voice VLAN learnt from external
sources.
Are you sure you want to continue? (Y/N) [Y] Y
30-Apr-2011 00:19:36 %VLAN-I-VoiceVlanCreated: Voice Vlan ID 104 was
created.
switchxxxxxx(config)#30-Apr-2011 00:19:51 %VLAN-I-ReceivedFromVSDP: Voice
VLAN updated by VSDP. Voice VLAN-ID 104, VPT 5, DSCP 46
```

35.1 voice vlan oui-table

Use the **voice vlan oui-table** Global Configuration mode command to configure the voice OUI table. Use the **no** form of this command to restore the default configuration.

Syntax

voice vlan oui-table {**add** *mac-address-prefix* | **remove** *mac-address-prefix*} [*text*]

no voice vlan oui-table

Parameters

- **add** *mac-address-prefix*—Adds the specified MAC address prefix to the voice VLAN OUI table (length: 3 bytes).
- **remove** *mac-address-prefix*—Removes the specified MAC prefix address from the voice VLAN OUI table (length: 3 bytes).
- **text**—Adds the specified text as a description of the specified MAC address to the voice VLAN OUI table (length: 1–32 characters).

Default Configuration

The default voice VLAN OUI table is:

OUI	Description
00:e0:bb	3COM Phone
00:03:6b	Cisco Phone
00:e0:75	Veritel Polycom Phone
00:d0:1e	Pingtel Phone
00:01:e3	Siemens AG Phone
00:60:b9	NEC/Philips Phone
00:0f:e2	Huawei-3COM Phone
00:09:6e	Avaya Phone

Command Mode

Global Configuration mode

User Guidelines

The classification of a packet from VoIP equipment/phones is based on the packet's OUI in the source MAC address. OUIs are globally assigned (administered) by the IEEE.

In MAC addresses, the first three bytes contain a manufacturer ID (Organizationally Unique Identifiers (OUI)) and the last three bytes contain a unique station ID.

Since the number of IP phone manufacturers that dominates the market is limited and well known, the known OUI values are configured by default and OUIs can be added/removed by the user when required.

Example

The following example adds an entry to the voice VLAN OUI table.

```
switchxxxxxx(config)# voice vlan oui-table add 00:AA:BB description
experimental
```

35.2 voice vlan cos mode

Use the **voice vlan cos mode** Interface Configuration mode command to select the OUI voice VLAN Class of Service (CoS) mode. Use the **no** form of this command to return to the default.

Syntax

voice vlan cos mode {*src* | *all*}

no voice vlan cos mode

Parameters

- **src**—QoS attributes are applied to packets with OUIs in the source MAC address. See the User Guidelines of [voice vlan oui-table](#).
- **all**—QoS attributes are applied to packets that are classified to the Voice VLAN.

Default Configuration

The default mode is **src**.

Command Mode

Global Configuration mode

Example

The following example applies QoS attributes to voice packets.

```
switchxxxxxx(config)# voice vlan cos mode all
```

35.3 voice vlan cos

Use the **voice vlan cos** Global Configuration mode command to set the OUI Voice VLAN Class of Service (CoS). Use the **no** form of this command to restore the default configuration.

Syntax

voice vlan cos *cos* [*remark*]

no voice vlan cos

Parameters

- **cos** *cos*—Specifies the voice VLAN Class of Service value. (Range: 0–7)
- **remark**—Specifies that the L2 user priority is remarked with the CoS value.

Default Configuration

The default CoS value is 5.

The L2 user priority is not remarked by default.

Command Mode

Global Configuration mode

Example

The following example sets the OUI voice VLAN CoS to 7 and does not do remarking.

```
switchxxxxxx(config)# voice vlan cos 7
```

35.4 voice vlan aging-timeout

Use the **voice vlan aging-timeout** Global Configuration mode command to set the OUI Voice VLAN aging timeout interval. Use the **no** form of this command to restore the default configuration.

Syntax

voice vlan aging-timeout *minutes*

no voice vlan aging-timeout

Parameters

aging-timeout *minutes*—Specifies the voice VLAN aging timeout interval in minutes. (Range: 1–43200).

Default Configuration

1440 minutes

Command Mode

Global Configuration mode

Example

The following example sets the OUI Voice VLAN aging timeout interval to 12 hours.

```
switchxxxxxx(config)# voice vlan aging-timeout 720
```

35.5 voice vlan enable

Use the **voice vlan enable** Interface Configuration (Ethernet, Port-channel) mode command to enable OUI voice VLAN configuration on an interface. Use the **no** form of this command to disable OUI voice VLAN configuration on an interface.

Syntax

voice vlan enable

no voice vlan enable

Default Configuration

Disabled

Command Mode

Interface Configuration (Ethernet, Port-channel) mode

User Guidelines

This command is applicable only if the voice VLAN state is globally configured as OUI voice VLAN (using [voice vlan state](#)).

The port is added to the voice VLAN if a packet with a source MAC address OUI address (defined by [voice vlan oui-table](#)) is trapped on the port. Note: The packet VLAN ID does not have to be the voice VLAN, it can be any VLAN.

The port joins the voice VLAN as a tagged port.

If the time since the last MAC address with a source MAC address OUI address was received on the interface exceeds the timeout limit (configured by [voice vlan aging-timeout](#)), the interface is removed from the voice VLAN.

Example

The following example enables OUI voice VLAN configuration on `fe1/0/12`.

```
switchxxxxxx(config)# interface fe1/0/12
switchxxxxxx(config-if)# voice vlan enable
```

35.6 voice vlan secure

Use the **voice vlan secure** Interface Configuration (Ethernet, Port-channel) mode command to enable the secure mode for the OUI voice VLAN. Use the **no** form of this command to disable the secure mode (see User Guidelines for an explanation of secure mode).

Syntax

voice vlan secure

no voice vlan secure

Default Configuration

Disabled

Command Mode

Interface Configuration (Ethernet, Port-channel) mode

User Guidelines

Secure mode specifies that packets that are classified to the voice VLAN with a source MAC address that is not a OUI address (defined by [voice vlan oui-table](#)) are discarded.

This command is relevant only to ports that were added to the voice VLAN automatically.

Example

The following example enables the secure mode for the OUI Voice VLAN on `fe1/0/18`.

```
switchxxxxxx(config)# interface fe1/0/18
switchxxxxxx(config-if)# voice vlan secure
```

35.7 show voice vlan

Use the **show voice vlan** EXEC mode command to display the voice VLAN status for all interfaces or for a specific interface if the voice VLAN type is OUI.

Syntax

show voice vlan [**type** {*oui* | *auto*}] [*interface-id*]

Parameters

- **type oui**—Common and OUI-voice-VLAN specific parameters are displayed.
- **type auto**—Common and Auto Voice VLAN-specific parameters are displayed.
- **interface-id**—Specifies an Ethernet port ID. Relevant only for the OUI type.

Default Configuration

If the **type** parameter is omitted the current Voice VLAN type is used.

If interface-id parameter is omitted then information about all interfaces is displayed.

Command Mode

EXEC mode

User Guidelines

Using this command without parameters displays the current voice VLAN type parameters and local and agreed voice VLAN settings.

Using this command with the **type** parameter displays the voice VLAN parameters relevant to the type selected. The local and agreed voice VLAN settings are displayed only if this is the current voice VLAN state.

The interface-id parameter is relevant only for the OUI VLAN type.

Examples:

The following examples display the output of this command in various configurations.

Example 1—Displays the **auto** voice VLAN parameters (this is independent of the voice VLAN state actually enabled).

```
switch>show voice vlan type auto
switchxxxxxx#show voice vlan type auto
Best Local Voice VLAN-ID is 5
Best Local VPT is 5 (default)
Best Local DSCP is 46 (default)
Agreed Voice VLAN is received from switch 00:24:01:30:10:00
Agreed Voice VLAN priority is 0 (active static source)
Agreed Voice VLAN-ID is 5
Agreed VPT is 5
Agreed DSCP is 46
Agreed Voice VLAN Last Change is 11-Jul-11 15:52:51
switchxxxxxx#
```

Example 2—Displays the current voice VLAN parameters when the voice VLAN state is auto-enabled.

```
switch>show voice vlan
Administrate Voice VLAN state is auto-enabled
Operational Voice VLAN state is auto-enabled
Best Local Voice VLAN-ID is 5
Best Local VPT is 5 (default)
Best Local DSCP is 46 (default)
Agreed Voice VLAN is received from switch 00:24:01:30:10:00
```

```
Agreed Voice VLAN priority is 0 (active static source)
Agreed Voice VLAN-ID is 5
Agreed VPT is 5
Agreed DSCP is 46
Agreed Voice VLAN Last Change is 11-Jul-11 16:48:13
switchxxxxxx#
```

Example 3—Displays the current voice VLAN parameters when the administrative voice VLAN state is auto-triggered but voice VLAN has not been triggered.

```
switch>show voice vlan
Administrate Voice VLAN state is auto-triggered
Operational Voice VLAN state is disabled
VSDP Authentication is disabled
```

Example 4—Displays the current voice VLAN parameters when the administrative voice VLAN state is auto-triggered and it has been triggered.

```
switchxxxxxx(config)#voice vlan state auto-triggered
switchxxxxxx(config)#voice vlan state auto-triggered
operational voice vlan state is auto
admin state is auto triggered
switchxxxxxx#show voice vlan
Administrate Voice VLAN state is auto-triggered
Operational Voice VLAN state is auto-enabled
Best Local Voice VLAN-ID is 5
Best Local VPT is 5 (default)
Best Local DSCP is 46 (default)
Agreed Voice VLAN is received from switch 00:24:01:30:10:00
Agreed Voice VLAN priority is 0 (active static source)
Agreed Voice VLAN-ID is 5
Agreed VPT is 5
Agreed DSCP is 46
Agreed Voice VLAN Last Change is 11-Jul-11 15:52:51
```

Example 5—Displays the current voice VLAN parameters when both auto voice VLAN and OUI are disabled.

```
switch>show voice vlan
switchxxxxxx#show voice vlan
Administrate Voice VLAN state is disabled
Operational Voice VLAN state is disabled
Best Local Voice VLAN-ID is 5
Best Local VPT is 5 (default)
Best Local DSCP is 46 (default)
Aging timeout: 1440 minutes
```

Example 5—Displays the voice VLAN parameters when the voice VLAN operational state is OUI.

```

switch>show voice vlan
Administrate Voice VLAN state is oui-enabled
Operational Voice VLAN state is oui-enabled
Best Local Voice VLAN-ID is 1 (default)
Best Local VPT is 4
Best Local DSCP is 1
Aging timeout: 1440 minutes
CoS: 6
Remark: Yes
OUI table
MAC Address - Prefix      Description
-----
00:E0:BB                  3COM
00:03:6B                  Cisco
00:E0:75                  Veritel
00:D0:1E                  Pingtel
00:01:E3                  Simens
00:60:B9                  NEC/Philips
00:0F:E2                  Huawei-3COM
00:09:6E                  Avaya
Interface      Enabled      Secure      Activated      CoS Mode
-----
gi1             Yes         Yes         Yes            all
gi2             Yes         Yes         No             src
gi3             No          No
...

```

36 Loopback Detection Commands

36.1 loopback-detection enable (Global)

Use the **loopback-detection enable** Global Configuration mode command to enable the Loopback Detection (LBD) feature globally. Use the **no** form of this command to disable the Loopback Detection feature.

Syntax

loopback-detection enable

no loopback-detection enable

Default Configuration

Loopback Detection is disabled.

Command Mode

Global Configuration mode

User Guidelines

This command enables the Loopback Detection feature globally. Use the **loopback-detection enable** Interface Configuration mode command to enable Loopback Detection on an interface.

Example

The following example enables the Loopback Detection feature on the device.

```
Console(config)# loopback-detection enable
```

36.2 loopback-detection enable (Interface)

Use the **loopback-detection enable** Interface Configuration (Ethernet) mode command to enable the Loopback Detection (LBD) feature on an interface. Use the **no** form of this command to disable the Loopback Detection feature on the interface.

Syntax

loopback-detection enable

no loopback-detection enable

Default Configuration

Loopback Detection is disabled on an interface.

Command Mode

Interface Configuration (Ethernet) mode

User Guidelines

This command enables Loopback Detection on an interface. Use the **loopback-detection enable** Global Configuration command to enable Loopback Detection globally.

LBD packets are sent only if the interface spanning tree state is Forwarding.

If the STP mode is MSTP, Loopback Detection can be enabled only on STP-disabled interfaces.

The interface should be a VLAN member of its PVID; otherwise, LBD packets are not trapped by the device.

The interface should be configured with Acceptable-Frame-Type Tagged-Only, otherwise LBD packets are not trapped by the device.

LBD packets are subject to the user's MAC ACLs. Therefore, an LBD packet can be discarded by an explicit deny rule, and by an implicit Deny All rule.

Example

The following example enables the Loopback Detection feature on gigabitethernet port fe1/0/16.

```
Console(config)# interface fe1/0/16
Console(config-if)# loopback-detection enable
```

36.3 loopback-detection mode

Use the **loopback-detection mode** Global Configuration mode command to set the Loopback Detection mode. Use the **no** form of this command to restore the default configuration.

Syntax

loopback-detection mode {*src-mac-addr* | *base-mac-addr*}

no loopback-detection mode

Parameters

- **src-mac-addr**—Specifies that the LBD packet destination MAC address is the source interface MAC address.
- **base-mac-addr**—Specifies that the LBD packet destination MAC address is the device base MAC address.

Default Configuration

Src-mac-addr is the default.

Command Mode

Global Configuration mode

Example

The following example sets the Loopback Detection mode to a **src-mac-addr**.

```
Console(config)# loopback-detection mode src-mac-addr
```

36.4 loopback-detection interval

Use the **loopback-detection interval** Global Configuration mode command to set the time interval between LBD packets. Use the **no** form of this command to restore the default configuration.

Syntax

loopback-detection interval *seconds*

no loopback-detection interval

Parameters

seconds—Specifies the time interval in seconds between LBD packets. (Range: 30–60 seconds)

Default Configuration

The default time interval between LBD packets is 30 seconds.

Command Mode

Global Configuration mode

User Guidelines

This command is not relevant for spanning-tree BPDU handling.

Example

The following example sets the time interval between LBD packets to 45 seconds.

```
Console(config)# loopback-detection interval 45
```

36.5 show loopback-detection

Use the **show loopback-detection** EXEC mode command to display information about Loopback Detection.

Syntax

show loopback-detection [*interface-id*]

Parameters

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

Command Mode

EXEC mode

Example

The following example display information about Loopback Detection.

```
Console# show loopback-detection
```

```
Loopback detection: Enabled
Mode: src-mac-addr
LBD packets interval: 30 Seconds
```

```
Interface      Loopback Detection
-----
fe1/0/11      Enabled
fe1/0/12      Enabled
fe1/0/13      Disabled
fe1/0/14      Disabled
fe1/0/15      Disabled
```

37 DHCP Snooping and ARP Inspection Commands

37.1 ip dhcp snooping

Use the **ip dhcp snooping** Global Configuration mode command to enable Dynamic Host Configuration Protocol (DHCP) Snooping globally. Use the **no** form of this command to restore the default configuration.

Syntax

ip dhcp snooping

no ip dhcp snooping

Default Configuration

DHCP snooping is disabled.

Command Mode

Global Configuration mode

User Guidelines

For any DHCP Snooping configuration to take effect, DHCP Snooping must be enabled globally. DHCP Snooping on a VLAN is not active until DHCP Snooping on a VLAN is enabled by using the **ip dhcp snooping vlan** Global Configuration mode command.

Example

The following example enables DHCP Snooping on the device.

```
Console(config)# ip dhcp snooping
```

37.2 ip dhcp snooping vlan

Use the **ip dhcp snooping vlan** Global Configuration mode command to enable DHCP Snooping on a VLAN. Use the **no** form of this command to disable DHCP Snooping on a VLAN.

Syntax

ip dhcp snooping vlan *vlan-id*

no ip dhcp snooping *vlan-id*

Parameters

vlan-id—Specifies the VLAN ID.

Default Configuration

DHCP Snooping on a VLAN is disabled.

Command Mode

Global Configuration mode

User Guidelines

DHCP Snooping must be enabled globally before enabling DHCP Snooping on a VLAN.

Example

The following example enables DHCP Snooping on VLAN 21.

```
Console(config)# ip dhcp snooping vlan 21
```

37.3 ip dhcp snooping trust

Use the **ip dhcp snooping trust** Interface Configuration (Ethernet, Port-channel) mode command to configure a port as trusted for DHCP snooping purposes. Use the **no** form of this command to restore the default configuration.

Syntax

ip dhcp snooping trust

no ip dhcp snooping trust

Default Configuration

The interface is untrusted.

Command Mode

Interface Configuration (Ethernet, Port-channel) mode

User Guidelines

Configure as trusted the ports that are connected to a DHCP server or to other switches or routers. Configure the ports that are connected to DHCP clients as untrusted.

Example

The following example configures `fe1/0/15` as trusted for DHCP Snooping.

```
Console(config)# interface fe1/0/15
Console(config-if)# ip dhcp snooping trust
```

37.4 ip dhcp snooping information option allowed-untrusted

Use the **ip dhcp snooping information option allowed-untrusted** Global Configuration mode command to allow a device to accept DHCP packets with option-82 information from an untrusted port. Use the **no** form of this command to drop these packets from an untrusted port.

Syntax

ip dhcp snooping information option allowed-untrusted

no ip dhcp snooping information option allowed-untrusted

Default Configuration

DHCP packets with option-82 information from an untrusted port are discarded.

Command Mode

Global Configuration mode

Example

The following example allows a device to accept DHCP packets with option-82 information from an untrusted port.

```
Console(config)# ip dhcp snooping information option allowed-untrusted
```

37.5 ip dhcp snooping verify

Use the **ip dhcp snooping verify** Global Configuration mode command to configure a device to verify that the source MAC address in a DHCP packet received on an untrusted port matches the client hardware address. Use the **no** form of this command to disable MAC address verification in a DHCP packet received on an untrusted port.

Syntax

ip dhcp snooping verify

no ip dhcp snooping verify

Default Configuration

The switch verifies that the source MAC address in a DHCP packet received on an untrusted port matches the client hardware address in the packet.

Command Mode

Global Configuration mode

Example

The following example configures a device to verify that the source MAC address in a DHCP packet received on an untrusted port matches the client hardware address.

```
Console(config)# ip dhcp snooping verify
```

37.6 ip dhcp snooping database

Use the **ip dhcp snooping database** Global Configuration mode command to enable the DHCP Snooping binding database file. Use the **no** form of this command to delete the DHCP Snooping binding database file.

Syntax

ip dhcp snooping database

no ip dhcp snooping database

Default Configuration

The DHCP Snooping binding database file is not defined.

Command Mode

Global Configuration mode

User Guidelines

The DHCP Snooping binding database file resides on Flash.

To ensure that the lease time in the database is accurate, the Simple Network Time Protocol (SNTP) must be enabled and configured.

The device writes binding changes to the binding database file only if the device system clock is synchronized with SNTP.

Example

The following example enables the DHCP Snooping binding database file.

```
Console(config)# ip dhcp snooping database
```

37.7 ip dhcp snooping database update-freq

Use the **ip dhcp snooping database update-freq** Global Configuration mode command to set the update frequency of the DHCP Snooping binding database file. Use the **no** form of this command to restore the default configuration.

Syntax

ip dhcp snooping database update-freq *seconds*

no ip dhcp snooping database update-freq

Parameters

seconds—Specifies the update frequency in seconds. (Range: 600–86400)

Default Configuration

The default update frequency value is 1200 seconds.

Command Mode

Global Configuration mode

Example

The following example sets the DHCP Snooping binding database file update frequency to 1 hour.

```
Console(config)# ip dhcp snooping database update-freq 3600
```

37.8 ip dhcp snooping binding

Use the **ip dhcp snooping binding** Privileged EXEC mode command to configure the DHCP Snooping binding database and add binding entries to the database. Use the **no** form of this command to delete entries from the binding database.

Syntax

ip dhcp snooping binding *mac-address* *vlan-id* *ip-address* *interface-id* **expiry** {*seconds* | *infinite*}
no ip dhcp snooping binding *mac-address* *vlan-id*

Parameters

- **mac-address**— specifies a MAC address.
- **vlan-id**— Specifies a VLAN number.
- **ip-address**— Specifies an IP address.
- **interface-id**— Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.
- **expiry** *seconds*— Specifies the time interval, in seconds, after which the binding entry is no longer valid. (Range: 10–4294967295)
- **expiry** *infinite*— Specifies infinite lease time.

Default Configuration

No static binding exists.

Command Mode

Privileged EXEC mode

User Guidelines

After entering this command, an entry is added to the DHCP Snooping database. If the DHCP Snooping binding file exists, the entry is also added to that file.

The entry is displayed in the show commands as a DHCP Snooping entry.

The user cannot delete dynamic temporary entries for which the IP address is 0.0.0.0.

Example

The following example adds a binding entry to the DHCP Snooping binding database.

```
Console# ip dhcp snooping binding 0060.704C.73FF 23 176.10.1.1 fe1/0/15
expiry 900
```

37.9 clear ip dhcp snooping database

Use the **clear ip dhcp snooping database** Privileged EXEC mode command to clear the DHCP Snooping binding database.

Syntax

clear ip dhcp snooping database

Command Mode

Privileged EXEC mode

Example

The following example clears the DHCP Snooping binding database.

```
Console# clear ip dhcp snooping database
```

37.10 show ip dhcp snooping

Use the **show ip dhcp snooping** EXEC mode command to display the DHCP snooping configuration for all interfaces or for a specific interface.**Syntax****show ip dhcp snooping** [*interface-id*]**Parameters****interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.**Command Mode**

EXEC mode

Example

The following example displays the DHCP snooping configuration.

```
console# show ip dhcp snooping
DHCP snooping is Enabled
DHCP snooping is configured on following VLANs: 21
DHCP snooping database is Enabled
Relay agent Information option 82 is Enabled
Option 82 on untrusted port is allowed
Verification of hwaddr field is Enabled
DHCP snooping file update frequency is configured to: 6666 seconds
```

```
Interface    Trusted
-----
fe1/0/11     Yes
fe1/0/12     Yes
```

37.11 show ip dhcp snooping binding

Use the **show ip dhcp snooping binding** User EXEC mode command to display the DHCP Snooping binding database and configuration information for all interfaces or for a specific interface.

**Syntax**

show ip dhcp snooping binding [*mac-address mac-address*] [*ip-address ip-address*] [*vlan vlan-id*] [*interface-id*]

Parameters

- **mac-address mac-address**—Specifies a MAC address.
- **ip-address ip-address**—Specifies an IP address.
- **vlan vlan-id**—Specifies a VLAN ID.
- **interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

Command Mode

User EXEC mode

Example

The following examples displays the DHCP snooping binding database and configuration information for all interfaces on a device.-

```
Console# show ip dhcp snooping binding
```

```
Update frequency: 1200
Total number of binding: 2
```

Mac Address	IP Address	Lease (sec)	Type	VLAN	Interface
0060.704C.73FF	10.1.8.1	7983	snooping	3	fe1/0/121
0060.704C.7BC1	10.1.8.2	92332	snooping (s)	3	fe1/0/122

37.12 ip source-guard

Use the **ip source-guard** Interface Configuration (Ethernet, Port-channel) mode command to enable IP Source Guard on an interface. Use the **no** form of this command to disable IP Source Guard on an interface.

Syntax

ip source-guard

no ip source-guard

Default Configuration

IP source guard is disabled.

Command Mode

Interface Configuration (Ethernet, Port-channel) mode

User Guidelines

IP Source Guard must be enabled globally before enabling IP Source Guard on an interface.

IP Source Guard is active only on DHCP snooping untrusted interfaces, and if at least one of the interface VLANs are DHCP snooping enabled.

Example

The following example enables IP Source Guard on fe1/0/15.

```
Console(config)# interface fe1/0/15
Console(config-if)# ip source-guard
```

37.13 ip source-guard binding

Use the **ip source-guard binding** Global Configuration mode command to configure the static IP source bindings on the device. Use the **no** form of this command to delete the static bindings.

Syntax

ip source-guard binding *mac-address* *vlan-id* *ip-address* [*interface-id*]

no ip source-guard binding *mac-address* *vlan-id*

Parameters

- **mac-address**—Specifies a MAC address.
- **vlan-id**—Specifies a VLAN number.
- **ip-address**—Specifies an IP address.
- **interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

Default Configuration

No static binding exists.

Command Mode

Global Configuration mode

User Guidelines

The device currently supports filtering that is based only on the source IP address. In future, the device might support filtering mode that is based on the MAC address and IP source address. Currently the MAC address field is an informative field.

Example

The following example configures the static IP source bindings.

```
Console(config)# ip source-guard binding 0060.704C.73FF 23 176.10.1.1
fe1/0/15
```

37.14 ip source-guard tcam retries-freq

Use the **ip source-guard tcam retries-freq** Global Configuration mode command to set the frequency of retries for TCAM resources for inactive IP Source Guard addresses. Use the **no** form of this command to restore the default configuration.

Syntax

ip source-guard tcam retries-freq {seconds | never}

no ip source-guard tcam retries-freq

Parameters

- **seconds**—Specifies the retries frequency in seconds. (Range: 10–600)
- **never**—Disables automatic searching for TCAM resources.

Default Configuration

The default retries frequency is 60 seconds.

Command Mode

Global Configuration mode

User Guidelines

Since the IP Source Guard uses the Ternary Content Addressable Memory (TCAM) resources, there may be situations when IP Source Guard addresses are inactive because of a lack of TCAM resources.

By default, once every minute the software conducts a search for available space in the TCAM for the inactive IP Source Guard addresses. Use this command to change the search frequency or to disable automatic retries for TCAM space.

The **ip source-guard tcam locate** Privileged EXEC mode command manually retries locating TCAM resources for the inactive IP Source Guard addresses.

The **show ip source-guard inactive** EXEC mode command displays the inactive IP Source Guard addresses.

Example

The following example sets the frequency of retries for TCAM resources to 2 minutes.

```
Console(config)# ip source-guard tcam retries-freq 120
```

37.15 ip source-guard tcam locate

Use the **ip source-guard tcam locate** Privileged EXEC mode command to manually retry to locate TCAM resources for inactive IP Source Guard addresses.

Syntax

ip source-guard tcam locate

Command Mode

Privileged EXEC mode

User Guidelines

Since the IP Source Guard uses the Ternary Content Addressable Memory (TCAM) resources, there may be situations when IP Source Guard addresses are inactive because of a lack of TCAM resources.

By default, once every minute the software conducts a search for available space in the TCAM for the inactive IP Source Guard addresses.

Execute the **ip source-guard tcam retries-freq never** Global Configuration mode command to disable automatic retries for TCAM space, and then execute this command to manually retry locating TCAM resources for the inactive IP Source Guard addresses.

The **show ip source-guard inactive** EXEC mode command displays the inactive IP source guard addresses.

Example

The following example manually retries to locate TCAM resources.

```
Console# ip source-guard tcam locate
```

37.16 show ip source-guard configuration

Use the **show ip source-guard configuration** EXEC mode command to display the IP source guard configuration for all interfaces or for a specific interface.

Syntax

show ip source-guard configuration [*interface-id*]

Parameters

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

Command Mode

EXEC mode

Example

The following example displays the IP Source Guard configuration.

```
Console# show ip source-guard configuration
```

```
IP source guard is globally enabled.
```

```
Interface                State
-----                -
fe1/0/121                Enabled
fe1/0/122                Enabled
fe1/0/123                Enabled
fe1/0/124                Enabled
fe1/0/132                Enabled
fe1/0/133                Enabled
fe1/0/134                Enabled
```



37.17 show ip source-guard status

Use the **show ip source-guard status** EXEC mode command to display the IP Source Guard status.

Syntax

show ip source-guard status [*mac-address mac-address*] [*ip-address ip-address*] [*vlan vlan*]
[*interface-id*]

Parameters

- **mac-address mac-address**—Specifies a MAC address.
- **ip-address ip-address**—Specifies an IP address.
- **vlan vlan-id**—Specifies a VLAN ID.
- **interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

Command Mode

EXEC mode

Example

The following examples display the IP Source Guard status.

```
Console# show ip source-guard status
```

```
IP source guard is globally disabled.
```

```
Console# show ip source-guard status
```

Interface	Filter	Status	IP Address	MAC Address	VLAN	Type
fe1/0/12	IP	Active	10.1.8.1	0060.704C.73FF	3	DHCP
1	IP	Active	10.1.8.2	0060.704C.7BC1	3	DHCP
fe1/0/12	IP	Active	10.1.12.2	0060.704C.7BC3	4	DHCP
2	IP	Active	Deny all			
fe1/0/12	IP	Active	10.1.8.218	0060.704C.7BAC	3	Static
3	IP	Inactive	10.1.8.32	0060.704C.83FF	3	DHCP
fe1/0/12	IP	Inactive				
4	IP	Inactive				
fe1/0/12	IP	Inactive				
5						
fe1/0/13						
2						
fe1/0/13						
3						
fe1/0/13						
4						
fe1/0/13						
5						

37.18 show ip source-guard inactive

Use the **show ip source-guard inactive** EXEC mode command to display the IP Source Guard inactive addresses.

Syntax

show ip source-guard inactive

Command Mode

EXEC mode

User Guidelines

Since the IP Source Guard uses the Ternary Content Addressable Memory (TCAM) resources, there may be situations when IP Source Guard addresses are inactive because of a lack of TCAM resources.

By default, once every minute the software conducts a search for available space in the TCAM for the inactive IP Source Guard addresses.

Use the **ip source-guard tcam retries-freq** Global Configuration mode command to change the retry frequency or to disable automatic retries for TCAM space.

Use the **ip source-guard tcam locate** Privileged EXEC mode command to manually retry locating TCAM resources for the inactive IP Source Guard addresses.

This command displays the inactive IP source guard addresses.

Example

The following example displays the IP source guard inactive addresses.

```
Console# show ip source-guard inactive
```

```
TBD: TCAM resources search frequency: 10 minutes
```

Interface	Filter	IP Address	MAC Address	VLAN	Type	Reason
-----	-----	-----	-----	-----	-----	-----
fe1/0/132	IP	10.1.8.32	0060.704C.8	3	DHCP	Resource
fe1/0/133	IP		3FF			Problem
fe1/0/134	I					Trust port No snooping VLAN

37.19 ip arp inspection

Use the **ip arp inspection** Global Configuration mode command globally to enable Address Resolution Protocol (ARP) inspection. Use the **no** form of this command to disable ARP inspection.

Syntax

ip arp inspection

no ip arp inspection

Default Configuration

ARP inspection is disabled.

Command Mode

Global Configuration mode

User Guidelines

Note that if a port is configured as an untrusted port, then it should also be configured as an untrusted port for DHCP Snooping, or the IP-address-MAC-address binding for this port should be configured statically. Otherwise, hosts that are attached to this port cannot respond to ARPs.

Example

The following example enables ARP inspection on the device.

```
Console(config)# ip arp inspection
```

37.20 ip arp inspection vlan

Use the **ip arp inspection vlan** Global Configuration mode command to enable ARP inspection on a VLAN, based on the DHCP Snooping database. Use the **no** form of this command to disable ARP inspection on a VLAN.

Syntax

ip arp inspection vlan *vlan-id*

no ip arp inspection vlan *vlan-id*

Parameters

vlan-id—Specifies the VLAN ID.

Default Configuration

DHCP Snooping based ARP inspection on a VLAN is disabled.

Command Mode

Global Configuration mode

User Guidelines

This command enables ARP inspection on a VLAN based on the DHCP snooping database. Use the **ip arp inspection list assign** Global Configuration mode command to enable static ARP inspection.

Example

The following example enables DHCP Snooping based ARP inspection on VLAN 23.

```
Console(config)# ip arp inspection vlan 23
```

37.21 ip arp inspection trust

Use the **ip arp inspection trust** Interface Configuration (Ethernet, Port-channel) mode command to configure an interface trust state that determines if incoming Address Resolution Protocol (ARP) packets are inspected. Use the **no** form of this command to restore the default configuration.

Syntax

ip arp inspection trust

no ip arp inspection trust

Default Configuration

The interface is untrusted.

Command Mode

Interface Configuration (Ethernet, Port-channel) mode

User Guidelines

The device does not check ARP packets that are received on the trusted interface; it only forwards the packets.

For untrusted interfaces, the device intercepts all ARP requests and responses. It verifies that the intercepted packets have valid IP-to-MAC address bindings before updating the local cache and before forwarding the packet to the appropriate destination. The device drops invalid packets and logs them in the log buffer according to the logging configuration specified with the **ip arp inspection log-buffer vlan** Global Configuration mode command.

Example

The following example configures `fe1/0/13` as a trusted interface.

```
Console(config)# interface fe1/0/13
Console(config-if)# ip arp inspection trust
```

37.22 ip arp inspection validate

Use the **ip arp inspection validate** Global Configuration mode command to perform specific checks for dynamic Address Resolution Protocol (ARP) inspection. Use the **no** form of this command to restore the default configuration.

Syntax

ip arp inspection validate

no ip arp inspection validate

Default Configuration

ARP inspection validation is disabled.

Command Mode

Global Configuration mode

User Guidelines

The following checks are performed:

- **Source MAC address:** Compares the source MAC address in the Ethernet header against the sender MAC address in the ARP body. This check is performed on both ARP requests and responses.
- **Destination MAC address:** Compares the destination MAC address in the Ethernet header against the target MAC address in the ARP body. This check is performed for ARP responses.
- **IP addresses:** Compares the ARP body for invalid and unexpected IP addresses. Addresses include 0.0.0.0, 255.255.255.255, and all IP multicast addresses.

Example

The following example executes ARP inspection validation.

```
Console(config)# ip arp inspection validate
```

37.23 ip arp inspection list create

Use the **ip arp inspection list create** Global Configuration mode command to create a static ARP binding list and enters the ARP list configuration mode. Use the **no** form of this command to delete the list.

Syntax

ip arp inspection list create *name*

no ip arp inspection list create *name*

Parameters

name—Specifies the static ARP binding list name. (Length: 1–32 characters)

Default Configuration

No static ARP binding list exists.

Command Mode

Global Configuration mode

User Guidelines

Use the **ip arp inspection list assign** command to assign the list to a VLAN.

Example

The following example creates the static ARP binding list 'servers' and enters the ARP list configuration mode.

```
Console(config)# ip arp inspection list create servers
Console(config-ARP-list)#
```

37.24 ip mac

Use the **ip mac** ARP-list Configuration mode command to create a static ARP binding. Use the **no** form of this command to delete a static ARP binding.

Syntax

ip *ip-address* **mac** *mac-address*

no ip *ip-address* **mac** *mac-address*

Parameters

- **ip-address**—Specifies the IP address to be entered to the list.
- **mac-address**—Specifies the MAC address associated with the IP address.

Default Configuration

No static ARP binding is defined.

Command Mode

ARP-list Configuration mode

Example

The following example creates a static ARP binding.

```
Console(config)# ip arp inspection list create servers
Console(config-ARP-list)# ip 172.16.1.1 mac 0060.704C.7321
Console(config-ARP-list)# ip 172.16.1.2 mac 0060.704C.7322
```

37.25 ip arp inspection list assign

Use the **ip arp inspection list assign** Global Configuration mode command to assign a static ARP binding list to a VLAN. Use the **no** form of this command to delete the assignment.

Syntax

ip arp inspection list assign *vlan-id* *name*

no ip arp inspection list assign *vlan-id*

Parameters

- **vlan-id**—Specifies the VLAN ID.
- **name**—Specifies the static ARP binding list name.

Default Configuration

No static ARP binding list assignment exists.

Command Mode

Global Configuration mode

Example

The following example assigns the static ARP binding list Servers to VLAN 37.

```
Console(config)# ip arp inspection list assign 37 servers
```

37.26 ip arp inspection logging interval

Use the **ip arp inspection logging interval** Global Configuration mode command to set the minimum time interval between successive ARP SYSLOG messages. Use the **no** form of this command to restore the default configuration.

Syntax

ip arp inspection logging interval {seconds | *infinite*}

no ip arp inspection logging interval

Parameters

- **seconds**—Specifies the minimum time interval between successive ARP SYSLOG messages. A 0 value means that a system message is immediately generated. (Range: 0–86400)
- **infinite**—Specifies that SYSLOG messages are not generated.

Default Configuration

The default minimum ARP SYSLOG message logging time interval is 5 seconds.

Command Mode

Global Configuration mode

Example

The following example sets the minimum ARP SYSLOG message logging time interval to 60 seconds.

```
Console(config)# ip arp inspection logging interval 60
```

37.27 show ip arp inspection

Use the **show ip arp inspection** EXEC mode command to display the ARP inspection configuration for all interfaces or for a specific interface.

Syntax

show ip arp inspection [*interface-id*]

Parameters

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

Command Mode

EXEC mode

Example

The following example displays the ARP inspection configuration.

```
console# show ip arp inspection
IP ARP inspection is Enabled
IP ARP inspection is configured on following VLANs: 1
Verification of packet header is Enabled
IP ARP inspection logging interval is: 222 seconds

Interface      Trusted
-----
fel/0/11       Yes
fel/0/12       Yes
```

37.28 show ip arp inspection list

Use the **show ip arp inspection list** Privileged EXEC mode command to display the static ARP binding list.

Syntax

show ip arp inspection list

Command Mode

Privileged EXEC mode

Example

The following example displays the static ARP binding list.

```
Console# show ip arp inspection list

List name: servers
Assigned to VLANs: 1,2

IP          ARP
-----
172.16.1.1  0060.704C.7322
172.16.1.2  0060.704C.7322
```

37.29 show ip arp inspection statistics

Use the **show ip arp inspection statistics** EXEC command to display Statistics For The Following Types Of Packets That Have Been Processed By This Feature: Forwarded, Dropped, IP/MAC Validation Failure.

Syntax

show ip arp inspection statistics [*vlan vlan-id*]



Parameters

vlan-id—Specifies VLAN ID.

Command Mode

EXEC mode

User Guidelines

To clear ARP Inspection counters use the **clear ip arp inspection statistics** CLI command. Counters values are kept when disabling the ARP Inspection feature.

Example

```
console# show ip arp inspection statistics
```

Vlan	Forwarded Packets	Dropped Packets	IP/MAC Failures
----	-----	-----	-----
2	1500	100	80

37.30 clear ip arp inspection statistics

Use the **clear ip arp inspection statistics** Privileged EXEC mode command to clear statistics ARP Inspection statistics globally.

Syntax

clear ip arp inspection statistics [*vlan vlan-id*]

Parameters

vlan-id—Specifies VLAN ID

Command Mode

Privileged EXEC mode

Example

```
console# clear ip arp inspection statistics
```

38 IP Addressing Commands

38.1 ip address

Use the **ip address** Interface Configuration (Ethernet, VLAN, Port-channel) mode command to define an IP address for an interface. Use the **no** form of this command to remove an IP address definition.

Syntax

If the product is in router mode (Layer 3).

ip address *ip-address* {*mask* | /*prefix-length*}

no ip address [*ip-address*]

If the product is in switch mode (Layer 2).

ip address *ip-address* {*mask* | /*prefix-length*} [**default-gateway** *ip-address*]

no ip address [*ip-address*]

If the product can only be switch mode (Layer 2) and supports a single IP address:

ip address *ip-address* {*mask* | /*prefix-length*} [**default-gateway** *ip-address*]

no ip address

Parameters

- **ip-address**—Specifies the IP address.
- **mask**—Specifies the network mask of the IP address.
- **prefix-length**—Specifies the number of bits that comprise the IP address prefix. The prefix length must be preceded by a forward slash (/). (Range: 8–30)
- **default-gateway ip-address**—Specifies the default gateway IP address.

Default Configuration

No IP address is defined for interfaces.

Command Mode

Interface Configuration (Ethernet, VLAN, Port-channel) mode. It cannot be configured for a range of interfaces (range context).

User Guidelines

Defining a static IP address on an interface implicitly removes the DHCP client configuration on the interface.

If the device is in router mode, it supports multiple IP addresses:

- The product supports up to IP addresses.
- The IP addresses must be from different IP subnets. When adding an IP address from a subnet that already exists in the list, the new IP address replaces the existing IP address from that subnet.

If the IP address is configured in Interface context, the IP address is bound to the interface in that context.

If a static IP address is already defined, the user must do **no IP address** in the relevant interface context before changing the IP address.

If a dynamic IP address is already defined, the user must do **no ip address** in the relevant interface context before configuring another dynamic IP address.

The Interface context may be a port, LAG or VLAN, depending on support that is defined for the product.

Example

The following example configures VLAN 1 with IP address 131.108.1.27 and subnet mask 255.255.255.0.

```
switchxxxxxx(config)# interface vlan 1
switchxxxxxx(config-if)# ip address 131.108.1.27 255.255.255.0
```

38.2 ip address dhcp

Use the **ip address dhcp** Interface Configuration (Ethernet, VLAN, Port-channel) mode command to acquire an IP address for an Ethernet interface from the Dynamic Host Configuration Protocol (DHCP) server. Use the **no** form of this command to release an acquired IP address.

Syntax

ip address dhcp

no ip address dhcp

Parameters

N/A

Command Mode

Interface Configuration (Ethernet, VLAN, Port-channel) mode. It cannot be configured for a range of interfaces (range context).

User Guidelines

This command enables any interface to dynamically learn its IP address by using the DHCP protocol.

DHCP client configuration on an interface implicitly removes the static IP address configuration on the interface.

If the device is configured to obtain its IP address from a DHCP server, it sends a DHCPDISCOVER message to provide information about itself to the DHCP server on the network.

The **no ip address dhcp** command releases any IP address that was acquired, and sends a DHCPRELEASE message.

Example

The following example acquires an IP address for fe1/0/116 from DHCP.

```
switchxxxxxx(config)# interface fe1/0/116
```

```
switchxxxxxx(config-if) # ip address dhcp
```

38.3 renew dhcp

Use the **renew dhcp** Privileged EXEC mode command to renew an IP address that was acquired from a DHCP server for a specific interface.

Syntax

renew dhcp *{interface-id}* [**force-autoconfig**]

Parameters

- **interface-id**—Only required in routing mode (Layer 3). Specifies an interface ID (Ethernet port, Port-channel or VLAN).
- **force-autoconfig** - If the DHCP server holds a DHCP option 67 record for the assigned IP address, the record overwrites the existing device configuration.

Command Mode

Privileged EXEC mode

User Guidelines

Note the following:

- When the device is in Layer 2 (switch mode), *interface-id* is not required..
- This command does not enable DHCP on an interface. If DHCP is not enabled on the requested interface, the command returns an error message.
- If DHCP is enabled on the interface and an IP address was already acquired, the command tries to renew that IP address.
- If DHCP is enabled on the interface and an IP address has not yet been acquired, the command initiates a DHCP request.

Example

The following example renews an IP address that was acquired from a DHCP server for VLAN 19. This assumes that the device is in Layer 3.

```
switchxxxxxx# renew dhcp vlan 19
```

38.4 ip default-gateway

The **ip default-gateway** Global Configuration mode command defines a default gateway (device). Use the **no** form of this command to restore the default configuration.

Syntax

ip default-gateway *ip-address*

no ip default-gateway

Parameters

ip-address—Specifies the default gateway IP address.

Command Mode

Global Configuration mode

Default Configuration

No default gateway is defined.

Example

The following example defines default gateway 192.168.1.1.

```
switchxxxxxx(config)# ip default-gateway 192.168.1.1
```

38.5 show ip interface

Use the **show ip interface** EXEC mode command to display the usability status of configured IP interfaces.

Syntax

show ip interface *[interface-id]*

Parameters

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port, Port-channel or VLAN.

Default Configuration

All IP addresses.

Command Mode

EXEC mode

Example

The following example displays the configured IP interfaces and their types when the device is in Switch mode.

```
switchxxxxxx# show ip interface
Gateway IP Address   Activity status   Type
-----
10.5.234.254        Active           static
IP Address          I/F             Type             Status
-----
10.5.234.207/24    vlan 1          Static           Valid
```

38.6 arp

Use the **arp** Global Configuration mode command to add a permanent entry to the Address Resolution Protocol (ARP) cache. Use the **no** form of this command to remove an entry from the ARP cache.

Syntax

arp *ip-address mac-address [interface-id]*

no arp *ip-address*

Parameters

- **ip-address**—IP address or IP alias to map to the specified MAC address.
- **mac-address**—MAC address to map to the specified IP address or IP alias.
- **interface-id**—Address pair is added for specified interface that can be Ethernet port, Port-channel or VLAN.

Command Mode

Global Configuration mode

Default Configuration

No permanent entry is defined.

If no interface ID is entered, address pair is relevant to all interfaces.

User Guidelines

The software uses ARP cache entries to translate 32-bit IP addresses into 48-bit hardware (MAC) addresses. Because most hosts support dynamic address resolution, static ARP cache entries generally do not need to be specified.

Example

The following example adds IP address 198.133.219.232 and MAC address 00:00:0c:40:0f:bc to the ARP table.

```
switchxxxxxx(config)# arp 198.133.219.232 00:00:0c:40:0f:bc fe1/0/16
```

38.7 arp timeout (Global)

Use the **arp timeout** Global Configuration mode command to set the time interval during which an entry remains in the ARP cache. Use the **no** form of this command to restore the default configuration.

Syntax

arp timeout *seconds*

no arp timeout

Parameters

seconds—Specifies the time interval (in seconds) during which an entry remains in the ARP cache. (Range: 1–40000000)

Default Configuration

The default ARP timeout is 60000 seconds in Router mode, and 300 seconds in Switch mode.

Command Mode

Global Configuration mode

Example

The following example configures the ARP timeout to 12000 seconds.

```
switchxxxxxx(config)# arp timeout 12000
```

38.8 arp timeout

Use the **arp timeout** inInterface Configuration command to configure how long an entry remains in the ARP cache for specific interface. Use the **no** form of this command restore the default value.

Syntax

arp timeout *seconds*

no arp timeout

Parameters

seconds—Time (in seconds) that an entry remains in the ARP cache. It is recommended not to set it to less than 3600. (Range: 1–40000000)

Default

Defined by the **arp timeout** Global Configuration command

Command Mode

Interface Configuration (Ethernet, VLAN, Port-channel) mode. It cannot be configured for a range of interfaces (range context).

User Guidelines

This configuration can be applied only if at least one IP address is defined on specific interface.

Example

```
switchxxxxxx (config)# interface vlan 1  
switchxxxxxx(config-if)# arp timeout 12000
```

38.9 ip arp proxy disable

Use the **ip arp proxy disable** Global Configuration mode command to globally disable proxy Address Resolution Protocol (ARP). Use the **no** form of this command reenable proxy ARP.

Syntax

ip arp proxy disable

no ip arp proxy disable

Parameters

N/A

Default

Enabled by default.

Command Mode

Global Configuration mode

User Guidelines

This command overrides any proxy ARP interface configuration. **Example**
The following example globally disables ARP proxy when the switch is in router mode.

```
switchxxxxxx(config)# ip arp proxy disable
```

38.10 ip proxy-arp

Use the **ip proxy-arp** Interface Configuration mode command to enable an ARP proxy on specific interfaces. Use the **no** form of this command disable it.

Syntax

ip proxy-arp

no ip proxy-arp

Default Configuration

ARP Proxy is disabled.

Command Mode

Interface Configuration (Ethernet, VLAN, Port-channel) mode. It cannot be configured for a range of interfaces (range context).

User Guidelines

This configuration can be applied only if at least one IP address is defined on a specific interface.

Example

The following example enables ARP proxy when the switch is in router mode.

```
switchxxxxxx(config-if)# ip proxy-arp
```

38.11 clear arp-cache

Use the **clear arp-cache** Privileged EXEC mode command to delete all dynamic entries from the ARP cache.

Syntax

clear arp-cache

Command Mode

Privileged EXEC mode

Example

The following example deletes all dynamic entries from the ARP cache.

```
switchxxxxxx# clear arp-cache
```

38.12 show arp

Use the **show arp** Privileged EXEC mode command to display entries in the ARP table.

Syntax

show arp [*ip-address ip-address*] [*mac-address mac-address*] [*interface-id*]

Parameters

- **ip-address** *ip-address*—Specifies the IP address.
- **mac-address** *mac-address*—Specifies the MAC address.
- **interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.

Command Mode

Privileged EXEC mode

User Guidelines

Since the associated interface of a MAC address can be aged out from the FDB table, the Interface field can be empty.

If an ARP entry is associated with an IP interface that is defined on a port or port-channel, the VLAN field is empty.

Example

The following example displays entries in the ARP table.

```
switchxxxxxx# show arp
ARP timeout: 80000 Seconds

VLAN      Interface  IP Address  HW Address      Status
-----  -
VLAN 1    fe1/0/11   10.7.1.102  00:10:B5:04:DB:4B  Dynamic
VLAN 1    fe1/0/12   10.7.1.135  00:50:22:00:2A:A4  Static
```

38.13 show arp configuration

Use the **show arp configuration** privileged EXEC command to display the global and interface configuration of the ARP protocol.

Syntax**show arp configuration****Parameters**

This command has no arguments or key words.

Command Mode

Privileged EXEC mode

Example

```
switchxxxxxx# show arp configuration
Global configuration:
  ARP Proxy: enabled
  ARP timeout: 80000 Seconds
Interface configuration:
g2:
  ARP Proxy: disabled
  ARP timeout:60000 Seconds
VLAN 1:
  ARP Proxy: enabled
  ARP timeout:70000 Seconds
VLAN 2:
  ARP Proxy: enabled
  ARP timeout:80000 Second (Global)
```

38.14 interface ip

Use the **interface ip** Global Configuration mode command to enter the IP Interface Configuration mode.**Syntax****interface ip-address****Parameters****ip-address**—Specifies one of the IP addresses of the device.**Command Mode**

Global Configuration mode

ExampleThe following example enters the IP interface configuration mode.

```
switchxxxxxx(config)# interface ip 192.168.1.1  
switchxxxxxx(config-ip)#
```

38.15 directed-broadcast

Use the **directed-broadcast** IP Interface Configuration mode command to enable the translation of a directed broadcast to physical broadcasts. Use the **no** form of this command to disable this function.

Syntax

directed-broadcast

no directed-broadcast

Default Configuration

Translation of a directed broadcast to physical broadcasts is disabled. All IP directed broadcasts are dropped.

Command Mode

IP Interface Configuration mode

Example

The following example enables the translation of a directed broadcast to physical broadcasts.

```
switchxxxxxx(config)# interface ip 192.168.1.1  
switchxxxxxx(config-ip)# directed-broadcast
```

38.16 broadcast-address

Use the **broadcast-address** IP Interface Configuration mode command to define a broadcast address for an interface. Use the **no** form of this command to restore the default IP broadcast address.

Syntax

broadcast-address {255.255.255.255 | 0.0.0.0}

no broadcast-address

Parameters

- **255.255.255.255**—Specifies 255.255.255.255 as the broadcast address.
- **0.0.0.0**—Specifies 0.0.0.0 as the broadcast address.

Default Configuration

The default broadcast address is 255.255.255.255.

Command Mode

IP Interface Configuration mode

Example

The following example enables the translation of a directed broadcast to physical broadcasts.

```
switchxxxxxx(config)# interface ip 192.168.1.1  
switchxxxxxx(config-ip)# broadcast-address 255.255.255.255
```

38.17 ip helper-address

Use the **ip helper-address** Global Configuration mode command to enable the forwarding of UDP Broadcast packets received on an interface to a specific (helper) address. Use the **no** form of this command to disable the forwarding of broadcast packets to a specific (helper) address.

Syntax

ip helper-address {*ip-interface* | *all*} *address* [*udp-port-list*]

no ip helper-address {*ip-interface* | *all*} *address*

Parameters

- **ip-interface**—Specifies the IP interface.
- **all**—Specifies all IP interfaces.
- **address**—Specifies the destination broadcast or host address to which to forward UDP broadcast packets. A value of 0.0.0.0 specifies that UDP broadcast packets are not forwarded to any host.
- **udp-port-list**—Specifies the destination UDP port number to which to forward Broadcast packets. (Range: 1–65535). This can be a list of port numbers separated by spaces.

Default Configuration

Forwarding of UDP Broadcast packets received on an interface to a specific (helper) address is disabled.

If **udp-port-list** is not specified, packets for the default services are forwarded to the helper address.

Command Mode

Global Configuration mode

User Guidelines

This command forwards specific UDP Broadcast packets from one interface to another, by specifying a UDP port number to which UDP broadcast packets with that destination port number are forwarded. By default, if no UDP port number is specified, the device forwards UDP broadcast packets for the following six services:

- IEN-116 Name Service (port 42)
- DNS (port 53)
- NetBIOS Name Server (port 137)
- NetBIOS Datagram Server (port 138)
- TACACS Server (port 49)
- Time Service (port 37)

Many helper addresses may be defined. However, the total number of address-port pairs is limited to 128 for the device.

The setting of a helper address for a specific interface has precedence over the setting of a helper address for all the interfaces.

Forwarding of BOOTP/DHCP (ports 67, 68) cannot be enabled with this command. Use the DHCP relay commands to relay BOOTP/DHCP packets.

Example

The following example enables the forwarding of UDP Broadcast packets received on all interfaces to the UDP ports of a destination IP address and UDP port 1 and 2.

```
switchxxxxxx(config)# ip helper-address all 172.16.9.9 49 53 1 2
```

38.18 show ip helper-address

Use the **show ip helper-address** Privileged EXEC mode command to display the IP helper addresses configuration on the system.

Syntax

show ip helper-address

Parameters

This command has no arguments or key words.

Command Mode

Privileged EXEC mode

Example

The following example displays the IP helper addresses configuration on the system.

```
switchxxxxxx# show ip helper-address
```

Interface	Helper Address	UDP Ports
-----	-----	-----
192.168.1.1	172.16.8.8	37, 42, 49, 53, 137, 138
192.168.2.1	172.16.9.9	37, 49

38.19 source-precedence

Use the **source-precedence** IP Interface Configuration mode command to define a preference for an IP address as a source IP address for DHCP relayed messages on an interface. Use the **no** form of this command to restore the default configuration.

This can be used in Router mode only.

Syntax

source-precedence

no source-precedence

Default Configuration

Source precedence is not defined for the address.

Command Mode

IP Interface Configuration mode

User Guidelines

To use this command, you must put the switch into routing mode using the [set system mode](#) command.

For relayed DHCP messages, the source IP address selected is:

1. The lowest of the IP addresses defined as source-precedence IP addresses.
2. The lowest of the IP addresses if there are no source-precedence IP addresses.

Example

The following example defines a preference for an IP address as a source IP address for DHCP relayed messages on an interface.

```
switchxxxxxx(config-ip) # source-precedence
```

38.20 ip domain lookup

Use the **ip domain lookup** Global Configuration mode command to enable the IP Domain Name System (DNS)-based host name-to-address translation. Use the **no** form of this command to disable DNS-based host name-to-address translation.

Syntax

ip domain lookup

no ip domain lookup

Default Configuration

Enabled.

Command Mode

Global Configuration mode

Example

The following example enables DNS-based host name-to-address translation.

```
switchxxxxxx(config) # ip domain lookup
```

38.21 ip domain name

Use the **ip domain name** Global Configuration mode command to define a default domain name used by the software to complete unqualified host names (names without a dotted-decimal domain name). Use the **no** form of this command to remove the default domain name.

Syntax

ip domain name *name*

no ip domain name

Parameters

name—Specifies the default domain name used to complete unqualified host names. Do not include the initial period that separates an unqualified name from the domain name. (Length: 1–158 characters. Maximum label length of each domain level is 63 characters)

Default Configuration

A default domain name is not defined.

Command Mode

Global Configuration mode

User Guidelines

Domain names and host names are restricted to the ASCII letters A through Z (case-insensitive), the digits 0 through 9, the underscore and the hyphen. A period (.) is used to separate labels.

The maximum size of each domain level is 63 characters. The maximum name size is 158 bytes.

Example

The following example defines the default domain name as 'www.website.com'.

```
switchxxxxxx(config)# ip domain name www.website.com
```

38.22 ip name-server

Use the **ip name-server** Global Configuration mode command to define the available name servers. Use the **no** form of this command to remove a name server.

Syntax

ip name-server [*server1-ip-address*] [*server-address2 ... server-address8*]

no ip name-server [*server-address ... server-address8*]

Parameters

server-address—IP addresses of the name server. Up to 8 servers can be defined in one command or by using multiple commands. The IP address can be an IPv4 address, IPv6 or IPv6z address. See [IPv6z Address Conventions](#).

Default Configuration

No name server IP addresses are defined.

Command Mode

Global Configuration mode

User Guidelines

The preference of the servers is determined by the order in which they were entered.

Up to 8 servers can be defined using one command or using multiple commands.

Example

The following example defines the available name server.

```
switchxxxxxx(config)# ip name-server 176.16.1.18
```

38.23 ip host

Use the **ip host** Global Configuration mode command to define the static host name-to-address mapping in the host cache. Use the **no** form of this command to remove the static host name-to-address mapping.

Syntax

ip host *name address [address2 address3 address4]*

no ip host *name*

Parameters

- **name**—Specifies the host name. (Length: 1–158 characters. Maximum label length of each domain level is 63 characters)
- **address**—Specifies the associated IP address. Up to 4 addresses can be defined separated by blanks.

Default Configuration

No host is defined.

Command Mode

Global Configuration mode

User Guidelines

Host names are restricted to the ASCII letters A through Z (case-insensitive), the digits 0 through 9, the underscore and the hyphen. A period (.) is used to separate labels.

Example

The following example defines a static host name-to-address mapping in the host cache.

```
switchxxxxxx(config)# ip host accounting.website.com 176.10.23.1
```

38.24 clear host

Use the **clear host** Privileged EXEC mode command to delete entries from the host name-to-address cache.

Syntax

clear host *{name | *}*

Parameters

- **name**—Specifies the host entry to remove. (Length: 1–158 characters. Maximum label length: of each domain level is 63 characters)
- *****—Removes all entries.

Command Mode

Privileged EXEC mode

Example

The following example deletes all entries from the host name-to-address cache.

```
switchxxxxxx# clear host *
```

38.25 clear host dhcp

Use the **clear host dhcp** Privileged EXEC mode command to delete entries from the host name-to-address mapping received from the Dynamic Host Configuration Protocol (DHCP) server.

Syntax

clear host dhcp *{name | *}*

Parameters

- **name** —Specifies the host entry to remove. (Length: 1–158 characters. Maximum label length of each domain level is 63 characters)
- *****—Removes all entries.

Command Mode

Privileged EXEC mode

User Guidelines

This command deletes the host name-to-address mapping temporarily until the next refresh of the IP addresses.

Example

The following example deletes all entries from the host name-to-address mapping received from DHCP.

```
switchxxxxxx# clear host dhcp *
```

38.26 show hosts

Use the **show hosts** EXEC mode command to display the default domain name, the list of name server hosts, the static and the cached list of host names and addresses.

Syntax

show hosts *[name]*

Parameters

name—Specifies the host name. (Length: 1–158 characters. Maximum label length of each domain level is 63 characters).

Command Mode

EXEC mode

Example

The following example displays host information.

```

switchxxxxxx# show hosts
System name: Device
Default domain is gm.com, sales.gm.com, usa.sales.gm.com(DHCP)
Name/address lookup is enabled
Name servers (Preference order): 176.16.1.18 176.16.1.19
Configured host name-to-address mapping:

Host                                IP Addresses
-----
accounting.gm.com                   176.16.8.8 176.16.8.9 (DHCP)
                                      2002:0:130F::0A0:1504:0BB4

Cache: TTL (Hours)

Host            Total  Elapsed  Type  IP Addresses
-----
www.stanford.edu 72     3        IP    171.64.14.203

```

39 IPv6 Addressing Commands

39.1 ipv6 enable

Use the **ipv6 enable** Interface Configuration (Ethernet, VLAN, Port-channel) mode command to enable the IPv6 addressing mode on an interface. Use the **no** form of this command to disable the IPv6 addressing mode on an interface.

Syntax

ipv6 enable [*no-autoconfig*]

no ipv6 enable

Parameters

no-autoconfig—Enables processing of IPv6 on an interface without the stateless address autoconfiguration procedure. This procedure assigns link-local addresses.

Default Configuration

IPv6 addressing is disabled.

Unless you are using the **no-autoconfig** parameter, when the interface is enabled, stateless address autoconfiguration procedure is enabled.

Command Mode

Interface Configuration (Ethernet, VLAN, Port-channel) mode. It cannot be configured for a range of interfaces (range context).

User Guidelines

This command automatically configures an IPv6 link-local Unicast address on the interface, while also enabling the interface for IPv6 processing. The **no ipv6 enable** command removes the entire IPv6 interface configuration.

To enable stateless address autoconfiguration on an enabled IPv6 interface, use the [ipv6 address autoconfig](#) command.

Example

The following example enables VLAN 1 for the IPv6 addressing.

```
switchxxxxxx(config)# interface vlan 1
switchxxxxxx(config-if)# ipv6 enable
```

39.2 ipv6 address autoconfig

Use the **ipv6 address autoconfig** Interface Configuration mode command to enable automatic configuration of IPv6 addresses, using stateless autoconfiguration on an interface. Addresses are configured depending on the prefixes received in Router Advertisement messages. Use the **no** form of this command to disable address autoconfiguration on the interface.

Syntax**ipv6 address *autoconfig*****no ipv6 address *autoconfig*****Parameters**

N/A

Default Configuration

Address autoconfiguration is enabled on the interface, no addresses are assigned by default.

Command Mode

Interface Configuration (Ethernet, VLAN, Port-channel) mode.

User Guidelines

When **address autoconfig** is enabled, the router solicitation ND procedure is initiated to discover a router and assign IP addresses to the interface, based on the advertised on-link prefixes.

When disabling address autoconfig, automatically generated addresses that were assigned to the interface are removed.

The default state of the address autoconfig is **enabled**. Use the **ipv6 enable no-autoconfig** command to enable an IPv6 interface without address autoconfig.

Example

```
switchxxxxxx(config)# interface vlan 1
switchxxxxxx(config-if)# ipv6 address autoconfig
```

39.3 ipv6 icmp error-interval

Use the **ipv6 icmp error-interval** Global Configuration mode command to configure the rate limit interval and bucket size parameters for IPv6 Internet Control Message Protocol (ICMP) error messages. Use the **no** form of this command to return the interval to its default setting.

Syntax**ipv6 icmp error-interval *milliseconds [bucketsize]*****no ipv6 icmp error-interval****Parameters**

- **milliseconds**—The time interval between tokens being placed in the bucket. Each token represents a single ICMP error message. The acceptable range is from 0–2147483647 with a default of 100 milliseconds. Setting milliseconds to 0 disables rate limiting. (Range: 0–2147483647)
- **bucketsize**—(Optional) The maximum number of tokens stored in the bucket. The acceptable range is from 1–200 with a default of 10 tokens.

Default Configuration

The default interval is 100ms and the default bucketsize is 10 i.e. 100 ICMP error messages per second.

Command Mode

Global Configuration mode

User Guidelines

To set the average ICMP error rate limit, calculate the interval with the following formula:

Average Packets Per Second = (1/ interval) * bucket size

Example

```
switchxxxxxx(config)# ipv6 icmp error-interval 123 45
```

39.4 show ipv6 icmp error-interval

Use the **show ipv6 error-interval** command in the EXEC mode to display the IPv6 ICMP error interval.

Syntax

show ipv6 icmp error-interval

Parameters

N/A

Default Configuration

N/A

Command Mode

EXEC mode

Example

```
switchxxxxxx# show ipv6 icmp error-interval
Rate limit interval: 100 ms
Bucket size: 10 tokens
```

39.5 ipv6 address

Use the **ipv6 address** Interface Configuration mode command to configure an IPv6 address for an interface. Use the **no** form of this command to remove the address from the interface.

Syntax

ipv6 address *ipv6-address/prefix-length* [**eui-64**] [**anycast**]

no ipv6 address [*ipv6-address/prefix-length*] [**link-local**] [**eui-64**]

Parameters

- **ipv6-address**—Specifies the IPv6 network assigned to the interface. This argument must be in the form documented in RFC 2373 where the address is specified in hexadecimal using 16-bit values between colons.

- **prefix-length**—Specifies the length of the IPv6 prefix. A decimal value that indicates how many of the high-order contiguous bits of the address comprise the prefix (the network portion of the address). A slash mark (/) must precede the decimal.
- **eui-64**—(Optional) Builds an interface ID in the low order 64 bits of the IPv6 address based on the interface MAC address.
- **anycast**—(Optional) Indicates that this address is an anycast address.
- **prefix-length**—3–128(64 when the **eui-64** parameter is used).
- **link-local**—Use the link-local address.

Default Configuration

No IP address is defined for the interface.

Command Mode

Interface configuration (Ethernet, VLAN, Port-channel) mode. It cannot be configured for a range of interfaces (range context).

User Guidelines

If the value specified for the /prefix-length argument is greater than 64 bits, the prefix bits have precedence over the interface ID.

Using the **no IPv6 address** command without arguments removes all manually configured IPv6 addresses from an interface, including link-local manually-configured addresses.

Example

```
switchxxxxxx(config)# interface vlan 1
switchxxxxxx(config-if)# ipv6 address 3000::123/64 eui-64 anycast
```

39.6 ipv6 address link-local

Use the **ipv6 address link-local** command to configure an IPv6 link-local address for an interface. Use the **no** form of this command to return to the default link-local address on the interface.

Syntax

ipv6 address *ipv6-address* /*prefix-length* **link-local**

no ipv6 address [*ipv6-address* /*prefix-length* **link-local**]

Parameters

- **ipv6-address**—Specifies the IPv6 network assigned to the interface. This argument must be in the format documented in RFC 2373, where the address is specified in hexadecimals using 16-bit values between colons.
- **prefix-length**—Specifies the length of the IPv6 prefix. A decimal value indicates how many of the high-order contiguous bits of the address comprise the prefix (the network portion of the address). A slash mark (/) must precede the decimal. Only 64-bit length is supported, according to IPv6 over Ethernet's well-known practice

Default Configuration

IPv6 is enabled on the interface, the link-local address of the interface is FE80::EUI64 (interface MAC address).

Command Mode

Interface Configuration (Ethernet, VLAN, Port-channel) mode. It cannot be configured for a range of interfaces (range context).

User Guidelines

Using the **no ipv6 link-local address** command removes the manually configured link-local IPv6 address from an interface. Multiple IPv6 addresses can be configured per interface, but only one link-local address. When the **no ipv6 link-local address** command is used, the interface is reconfigured with the standard link-local address (the same IPv6 link-local address that is set automatically when the **enable ipv6** command is used). The system automatically generates a link-local address for an interface when IPv6 processing is enabled on the interface. To manually specify a link-local address to be used by an interface, use the **ipv6 link-local address** command. The system supports only 64 bits prefix length for link-local addresses.

Example

```
switchxxxxxx(config)# interface vlan 1
switchxxxxxx(config-if)# ipv6 address fe80::123/64 link-local
```

39.7 ipv6 unreachablees

Use the **ipv6 unreachablees** Interface Configuration mode command to enable the generation of Internet Control Message Protocol for IPv6 (ICMPv6) unreachable messages for any packets arriving on a specified interface. Use the **no** form of this command To prevent the generation of unreachable messages.

Syntax

ipv6 unreachablees

no ipv6 unreachablees

Parameters

N/A

Default Configuration

ICMP unreachable messages are sent by default.

Command Mode

Interface Configuration (Ethernet, VLAN, Port-channel) mode.

User Guidelines

When ICMP unreachable messages are enabled, when receiving a packet addressed to one of the interface's IP address with TCP/UDP port not assigned, the device sends ICMP unreachable messages.

Example

```
switchxxxxxx(config)# interface fe1/0/11
switchxxxxxx(config-if)# ipv6 unreachablees
```

39.8 ipv6 link-local default zone

Use the **ipv6 link-local default zone** Interface command to configure an interface to egress a link-local packet without a specified interface or with the default zone 0. Use the **no** form of this command to return the default link-local interface to the default value.

Syntax

ipv6 link-local default zone *{interface-id}*

no ipv6 link-local default zone

Parameters

interface-id—Specifies the interface that is used as the egress interface for packets sent without a specified IPv6z interface identifier or with the default 0 identifier. The interface ID can be one of the following types: Ethernet port, Port-channel or VLAN.

Default Configuration

By default, **link local default zone** is disabled.

Command Mode

Interface configuration (Ethernet port, Port-channel or VLAN).

Example

```
switchxxxxxxx(config)# ipv6 link-local default zone
```

39.9 ipv6 default-gateway

Use the **ipv6 default-gateway** Global Configuration mode command to define an IPv6 default gateway. Use the **no** form of this command To remove the default gateway.

Syntax

ipv6 default-gateway *ipv6-address*

no ipv6 default-gateway

Parameters

ipv6-address—Specifies the IPv6 address of the next hop that can be used to reach the required network. When the IPv6 address is a link-local address (IPv6Z address), see [IPv6z Address Conventions](#).

Default Configuration

No default gateway is defined.

Command Mode

Global Configuration mode

User Guidelines

Configuring a new default GW without deleting the previous configured information overwrites the previous configuration.

A configured default GW has a higher precedence over an automatically advertised (via router advertisement message).

Precedence takes effect after the configured default GW is reachable.

Reachability state is not verified automatically by the neighbor discovery protocol. Router reachability can be confirmed by either receiving a Router Advertisement message containing the router's MAC address or by manually configuring this using the `ipv6 neighbor` command. Another option to force reachability confirmation is to ping the router link-local address (this will initiate the neighbor discovery process).

If the egress interface is not specified, the default interface is selected. Specifying interface zone=0 is equal to not defining an egress interface.

Example

```
switchxxxxxx(config)# ipv6 default-gateway fe80::abcd
```

39.10 show ipv6 interface

Use the `show ipv6 interface` EXEC command mode to display the usability status of interfaces configured for IPv6.

Syntax

`show ipv6 interface [interface-id]`

Parameters

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port, Port-channel or VLAN.

Default Configuration

Displays all IPv6 interfaces.

Command Mode

EXEC mode

User Guidelines

Use the `show ipv6 neighbors` command in the privileged EXEC mode to display an IPv6 neighbor's discovery cache information.

Examples

Example 1- Show all IPv6 interfaces.

```
switchxxxxxx# show ipv6 interface
```

Interface	IP addresses	Type
VLAN 1	4004::55/64 [ANY]	manual

```

VLAN 1      fe80::200:b0ff:fe00:0      linklayer
VLAN 1      ff02::1                          linklayer
VLAN 1      ff02::77                      manual
VLAN 1      ff02::1:ff00:0              manual
VLAN 1      ff02::1:ff00:1              manual
VLAN 1      ff02::1:ff00:55             manual
Default Gateway IP address      Type      Interface  State
-----
fe80::77                          Static    VLAN 1     unreachable
fe80::200:cff:fe4a:dfa8           Dynamic  VLAN 1     stale

```

Example 2 - Show IPv6 interfaces on VLAN 15 where IPv6 is not enabled.

```

switchxxxxx# show ipv6 interface Vlan 15
IPv6 is disabled

```

Example 3 - Show IPv6 interfaces on VLAN 15 where it is enabled.

```

switchxxxxx# show ipv6 interface Vlan 1
Number of ND DAD attempts: 1
MTU size: 1500
Stateless Address Autoconfiguration state: enabled
ICMP unreachable message state: enabled
MLD version: 2
IP addresses                                Type      DAD State
-----
4004::55/64 [ANY]                          manual    Active
fe80::200:b0ff:fe00:0                       linklayer Active
ff02::1                                      linklayer -----
ff02::77                                    manual    -----
ff02::1:ff00:0                              manual    -----
ff02::1:ff00:1                              manual    -----
ff02::1:ff00:55                             manual    -----

```

39.11 show IPv6 route

Use the **show ipv6 route** Exec mode command to display the current state of the IPv6 routing table.

Syntax

show ipv6 route

Parameters

N/A



Default Configuration

N/A

Command Mode

EXEC mode

Example

```
switchxxxxxx# show ipv6 route
Codes: L - Local, S - Static, I - ICMP, ND - Router Advertisement
The number in the brackets is the metric.
S ::/0 via fe80::77 [0] VLAN 1 Lifetime Infinite
ND ::/0 via fe80::200:cff:fe4a:dfa8 [0] VLAN 1 Lifetime 1784 sec
L 2001::/64 is directly connected, g2 Lifetime Infinite
L 2002:1:1:1::/64 is directly connected, VLAN 1 Lifetime 2147467 sec
L 3001::/64 is directly connected, VLAN 1 Lifetime Infinite
L 4004::/64 is directly connected, VLAN 1 Lifetime Infinite
L 6001::/64 is directly connected, g2 Lifetime Infinite
```

39.12 show ipv6 link-local default zone

Use the **show ipv6 link-local default zone** command in the EXEC mode to display the IPv6 link-local default zone.

Syntax

show ipv6 link-local default zone

Parameters

N/A

Default Configuration

N/A

Command Mode

EXEC mode

Example

```
switchxxxxxx# show ipv6 link-local default zone
Link Local Default Zone is defined on interface g1
```

```
switchxxxxxx# show ipv6 link-local default zone
Link Local Default Zone is not defined
```

39.13 ipv6 nd dad attempts

Use the **ipv6 nd dad attempts** Interface Configuration (Ethernet, VLAN, Port-channel) mode command to configure the number of consecutive neighbor solicitation messages that are sent on an interface while Duplicate Address Detection (DAD) is performed on the unicast IPv6 addresses of the interface. Use the **no** form of this command to restore the number of messages to the default value.

Syntax

ipv6 nd dad attempts *attempts*

Parameters

attempts—Specifies the number of neighbor solicitation messages. A value of 0 disables DAD processing on the specified interface. A value of 1 configures a single transmission without follow-up transmissions. (Range: 0–600)

Default Configuration

DAD on Unicast IPv6 addresses with the sending of one neighbor solicitation message is enabled.

Command Mode

Interface Configuration (Ethernet, VLAN, Port-channel) mode. It cannot be configured for a range of interfaces (range context).

User Guidelines

DAD verifies the uniqueness of new Unicast IPv6 addresses before the addresses are assigned to interfaces (the new addresses remain in a tentative state while DAD is performed). DAD uses neighbor solicitation messages to verify the uniqueness of unicast IPv6 addresses.

An interface returning to the administrative Up state restarts DAD for all Unicast IPv6 addresses on the interface. While DAD is performed on the link-local address of an interface, the state of the other IPv6 addresses is still set to TENTATIVE. When DAD is completed on the link-local address, DAD is performed on the remaining IPv6 addresses.

When DAD identifies a duplicate address, the address state is set to DUPLICATE and the address is not used. If the duplicate address is the link-local address of the interface, the processing of IPv6 packets is disabled on the interface and an error message is displayed.

All configuration commands associated with the duplicate address remain as configured, while the address state is set to DUPLICATE.

If the link-local address for an interface changes, DAD is performed on the new link-local address and all of the other IPv6 address associated with the interface are regenerated (DAD is performed only on the new link-local address).

Configuring a value of 0 with this command disables duplicate address detection processing on the specified interface. A value of 1 configures a single transmission without follow-up transmissions. The default is 1 message.

Until the DAD process is completed, an IPv6 address is in the tentative state and cannot be used for data transfer. It is recommended to limit the configured value.

Example

The following example configures the number of consecutive neighbor solicitation messages sent during DAD processing to 2 on fe1/0/19.

```
switchxxxxxx (config)# interface fe1/0/19
switchxxxxxx (config-if)# ipv6 nd dad attempts 2
```

39.14 ipv6 host

Use the **ipv6 host** Global Configuration mode command to define a static host name-to-address mapping in the host name cache. Use the **no** form of this command to remove the host name-to-address mapping.

Syntax

ipv6 host *name ipv6-address1 [ipv6-address2...ipv6-address4]*

no ipv6 host *name*

Parameters

host name - Name of the host. (Range: 1–158 characters)

- **ipv6-address1**—Associated IPv6 address. This argument must be in the form documented in RFC 2373 where the address is specified in hexadecimal using 16-bit values between colons. When the IPv6 address is a link-local address (IPv6Z address), the outgoing interface name must be specified. See [IPv6Z Address Conventions](#).
- **ipv6-address2-4**—(Optional) Additional IPv6 addresses that may be associated with the host's name

Default Configuration

No host is defined.

Command Mode

Global Configuration mode

Example

```
switchxxxxxx(config)# ipv6 host server 3000::a31b
```

39.15 ipv6 neighbor

Use the **ipv6 neighbor** command to configure a static entry in the IPv6 neighbor discovery cache. Use the **no** form of this command to remove a static IPv6 entry from the IPv6 neighbor discovery cache.

Syntax

ipv6 neighbor *ipv6_addr interface-id hw_addr*

no ipv6 neighbor *ipv6_addr interface-id*

Parameters

- **ipv6_addr**—Specifies the P6 address to map to the specified MAC address.
- **interface-id**—Specifies the interface that is associated with the IPv6 address
- **hw_addr**—Specifies the MAC address to map to the specified IPv6 address.

Command Mode

Global Configuration mode

User Guidelines

The **IPv6 neighbor** command is similar to the [arp](#) command.

If an entry for the specified IPv6 address already exists in the neighbor discovery cache—learned through the IPv6 neighbor discovery process—the entry is automatically converted to a static entry.

A new static neighbor entry with a global address can be configured only if a manually configured subnet already exists in the device.

Use the [show ipv6 neighbors](#) command to view static entries in the IPv6 neighbor discovery cache.

Example

```
switchxxxxxx(config)# ipv6 neighbor 3000::a31b vlan 1 001b.3f9c.84ea
```

39.16 ipv6 set mtu

Use the **ipv6 mtu** Privileged EXEC mode command to set the maximum transmission unit (MTU) size of IPv6 packets sent on an interface. Use the default parameter to restore the default MTU size.

Syntax

```
ipv6 set mtu {interface-id} {bytes | default}
```

Parameters

- **interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or Port-channel.
- **bytes**—Specifies the MTU in bytes. Range is 1280-65535.
- **default**—Sets the default MTU size 1500 bytes. Minimum is 1280 bytes

Default Configuration

1500 bytes

Command Mode

Privileged EXEC mode

User Guidelines

This command is intended for debugging and testing purposes and should be used only by technical support personnel.

Example

```
switchxxxxxx# ipv6 set mtu fe1/0/11 default
```

39.17 ipv6 mld version

Use the **ipv6 mld version** Interface Configuration mode command to change the version of the Multicast Listener Discovery Protocol (MLD). Use the **no** form of this command to change to the default version.

Syntax

ipv6 mld version {1 | 2}

no ipv6 mld version

Parameters

- 1—Specifies MLD version 1.
- 2—Specifies MLD version 2.

Default Configuration

MLD version 1.

Command Mode

Interface Configuration (Ethernet, VLAN, Port-channel) mode

```
switchxxxxxx(config)# interface vlan 1
switchxxxxxx(config-if)# ipv6 mld version 2
```

39.18 ipv6 mld join-group

Use the **ipv6 mld join-group** Interface Configuration mode command to configure MLD reporting for a specified group. Use the **no** form of this command to cancel reporting and leave the group.

Syntax

ipv6 mld join-group *group-address*

no ipv6 mld join-group *group-address*

Parameters

group-address—Specifies the IPv6 address of the Multicast group.

Default Configuration

N/A

Command Mode

Interface Configuration (Ethernet, VLAN, Port-channel) mode

User Guidelines

This command configures MLD reporting for a specified group. The packets that are addressed to a specified group address that will be passed to the client process in the device.

Example

The following example configures MLD reporting for specific groups:

```
switchxxxxxx(conf)#interface gi1
switchxxxxxx(conf-if)#ipv6 mld join-group ff02::10
```

39.19 show ipv6 neighbors

Use the **show ipv6 neighbors** Privileged EXEC mode command to display IPv6 neighbor discovery cache information.

Syntax

```
show ipv6 neighbors {static | dynamic}[ipv6-address ipv6-address] [mac-address mac-address]
[interface-id]
```

Parameters

- **static**—Shows static neighbor discovery cache entries.
- **dynamic**—Shows dynamic neighbor discovery cache entries.
- **ipv6-address**—Shows the neighbor discovery cache information entry of a specific IPv6 address.
- **mac-address**—Shows the neighbor discovery cache information entry of a specific MAC address.
- **interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port, Port-channel or VLAN.

Command Mode

Privileged EXEC mode

User Guidelines

Since the associated interface of a MAC address can be aged out from the FDB table, the Interface field can be empty.

When an ARP entry is associated with an IP interface that is defined on a port or port-channel, the VLAN field is empty.

The possible neighbor cache states are:

- **INCMP (Incomplete)**—Address resolution is being performed on the entry. Specifically, a Neighbor Solicitation has been sent to the solicited-node multicast address of the target, but the corresponding Neighbor Advertisement has not yet been received.
- **REACH (Reachable)**—Positive confirmation was received within the last ReachableTime milliseconds that the forward path to the neighbor was functioning properly. While REACHABLE, no special action takes place as packets are sent.
- **STALE**—More than ReachableTime milliseconds have elapsed since the last positive confirmation was received that the forward path was functioning properly. While stale, no action takes place until a packet is sent.
- **DELAY**—More than ReachableTime milliseconds have elapsed since the last positive confirmation was received that the forward path was functioning properly, and a packet was sent within the last DELAY_FIRST_PROBE_TIME seconds. If no reachability confirmation is received within DELAY_FIRST_PROBE_TIME seconds of entering the DELAY state, send a Neighbor Solicitation and change the state to PROBE.



- **PROBE**—A reachability confirmation is actively sought by retransmitting Neighbor Solicitations every RetransTimer milliseconds until a reachability confirmation is received.

Example

```
switchxxxxxx# show ipv6 neighbors dynamic
Interface      IPv6 Address           HW Address           State*  Router
-----
VLAN 1        fe80::200:cff:fe4a:dfa8 00:00:0c:4a:df:a8  stale  yes
VLAN 1        fe80::2d0:b7ff:fea1:264d 00:d0:b7:a1:26:4d  stale  no
*See State values above.
```

39.20 clear ipv6 neighbors

Use the **clear ipv6 neighbors** Privileged EXEC mode command to delete all entries in the IPv6 neighbor discovery cache, except for static entries.

Syntax

clear ipv6 neighbors

Parameters

This command has no keywords or arguments.

Command Mode

Privileged EXEC mode

Example

```
switchxxxxxx# clear ipv6 neighbors
```

40 Tunnel Commands

40.1 interface tunnel

Use the **interface tunnel** Global Configuration mode command to enter the Interface Configuration (Tunnel) mode.

Syntax

interface tunnel *number*

Parameters

number—Specifies the tunnel index.

Default Configuration

N/A

Command Mode

Global Configuration mode

Example

The following example enters the Interface Configuration (Tunnel) mode.

```
switchxxxxxx(config)# interface tunnel 1
switchxxxxxx(config-tunnel)#
```

40.2 tunnel mode ipv6ip

Use the **tunnel mode ipv6ip** Interface Configuration (Tunnel) mode command to configure an IPv6 transition-mechanism global support mode. Use the **no** form of this command to remove an IPv6 transition mechanism.

Syntax

tunnel mode ipv6ip *{isatap}*

no tunnel mode ipv6ip

Parameters

isatap—Enables an automatic IPv6 over IPv4 ISATAP tunnel.

Default Configuration

Disabled.

Command Mode

Interface Configuration (Tunnel) mode

User Guidelines

The system can be enabled to support ISATAP tunnels. When enabled, an automatic tunnel interface is created on each interface that is assigned an IPv4 address.

Note that on a specific interface (for example, port or VLAN), both native IPv6 and transition-mechanisms can coexist. The host implementation chooses the egress interface according to the scope of the destination IP address (such as ISATAP or native IPv6).

Example

The following example configures an ISATAP tunnel mechanism.

```
switchxxxxxx(config)# interface tunnel 1
switchxxxxxx(config-tunnel)# tunnel mode ipv6ip isatap
```

40.3 tunnel isatap router

Use the **tunnel isatap router** Interface Configuration (Tunnel) mode command to configure a global string that represents a specific automatic tunnel router domain name. Use the **no** form of this command to remove this router name and restore the default configuration.

Syntax

tunnel isatap router *router-name*

no tunnel isatap router

Parameters

router-name—Specifies the router's domain name.

Default Configuration

The automatic tunnel router's default domain name is ISATAP.

Command Mode

Interface Configuration (Tunnel) mode

User Guidelines

This command determines the string that the host uses for automatic tunnel router lookup in the IPv4 DNS procedure. By default, the string ISATAP is used for the corresponding automatic tunnel types.

Only one string can represent the automatic tunnel router name per tunnel. Using this command, therefore, overwrites the existing entry.

Example

The following example configures the global string ISATAP2 as the automatic tunnel router domain name.

```
switchxxxxxx(config)# tunnel 1
switchxxxxxx(config-tunnel)# tunnel isatap router ISATAP2
```

40.4 tunnel source

Use the **tunnel source** Interface Configuration (Tunnel) mode command to set the local (source) IPv4 address of a tunnel interface. The **no** form deletes the tunnel local address.

Syntax

tunnel source {*auto* | **ipv4-address** *ipv4-address*}

no tunnel source

Parameters

- **auto**—The system minimum IPv4 address is used as the source address for packets sent on the tunnel interface. If the IPv4 address is changed, then the local address of the tunnel interface is changed too.
- **ip4-address**—Specifies the IPv4 address to use as the source address for packets sent on the tunnel interface. The local address of the tunnel interface is not changed when the IPv4 address is moved to another interface (only if StackTable is changed).

Default

No source address is defined.

Command Mode

Interface Configuration (Tunnel) mode

User Guidelines

The configured source IPv4 address is used for forming the tunnel interface identifier. The interface identifier is set to the 8 least significant bytes of the SIP field of the encapsulated IPv6 tunneled packets.

Example

```
switchxxxxxx(config)# interface tunnel 1
switchxxxxxx(config-tunnel)# tunnel source auto
```

40.5 tunnel isatap query-interval

Use the **tunnel isatap query-interval** Global Configuration mode command to set the time interval between DNS queries (before the ISATAP router IP address is known) for the automatic tunnel router domain name. Use the **no** form of this command to restore the default configuration.

Syntax

tunnel isatap query-interval *seconds*

no tunnel isatap query-interval

Parameters

seconds—Specifies the time interval in seconds between DNS queries. (Range: 10–3600)

Default Configuration

The default time interval between DNS queries is 10 seconds.

Command Mode

Global Configuration mode

User Guidelines

This command determines the time interval between DNS queries before the ISATAP router IP address is known. If the IP address is known, the robustness level that is set by the [tunnel isatap robustness](#) Global Configuration mode command determines the refresh rate.

Example

The following example sets the time interval between DNS queries to 30 seconds.

```
switchxxxxxx(config)# tunnel isatap query-interval 30
```

40.6 tunnel isatap solicitation-interval

Use the **tunnel isatap solicitation-interval** Global Configuration mode command to set the time interval between ISATAP router solicitation messages. Use the **no** form of this command to restore the default configuration.

Syntax

tunnel isatap solicitation-interval *seconds*

no tunnel isatap solicitation-interval

Parameters

seconds—Specifies the time interval in seconds between ISATAP router solicitation messages. (Range: 10–3600)

Default Configuration

The default time interval between ISATAP router solicitation messages is 10 seconds.

Command Mode

Global Configuration mode

User Guidelines

This command determines the interval between router solicitation messages when there is no active ISATAP router. If there is an active ISATAP router, the robustness level set by the **tunnel isatap robustness** Global Configuration mode command determines the refresh rate.

Example

The following example sets the time interval between ISATAP router solicitation messages to 30 seconds.

```
switchxxxxxx(config)# tunnel isatap solicitation-interval 30
```

40.7 tunnel isatap robustness

Use the **tunnel isatap robustness** Global Configuration mode command to configure the number of DNS query/router solicitation refresh messages that the device sends. Use the **no** form of this command to restore the default configuration.

Syntax

tunnel isatap robustness *number*

no tunnel isatap robustness

Parameters

number—Specifies the number of DNS query/router solicitation refresh messages that the device sends. (Range: 1–20)

Default Configuration

The default number of DNS query/router solicitation refresh messages that the device sends is 3.

Command Mode

Global Configuration mode

User Guidelines

The DNS query interval (after the ISATAP router IP address is known) is the Time-To-Live (TTL) that is received from the DNS, divided by (Robustness + 1).

The router solicitation interval (when there is an active ISATAP router) is the minimum-router-lifetime that is received from the ISATAP router, divided by (Robustness + 1).

Example

The following example sets the number of DNS query/router solicitation refresh messages that the device sends to 5.

```
switchxxxxxx(config)# tunnel isatap robustness 5
```

40.8 show ipv6 tunnel

Use the **show ipv6 tunnel** EXEC mode command to display information on the ISATAP tunnel.

Syntax

show ipv6 tunnel

Command Mode

EXEC mode

Example

The following example displays information on the ISATAP tunnel.

```
switchxxxxxx# show ipv6 tunnel
```



```
Tunnel 1
-----
Tunnel status                : DOWN
Tunnel protocol              : NONE
Tunnel Local address type    : auto
Tunnel Local Ipv4 address    : 0.0.0.0
Router DNS name              : ISATAP
Router IPv4 address          : 0.0.0.0
DNS Query interval          : 300 seconds
Min DNS Query interval      : 0 seconds
Router Solicitation interval : 10 seconds
Min Router Solicitation interval : 0 seconds
Robustness                   : 2
```

41

DHCP Relay Commands

41.1 ip dhcp relay enable (Global)

Use the **ip dhcp relay enable** Global Configuration mode command to enable the DHCP relay feature on the device. Use the **no** form of this command to disable the DHCP relay feature.

Syntax

ip dhcp relay enable

no ip dhcp relay enable

Parameters

N/A

Default Configuration

DHCP relay feature is disabled.

Command Mode

Global Configuration mode

Example

The following example enables the DHCP relay feature on the device.

```
switchxxxxxx(config)# ip dhcp relay enable
```

41.2 ip dhcp relay enable (Interface)

Use the **ip dhcp relay enable** Interface Configuration (VLAN, Ethernet, Port-channel) mode command to enable the DHCP relay feature on an interface. Use the **no** form of this command to disable the DHCP relay agent feature on an interface.

Syntax

ip dhcp relay enable

no ip dhcp relay enable

Parameters

N/A

Default Configuration

Disabled

Command Mode

Interface Configuration (VLAN, Ethernet, Port-channel) mode

User Guidelines

The operational status of DHCP Relay on an interface is active if one of the following conditions exist:

- DHCP Relay is globally enabled, and there is an IP address defined on the interface.
Or
- DHCP Relay is globally enabled, there is no IP address defined on the interface, the interface is a VLAN, and option 82 is enabled.

Example

The following example enables DHCP Relay on VLAN 21.

```
switchxxxxxx(config)# interface vlan 21
switchxxxxxx(config-if)# ip dhcp relay enable
```

41.3 ip dhcp relay address

Use the **ip dhcp relay address** Global Configuration mode command to define the DHCP servers available for the DHCP relay. Use the **no** form of this command to remove servers from the list.

Syntax

ip dhcp relay address *ip-address*

no ip dhcp relay address [*ip-address*]

Parameters

ip-address—Specifies the DHCP server IP address. Up to 8 servers can be defined.

Default Configuration

No server is defined.

Command Mode

Global Configuration mode

Example

The following example defines the DHCP server on the device.

```
switchxxxxxx(config)# ip dhcp relay address 176.16.1.1
```

41.4 show ip dhcp relay

Use the **show ip dhcp relay** EXEC mode command to display the DHCP relay information.

Syntax

show ip dhcp relay

Command Mode

EXEC mode

Example

Example 1. Option 82 is not supported:

```
switchxxxxxx# show ip dhcp relay
DHCP relay is globally enabled
Option 82 is Disabled
Maximum number of supported VLANs without IP Address is 256
Number of DHCP Relays enabled on VLANs without IP Address is 0
DHCP relay is not configured on any port.
DHCP relay is not configured on any vlan.
No servers configured
```

Example 2. Option 82 is supported (disabled):

```
switchxxxxxx# show ip dhcp relay
DHCP relay is globally disabled
Option 82 is disabled
Maximum number of supported VLANs without IP Address: 0
Number of DHCP Relays enabled on VLANs without IP Address: 4
DHCP relay is enabled on Ports: fe1/0/15,po3-4
Active:
Inactive: fe1/0/15, po3-4
DHCP relay is enabled on VLANs: 1, 2, 4, 5
Active:
Inactive: 1, 2, 4, 5
Servers: 1.1.1.1 , 2.2.2.2
```

Example 3. Option 82 is supported (enabled):

```
switchxxxxxx# show ip dhcp relay
DHCP relay is globally enabled
Option 82 is enabled
Maximum number of supported VLANs without IP Address is 4
Number of DHCP Relays enabled on VLANs without IP Address: 2
DHCP relay is enabled on Ports: fe1/0/15,po3-4
Active: fe1/0/15
Inactive: po3-4
DHCP relay is enabled on VLANs: 1, 2, 4, 5
Active: 1, 2, 4, 5
Inactive:
Servers: 1.1.1.1 , 2.2.2.2
```

41.5 ip dhcp information option

Use the **ip dhcp information option** Global Configuration command to enable DHCP option-82 data insertion. Use the **no** form of this command to disable DHCP option-82 data insertion.

Syntax

ip dhcp information option

no ip dhcp information option

Parameters

N/A

Default Configuration

DHCP option-82 data insertion is disabled.

Command Mode

Global Configuration mode

User Guidelines

DHCP option 82 would be enabled only if DHCP snooping or DHCP relay are enabled.

Example

```
switchxxxxxx(config)# ip dhcp information option
```

41.6 show ip dhcp information option

The **show ip dhcp information option** EXEC mode command displays the DHCP Option 82 configuration.

Syntax

show ip dhcp information option

Parameters

N/A

Default Configuration

N/A

Command Mode

EXEC mode

Example

The following example displays the DHCP Option 82 configuration.

```
switchxxxxxx# show ip dhcp information option
```

Relay agent Information option is Enabled



42 DHCP Server Commands

42.1 ip dhcp server

Use the **ip dhcp server** Global Configuration mode command to enable the Dynamic Host Configuration Protocol (DHCP) server features on the device. Use the **no** form of this command to disable the DHCP server.

Syntax

ip dhcp server

no ip dhcp server

Default Configuration

The DHCP server is disabled.

Command Mode

Global Configuration mode

Example

The following example enables the DHCP server on the device:

```
Console(config)# ip dhcp server
```

42.2 ip dhcp pool host

Use the **ip dhcp pool host** Global Configuration mode command to configure a Dynamic Host Configuration Protocol (DHCP) static address on a DHCP Server and enter the DHCP Pool Host Configuration mode. Use the **no** form of this command to remove the address pool.

Syntax

ip dhcp pool host *name*

no ip dhcp pool host *name*

Parameters

name—Specifies the DHCP address pool name. It can be either a symbolic string (such as Engineering) or an integer (such as 8). (Length: 1–32 characters)

Default Configuration

DHCP hosts are not configured.

Command Mode

Global Configuration mode

User Guidelines

During execution of this command, the configuration mode changes to the DHCP Pool Configuration mode, which is identified by the (config-dhcp)# prompt. In this mode, the administrator can configure host parameters, such as the IP subnet number and default router list.

Example

The following example configures Station as the DHCP address pool:

```
Console(config)# ip dhcp pool host station
Console(config-dhcp)#
```

42.3 ip dhcp pool network

Use the **ip dhcp pool network** Global Configuration mode command to configure a Dynamic Host Configuration Protocol (DHCP) address pool on a DHCP Server and enter DHCP Pool Configuration mode. Use the **no** form of this command to remove the address pool.

Syntax

ip dhcp pool network *name*

no ip dhcp pool network *name*

Parameters

name—Specifies the DHCP address pool name. It can be either a symbolic string (such as 'engineering') or an integer (such as 8). (Length: 1–32 characters)

Default Configuration

DHCP address pools are not configured.

Command Mode

Global Configuration mode

User Guidelines

During execution of this command, the configuration mode changes to DHCP Pool Network Configuration mode, which is identified by the (config-dhcp)# prompt. In this mode, the administrator can configure pool parameters, such as the IP subnet number and default router list.

Example

The following example configures Pool1 as the DHCP address pool.

```
Console(config)# ip dhcp pool network pool1
Console(config-dhcp)#
```

42.4 address (DHCP Host)

Use the **address** DHCP Pool Host Configuration mode command to manually bind an IP address to a Dynamic Host Configuration Protocol (DHCP) client. Use the **no** form of this command to remove the IP address binding to the client.

Syntax

address *ip-address* {*mask* | *prefix-length*} {*client-identifier* *unique-identifier* | *hardware-address* *mac-address*}

no address

Parameters

- **address**—Specifies the client IP address.
- **mask**—Specifies the client network mask.
- **prefix-length**—Specifies the number of bits that comprise the address prefix. The prefix is an alternative way of specifying the client network mask. The prefix length must be preceded by a forward slash (/).
- **unique-identifier**—Specifies the distinct client identification in dotted hexadecimal notation: Each byte in a hexadecimal character string is two hexadecimal digits. Bytes are separated by a period or colon. For example, 01b7.0813.8811.66.
- **hardware-address**—Specifies the MAC address.

Default Configuration

DHCP hosts are not configured.

Command Mode

DHCP Pool Host Configuration mode

Example

The following example manually binds an IP address to a Dynamic Host Configuration Protocol (DHCP) client.

```
Console(config-dhcp)# address 10.12.1.99 255.255.255.0 01b7.0813.8811.66
```

42.5 address (DHCP Network)

Use the **address** DHCP Pool Network Configuration mode command to configure the subnet number and mask for a Dynamic Host Configuration Protocol (DHCP) address pool on DHCP Server. Use the **no** form of this command to remove the subnet number and mask.

Syntax

address {*network-number* | *low* *low-address* *high* *high-address*} {*mask* | *prefix-length*}

no address

Parameters

- **network-number**—Specifies the IP address of the DHCP address pool.
- **mask**—Specifies the pool network mask.
- **prefix-length**—Specifies the number of bits that comprise the address prefix. The prefix is an alternative way of specifying the client network mask. The prefix length must be preceded by a forward slash (/).
- **low** **low-address**—Specifies the first IP address to use in the address range.
- **high** **high-address**—Specifies the last IP address to use in the address range.

Default Configuration

DHCP address pools are not configured.

If the low address is not specified, it defaults to the first IP address in the network.

If the high address is not specified, it defaults to the last IP address in the network.

Command Mode

DHCP Pool Network Configuration mode

Example

The following example configures the subnet number and mask for a Dynamic Host Configuration Protocol (DHCP) address pool on DHCP Server.

```
Console(config-dhcp)# address 10.12.1.0 255.255.255.0
```

42.6 lease

Use the **lease** DHCP Pool Network Configuration mode command to configure the time duration of the lease for an IP address that is assigned from a Dynamic Host Configuration Protocol (DHCP) Server to a DHCP client. Use the **no** form of this command to restore the default value.

Syntax

```
lease {days [{hours} [minutes]} | infinite}
```

```
no lease
```

Parameters

- **days**—Specifies the number of days in the lease.
- **hours**—Specifies the number of hours in the lease. A **days** value must be supplied before configuring an **hours** value.
- **minutes**—Specifies the number of minutes in the lease. A **days** value and an **hours** value must be supplied before configuring a **minutes** value.
- **infinite**—Specifies that the duration of the lease is unlimited.

Default Configuration

The default lease duration is 1 day.

Command Mode

DHCP Pool Network Configuration mode

Examples

The following example shows a 1-day lease.

```
Console(config-dhcp)# lease 1
```

The following example shows a one-hour lease.

```
Console(config-dhcp)# lease 0 1
```

The following example shows a one-minute lease.

```
Console(config-dhcp)# lease 0 0 1
```

The following example shows an infinite (unlimited) lease.

```
Console(config-dhcp)# lease infinite
```

42.7 client-name

Use the **client-name** DHCP Pool Host Configuration mode command to define the name of a DHCP client. The client name should not include the domain name. Use the **no** form of this command to remove the client name.

Syntax

client-name *name*

no client-name

Parameters

name—Specifies the client name, using standard ASCII characters. The client name should not include the domain name. For example, the name Mars should not be specified as mars.yahoo.com. (Length: 1–32 characters)

Command Mode

DHCP Pool Host Configuration mode

Default Configuration

No client name is defined.

Example

The following example defines the string Client1 as the client name.

```
Console(config-dhcp)# client-name client1
```

42.8 default-router

Use the **default-router** DHCP Pool Configuration mode command to configure the default router list for a Dynamic Host Configuration Protocol (DHCP) client. Use the **no** form of this command to remove the default router list.

Syntax

default-router *ip-address* [*ip-address2* ... *ip-address8*]

no default-router

Parameters

ip-address—Specifies the IP address of a router. One IP address is required, although up to eight addresses can be specified in one command line.

Command Mode

DHCP Pool Host Configuration mode

DHCP Pool Network Configuration mode

Default Configuration

No default router is defined.

User Guidelines

The router IP address should be on the same subnet as the client subnet.

Example

The following example specifies 10.12.1.99 as the default router IP address.

```
Console(config-dhcp)# default-router 10.12.1.99
```

42.9 dns-server

Use the **dns-server** DHCP Pool Configuration mode command to configure the Domain Name System (DNS) IP servers available to a Dynamic Host Configuration Protocol (DHCP) client. Use the **no** form of this command to remove the DNS server list.

Syntax

dns-server *ip-address* [*ip-address2* ... *ip-address8*]

no dns-server

Parameters

ip-address—Specifies a DNS Server IP address. One IP address is required, although up to eight addresses can be specified in one command line.

Command Mode

DHCP Pool Host Configuration mode

DHCP Pool Network Configuration mode

Default Configuration

No DNS server is defined.

User Guidelines

If DNS IP servers are not configured for a DHCP client, the client cannot correlate host names to IP addresses.

Example

The following example specifies 10.12.1.99 as the client domain name server IP address.

```
Console (config-dhcp) # dns-server 10.12.1.99
```

42.10 domain-name

Use the **domain-name** DHCP Pool Configuration mode command to specify the domain name for a Dynamic Host Configuration Protocol (DHCP) client. Use the **no** form of this command to remove the domain name.

Syntax

domain-name *domain*

no domain-name

Parameters

domain—Specifies the DHCP client domain name string. (Length: 1–32 characters)

Command Mode

DHCP Pool Host Configuration mode

DHCP Pool Network Configuration mode

Default Configuration

No domain name is defined.

Example

The following example specifies yahoo.com as the DHCP client domain name string.

```
Console (config-dhcp) # domain-name yahoo.com
```

42.11 netbios-name-server

Use the **netbios-name-server** DHCP Pool Configuration mode command to configure the NetBIOS Windows Internet Naming Service (WINS) servers that are available to Microsoft Dynamic Host Configuration Protocol (DHCP) clients. Use the **no** form of this command to remove the NetBIOS name server list.

Syntax

netbios-name-server *ip-address* [*ip-address2* ... *ip-address8*]

no netbios-name-server

Parameters

ip-address—Specifies the NetBIOS WINS name server IP address. One IP address is required, although up to eight addresses can be specified in one command line.

Command Mode

DHCP Pool Host Configuration mode
DHCP Pool Network Configuration mode

Default Configuration

No bios server is defined.

Example

The following example specifies the IP address of a NetBIOS name server available to the DHCP client.

```
Console(config-dhcp) # netbios-name-server 10.12.1.90
```

42.12 netbios-node-type

Use the **netbios-node-type** DHCP Pool Configuration mode command to configure the NetBIOS node type for Microsoft Dynamic Host Configuration Protocol (DHCP) clients. Use the **no** form of this command to return to default.

Syntax

netbios-node-type {**b-node** | **p-node** | **m-node** | **h-node**}

no netbios-node-type

Parameters

- **b-node**—Specifies the Broadcast NetBIOS node type.
- **p-node**—Specifies the Peer-to-peer NetBIOS node type.
- **m-node**—Specifies the Mixed NetBIOS node type.
- **h-node**—Specifies the Hybrid NetBIOS node type.

Command Mode

DHCP Pool Host Configuration mode
DHCP Pool Network Configuration mode

Default Configuration

h-node (Hybrid NetBIOS node type).

Example

The following example specifies the client's NetBIOS type as mixed.

```
Console(config-dhcp) # netbios node-type m-node
```

42.13 next-server

Use the **next-server** DHCP Pool Configuration mode command to configure the next server in the boot process of a Dynamic Host Configuration Protocol (DHCP) client. Use the **no** form of this command to remove the boot server.

Syntax**next-server** *ip-address***no next-server****Parameters****ip-address**—Specifies the IP address of the next server in the boot process, which is typically a Trivial File Transfer Protocol (TFTP) server.**Default Configuration**If the **next-server** command is not used to configure a boot server list, the DHCP Server uses inbound interface helper addresses as boot servers.**Command Mode**

DHCP Pool Host Configuration mode

DHCP Pool Network Configuration mode

Example

The following example specifies 10.12.1.99 as the IP address of the next server in the boot process.

```
Console (config-dhcp) # next-server 10.12.1.99
```

42.14 next-server-name

Use the **next-server-name** DHCP Pool Configuration mode command to configure the next server name in the boot process of a Dynamic Host Configuration Protocol (DHCP) client. Use the **no** form of this command to remove the boot server name.**Syntax****next-server-name** *name***no next-server-name****Parameters****name**—Specifies the name of the next server in the boot process. (Length: 1–64 characters)**Command Mode**

DHCP Pool Host Configuration mode

DHCP Pool Network Configuration mode

Default Configuration

No next server name is defined.

Example

The following example specifies www.bootserver.com as the name of the next server in the boot process of a DHCP client.

```
Console (config-dhcp) # next-server www.bootserver.com
```

42.15 bootfile

Use the **bootfile** DHCP Pool Configuration mode command to specify the default boot image file name for a Dynamic Host Configuration Protocol (DHCP) client. Use the **no** form of this command to delete the boot image file name.

Syntax

bootfile *filename*

no bootfile

Parameters

filename—Specifies the file name used as a boot image. (Length: 1–128 characters)

Command Mode

DHCP Pool Host Configuration mode

DHCP Pool Network Configuration mode

Example

The following example specifies `boot_image_file` as the default boot image file name for a DHCP client.

```
Console(config-dhcp)# bootfile boot_image_file
```

42.16 time-server

Use the **time-server** DHCP Pool Configuration mode command to specify the time servers list for a Dynamic Host Configuration Protocol (DHCP) client. Use the **no** form of this command to remove the time servers list.

Syntax

time-server *ip-address* [*ip-address2* ... *ip-address8*]

no time-server

Parameters

ip-address—Specifies the IP address of a time server. One IP address is required, although up to eight addresses can be specified in one command line.

Command Mode

DHCP Pool Host Configuration mode

DHCP Pool Network Configuration mode

Default Configuration

No time server name is defined.

User Guidelines

The router IP address should be on the same subnet as the client subnet.

Example

The following example specifies 10.12.1.99 as the time server IP address.

```
Console (config-dhcp) # time-server 10.12.1.99
```

42.17 option

Use the **option** DHCP Pool Configuration mode command to configure the Dynamic Host Configuration Protocol (DHCP) Server options. Use the **no** form of this command to remove the options.

Syntax

option *code* {*ascii* *ascii-string* | *hex* *hex-string* | *ip* *ip-address*}

option ip-list *code* *ip-address1* [*ip-address2* ...]

no option *code*

Parameters

- **code**—Specifies the DHCP option code.
- **ascii** **ascii-string**—Specifies an NVT ASCII character string. ASCII character strings, which contain white space, must be delimited by quotation marks.
- **hex** **hex-string**—Specifies dotted hexadecimal data: Each byte in hexadecimal character strings is two hexadecimal digits. Bytes are separated by a period or colon.
- **ip** **ip-address**—Specifies an IP address.
- **ip-list**—Specifies that a list of IP addresses immediately follows the option code.
- **ip-address1** [**ip-address2** ...]—Specifies a list of one or more IP addresses.

Command Mode

DHCP Pool Host Configuration mode

DHCP Pool Network Configuration mode

User Guidelines

DHCP provides a framework for passing configuration information to hosts on a TCP/IP network. Configuration parameters and other control information are carried in tagged data items that are stored in the DHCP message options field. The data items themselves are also called options. The current set of DHCP options are documented in RFC 2131, *Dynamic Host Configuration Protocol*.

For options in hexadecimal format, the string parameter should include all the bytes in the option value, including leading zeros.

Examples

The following example configures DHCP option 19, which specifies whether the client should configure its IP layer for packet forwarding. A value of 0 means disable IP forwarding. A value of 1 means enable IP forwarding. IP forwarding is enabled in the following example.

```
Console (config-dhcp) # option 19 hex 01
```

The following example configures DHCP option 2, which specifies the offset of the client's subnet in seconds from Coordinated Universal Time (UTC). A value of 0xE10 in the following example indicates a location 1 hour east of the meridian.

```
Console(config-dhcp)# option 2 hex 00000E10
```

The following example configures DHCP option 72, which specifies the World Wide Web servers for DHCP clients. World Wide Web servers 172.16.3.252 and 172.16.3.253 are configured in the following example.

```
Console(config-dhcp)# option ip-list 72 172.16.3.252 172.16.3.253
```

42.18 ip dhcp excluded-address

Use the **ip dhcp excluded-address** Global Configuration mode command to specify the IP addresses that a Dynamic Host Configuration Protocol (DHCP) Server should not assign to DHCP clients. Use the **no** form of this command to remove the excluded IP addresses.

Syntax

ip dhcp excluded-address *low-address* [*high-address*]

no ip dhcp excluded-address *low-address* [*high-address*]

Parameters

- **low-address**—Specifies the excluded IP address, or first IP address in an excluded address range.
- **high-address**—Specifies the last IP address in the excluded address range.

Default Configuration

All IP pool addresses are assignable.

Command Mode

Global Configuration mode

User Guidelines

The DHCP Server assumes that all pool addresses can be assigned to clients. Use this command to exclude a single IP address or a range of IP addresses.

Example

The following example configures an excluded IP address range from 172.16.1.100 through 172.16.1.199.

```
Console(config)# ip dhcp excluded-address 172.16.1.100 172.16.1.199
```

42.19 ip dhcp ping enable

Use the **ip dhcp ping enable** Global Configuration mode command to enable the Dynamic Host Configuration Protocol (DHCP) Server to send ping packets before assigning the address to a

requesting client. Use the **no** form of this command to prevent the server from pinging pool addresses.

Syntax

ip dhcp ping enable

no ip dhcp ping enable

Default Configuration

DHCP pinging is disabled.

Command Mode

Global Configuration mode

User Guidelines

The DHCP Server pings a pool address before assigning the address to a requesting client. If the ping is unanswered, the DHCP Server assumes (with a high probability) that the address is not in use and assigns the address to the requesting client.

Example

The following example enables the DHCP Server to send ping packets before assigning the address to a requesting client.

```
Console(config)# ip dhcp ping enable
```

42.20 ping enable

Use the **ping enable** DHCP Pool Network Configuration mode command to enable the Dynamic Host Configuration Protocol (DHCP) Server to send ping packets before assigning the address to a requesting client. Use the **no** form of this command to prevent the server from pinging pool addresses.

Syntax

ping enable

no ping enable

Default Configuration

The default configuration is set to enable.

Command Mode

DHCP Pool Network Configuration mode

User Guidelines

The DHCP Server pings a pool address before assigning the address to a requesting client. If the ping is unanswered, the DHCP Server assumes (with a high probability) that the address is not in use and assigns the address to the requesting client.

Example

The following example enables the DHCP Server to send ping packets before assigning the address to a requesting client.

```
Console (config-dhcp) # ping enable
```

42.21 ip dhcp ping count

Use the **ip dhcp ping count** Global Configuration mode command to specify the number of packets a Dynamic Host Configuration Protocol (DHCP) Server sends to a pool address as part of a ping operation. Use the **no** form of this command to restore the default configuration.

Syntax

ip dhcp ping count *number*

no ip dhcp ping count

Parameters

number—Specifies the number of ping packets that are sent before assigning the address to a requesting client. (Range: 1-10)

Default Configuration

A Dynamic Host Configuration Protocol (DHCP) Server sends two packets to a pool address as part of a ping operation.

Command Mode

Global Configuration mode

Example

The following example specifies that a DHCP Server sends five packets to a pool address as part of a ping operation.

```
Console (config) # ip dhcp ping count 5
```

42.22 ip dhcp ping timeout

The **ip dhcp ping timeout** Global Configuration mode command specifies the time interval during which a Dynamic Host Configuration Protocol (DHCP) Server waits for a ping reply from an address pool. To restore the default timeout, use the **no** form of this command.

Syntax

ip dhcp ping timeout *milliseconds*

no ip dhcp ping timeout

Parameters

milliseconds — Specifies the amount of time (in milliseconds) that the DHCP server waits for a ping reply before it stops attempting to reach a pool address for client assignment. The timeout range is 300-10000 milliseconds.

Default Configuration

The default timeout is 500 milliseconds.

Command Mode

Global Configuration mode

User Guidelines

This command specifies how long to wait for a ping reply (in milliseconds).

Example

The following example specifies that a DHCP Server waits 1 second for a ping reply from an address pool before it stops attempting to reach a pool address for client assignment.

```
Console(config)# ip dhcp ping timeout 1000
```

42.23 clear ip dhcp binding

The **clear ip dhcp binding** Privileged EXEC mode command deletes the dynamic address binding from the Dynamic Host Configuration Protocol (DHCP) Server database.

Syntax

```
clear ip dhcp binding {address | *}
```

Parameters

- *address* — Specifies the binding address to delete from the DHCP database.
- *** — Clears all automatic bindings.

Command Mode

Privileged EXEC mode

User Guidelines

Typically, the address denotes the client IP address. If the asterisk (*) character is specified as the address parameter, DHCP clears all dynamic bindings.

Use the **no ip dhcp pool** Global Configuration mode command to delete a manual binding.

Example

The following example deletes the address binding 10.12.1.99 from a DHCP server database:

```
Console# clear ip dhcp binding 10.12.1.99
```

42.24 show ip dhcp

The **show ip dhcp** EXEC mode command displays the DHCP configuration.

Syntax

```
show ip dhcp
```

Command Mode

EXEC mode

Example

The following example displays the DHCP configuration.

```
console# show ip dhcp
```

```
DHCP server is enabled.
```

```
DHCP ping packets is enabled with 2 retries and 500 milliseconds.
```

42.25 show ip dhcp excluded-addresses

The **show ip dhcp excluded-addresses** EXEC mode command displays the excluded addresses.

Syntax**show ip dhcp excluded-addresses****Command Mode**

EXEC mode

Example

The following example displays the excluded addresses.

```
console# show ip dhcp excluded-addresses
```

```
The number of excluded addresses ranges is 2
```

```
Excluded addresses:
```

```
10.1.1.212- 10.1.1.219, 10.1.2.212- 10.1.2.219
```

42.26 show ip dhcp pool host

The **show ip dhcp pool host** EXEC mode command displays the DHCP pool host configuration.

Syntax**show ip dhcp pool host** [*address* | *name*]**Parameters**

- *address* — Specifies the client IP address.
- *name* — Specifies the DHCP pool name. (Length: 1-32 characters)

Command ModeEXEC mode

**Example**

The following example displays the DHCP pool host configuration.

```
console# show ip dhcp pool host
The number of host pools is 1

Name          IP Address      Hardware        Client Identifier
-----          -
Station       172.16.1.11     -----        01b7.0813.8811.66

console# show ip dhcp pool host station

Name          IP Address      Hardware        Client Identifier
-----          -
Station       172.16.1.11     -----        01b7.0813.8811.66

Mask: 255.255.0.0
Default router: 172.16.1.1
Client name: client1
DNS server: 10.12.1.99
Domain name: yahoo.com
NetBIOS name server: 10.12.1.90
NetBIOS node type: h-node
Next server: 10.12.1.99
Next-server-name: 10.12.1.100
Bootfile: Bootfile
Time server 10.12.1.99
Options:

Code          Value
----          -
19            0x01
```

42.27 show ip dhcp pool network

The **show ip dhcp pool network** EXEC mode command displays the DHCP network configuration.

Syntax

show ip dhcp pool network [*name*]

Parameters

name — Specifies the DHCP pool name. (Length: 1-32 characters)

Command Mode

EXEC mode

Example

```
Router> show ip dhcp pool network
```

```

The number of network pools is 2
Name Address range mask Lease
-----
marketing 10.1.1.17-10.1.1.178 255.255.255.0 0d:12h:0m
finance 10.1.2.8-10.1.2.178 255.255.255.0 0d:12h:0m
Router> show ip dhcp pool network marketing
Name Address range mask Lease
-----
marketing 10.1.1.17-10.1.1.178 255.255.255.0 0d:12h:0m
Statistics:
All-range Available Free Pre-allocated Allocated Expired Declined
-----
162 150 68 50 20          3          9
Default router: 10.1.1.1
Ping packets: enabled
DNS server: 10.12.1.99
Domain name: yahoo.com
NetBIOS name server: 10.12.1.90
NetBIOS node type: h-node
Next server: 10.12.1.99
Next-server-name: 10.12.1.100
Bootfile: Bootfile
Time server 10.12.1.99
Options:
Code Value
-----
19 0x01

```

42.28 show ip dhcp binding

Use the **show ip dhcp binding** EXEC mode command to display the specific one or all the address bindings on the Dynamic Host Configuration Protocol (DHCP) Server.

Syntax

show ip dhcp binding [*ip-address*]

Parameters

ip-address — Specifies the IP address

Command Mode

EXEC mode

Example

The following example displays the DHCP Server binding address parameters.

```
Router> show ip dhcp binding
```



```

DHCP server enabled
The number of used (all types) entries is 6
The number of pre-allocated entries is 1
The number of allocated entries is 1
The number of expired entries is 1
The number of declined entries is 2
The number of static entries is 1
The number of dynamic entries is 2
The number of automatic entries is 1

```

IP address	Hardware Address	Lease Expiration	Type	State
1.16.1.11	00a0.9802.32de	Feb 01 1998	dynamic	allocated
1.16.3.23	02c7.f801.0422	12:00AM	dynamic	expired
1.16.3.24	02c7.f802.0422		dynamic	declined
1.16.3.25	02c7.f803.0422		dynamic	pre-allocated
1.16.3.26	02c7.f804.0422		dynamic	declined

```

Router> show ip dhcp binding 1.16.1.11
DHCP server enabled
The number of used (all types) entries is 6
The number of pre-allocated entries is 1
The number of allocated entries is 1
The number of expired entries is 1
The number of declined entries is 2
The number of static entries is 1
The number of dynamic entries is 2
The number of automatic entries is 1

```

IP address	Hardware Address	Lease Expiration	Type	State
1.16.1.11	00a0.9802.32de	Feb 01 1998 12:00 AM	dynamic	allocated

```

Router> show ip dhcp binding 1.16.3.24
The number of used (all types) entries is 6
The number of pre-allocated entries is 1
The number of allocated entries is 1
The number of expired entries is 1
The number of declined entries is 2
The number of static entries is 1
The number of dynamic entries is 2
The number of automatic entries is 1

```

IP address	Hardware Address	Lease Expiration	Type	State
------------	------------------	------------------	------	-------

```

-----
1.16.3.24  02c7.f802.0422                dynamic declined

```

The following table describes the significant fields shown in the display.

Field	Description
IP address	The host IP address as recorded on the DHCP Server.
Hardware address	The MAC address or client identifier of the host as recorded on the DHCP Server.
Lease expiration	The lease expiration date of the host IP address.
Type	The manner in which the IP address was assigned to the host.
State	The IP Address state.

42.29 show ip dhcp server statistics

Use the **show ip dhcp server statistics** EXEC command to display Dynamic Host Configuration Protocol (DHCP) Server statistics.

Syntax

show ip dhcp server statistics

Command Mode

EXEC mode

Example

The following example displays DHCP Server statistics

```

DHCP server enabled
The number of network pools is 7
The number of excluded pools is 2
The number of used (all types) entries is 7
The number of pre-allocated entries is 1
The number of allocated entries is 3
The number of expired entries is 1
The number of declined entries is 2
The number of static entries is 1
The number of dynamic entries is 2
The number of automatic entries is 1

```

42.30 show ip dhcp allocated

Use the **show ip dhcp allocated** EXEC mode command to display the specific one or all the allocated address on the Dynamic Host Configuration Protocol (DHCP) Server.

Syntax

show ip dhcp allocated [*ip-address*]

Parameters

ip-address — Specifies the IP address

Command Mode

EXEC mode

Example

The following example displays the DHCP Server allocated IP addresses.

```
Router> show ip dhcp allocated
DHCP server enabled
The number of allocated entries is 3
```

IP address	Hardware address	Lease expiration	Type
172.16.1.11	00a0.9802.32de	Feb 01 1998 12:00 AM	Dynamic
172.16.3.253	02c7.f800.0422	Infinite	Automatic
172.16.3.254	02c7.f800.0422	Infinite	Static

```
Router> show ip dhcp allocated 172.16.1.11
DHCP server enabled
The number of allocated entries is 2
```

IP address	Hardware address	Lease expiration	Type
172.16.1.11	00a0.9802.32de	Feb 01 1998 12:00 AM	Dynamic

```
Router> show ip dhcp allocated 172.16.3.254
DHCP server enabled
The number of allocated entries is 2
```

IP address	Hardware address	Lease expiration	Type
172.16.3.254	02c7.f800.0422	Infinite	Static

The following table describes the significant fields shown in the display.

Field	Description
IP address	The host IP address as recorded on the DHCP Server.
Hardware address	The MAC address or client identifier of the host as recorded on the DHCP Server.

Lease expiration	The lease expiration date of the host IP address.
Type	The manner in which the IP address was assigned to the host.

42.31 show ip dhcp declined

Use the **show ip dhcp declined** EXEC command to display the specific one or all the declined addresses on the Dynamic Host Configuration Protocol (DHCP) server.

show ip dhcp declined Field Descriptions

Syntax

show ip dhcp declined [*ip-address*]

Parameters

ip-address—Specifies the IP address.

Command Mode

EXEC mode

Example

```
Router> show ip dhcp declined
DHCP server enabled
The number of declined entries is 2
```

```
IP address   Hardware address
172.16.1.11  00a0.9802.32de
172.16.3.254 02c7.f800.0422
```

```
Router> show ip dhcp declined 172.16.1.11
DHCP server enabled
The number of declined entries is 2
```

```
IP address   Hardware address
172.16.1.11  00a0.9802.32de
```

42.32 show ip dhcp expired

Use the **show ip dhcp expired** EXEC command to display the specific one or all the expired addresses on the Dynamic Host Configuration Protocol (DHCP) server.

Syntax

show ip dhcp expired [*ip-address*]

Parameters

ip-address—Specifies the IP.



Command Mode

EXEC mode

Example

```
Router> show ip dhcp expired
DHCP server enabled
The number of expired entries is 1
```

```
IP address   Hardware address
172.16.1.11  00a0.9802.32de
172.16.3.254 02c7.f800.0422
```

```
Router> show ip dhcp expired 172.16.1.11
DHCP server enabled
The number of expired entries is 1
```

```
IP address   Hardware address
172.16.1.13  00a0.9802.32de
```

42.33 show ip dhcp pre-allocated

Use the **show ip dhcp pre-allocated** EXEC command to display the specific one or all the pre-allocated addresses on the Dynamic Host Configuration Protocol (DHCP) server.

Syntax

show ip dhcp pre-allocated [*ip-address*]

Parameters

ip-address—Specifies the IP.

Command Mode

EXEC mode

Examples

```
Router> show ip dhcp pre-allocated
DHCP server enabled
The number of pre-allocated entries is 1
```

```
IP address   Hardware address
172.16.1.11  00a0.9802.32de
172.16.3.254 02c7.f800.0422
```

```
Router> show ip dhcp pre-allocated 172.16.1.11
DHCP server enabled
```

The number of pre-allocated entries is 1

IP address	Hardware address
172.16.1.15	00a0.9802.32de

43 IP Routing Protocol-Independent Commands

43.1 ip route

Use the **ip route** Global Configuration mode command to configure static routes. Use the **no** form of this command to remove static routes.

Syntax

ip route *prefix* {*mask* | *prefix-length*} {{*ip-address* [*metric distance*]} | **reject-route**}

no ip route *prefix* {*mask* | *prefix-length*} [*ip-address*]

Parameters

- **prefix**—Specifies the IP address that is the IP route prefix for the destination IP.
- **mask**—Specifies the network subnet mask of the IP address prefix.
- **prefix-length**—Specifies the number of bits that comprise the IP address prefix. The prefix length must be preceded by a forward slash (/). (Range: 0–32)
- **ip-address**—Specifies the IP address or IP alias of the next hop that can be used to reach the network.
- **metric distance**—Specifies an administrative distance. (Range: 1–255).
- **reject-route**—Stops routing to the destination network via all gateways.

Default Configuration

The default administrative distance is 1.

Command Mode

Global Configuration mode

User Guidelines

Use the **no ip route** command with the *ip-address* parameter to remove a single static route to the given subnet via the given next hop.

Use the **no ip route** command without the *ip-address* parameter to remove all static routes to the given subnet.

Examples

Example 1 - The following example shows how to route packets for network 172.31.0.0 to a router at 172.31.6.6 using mask:

```
switchxxxxxx(conf)#ip route 172.31.0.0 255.255.0.0 172.31.6.6 metric 2
```

Example 2 - The following example shows how to route packets for network 172.31.0.0 to a router at 172.31.6.6 using prefix length:


```
switchxxxxxx(conf)#ip route 172.31.0.0 /16 172.31.6.6 metric 2
```

Example 3 - The following example shows how to reject packets for network 194.1.1.0:

```
switchxxxxxx(conf)#ip route 194.1.1.0 255.255.255.0 reject-route
```

Example 4 - The following example shows how to remove all static routes to network 194.1.1.0/24:

```
switchxxxxxx(conf)#no ip route 194.1.1.0 /24
```

Example 5 - The following example shows how to remove one static route to network 194.1.1.0/24 via 1.1.1.1:

```
switchxxxxxx(conf)#no ip route 194.1.1.0 /24 1.1.1.1
```

43.2 ip routing

Use the **ip routing** Global Configuration mode command to enable IPv4 Routing. Use the **no** format of the command to disable IPv4 Routing.

Syntax

ip routing

no ip routing

Parameters

N/A

Default Configuration

Enabled.

Command Mode

Global Configuration mode

Example. The following example enables ipv4 routing.

```
switchxxxxxx# ip routing
```

43.3 key chain

To enable authentication for routing protocols, identify a group of authentication keys by using the **key chain** command in Global Configuration mode. This command puts the user into the Keychain mode.

To remove the key chain, use the **no** form of this command.

Syntax

key chain *name-of-chain*

no key chain *chain-name*

Parameters

name-of-chain—Name of a key chain. The chain-name may have from 1 to 32 characters. A key chain must have at least one key and can have up to 256 keys.

Default Configuration

No key chain exists.

Command Mode

Global Configuration mode

User Guidelines

You must configure a key chain with keys to enable authentication.

Although you can identify multiple key chains, it is recommended to use a single key chain per interface per routing protocol. The **key chain** command enters the **key-chain** configuration mode.

Example

The following example configures a key chain named chain1. The key named **key1** will be accepted from 1:30 p.m. to 3:30 p.m. and be sent from 2:00 p.m. to 3:00 p.m. The key named **key2** will be accepted from 2:30 p.m. to 4:30 p.m. and be sent from 3:00 p.m. to 4:00 p.m. The overlap allows for migration of keys or a discrepancy in the set time of the router. There is a 30-minute leeway on each side to handle time differences:

```
switchxxxxxx(conf)#key chain chain1
switchxxxxxx(config-keychain)#key 1
switchxxxxxx(config-keychain-key)key-string key1
switchxxxxxx(config-keychain-key)accept-lifetime 13:30:00 Jan 25 2011
duration 7200
switchxxxxxx(config-keychain-key)send-lifetime 14:00:00 Jan 25 2011
duration 3600
switchxxxxxx(config-keychain-key)key 2
switchxxxxxx(config-keychain-key)key-string key2
switchxxxxxx(config-keychain-key)accept-lifetime 14:30:00 Jan 25 2011
duration 7200
switchxxxxxx(config-keychain-key)send-lifetime 15:00:00 Jan 25 2011
duration 3600
switchxxxxxx(config-keychain-key)#exit
switchxxxxxx(config-keychain)#exit
switchxxxxxx(config)#exit
switchxxxxxx(config)#router rip
switchxxxxxx(config-router-rip)#network 172.19.1.1
switchxxxxxx(config-router-rip)#exit
switchxxxxxx(config)interface ip 172.19.1.1
switchxxxxxx(config)ip rip authentication mode md5
switchxxxxxx(config-interface)#ip rip authentication key-chain chain1
switchxxxxxx(config-interface)#exit
```

43.4 key (key chain)

Use the **key** command in Key-chain Configuration mode to identify an authentication key on a key chain. This command places the user in Keychain Key mode.

To remove the key from the key chain, use the **no** form of this command.

Syntax

key *key-id*

no key *key-id*

Parameters

key-id—Identification number of an authentication key on a key chain. The range of keys is from 1 to 255. The key identification numbers need not be consecutive. The scope of a key identification number is the key chain where the key is defined.

Default Configuration

No key exists on the key chain.

Command Mode

Key-Chain Configuration mode

User Guidelines

It is useful to have multiple keys on a key chain so that the software can sequence through the keys as they become invalid after time, based on the [accept-lifetime](#) and [send-lifetime](#) key chain key command settings.

Each key has its own key identifier that is stored locally. The combination of the key identifier and the interface associated with the message uniquely identifies the authentication algorithm and authentication key in use. Only one authentication packet is sent, regardless of the number of valid keys. The software starts looking at the lowest key identifier number and uses the first valid key.

If the last key expires, authentication will be finished with an error.

To remove all keys, remove the key chain by using the **no key chain** command.

Example

The following example configures a key chain named **chain1**. The key named **key1** will be accepted from 1:30 p.m. to 3:30 p.m. and be sent from 2:00 p.m. to 3:00 p.m. The key named **key2** will be accepted from 2:30 p.m. to 4:30 p.m. and be sent from 3:00 p.m. to 4:00 p.m. The overlap allows for migration of keys or a discrepancy in the set time of the router. There is a 30-minute leeway on each side to handle time differences:

```
switchxxxxxx(config)# key 1
key chain chain1
  key 1
  key-string key1
  accept-lifetime 13:30:00 Jan 25 2011 duration 7200
  send-lifetime 14:00:00 Jan 25 2011 duration 3600
  key 2
  key-string key2
```

```
accept-lifetime 14:30:00 Jan 25 2011 duration 7200
send-lifetime 15:00:00 Jan 25 2011 duration 3600
exit
router rip
network 172.19.1.1
exit
interface ip 172.19.1.1
ip rip authentication mode md5
ip rip authentication key-chain chain1
exit
```

43.5 key-string

To specify the authentication string for a key, use the **key-string** command in key chain key configuration mode. To remove the authentication string, use the **no** form of this command.

Syntax

key-string *text*

no key-string

Parameters

text—Specifies the authentication string. The string can contain from 1 to 16 characters.

Default Configuration

N/A

Command Mode

Key chain key configuration.

Example

The following example configures a key chain named **chain1**. The key named **key1** will be accepted from 1:30 p.m. to 3:30 p.m. and be sent from 2:00 p.m. to 3:00 p.m. The key named **key2** will be accepted from 2:30 p.m. to 4:30 p.m. and be sent from 3:00 p.m. to 4:00 p.m. The overlap allows for migration of keys or a discrepancy in the set time of the router. There is a 30-minute leeway on each side to handle time differences:

```
key chain chain1
key 1
key-string key1
accept-lifetime 13:30:00 Jan 25 2011 duration 7200
send-lifetime 14:00:00 Jan 25 2011 duration 3600
key 2
key-string key2
accept-lifetime 14:30:00 Jan 25 2011 duration 7200
send-lifetime 15:00:00 Jan 25 2011 duration 3600
exit
```

```
router rip
 network 172.19.1.1
 version 2
 exit
 interface ip 172.19.1.1
  ip rip authentication key-chain chain1
  ip rip authentication mode md5
 exit
```

43.6 accept-lifetime

Use the **accept-lifetime** command in Key Chain Key Configuration mode to set the time period during which the authentication key on a key chain is received as valid. To revert to the default value, use the **no** form of this command.

Syntax

accept-lifetime *start-time* {**infinite** | *end-time* | **duration** *seconds*}

no accept-lifetime

Parameters

- **start-time**—Beginning time that the key specified by the key command is valid to be received. The syntax can be either of the following:
 - *hh:mm:ss month day year*
 - *hh:mm:ss day month year*
 - *hh*—hours (0-23)
 - *mm*—minutes (0-59)
 - *ss*—seconds (0-59)
 - *month*—first three letters of the month
 - *day*—day (1-31)
 - *year*—year (four digits)
- **infinite**—Key is valid to be received from the *start-time* value on.
- **end-time**—Key is valid to be received from the *start-time* value until the *end-time* value. The syntax is the same as that for the *start-time* value. The *end-time* value must be after the *start-time* value. The default end time is an infinite time period.
- **duration** *seconds*—Length of time (in seconds) that the key is valid to be received. The range is from 1 to 2147483646.

Default Configuration

The default start time and the earliest acceptable date is January 1, 2000.

The default time period during which the authentication key is valid for authenticating incoming packets is set to forever and the ending time is infinite.

Command Mode

Key chain key configuration

User Guidelines

Specify a *start-time* value and one of the following values: **infinite**, *end-time*, or **duration** *seconds*.

A key is considered as expired if Time-of-Date is not set by management or by SNTP.
If the last key expires, authentication will be finished with error.

Example

The following example configures a key chain called **keychain1**. The key named **string1** will be accepted from 1:30 p.m. to 3:30 p.m. and be sent from 2:00 p.m. to 3:00 p.m. The key named **string2** will be accepted from 2:30 p.m. to 4:30 p.m. and be sent from 3:00 p.m. to 4:00 p.m. The overlap allows for migration of keys or discrepancies in the set time of the router. There is a 30-minute leeway on each side to handle time differences:

```
router rip
  network 172.19.1.1
exit
interface ip 172.19.1.1
  ip rip authentication mode md5
  ip rip authentication key-chain keychain1
exit
key chain keychain1
  key 1
  key-string string1
  accept-lifetime 13:30:00 Jan 25 2011 duration 7200
  send-lifetime 14:00:00 Jan 25 2011 duration 3600
  key 2
  key-string string2
  accept-lifetime 14:30:00 Jan 25 2011 duration 7200
  send-lifetime 15:00:00 Jan 25 2011 duration 3600
exit
```

43.7 send-lifetime

Use the **send-lifetime** command in Key Chain Key Configuration mode to set the time period during which an authentication key on a key chain is valid to be sent. To revert to the default value, use the **no** form of this command.

Syntax

send-lifetime *start-time* {**infinite** | *end-time* | **duration seconds**}

no send-lifetime

Parameters

- **start-time**—Beginning time that the key specified by the key command is valid to be received. The syntax can be either of the following:
 - *hh:mm:ss month day year*
 - *hh:mm:ss day month year*
 - *hh*—hours (0-23)
 - *mm*—minutes (0-59)
 - *ss*—seconds (0-59)

- *month*—first three letters of the month
- *day*—day (1-31)
- *year*—year (four digits)
- **infinite**—Key is valid to be received from the *start-time* value on.
- **end-time**—Key is valid to be received from the *start-time* value until the *end-time value*. The syntax is the same as that for the *start-time* value. The *end-time* value must be after the *start-time* value. The default end time is an infinite time period.
- **duration seconds**—Length of time (in seconds) that the key is valid to be received. The range is from 1 to 2147483646.

Default Configuration

The default start time and the earliest acceptable date is January 1, 2000.

The default time period during which the authentication key is valid for authenticating incoming packets is set to forever and the ending time is infinite.

Command Mode

Key chain key configuration

User Guidelines

Specify a *start-time* value and one of the following values: **infinite**, **end-time**, or **duration seconds**.

A key is considered as expired if Time-of-Date is not set by management or by SNTP.

If the last key expires, authentication will be finished with error.

Example

The following example configures a key chain called **chain1**. The key named **key1** will be accepted from 1:30 p.m. to 3:30 p.m. and be sent from 2:00 p.m. to 3:00 p.m. The key named **key2** will be accepted from 2:30 p.m. to 4:30 p.m. and be sent from 3:00 p.m. to 4:00 p.m. The overlap allows for migration of keys or discrepancies in the set time of the router. There is a 30-minute leeway on each side to handle time differences:

```
router rip
 network 172.19.1.1
 exit
 interface ip 172.19.1.1
  ip rip authentication mode md5
  ip rip authentication key-chain chain1
 exit
 key chain chain1
  key 1
  key-string key1
  accept-lifetime 13:30:00 Jan 25 1996 duration 7200
  send-lifetime 14:00:00 Jan 25 1996 duration 3600
  key 2
  key-string key2
  accept-lifetime 14:30:00 Jan 25 1996 duration 7200
  send-lifetime 15:00:00 Jan 25 1996 duration 3600
```

exit

43.8 show ip route

Use the **show ip route** EXEC mode command to display the current routing table state.

Syntax

show ip route [*connected* | *static* | {**address** *address* [*mask* | *prefix-length*] [*longer-prefixes*]}]

Parameters

- **connected**—Displays connected routing entries only.
- **static**—Displays static routing entries only.
- **address address**—Specifies the address for which routing information is displayed.
- **mask**—Specifies the network subnet mask of the IP address.
- **prefix-length**—Specifies the number of bits that comprise the IP address prefix. The prefix length must be preceded by a forward slash (/). (Range: 1–32)
- **longer-prefixes**—Specifies that the **address** and **mask** pair becomes a prefix and any routes that match that prefix are displayed.

Command Mode

EXEC mode

Example

The following example displays the current routing table state.

```
switchxxxxxx# show ip route
switchxxxxxx# show ip route
Maximum Parallel Paths: 1 (1 after reset)
IP Forwarding:          enabled
Codes: C - connected, S - static, D - DHCP
S  0.0.0.0/0             [fe1/0/11] via 10.5.234.254 119:9:27  vlan 1
C  10.5.234.0/24        is directly connected                vlan 1
```

```
switchxxxxxx# show ip route address 172.1.1.0 255.255.255.0
Codes: C - connected, S - static, E - OSPF external, * - candidate default
S 172.1.1.0/24 [fe1/0/13] via 10.0.2.1, 17:12:19, fe1/0/11
```

```
switchxxxxxx# show ip route address 172.1.1.0 255.255.255.0
longer-prefixes
Codes: C - connected, S - static, E - OSPF external
S 172.1.1.0/24 [fe1/0/13] via 10.0.2.1, 17:12:19, fe1/0/11
S 172.1.1.1/32 [fe1/0/13] via 10.0.3.1, 19:51:18, fe1/0/11
```

The following table describes the significant fields shown in the display:

Field	Description
O	The protocol that derived the route.
10.8.1.0/24	The remote network address.
[30/2000]	The first number in the brackets is the administrative distance of the information source; the second number is the metric for the route.
via 10.0.1.2	The address of the next router to the remote network.
00:39:08	The last time the route was updated in hours:minutes:seconds.
fe1/0/11	The interface through which the specified network can be reached.

43.9 show ip protocols

Use the **show ip protocols** EXEC mode command to display the parameters and current state of the active routing protocols.

Syntax

show ip protocols

Parameters

N/A

Default Usage

N/A

Command Mode

EXEC mode

Example

The following example displays the parameters and current state of the active routing protocols.

```

switchxxxxxx# show ip protocols
Routing Protocol is "rip"
Sending updates every 30 seconds
Invalid after 180 seconds, hold down 120, flushed after 300
Redistributing: RIP, Static, OSPF
Default version control: send version 1, receive version 1
Interfaces:

Interface          Send          Receive      Key-chain
176.1.1.1          1             1            flowers
176.2.1.1          passive       2
Routing Information Sources:

```



```
Gateway          Last Update
176.1.1.2        0:00:17
Preference: 60

Routing Protocol is "ospf"
Redistributing: OSPF, External direct, Static,
RIP
Interfaces:

Interface        Metric          Key-chain
176.1.1.1        10              flowers
176.2.1.1        1

Routing Information Sources:

Gateway          State
176.1.1.2        Full

External Preference: 60
Internal Preference: 20
```

43.10 show key-chains

Use the **show key chain** command in Privileged EXEC mode to display authentication key information,.

Syntax

show key chains [*name-of-chain*]

Parameters

name-of-chain—Name of the key chain to display, as named in the key chain command.

Default Configuration

Information about all key chains is displayed.

Command Mode

Privileged EXEC mode

Examples

Example 1 - The following is sample output from the show key chain command when the current time or date is defined:

```
Router# show key chain
Current Time of Date is Feb 8 2011
Key-chain trees:
  key 1 -- text "chestnut"
    accept lifetime (always valid) - (always valid) [valid now]
    send lifetime (always valid) - (always valid) [valid now]
```

```
key 2 -- text "birch"
  accept lifetime (00:00:00 Dec 5 2010) - (23:59:59 Dec 5 2010)
  send lifetime (06:00:00 Dec 5 2010) - (18:00:00 Dec 5 2016)[valid now]
```

Example 2 - The following is sample output from the show key chain command when the current time or date is not defined:

```
Router# show key chain
Current Time of Date is not defined
Key-chain trees:
  key 1 -- text "chestnut"
    accept lifetime (always valid) - (always valid) [valid now]
    send lifetime (always valid) - (always valid) [valid now]
  key 2 -- text "birch"
    accept lifetime (00:00:00 Dec 5 2010) - (23:59:59 Dec 5 2010)
    send lifetime (06:00:00 Dec 5 2010) - (18:00:00 Dec 5 2016)
```

43.11 show keys

Use the **show keys** Privileged EXEC mode command to display keys information.

Syntax

```
show keys [key-id]
```

Parameters

key-id—Specifies the identification number of an authentication key on a key chain. (Range: 1–255)

Default Usage

Display information for all keys.

Command Mode

Privileged EXEC mode

Example

The following example displays keys information.

```
switchxxxxxx# show keys
  key 1
    accept:    13:30:00 Jan 25 2002 forever
    send:     13:30:00 Jan 25 2002 forever
```

key 2

```
accept: 13:30:00 Jan 25 2002 until 15:30:00
        Jan 25 2002
send:   14:00:00 Jan 25 2002 until 15:00:00
        Jan 25 2002
```

key 3

```
accept: 14:30:00 Jan 25 2002 until 16:30:00
        Jan 25 2002
send:   15:00:00 Jan 25 2002 until 16:00:00
        Jan 25 2002
```

44 RIP Commands

44.1 router rip

The **router rip** Global Configuration mode command enables or disables RIP globally. The **no** format of the command disables RIP globally and removes its configuration.

Syntax

router rip

no router rip

Parameters

N/A

Default Configuration

Disabled

Command Mode

Global Configuration mode

User Guidelines

RIP supports the following global states:

- **disabled**
RIP is not operational and cannot be configured. When this state is set, the RIP configuration is removed. This state can be set by the **no router rip** CLI command from any RIP global state.
- **enabled**
RIP is operational, and can be configured. This state is set by the **router rip** CLI command from the **disabled** RIP global state and by the **no shutdown** CLI command from the **shutdown** RIP global state.
- **shutdown**
RIP is not operational, but can be configured. When this state is set, the RIP configuration is not changed. This state can be set by the **shutdown** CLI command from the **enabled** RIP global state.

Example

The following example shows how to enable RIP globally:

```
switchxxxxxx(config)# router rip
switchxxxxxx(config-rip)#
```

44.2 shutdown

The **shutdown** Router RIP configuration mode command sets the RIP global state to **shutdown**. The **no** format of the command sets the RIP global state to **enabled**.

Syntax**shutdown****no shutdown****Parameters**

N/A

Default Configuration

Enabled

Command Mode

Router RIP configuration.

User GuidelinesUse the [shutdown](#) CLI command to disable RIP globally without removing its configuration.**Example**

The following example shows how to disable RIP globally:

```
switchxxxxxx(config)#router rip
switchxxxxxx(config-rip)#shutdown
```

44.3 redistribute static

The **redistribute static** Router RIP configuration mode command enables RIP to advertise static routes. The **no** format of the command disables advertisement of static routes.**Syntax****redistribute static [metric transparent]****no redistribute static [metric transparent]****Parameters****metric transparent**—Causes RIP to use the routing table metric for redistributing static routes as the RIP metric. If this parameter is omitted, the metric specified by the [default-metric](#) command is used.**Default Configuration**

Static routes are not redistributed by RIP.

Command Mode

Router RIP configuration.

User Guidelines

If this command specifies the Metric Transparent mode, a static route is sent by RIP only if its metric is less than 16.

Use the **no redistribute static metric transparent** to change the metric of static redistributed routes to the default metric specified by the [default-metric](#) command.

Use the **no redistribute static** to disable distributing static routes by RIP.

Examples

Example 1. The following example enables redistribution of static routes by RIP with transparent metric:

```
switchxxxxxx(config)#router rip
switchxxxxxx(config-rip)#redistribute static metric transparent
exit
```

Example 2. The following example enables redistribution of static routes by RIP with transparent metric and then changes the metric to default:

```
switchxxxxxx(config)#router rip
switchxxxxxx(config-rip)#redistribute static metric transparent
switchxxxxxx(config-rip)#no redistribute static metric transparent
switchxxxxxx(config-rip)#exit
```

Example 3. The following example enables redistribution of static routes by RIP with the default metric and then changes the metric to transparent:

```
switchxxxxxx(config)#router rip
switchxxxxxx(config-rip)#redistribute static
switchxxxxxx(config-rip)#redistribute static metric transparent
switchxxxxxx(config-rip)#exit
```

Example 4. The following example enables redistribution of static routes by RIP with transparent metric. The second redistribute command has no effect.

```
switchxxxxxx(config)#router rip
switchxxxxxx(config-rip)#redistribute static metric transparent
switchxxxxxx(config-rip)#redistribute static
switchxxxxxx(config-rip)#exit
```

Example 5. The following example disables redistribution of static routes by RIP:

```
switchxxxxxx(config)#router rip
switchxxxxxx(config-rip)#no redistribute static
switchxxxxxx(config-rip)#exit
```

44.4 default-metric

The **default-metric** Router RIP configuration mode command sets the default metric value when RIP advertises routes derived by other protocols or by static configuration. The **no** format of the command sets the default value.

Syntax**default-metric** [*metric-value*]**no default-metric****Parameters****metric-value**—Default metric value. Range 1-15.**Default Configuration**

1.

Command Mode

Router RIP configuration.

Example

The following example shows how to set the default metric to 2:

```
switchxxxxxx(config)#router rip
switchxxxxxx(config-rip)#default-metric 2
```

44.5 network

The **network** Router RIP configuration mode command enables RIP on the given IP interfaces. The **no** format of the command disables RIP on the given IP interfaces and removes its interface configuration.

Syntax**network** *ip-address***no network** *ip-address***Parameters****ip-address**—IP address of a switch's IP interface.**Default Configuration**

N/A

Command Mode

Router RIP configuration.

User Guidelines

RIP can be defined only on manually-configured IP interfaces, meaning that RIP cannot be defined on an IP address defined by DHCP or on a default IP address.

Use the **no network** command to remove RIP on an IP interface and remove its interface configuration.

Example

The following example shows how to enable RIP on IP interface 1.1.1.1:

```
switchxxxxxx(config)#router rip
switchxxxxxx(config-rip)#network 1.1.1.1
```

44.6 clear statistics

The **clear statistics** Router RIP configuration mode command clears RIP statistics counters of all interfaces and all peers.

Syntax

clear statistics

Parameters

N/A

Default Configuration

N/A

Command Mode

Router RIP configuration mode

Example

The following example shows how to clear all counters:

```
switchxxxxxx(config)# router rip
switchxxxxxx(config-rip)# clear statistics
```

44.7 ip rip shutdown

The **ip rip shutdown** IP Interface configuration mode command changes the RIP state from **enabled** to **disabled** on an IP interface. The **no** format of the command returns the state to a value of **enabled**.

Syntax

ip rip shutdown

no ip rip shutdown

Parameters

N/A

Default Configuration

Enabled

Command Mode

IP Interface mode.

User Guidelines

Use the [ip rip shutdown](#) CLI command to disable RIP on an IP interface without removing its configuration. The **ip rip shutdown** command may be applied only to RIP interfaces created by the [network](#) command. The **ip rip shutdown** CLI command does not remove the RIP interface configuration.

Example

The following example shows how to disable RIP on the 1.1.1.1 IP interface:

```
switchxxxxxx(config)# interface ip 1.1.1.1
switchxxxxxx(config-ip)#ip rip shutdown
```

44.8 ip rip passive-interface

The **ip rip passive-interface** IP Interface Configuration mode command disables sending RIP packets on an IP interface. The **no** format of the command re-enables the sending of RIP packets.

Syntax

ip rip passive-interface

no ip rip passive-interface

Parameters

N/A.

Default Configuration

RIP messages are sent.

Command Mode

IP interface mode

Example

The following example shows how to stop transmitting RIP messages:

```
switchxxxxxx(config)# interface ip 1.1.1.1
switchxxxxxx(config-ip)# ip rip passive-interface
```

44.9 ip rip default-information originate

The **ip rip default-information originate** IP Interface includes a default route in sent RIP messages. The **no** format of the command returns to default.

Syntax

ip rip default-information originate *metric*

no ip rip default-information originate

Parameters

metric—Default route metric value. Range 1-15.

Default Configuration

Default route is not generated by RIP.

Command Mode

IP Interface mode

Example

The following example shows how to enable sending of default route with metric 3:

```
switchxxxxxx(config)# interface ip 1.1.1.1
switchxxxxxx(config-ip)# ip rip default-information originate 3
```

44.10 ip rip offset

The **ip rip offset** IP Configuration mode command defines a metric to add to incoming routes. The **no** format of the command returns to default.

Syntax

ip rip offset *offset*

no ip rip offset

Parameters

offset—Specifies the offset to be applied to received routes. Range: 1-15.

Default Configuration

1.

Command Mode

IP Interface mode

Example

The following example shows how to set offset to 2:

```
switchxxxxxx(config)# interface ip 1.1.1.1
switchxxxxxx(config-ip)# ip rip offset 2
```

44.11 ip rip distribute-list in

The **ip rip distribute-list in** IP configuration mode command enables filtering of incoming routes. The **no** format of the command disables the filtering.

Syntax

ip rip distribute-list access *access-list-name* in
no ip rip distribute-list in

Parameters

access-list-name—Standard IP access list name, up to 32 characters. The list defines which networks are to be sent and which are to be suppressed.

Default Configuration

No filtering

Command Mode

IP interface mode

Example

The following example shows how to define input filtering using access list aaa:

```
switchxxxxxx(config)# interface ip 1.1.1.1  
switchxxxxxx(config-ip)# ip rip distribute-list aaa in
```

44.12 ip rip distribute-list out

The **ip rip distribute-list out** IP configuration mode command enables filtering of outgoing routes. The **no** format of the command disables the filtering.

Syntax

ip rip distribute-list access *access-list-name* out
no ip rip distribute-list out

Parameters

access-list-name—Standard IP access list name, up to 32 characters. The list defines which networks are to be sent and which are to be suppressed.

Default Configuration

No filtering

Command Mode

IP interface mode

Example

The following example shows how to define outgoing filtering using access list aaa:

```
switchxxxxxx(config)# interface ip 1.1.1.1  
switchxxxxxx(config-ip)# ip rip distribute-list aaa out
```

44.13 ip rip authentication mode

The **ip rip authentication mode** IP Interface Configuration mode command enables authentication. The **no** format of the command returns to default.

Syntax

ip rip authentication mode {text | md5}

no ip rip authentication mode

Parameters

- **text**—Specifies the clear text authentication.
- **md5**—Specifies the MD5 authentication.

Default Configuration

No authentication.

Command Mode

IP interface mode

User Guidelines

If you enable the MD5 authentication, you must configure a key chain name with the [ip rip authentication key-chain](#) Interface mode command. If a key chain is not defined for the IP interface or there is no valid key, RIP packets are not sent on the IP interface and received IP interface packets are dropped.

If you enable the clear text authentication, you must configure a password with the [ip rip authentication-key](#) Interface mode command. If a password is not defined for the IP interface then RIP packets are not sent on the IP interface and received IP interface packets are dropped.

Example

The following example shows how to set the MD5 authentication mode:

```
switchxxxxxx(config)# interface ip 1.1.1.1
switchxxxxxx(config-ip)# ip rip authentication mode md5
```

44.14 ip rip authentication key-chain

The **ip rip authentication key-chain** IP Interface Configuration mode command specifies the set of keys that can be used. The **no** format of the command returns to default.

Syntax

ip rip authentication key-chain *name-of-chain*

no ip rip authentication key-chain

Parameters

name-of-chain—Specifies the name of key set. The name-change parameter points to list of keys specified by the **key chain** command.

Default Configuration

No defined key chain.

Command Mode

IP Interface mode

User Guidelines

Only one key chain may be defined per IP interface. Each **ip rip authentication key-chain** command overrides the previous definition.

Example

The following example shows how to define a key chain name:

```
switchxxxxxx(config)# interface ip 1.1.1.1  
switchxxxxxx(config-ip)# ip rip authentication key-chain alpha
```

44.15 ip rip authentication-key

To assign a password to be used by neighboring routers that are using the RIP clear text authentication, use the **ip rip authentication-key** command in Interface Configuration mode. To remove a previously-assigned RIP password, use the **no** form of this command.

Syntax

ip rip authentication-key *password*

no ip rip authentication-key

Parameters

password—Any continuous string of characters that can be entered from the keyboard. Length: 1-8 characters.

Default Configuration

No password is specified.

Command Mode

IP Interface mode

User Guidelines

The password created by this command is used as a "key" that is inserted directly into the RIP header when the switch software builds routing protocol packets. A separate password can be assigned to each subnetwork. All neighboring routers on the same subnetwork must have the same password to be able to exchange RIP information.

Only one password may be defined per IP interface. Each **ip rip authentication-key** command overrides the previous definition.

Example

The following example shows how to define a password:

```
switchxxxxxx(config)# interface ip 1.1.1.1
switchxxxxxx(config-ip)# ip rip authentication mode text
switchxxxxxx(config-ip)# ip rip authentication-key alph$$12
```

44.16 show ip rip database

The **show ip rip database** Privileged EXEC mode command displays information about the RIP database.

Syntax

show ip rip database [**all** | **brief** | *ip-address*]

Parameters

- **all**—Provides the full RIP database information about all RIP interfaces. The option is assumed if the parameter is omitted.
- **brief**—Provides a summary view of the RIP database information.
- **ip-address**—Provides the full RIP database information about the given IP Address.

Default Configuration

N/A

Command Mode

Privileged EXEC mode

Examples

Example 1. The following example shows the full RIP database information about all RIP interfaces:

```
switchxxxxxx#show ip rip database
RIP is enabled
RIP Administrative state is UP
Redistributing is enabled from
  Static:
    Metric is transparent
IP Interface: 1.1.1.1
Administrative State is enabled
IP Interface Offset is 10
Default Originate Metric is 12
Authentication Type is text
Password is afGRwitew%3
IN Filtering Type is Access List
Access List Name is 10
OUT Filtering Type is Access List
Access List Name is List12
IP Interface: 2.2.2.2
Administrative State is enabled
IP Interface Offset is 2
```



```
No Default Originate Metric
Authentication Type is MD5
Key Chain Name is chain1
No IN Filtering
Prefix List Name is PrefixList10
OUT Filtering Type is Access List
Access List Name is 12
IP Interface: 3.3.3.3
Administrative State is enabled
IP Interface Offset is 1
IP Interface is passive
No Default Originate Metric
No Authentication
No IN Filtering
No OUT Filtering
IP Interface: 4.4.4.4
Administrative State is shutdown
IP Interface Offset is 1
No Default Originate Metric
No Authentication
No IN Filtering
No OUT Filtering
```

Example 2. The following example shows the full RIP database information about a given IP address:

```
switchxxxxx#show ip rip database 1.1.1.1
RIP is enabled
RIP Administrative state is UP
Redistributing is enabled from
  Static:
    Metric is transparent
IP Interface: 1.1.1.1
Administrative State is enabled
IP Interface Offset is 10
Default Originate Metric is 12
Authentication Type is text
Password is afGRwiteW%3
IN Filtering Type is Access List
Access List Name is 10
OUT Filtering Type is Access List
Access List Name is List12
```

Example 3. The following example shows the brief RIP database information about all RIP interfaces is displayed:

```
switchxxxxxx#show ip rip database brief
RIP is enabled
RIP Administrative state is UP
Redistributing is enabled from
  Static:
    Metric is transparent
IP Interface      Admin   Offset  Passive  Default Auth.  IN Filt.  OUT Filt.
                  State                Interface Origin. Type  Type      Type
                  Metric
-----
100.100.100.100  enabled  10      No        12    Text  Access  Access
2.2.2.2          enabled  2       No        MD5   Access
3.3.3.3          enabled  1       Yes
4.4.4.4          shutdown 1       No
```

Example 4. The following example shows the output when RIP is disabled:

```
switchxxxxxx#show ip rip database
RIP is disabled
```

44.17 show ip rip statistics

The **show ip rip statistics** Privileged EXEC mode command displays RIP Statistics.

Syntax

show ip rip statistics

Parameters

N/A

Default Configuration

N/A

Command Mode

Privileged EXEC mode

Example

```
switchxxxxxx#show ip rip statistics
RIP is enabled
Static redistributing is enabled with transparent metric
Default redistributing metric is 1
Interface      Received      Received      Sent
              Bad           Bad           Triggered
```



	Pakets	Routes	Packets
-----	-----	-----	-----
1.1.1.1	-	1	8
2.2.2.2	-	-	7

44.18 show ip rip peers

The `show ip rip peers` Privileged EXEC mode command displays information about RIP peers.

Syntax

`show ip rip peers`

Parameters

N/A

Default Configuration

N/A

Command Mode

Privileged EXEC mode

Example

```
switchxxxxxx>show ip rip peers
RIP is enabled
Static redistributing is enabled with Default metric
Default redistributing metric is 1
Address          Last           Received      Received
                Update        Bad Packets   Bad Route
-----
1.1.12           00:10:17      -             1
2.2.2.3         00:10:01      -             -
```

45 ACL Commands

45.1 ip access-list

Use the **ip access-list extended** Global Configuration mode command to name an IPv4 access list (ACL) and to place the device in IPv4 Access List Configuration mode. All commands after this command refer to this ACL. The rules (ACEs) for this ACL are defined in the [permit \(IP \)](#) and [deny \(IP \)](#) commands. The [service-acl input](#) command is used to attach this ACL to an interface.

Use the **no** form of this command to remove the access list.

Syntax

```
ip access-list extended acl-name
no ip access-list extended acl-name
```

Parameters

- **acl-name**—Name of the IPv4 access list. (Range 1-32 characters)

Default Configuration

No IPv4 access list is defined.

Command Mode

Global Configuration mode

User Guidelines

An IPv4 ACL is defined by a unique name. IPv4 ACL, IPv6 ACL, MAC ACL or policy maps cannot have the same name.

Example

```
switchxxxxxx(config)# ip access-list extended server
switchxxxxxx(config-ip-al)#
```

45.2 permit (IP)

Use the **permit** IP Access-list Configuration mode command to set permit conditions for an IPv4 access list (ACL). Permit conditions are also known as access control entries (ACEs).

Syntax

```
permit protocol {any | source source-wildcard} {any | destination destination-wildcard} [dscp
number | precedence number] [time-range time-range-name]
permit icmp {any | source source-wildcard} {any | destination destination-wildcard} [any | icmp-type]
[any | icmp-code] [dscp number | precedence number] [time-range time-range-name]
permit igmp {any | source source-wildcard} {any | destination destination-wildcard}[igmp-type]
[dscp number | precedence number] time-range time-range-name]
```

permit tcp *{any | source source-wildcard} {any|source-port/port-range}{any | destination destination-wildcard} {any|destination-port/port-range} [dscp number | precedence number] [match-all list-of-flags] [time-range time-range-name]*

permit udp *{any | source source-wildcard} {any|source-port/port-range} {any | destination destination-wildcard} {any|destination-port/port-range} [dscp number | precedence number][match-all time-range-name] [time-range time-range-name]*

Parameters

- **permit protocol**—The name or the number of an IP protocol. Available protocol names are: icmp, igmp, ip, tcp, egp, igp, udp, hmp, rdp, idpr, ipv6, ipv6:rout, ipv6:frag, idrp, rsvp, gre, esp, ah, ipv6:icmp, eigrp, ospf, ipinip, pim, l2tp, isis. To match any protocol, use the **ip** keyword. (Range: 0–255)
- **source**—Source IP address of the packet.
- **source-wildcard**—Wildcard bits to be applied to the source IP address. Use ones in the bit position that you want to be ignored.
- **destination**—Destination IP address of the packet.
- **destination-wildcard**—Wildcard bits to be applied to the destination IP address. Use ones in the bit position that you want to be ignored.
- **dscp number**—Specifies the DSCP value.
- **precedence number**—Specifies the IP precedence value.
- **icmp-type**—Specifies an ICMP message type for filtering ICMP packets. Enter a number or one of the following values: echo-reply, destination-unreachable, source-quench, redirect, alternate-host-address, echo-request, router-advertisement, router-solicitation, time-exceeded, parameter-problem, timestamp, timestamp-reply, information-request, information-reply, address-mask-request, address-mask-reply, traceroute, datagram-conversion-error, mobile-host-redirect, mobile-registration-request, mobile-registration-reply, domain-name-request, domain-name-reply, skip, photuris. (Range: 0–255)
- **icmp-code**—Specifies an ICMP message code for filtering ICMP packets. (Range: 0–255)
- **igmp-type**—IGMP packets can be filtered by IGMP message type. Enter a number or one of the following values: host-query, host-report, dvmrp, pim, cisco-trace, host-report-v2, host-leave-v2, host-report-v3. (Range: 0–255)
- **destination-port**—Specifies the UDP/TCP destination port. You can enter range of ports by using hyphen. E.g. 20 - 21. For TCP enter a number or one of the following values: bgp (179), chargen (19), daytime (13), discard (9), domain (53), drip (3949), echo (7), finger (79), ftp (21), ftp-data (20), gopher (70), hostname (42), irc (194), klogin (543), kshell (544), lpd (515), nntp (119), pop2 (109), pop3 (110), smtp (25), sunrpc (1110), syslog (514), tacacs-ds (49), talk (517), telnet (23), time (37), uucp (117), whois (43), www (80). For UDP enter a number or one of the following values: biff (512), bootpc (68), bootps (67), discard (9), dnsmx (90), domain (53), echo (7), mobile-ip (434), nameserver (42), netbios-dgm (138), netbios-ns (137), on500-isakmp (4500), ntp (123), rip (520), snmp (161), snmptrap (162), sunrpc (111), syslog (514), tacacs-ds (49), talk (517), tftp (69), time (37), who (513), xdmcp (177). (Range: 0–65535).
- **source-port**—Specifies the UDP/TCP source port. Predefined port names are defined in the destination-port parameter. (Range: 0–65535)
- **match-all list-of-flags**—List of TCP flags that should occur. If a flag should be set, it is prefixed by "+". If a flag should be unset, it is prefixed by "-". Available options are +urg, +ack, +psh, +rst, +syn, +fin, -urg, -ack, -psh, -rst, -syn and -fin. The flags are concatenated to a one string. For example: +fin-ack.
- **time-range-name**—Name of the time range that applies to this permit statement. (Range: 1–32)

Default Configuration

No IPv4 access list is defined.

Command Mode

IP Access-list Configuration mode

User Guidelines

After an ACE is added to an access control list, an implicit **deny any** condition exists at the end of the list. That is, if there are no matches, the packets are denied. However, before the first ACE is added, the list permits all packets up to #ASIC-specific ranges for TCP and up to #ASIC-specific ranges for UDP. If a range of ports is used for source port in an ACE, it is not counted again, if it is also used for a source port in another ACE. If a range of ports is used for the destination port in an ACE, it is not counted again if it is also used for destination port in another ACE.

If a range of ports is used for source port it is counted again if it is also used for destination port.

Example

```
switchxxxxxx(config)# ip access-list extended server
switchxxxxxx(config-ip-al)# permit ip 176.212.0.0 00.255.255
```

45.3 deny (IP)

Use the **deny** IP Access-list Configuration mode command to set deny conditions for IPv4 access list. Deny conditions are also known as access control entries (ACEs).

Syntax

deny protocol {*any* | *source source-wildcard*} {*any* | *destination destination-wildcard*} [*dscp number* | *precedence number*] [*time-range time-range-name*]

deny icmp {*any* | *source source-wildcard*} {*any* | *destination destination-wildcard*} [*any* | *icmp-type*] [*any* | *icmp-code*]] [*dscp number* | *precedence number*] <*all but Cisco*> [*time-range time-range-name*]

deny igmp {*any* | *source source-wildcard*} {*any* | *destination destination-wildcard*}[*igmp-type*] [*dscp number* | *precedence number*] <*all but Cisco*> *time-range time-range-name*

deny tcp {*any* | *source source-wildcard*} {*any*|*source-port/port-range*}{*any* | *destination destination-wildcard*} {*any*|*destination-port/port-range*} [*dscp number* | *precedence number*] [*match-all list-of-flags*] <*all but Cisco*> [*time-range time-range-name*]

deny udp {*any* | *source source-wildcard*} {*any*|*source-port/port-range*} {*any* | *destination destination-wildcard*} {*any*|*destination-port/port-range*} [*dscp number* | *precedence number*][*match-all time-range-name*] [*time-range time-range-name*]

Parameters

- **protocol**—The name or the number of an IP protocol. Available protocol names: icmp, igmp, ip, tcp, egp, igp, udp, hmp, rdp, idpr, ipv6, ipv6:rout, ipv6:frag, idrp, rsvp, gre, esp, ah, ipv6:icmp, eigrp, ospf, ipinip, pim, l2tp, isis. To match any protocol, use the *ip* keyword. (Range: 0–255)
- **source**—Source IP address of the packet.
- **source-wildcard**—Wildcard bits to be applied to the source IP address. Use 1s in the bit position that you want to be ignored.
- **destination**—Destination IP address of the packet.
- **destination-wildcard**—Wildcard bits to be applied to the destination IP address. Use 1s in the bit position that you want to be ignored.
- **dscp number**—Specifies the DSCP value.
- **precedence number**—Specifies the IP precedence value.

- **icmp-type**—Specifies an ICMP message type for filtering ICMP packets. Enter a number or one of the following values: echo-reply, destination-unreachable, source-quench, redirect, alternate-host-address, echo-request, router-advertisement, router-solicitation, time-exceeded, parameter-problem, timestamp, timestamp-reply, information-request, information-reply, address-mask-request, address-mask-reply, traceroute, datagram-conversion-error, mobile-host-redirect, mobile-registration-request, mobile-registration-reply, domain-name-request, domain-name-reply, skip, photuris. (Range: 0–255)
- **icmp-code**—Specifies an ICMP message code for filtering ICMP packets. (Range: 0–255)
- **igmp-type**—IGMP packets can be filtered by IGMP message type. Enter a number or one of the following values: host-query, host-report, dvmrp, pim, cisco-trace, host-report-v2, host-leave-v2, host-report-v3. (Range: 0–255)
- **destination-port**—Specifies the UDP/TCP destination port. You can enter range of ports by using hyphen. E.g. 20 - 21. For TCP enter a number or one of the following values: bgp (179), chargen (19), daytime (13), discard (9), domain (53), drip (3949), echo (7), finger (79), ftp (21), ftp-data (20), gopher (70), hostname (42), irc (194), klogin (543), kshell (544), lpd (515), nntp (119), pop2 (109), pop3 (110), smtp (25), sunrpc (1110), syslog (514), tacacs-ds (49), talk (517), telnet (23), time (37), uucp (117), whois (43), www (80). For UDP enter a number or one of the following values: biff (512), bootpc (68), bootps (67), discard (9), dnsix (90), domain (53), echo (7), mobile-ip (434), nameserver (42), netbios-dgm (138), netbios-ns (137), non500-isakmp (4500), ntp (123), rip (520), snmp 161), snmptrap (162), sunrpc (111), syslog (514), tacacs-ds (49), talk (517), tftp (69), time (37), who (513), xdmcp (177). (Range: 0–65535)
- **source-port**—Specifies the UDP/TCP source port. Predefined port names are defined in the destination-port parameter. (Range: 0–65535)
- **match-all list-of-flags**—List of TCP flags that should occur. If a flag should be set it is prefixed by “+”. If a flag should be unset it is prefixed by “-”. Available options are +urg, +ack, +psh, +rst, +syn, +fin, -urg, -ack, -psh, -rst, -syn and -fin. The flags are concatenated to a one string. For example: +fin-ack.
- **time-range-name**—Name of the time range that applies to this permit statement. (Range: 1–32)
- **disable-port**—The Ethernet interface is disabled if the condition is matched.
- **log-input**—Specifies sending an informational syslog message about the packet that matches the entry. Because forwarding is done in hardware and logging is done in software, if a large number of packets match a deny ACE containing a log-input keyword, the software might not be able to match the hardware processing rate, and not all packets will be logged.

Default Configuration

No IPv4 access list is defined.

Command Mode

IP Access-list Configuration mode

User Guidelines

After an ACE is added to an access control list, an implicit **deny any any** condition exists at the end of the list. That is, if there are no matches, the packets are denied. However, before the first ACE is added, the list permits all packets.

The number of TCP/UDP ranges that can be defined in ACLs is limited. You can define up to #ASIC-specific ranges for TCP and up to #ASIC-specific ranges for UDP. If a range of ports is used for a source port in ACE it is not counted again if it is also used for source port in another ACE. If a range of ports is used for destination port in ACE it is not counted again if it is also used for destination port in another ACE.

If a range of ports is used for source port, it is counted again if it is also used for destination port.

Example

```
switchxxxxxx(config)# ip access-list extended server
switchxxxxxx(config-ip-acl)# deny ip 176.212.0.0 00.255.255
```

45.4 ipv6 access-list (IPv6 extended)

Use the **ipv6 access-list** Global Configuration mode command to define an IPv6 access list (ACL) and to place the device in IPv6 Access List Configuration mode. All commands after this command refer to this ACL. The rules (ACEs) for this ACL are defined in the [permit \(IPv6 \)](#) and [deny \(IPv6 \)](#) commands. The [service-acl input](#) command is used to attach this ACL to an interface.

Use the **no** form of this command to remove the access list.

Syntax

```
ipv6 access-list [acl-name]
```

```
no ipv6 access-list [acl-name]
```

Parameters

- **acl-name**—Name of the IPv6 access list. Range 1-32 characters.

Default Configuration

No IPv6 access list is defined.

Command Mode

Global Configuration mode

User Guidelines

IPv6 ACL is defined by a unique name. IPv4 ACL, IPv6 ACL, MAC ACL or policy maps cannot have the same name.

Every IPv6 ACL has an implicit **permit icmp any any nd-ns any**, **permit icmp any any nd-na any**, and **deny ipv6 any any** statements as its last match conditions. (The former two match conditions allow for ICMPv6 neighbor discovery.)

The IPv6 neighbor discovery process uses the IPv6 network layer service, therefore, by default, IPv6 ACLs implicitly allow IPv6 neighbor discovery packets to be sent and received on an interface. In IPv4, the Address Resolution Protocol (ARP), which is equivalent to the IPv6 neighbor discovery process, uses a separate data link layer protocol; therefore, by default, IPv4 ACLs implicitly allow ARP packets to be sent and received on an interface.

Example

```
Switch (config)# ipv6 access-list acl1
Switch(config-ipv6-acl)# permit tcp 2001:0DB8:0300:0201::/64 any any 80
```

45.5 permit (IPv6)

Use the **permit** command in IPv6 Access-list Configuration mode to set permit conditions (ACEs) for IPv6 ACLs.

Syntax

permit protocol {*any* | {*source-prefix/length*}{*any* | *destination- prefix/length*}} [*dscp number* | *precedence number*] [*time-range time-range-name*]

permit icmp {*any* | {*source-prefix/length*}{*any* | *destination- prefix/length*}} {*any*|*icmp-type*} {*any*|*icmp-code*} [*dscp number* | *precedence number*] <*all but Cisco*> [*time-range time-range-name*]

permit tcp {*any* | {*source-prefix/length*}} {*any* | *source-port/port-range*}} {*any* | *destination- prefix/length*}} {*any*| *destination-port/port-range*}} [*dscp number* | *precedence number*] [*match-all list-of-flags*] <*all but Cisco*> [*time-range time-range-name*]

permit udp {*any* | {*source-prefix/length*}} {*any* | *source-port/port-range*}} {*any* | *destination- prefix/length*}} {*any*| *destination-port/port-range*}} [*dscp number* | *precedence number*] <*all but Cisco*> [*time-range time-range-name*]

Parameters

- **protocol**—The name or the number of an IP protocol. Available protocol names are: icmp (58), tcp (6) and udp (17). To match any protocol, use the ipv6 keyword. (Range: 0–255)
- **source-prefix/length**—The source IPv6 network or class of networks about which to set permit conditions. This argument must be in the form documented in RFC 3513 where the address is specified in hexadecimal using 16-bit values between colons.
- **destination-prefix/length**—The destination IPv6 network or class of networks about which to set permit conditions. This argument must be in the form documented in RFC 3513 where the address is specified in hexadecimal using 16-bit values between colons.
- **dscp number**—Specifies the DSCP value. (Range: 0–63)
- **precedence number**—Specifies the IP precedence value.
- **icmp-type**—Specifies an ICMP message type for filtering ICMP packets. Enter a number or one of the following values: destination-unreachable (1), packet-too-big (2), time-exceeded (3), parameter-problem (4), echo-request (128), echo-reply (129), mld-query (130), mld-report (131), mldv2-report (143), mld-done (132), router-solicitation (133), router-advertisement (134), nd-ns (135), nd-na (136). (Range: 0–255)
- **icmp-code**—Specifies an ICMP message code for filtering ICMP packets. (Range: 0–255)
- **destination-port**—Specifies the UDP/TCP destination port. You can enter a range of ports by using a hyphen. E.g. 20 - 21. For TCP enter a number or one of the following values: bgp (179), chargen (19), daytime (13), discard (9), domain (53), drip (3949), echo (7), finger (79), ftp (21), ftp-data (20), gopher (70), hostname (42), irc (194), klogin (543), kshell (544), lpd (515), nntp (119), pop2 (109), pop3 (110), smtp (25), sunrpc (1110), syslog (514), tacacs-ds (49), talk (517), telnet (23), time (37), uucp (117), whois (43), www (80). For UDP enter a number or one of the following values: biff (512), bootpc (68), bootps (67), discard (9), dnsix (90), domain (53), echo (7), mobile-ip (434), nameserver (42), netbios-dgm (138), netbios-ns (137), non500-isakmp (4500), ntp (123), rip (520), snmp (161), snmptrap (162), sunrpc (111), syslog (514), tacacs (49), talk (517), tftp (69), time (37), who (513), xdmcp (177). (Range: 0–65535)
- **source-port**—Specifies the UDP/TCP source port. Predefined port names are defined in the destination-port parameter. (Range: 0–65535)
- **match-all list-of-flag**—List of TCP flags that should occur. If a flag should be set it is prefixed by "+". If a flag should be unset it is prefixed by "-". Available options are +urg, +ack, +psh, +rst, +syn, +fin, -urg, -ack, -psh, -rst, -syn and -fin. The flags are concatenated to a one string. For example: +fin-ack.
- **time-range-name**—Name of the time range that applies to this permit statement. (Range: 1–32)

Default Configuration

No IPv6 access list is defined.

Command Mode

Ipv6 Access-list Configuration mode

User Guidelines

The number of TCP/UDP ranges that can be defined in ACLs is limited. You can define up to #ASIC-specific ranges for TCP and up to #ASIC-specific ranges for UDP. If a range of ports is used for a source port in ACE, it is not counted again if it is also used for a source port in another ACE. If a range of ports is used for destination port in ACE it is not counted again if it is also used for destination port in another ACE.

If a range of ports is used for source port it is counted again if it is also used for destination port.

Example

This example defines an ACL by the name of server and enters a rule (ACE) for tcp packets.

```
switchxxxxxx(config)# ipv6 access-list server
switchxxxxxx(config-ipv6-al)# permit tcp 3001::2/64 any any 80
```

45.6 deny (IPv6)

Use the **deny** command in IPv6 Access List Configuration mode to set permit conditions (ACEs) for IPv6 ACLs.

Syntax

deny protocol {*any* | {*source-prefix/length*}}{*any* | *destination-prefix/length*} [*dscp number* | *precedence number*][*time-range time-range-name*] [*disable-port* | *log-input*]

deny icmp {*any* | {*source-prefix/length*}}{*any* | *destination-prefix/length*} {*any*|*icmp-type*} {*any*|*icmp-code*} [*dscp number* | *precedence number*][*time-range time-range-name*] [*disable-port* | *log-input*]

deny tcp {*any* | {*source-prefix/length*}} {*any* | *source-port/port-range*}}{*any* | *destination-prefix/length*} {*any*| *destination-port/port-range*} [*dscp number* | *precedence number*] [*match-all list-of-flags*][*time-range time-range-name*] [*disable-port* | *log-input*]

deny udp {*any* | {*source-prefix/length*}} {*any* | *source-port/port-range*}}{*any* | *destination-prefix/length*} {*any*| *destination-port/port-range*} [*dscp number* | *precedence number*][*time-range time-range-name*] [*disable-port* | *log-input*]

Parameters

- **protocol**—The name or the number of an IP protocol. Available protocol names are: icmp (58), tcp (6) and udp (17). To match any protocol, use the ipv6 keyword. (Range: 0–255)
- **source-prefix/length**—The source IPv6 network or class of networks about which to set permit conditions. This argument must be in the format documented in RFC 3513 where the address is specified in hexadecimal using 16-bit values between colons.
- **destination-prefix/length**—The destination IPv6 network or class of networks about which to set permit conditions. This argument must be in the format documented in RFC 3513 where the address is specified in hexadecimal using 16-bit values between colons.
- **dscp number**—Specifies the DSCP value. (Range: 0–63)
- **precedence number**—Specifies the IP precedence value.
- **icmp-type**—Specifies an ICMP message type for filtering ICMP packets. Enter a number or one of the following values: destination-unreachable (1), packet-too-big (2), time-exceeded (3), parameter-problem (4), echo-request (128), echo-reply (129), mld-query (130), mld-report

(131), mldv2-report (143), mld-done (132), router-solicitation (133), router-advertisement (134), nd-ns (135), nd-na (136). (Range: 0–255)

- **icmp-code**—Specifies an ICMP message code for filtering ICMP packets. (Range: 0–255)
- **destination-port**—Specifies the UDP/TCP destination port. You can enter a range of ports by using a hyphen. E.g. 20 - 21. For TCP enter a number or one of the following values: bgp (179), chargen (19), daytime (13), discard (9), domain (53), drip (3949), echo (7), finger (79), ftp (21), ftp-data (20), gopher (70), hostname (42), irc (194), klogin (543), kshell (544), lpd (515), nntp (119), pop2 (109), pop3 (110), smtp (25), sunrpc (1110), syslog (514), tacacs-ds (49), talk (517), telnet (23), time (37), uucp (117), whois (43), www (80). For UDP enter a number or one of the following values: biff (512), bootpc (68), bootps (67), discard (9), dnsix (90), domain (53), echo (7), mobile-ip (434), nameserver (42), netbios-dgm (138), netbios-ns (137), non500-isakmp (4500), ntp (123), rip (520), snmp (161), snmptrap (162), sunrpc (111), syslog (514), tacacs (49), talk (517), tftp (69), time (37), who (513), xdmcp (177). (Range: 0–65535)
- **source-port**—Specifies the UDP/TCP source port. Predefined port names are defined in the destination-port parameter. (Range: 0–65535)
- **match-all list-of-flags**—List of TCP flags that should occur. If a flag should be set it is prefixed by “+”. If a flag should be unset it is prefixed by “-”. Available options are +urg, +ack, +psh, +rst, +syn, +fin, -urg, -ack, -psh, -rst, -syn and -fin. The flags are concatenated to a one string. For example: +fin-ack.
- **time-range-name**—Name of the time range that applies to this permit statement. (Range: 1–32)
- **disable-port**—The Ethernet interface is disabled if the condition is matched.
- **log-input**—Specifies to send an informational syslog message about the packet that matches the entry. Because forwarding is done in hardware and logging is done in software, if a large number of packets match a deny ACE containing a log-input keyword, the software might not be able to match the hardware processing rate, and not all packets will be logged.

Default Configuration

No IPv6 access list is defined.

Command Mode

IPv6 Access-list Configuration mode

User Guidelines

The number of TCP/UDP ranges that can be defined in ACLs is limited. You can define up to #ASIC-specific ranges for TCP and up to #ASIC-specific ranges for UDP. If a range of ports is used for source port in ACE it is not counted again if it is also used for source port in another ACE. If a range of ports is used for a destination port in ACE it is not counted again if it is also used for a destination port in another ACE.

If a range of ports is used for source port it is counted again if it is also used for destination port.

Example

```
switchxxxxxx(config)# ipv6 access-list server
switchxxxxxx(config-ipv6-al)# deny tcp 3001::2/64 any any 80
```

45.7 mac access-list

Use the **mac access-list** Global Configuration mode command to define a Layer 2 access list (ACL) based on source MAC address filtering and to place the device in MAC Access List Configuration mode. All commands after this command refer to this ACL. The rules (ACEs) for this ACL are

defined in the [permit \(MAC \)](#) and [deny \(MAC \)](#) commands. The [service-acl input](#) command is used to attach this ACL to an interface.

Use the **no** form of this command to remove the access list.

Syntax

mac access-list extended *acl-name*

no mac access-list extended *acl-name*

Parameters

acl-name—Specifies the name of the MAC ACL (Range: 1–32 characters).

Default Configuration

No MAC access list is defined.

Command Mode

Global Configuration mode

User Guidelines

A MAC ACL is defined by a unique name. IPv4 ACL, IPv6 ACL, MAC ACL or policy maps cannot have the same name.

Example

```
switchxxxxxx(config)# mac access-list extended server1
switchxxxxxx(config-mac-acl)# permit 00:00:00:00:00:01 00:00:00:00:00:ff any
```

45.8 permit (MAC)

Use the **permit** command in MAC Access List Configuration mode to set permit conditions (ACEs) for a MAC ACL.

Syntax

permit {*any* | *source source-wildcard*} {*any* | *destination destination-wildcard*} [*eth-type 0* | *aarp* | *amber* | *dec-spanning* | *decnet-iv* | *diagnostic* | *dsm* | *etype-6000*] [*vlan vlan-id*] [*cos cos cos-wildcard*] [*time-range time-range-name*]

Parameters

- **source**—Source MAC address of the packet.
- **source-wildcard**—Wildcard bits to be applied to the source MAC address. Use 1s in the bit position that you want to be ignored.
- **destination**—Destination MAC address of the packet.
- **destination-wildcard**—Wildcard bits to be applied to the destination MAC address. Use 1s in the bit position that you want to be ignored.
- **eth-type**—The Ethernet type in hexadecimal format of the packet.
- **vlan-id**—The VLAN ID of the packet. (Range: 1–4094)
- **cos**—The Class of Service of the packet. (Range: 0–7)
- **cos-wildcard**—Wildcard bits to be applied to the CoS.

- **time-range-name**—Name of the time range that applies to this permit statement. (Range: 1–32)

Default Configuration

No MAC access list is defined.

Command Mode

MAC Access-list Configuration mode

User Guidelines

After an access control entry (ACE) is added to an access control list, an implicit **deny any any** condition exists at the end of the list. That is, if there are no matches, the packets are denied. However, before the first ACE is added, the list permits all packets.

Example

```
switchxxxxxx(config)# mac access-list extended server1
switchxxxxxx(config-mac-al)# permit 00:00:00:00:00:01 00:00:00:00:00:ff any
```

45.9 deny (MAC)

Use the **deny** command in MAC Access List Configuration mode to set deny conditions (ACEs) for a MAC ACL.

Syntax

deny {*any* | *source source-wildcard*} {*any* | *destination destination-wildcard*} [*eth-type 0*] **aarp** | **amber** | **dec-spanning** | **decnet-iv** | **diagnostic** | **dsm** | **etype-6000**] [*vlan vlan-id*] [*cos cos cos-wildcard*][*time-range time-range-name*] [*disable-port* | *log-input*]

Parameters

- **source**—Source MAC address of the packet.
- **source-wildcard**—Wildcard bits to be applied to the source MAC address. Use ones in the bit position that you want to be ignored.
- **destination**—Destination MAC address of the packet.
- **destination-wildcard**—Wildcard bits to be applied to the destination MAC address. Use 1s in the bit position that you want to be ignored.
- **eth-type**—The Ethernet type in hexadecimal format of the packet.
- **vlan-id**—The VLAN ID of the packet. (Range: 1–4094)
- **cos**—The Class of Service of the packet. (Range: 0–7)
- **cos-wildcard**—Wildcard bits to be applied to the CoS.
- **time-range-name**—Name of the time range that applies to this permit statement. (Range: 1–32)
- **disable-port**—The Ethernet interface is disabled if the condition is matched.
- **log-input**—Sends an informational syslog message about the packet that matches the entry. Because forwarding is done in hardware and logging is done in software, if a large number of packets match a deny ACE containing a log-input keyword, the software might not be able to match the hardware processing rate, and not all packets will be logged.

Default Configuration

No MAC access list is defined.

Command Mode

MAC Access-list Configuration mode

User Guidelines

After an access control entry (ACE) is added to an access control list, an implicit **deny any any** condition exists at the end of the list. That is, if there are no matches, the packets are denied. However, before the first ACE is added, the list permits all packets.

Example

```
switchxxxxxx(config)# mac access-list extended server1
switchxxxxxx(config-mac-al)# deny 00:00:00:00:00:01 00:00:00:00:00:ff any
```

45.10 service-acl input

Use the **service-acl input** command in interface Configuration mode to bind an access list(s) (ACL) to an interface.

Use the **no** form of this command to remove all ACLs from the interface.

Syntax

service-acl input *acl-name1* [*acl-name2*]

no service-acl input

Parameters

acl-name—Specifies an ACL to apply to the interface. See the user guidelines. (Range: 1–32 characters).

Default Configuration

No ACL is assigned.

Command Mode

Interface Configuration (Ethernet, Port-Channel) mode.

User Guidelines

The following rules govern when ACLs can be bound or unbound from an interface:

- IPv4 ACLs and IPv6 ACLs can be bound together to an interface.
- A MAC ACL cannot be bound on an interface which already has an IPv4 ACL or IPv6 ACL bound to it.
- Two ACLs of the same type cannot be bound to a port.
- An ACL cannot be bound to a port that is already bound to an ACL, without first removing the current ACL. Both ACLs must be mentioned at the same time in this command.

Example

```
switchxxxxxx(config)# mac access-list extended server-acl
switchxxxxxx(config-mac-al)# permit 00:00:00:00:00:01 00:00:00:00:00:ff any
switchxxxxxx(config-mac-al)# exit
```

```
switchxxxxxx(config)# interface fe1/0/11
switchxxxxxx(config-if)# service-acl input server-acl
```

45.11 service-acl output

Use the **service-acl output** command in Interface Configuration mode to control access to an interface on the Egress (transmit path). Use the **no** form of this command to remove the access control.

Syntax

```
service-acl output acl-name1 [acl-name2]
no service-acl output
```

Parameters

acl-name—Specifies an ACL to apply to the interface. See the usage guidelines. (Range: acl-name 0–32 characters. Use "" for empty string)

Default

No ACL is assigned.

Command Mode

Interface Configuration (Ethernet, Port-Channel) mode.

User Guidelines

The deny rule actions - **log-input** and **disable-port** are not supported. Trying to use these actions will result in an error.

IPv4 ACL and IPv6 ACL can be bound together on an interface.

A MAC ACL cannot be bound on an interface together with an IPv4 ACL or IPv6 ACL.

Two ACLs of the same type cannot be added to a port.

An ACL cannot be added to a port that is already bounded to an ACL, without first removing the current ACL and binding the two ACLs together.

Example

This example binds an Egress ACL to a port:

```
switchxxxxxx(config)# mac access-list extended server
switchxxxxxx(config-mac-acl)# permit 00:00:00:00:00:01 00:00:00:00:00:ff any
switchxxxxxx(config-mac-acl)# exit
switchxxxxxx(config)# interface fe1/0/11
switchxxxxxx(config-if)# service-acl output server
```

45.12 service-acl input block

Use the **service-acl input block** Interface Configuration mode commands to discard packets that are classified to specific protocols. Use the **no** form of those commands to disable discarding of the packets.

Syntax

service-acl input block *protocol1* [*protocol2* ... *protocol6*]

no service-acl input

Parameters

protocol—Specifies a protocol to filter. Available values are: blockcdp, blockvtp, blockdtp, blockudld, blockpagp, blocksstp, and blockall.

Default Configuration

No protocol is defined.

Command Mode

Interface Configuration ((Ethernet, Port-Channel) mode)

User Guidelines

If you want to define multiple protocols on the same interface, those protocols should be defined in the same command.

To change configuration of the protocol filtering for an interface, you should first remove the current assignment of protocol filtering assignment, and then assign the new configuration of the protocol filtering.

If Proprietary Protocol Filtering rules are assigned on an interface, the user is not able to assign ACL or Policy Map or Security suite rules to that interface and to enable 802.1X Dynamic Policy Assignment to that interface.

If ACL or Policy Map or Security suite rules are assigned to an interface or 802.1X Dynamic Policy Assignment is enabled for an interface, the user is not able to assign Proprietary Protocol Filtering rules to that interface.

The following table defines the DA and protocol types of the packets that are subject for discarding per each command:

Command	Destination Address	Protocol Type
blockcdp	0100.0ccc.cccc	0x2000
blockvtp	0100.0ccc.cccc	0x2003
blockdtp	0100.0ccc.cccc	0x2004
blockudld	0100.0ccc.cccc	0x0111
blockpagp	0100.0ccc.cccc	0x0104
blocksstp	0100.0ccc.cccd	-
blockall	0100.0ccc.cccc0 - 0100.0ccc.cccf	-

Example

```
switchxxxxxx(Config-if) # service-acl input blockcdp blockvtp
```

45.13 time-range

Use the **time-range** Global Configuration mode command to define time ranges for functions or ACLs. In addition, this command enters the Time-range Configuration mode. All commands after this one refer to the time-range being defined.

This command sets a time-range name. Use the **absolute** and **periodic** commands to actually configure the time-range.

Use the **no** form of this command to remove the time range from the device.

Syntax

time-range *time-range-name*

no time-range *time-range-name*

Parameters

time-range-name—Specifies the name for the time range. (Range: 1–32 characters)

Default Configuration

No time range is defined

Command Mode

Global Configuration mode

User Guidelines

After the time-range command, use the **absolute** and **periodic** commands to actually configure the time-range. Multiple periodic commands are allowed in a time range. Only one absolute command is allowed.

If a time-range command has both absolute and periodic values specified, then the periodic items are evaluated only after the absolute start time is reached, and are not evaluated again after the absolute end time is reached.

All time specifications are interpreted as local time.

To ensure that the time range entries take effect at the desired times, the software clock should be set by the user or by SNTP. If the software clock is not set by the user or by SNTP, the time range ACEs are not activated.

The user cannot delete a time-range that is bound to any features, such as ACLs.

Example

```
switchxxxxxx(config)# time-range http-allowed
switchxxxxxx(config-time-range)# absolute start 12:00 1 jan 2005 end 12:00 31 dec
2005 switchxxxxxx(config-time-range)# periodic monday 8:00 to friday 20:00
```

45.14 absolute

Use the **absolute** Time-range Configuration mode command to specify an absolute time when a time range is in effect. Use the **no** form of this command to remove the time limitation.

Syntax**absolute start** *hh:mm day month year***no absolute start****absolute end** *hh:mm day month year***no absolute end****Parameters**

- **start**—Absolute time and date that the permit or deny statement of the associated function going into effect. If no start time and date are specified, the function is in effect immediately.
- **end**—Absolute time and date that the permit or deny statement of the associated function is no longer in effect. If no end time and date are specified, the function is in effect indefinitely.
- **hh:mm**—Time in hours (military format) and minutes (Range: 0–23, mm: 0–5)
- **day**—Day (by date) in the month. (Range: 1–31)
- **month**—Month (first three letters by name). (Range: Jan...Dec)
- **year**—Year (no abbreviation) (Range: 2000–2097)

Default Configuration

There is no absolute time when the time range is in effect.

Command Mode

Time-range Configuration mode

Example

```
switchxxxxxx(config)# time-range
switchxxxxxx(config-time-range)# absolute start 12:00 1 jan 2005
switchxxxxxx(config-time-range)# absolute end 12:00 31 dec 2005
```

45.15 periodic

Use the **periodic** Time-range Configuration mode command to specify a recurring (weekly) time range for functions that support the time-range feature. Use the **no** form of this command to remove the time limitation.

Syntax**periodic** *day-of-the-week hh:mm to day-of-the-week hh:mm***no periodic** *day-of-the-week hh:mm to day-of-the-week hh:mm***periodic list** *hh:mm to hh:mm day-of-the-week1 [day-of-the-week2... day-of-the-week7]***no periodic list** *hh:mm to hh:mm day-of-the-week1 [day-of-the-week2... day-of-the-week7]***periodic list** *hh:mm to hh:mm all***no periodic list** *all hh:mm to hh:mm all***Parameters**

- **day-of-the-week**—The starting day that the associated time range is in effect. The second occurrence is the ending day the associated statement is in effect. The second occurrence can

be the following week (see description in the User Guidelines). Possible values are: Monday, Tuesday, Wednesday, Thursday, Friday, Saturday, and Sunday.

- **hh:mm**—The first occurrence of this argument is the starting hours:minutes (military format) that the associated time range is in effect. The second occurrence is the ending hours:minutes (military format) the associated statement is in effect. The second occurrence can be at the following day (see description in the User Guidelines). (Range: 0–23, mm: 0–59)
- **list day-of-the-week1**—Specifies a list of days that the time range is in effect.

Default Configuration

There is no periodic time when the time range is in effect.

Command Mode

Time-range Configuration mode

User Guidelines

The second occurrence of the day can be at the following week, e.g. Thursday–Monday means that the time range is effective on Thursday, Friday, Saturday, Sunday, and Monday.

The second occurrence of the time can be on the following day, e.g. “22:00–2:00”.

Example

```
switchxxxxxx(config)# time-range
switchxxxxxx(config-time-range)# periodic Monday 12:00 to Wednesday 12:00
```

45.16 show time-range

Use the **show time-range** EXEC command to display the time range configuration.

Syntax

show time-range *time-range-name*

Parameters

time-range-name—Specifies the name of an existing time range.

Command Mode

EXEC mode

Example

```
switchxxxxxx# show time-range
http-allowed
-----
absolute start 12:00 1 jan 2005
absolute end 12:00 31 dec 2005
periodic monday 8:00 to friday 20:00
```

45.17 show access-lists

Use the **show access-lists** Privileged EXEC mode command to display access control lists (ACLs) configured on the switch.

Syntax

show access-lists [*name*]

show access-lists *time-range-active* [*name*]

Parameters

- **name**—Specifies the name of the ACL.
- **time-range-active**—Shows only the Access Control Entries (ACEs) whose time-range is currently active (including those that are not associated with time-range).

Command Mode

Privileged EXEC mode

Example

```
switchxxxxxx#show access-lists
Standard IP access list 1
deny any any
Standard IP access list 2
deny 192.168.0.0/24
permit any any
Standard IP access list 3
deny 192.168.0.1 10.0.0.0/8
permit any any
Standard IP access list ACL1
permit 192.168.0.0/16 10.1.1.1
Extended IP access list ACL2
permit 234 172.30.19.1 0.0.0.255 any time-range weekdays
permit 234 172.30.23.8 0.0.0.255 any time-range weekdays
```

```
switchxxxxxx#show access-lists time-range-active
Extended IP access list ACL1
permit 234 172.30.40.1 0.0.0.0 any
permit 234 172.30.8.8 0.0.0.0 any
Extended IP access list ACL2
permit 234 172.30.19.1 0.0.0.255 any time-range weekdays
```

```
switchxxxxxx#show access-lists ACL1
Standard IP access list ACL1
permit 0.0.0.0
```

```
permit 192.168.0.2, wildcard bits 0.0.0.255
Extended IP access list ACL1
permit 234 172.30.40.1 0.0.0.0 any
permit 234 172.30.8.8 0.0.0.0 any
```

45.18 show interfaces access-lists

Use the **show interfaces access-lists** Privileged EXEC mode command to display access lists (ACLs) applied on interfaces.

Syntax

show interfaces access-lists [*interface-id*]

Parameters

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port, port-channel or VLAN.

Command Mode

Privileged EXEC mode

Example

```
Console# show interfaces access-lists
Interface Ingress ACL          Egress ACL
-----
fe1/0/11      ACL1                ACL2
fe1/0/12      ACL3
fe1/0/13      blockcdp, blockvtp
```

45.19 clear access-lists counters

Use the **clear access-lists counters** Privileged EXEC mode command to clear access-lists (ACLs) counters.

Syntax

clear access-lists counters [*interface-id*]

Parameters

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or port-channel.

Command Mode

Privileged EXEC mode

Example

```
switchxxxxxx# clear access-lists counters fe1/0/11
```

45.20 show interfaces access-lists counters

Use the **show interfaces access-lists counters** Privileged EXEC mode command to display Access List (ACLs) counters.

Syntax

```
show interfaces access-lists counters [interface-id | port-channel-number]
```

Parameters

interface-id—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port or port-channel.

Command Mode

Privileged EXEC mode

User Guidelines

The deny ACE hits count includes only ACEs with the log-input keyword.

Because forwarding is done in hardware and counting is done in software, if a large number of packets match a deny ACE containing a log-input keyword, the software might not be able to match the hardware processing rate, and not all packets are counted.

Example

```
switchxxxxxx# show interfaces access-lists counters
```

```
Interface          Deny ACE Hits
-----          -
fe1/0/11           79
fe1/0/12           9
fe1/0/13           0
```

```
Number of hits that were counted in global counter (due to lack of resources) =19
```

46 Quality of Service (QoS) Commands

46.1 qos

Use the **qos** Global Configuration mode command to enable QoS on the device and set its mode. Use the **no** form of this command to disable QoS on the device.

Syntax

qos [*basic* | *advanced* [*ports-not-trusted* | *ports-trusted*]]

no qos

Parameters

- **basic**—QoS basic mode. If no option is specified, the QoS mode defaults to the basic mode.
- **advanced**—Specifies the QoS advanced mode, which enables the full range of QoS configuration.
- **ports-not-trusted**—Relevant for advanced mode only. Indicates that packets, which are not classified by policy map rules to a QoS action, are mapped to egress queue 0. This is the default setting in advanced mode.
- **ports-trusted**—Relevant for advanced mode only. Indicates that packets, which are not classified by policy map rules to a QoS action, are mapped to an egress queue based on the packet's fields. Use the [qos advanced-mode trust](#) command to specify the trust mode.

Default Configuration

If **qos** is entered without any keywords, the QoS **basic** mode is **enabled**.

If **qos advanced** is entered without a keyword, the default is **ports-not-trusted**.

Command Mode

Global Configuration mode

Examples

Example 1- The following example enables QoS basic mode on the device.

```
switchxxxxxx(config)# qos
```

Example 2 - The following example enables QoS advanced mode on the device with the **ports-not-trusted** option.

```
switchxxxxxx(config)# qos advanced
```

46.2 qos advanced-mode trust

Use the **qos advanced-mode trust** Global Configuration command to configure the trust mode in advanced mode. Use the **no** form of this command to return to default.

Syntax

qos advanced-mode trust {*cos* | *dscp* | *cos-dscp*}

no qos advanced-mode trust

Parameters

- **cos**—Classifies ingress packets with the packet CoS values. For untagged packets, the port default CoS is used.
- **dscp**—Classifies ingress packets with the packet DSCP values.
- **cos-dscp**—Classifies ingress packets with the packet DSCP values for IP packets. For other packet types, use the packet CoS values.

Default Configuration

cos-dscp

Command Mode

Global Configuration

User Guidelines

The configuration is relevant for advanced mode in the following cases:

- **ports-not-trusted mode**: For packets that are classified to the QoS action trust.
- **ports-trusted mode**: For packets that are not classified by to any QoS action or classified to the QoS action trust.

Example

The following example sets **cos** as the trust mode for QoS on the device.

```
switchxxxxxx(config)# qos advanced-mode trust cos
```

46.3 show qos

Use the **show qos** EXEC mode command to display the QoS information for the device. The trust mode is displayed for the QoS basic mode.

Syntax

show qos

Parameters

N/A

Default Configuration

Disabled Command Mode

Command Mode

EXEC mode

User Guidelines

Trust mode is displayed if QoS is enabled in basic mode.

Examples

Example 1 - The following example displays QoS attributes when QoS is enabled in basic mode and the advanced mode is supported.

```
switchxxxxxx# show qos
Qos: basic
Basic trust: dscp
```

Example 2 - The following example displays QoS attributes when QoS is enabled in basic mode on the device and the advanced mode is not supported.

```
switchxxxxxx# show qos
Qos: disable
Trust: dscp
```

46.4 class-map

The **class-map** command and its subcommands are used to define packet classification, marking, and aggregate policing as part of a globally-named service policy applied on a per-interface basis.

A class map consists of one or more ACLs (see [ACL Commands](#)). It defines a traffic flow by determining which packets match some or all of the criteria specified in the ACLs.

Use the **class-map** Global Configuration mode command to create or modify a class map and enter the Class-map Configuration mode (only possible when QoS is in the advanced mode).

Use the **no** form of this command to delete a class map.

All class map commands are only available when QoS is in advanced mode.

Syntax

class-map *class-map-name* [*match-all* | *match-any*]

no class-map *class-map-name*

Parameters

- **class-map-name**—Specifies the class map name.
- **match-all**—Performs a logical AND of all the criteria of the ACLs belonging to this class map. All match criteria in this class map must be matched.
- **match-any**—Performs a logical OR of the criteria of the ACLs belonging to this class map. Only a single match criteria in this class map must be matched.

Default Configuration

If neither **match-all** nor **match-any** is specified, the **match-all** parameter is selected by default.

Command Mode

Global Configuration mode

User Guidelines

The **class-map** enters Class-map Configuration mode. In this mode, up to two **match** commands can be entered to configure the criteria for this class. Each **match** specifies an ACL.

When using two **match** commands, each must point to a different type of ACL, such as: one IP ACL and one MAC ACL. The classification is by first match, therefore, the order of the ACLs is important.

Error messages are generated in the following cases:

- There is more than one **match** command in a **match-all** class map
- There is a repetitive classification field in the participating ACLs.

After entering the Class-map Configuration mode, the following configuration commands are available:

- **exit**: Exits the Class-map Configuration mode.
- **match**: Configures classification criteria.
- **no**: Removes a match statement from a class map.

Example

The following example creates a class map called Class1 and configures it to check that packets match all classification criteria in the ACL specified.

```
switchxxxxxx(config)# class-map class1 match-all
switchxxxxxx(config-cmap)#match access-group acl-name
```

46.5 show class-map

The **show class-map** EXEC mode command displays all class maps when QoS is in advanced mode.

Syntax

show class-map [*class-map-name*]

Parameters

class-map-name—Specifies the name of the class map to be displayed.

Command Mode

EXEC mode

Example

The following example displays the class map for Class1.

```
switchxxxxxx# show class-map class1
Class Map match-any class1 (id4)
Match IP dscp 11 21
```

46.6 match

Use the **match** Class-map Configuration mode command to bind the ACLs that belong to the class-map being configured. Use the **no** form of this command to delete the ACLs.

This command is available only when the device is in QoS advanced mode.

Syntax

match access-group *acl-name*

no match access-group *acl-name*

Parameters

acl-name—Specifies the MAC or IP ACL name.

Default Configuration

No match criterion is supported.

Command Mode

Class-map Configuration mode.

Example

The following example defines a class map called Class1. Class1 contains an ACL called **enterprise**. Only traffic matching all criteria in **enterprise** belong to the class map.

```
switchxxxxxx(config)# class-map class1  
switchxxxxxx(config-cmap)# match access-group enterprise
```

46.7 policy-map

A policy map contains one or more class maps and an action that is taken if the packet matches the class map. Policy maps may be bound to ports/port-channels.

Use the **policy-map** Global Configuration mode command to create a policy map and enter the Policy-map Configuration mode. Use the **no** form of this command to delete a policy map.

This command is only available when QoS is in advanced mode.

Syntax

policy-map *policy-map-name*

no policy-map *policy-map-name*

Parameters

policy-map-name—Specifies the policy map name.

Default Configuration

N/A

Command Mode

Global Configuration mode

User Guidelines

Use the **policy-map** Global Configuration mode command to specify the name of the policy map to be created, added to, or modified before configuring policies for classes whose match criteria are defined in a class map.

Entering the [policy-map](#) Global Configuration mode command also enables configuring or modifying the class policies for that policy map. Class policies in a policy map can be configured only if the classes have match criteria defined for them.

Policy map is applied on the ingress path.

The match criteria is for a class map. Only one policy map per interface is supported. The same policy map can be applied to multiple interfaces and directions.

The [service-policy](#) command binds a policy map to a port/port-channel.

Example

The following example creates a policy map called Policy1 and enters the Policy-map Configuration mode.

```
switchxxxxxx(config)# policy-map policy1
switchxxxxxx(config-pmap)#
```

46.8 class

Use the **class** Policy-map Configuration mode command after the [policy-map](#) command to attach ACLs to a policy-map.

Use the **no** form of this command to detach a class map from a policy map.

This command is only available when QoS is in advanced mode.

Syntax

class *class-map-name* [**access-group** *acl-name*]

no class *class-map-name*

Parameters

- **class-map-name**—Specifies the name of an existing class map. If the class map does not exist, a new class map is created under the specified name.
- **access-group** *acl-name*—Specifies the name of an IP or MAC Access Control List (ACL).

Default Configuration

No class map is defined for the policy map.

Command Mode

Policy-map Configuration mode

User Guidelines

This is the same as creating a class map and then binding it to the policy map.

You can specify an existing class map in this command, or you can use the **access-group** parameter to create a new class map.

After the policy-map is defined, use the [service-policy](#) command to attach it to a port/port-channel.

Example

The following example defines a traffic classification (class map) called **class1** containing an ACL called **enterprise**. The class is in a policy map called **policy1**. The policy-map **policy1** now contains the ACL **enterprise**.

```
switchxxxxxx(config)# policy-map policy1
switchxxxxxx(config-pmap)# class class1 access-group enterprise
```

46.9 show policy-map

Use the **show policy-map** EXEC mode command to display all policy maps or a specific policy map.

This command is only available when QoS is in advanced mode.

Syntax

show policy-map [*policy-map-name*]

Parameters

policy-map-name—Specifies the policy map name.

Default Configuration

All policy-maps are displayed.

Command Mode

EXEC mode

Example

The following example displays all policy maps.

```
switchxxxxxx# show policy-map
Policy Map policy1
class class1
set IP dscp 7
Policy Map policy2
class class 2
police 96000 4800 exceed-action drop
class class3
police 124000 96000 exceed-action policed-dscp-transmit
```

46.10 trust

Use the **trust** Policy-map Class Configuration mode command to configure the trust state. This command is relevant only when QoS is in advanced, ports-not-trusted mode. Trust indicates that traffic is sent to the queue according to the packet's QoS parameters (UP or DSCP).

Use the **no** form of this command to return to the default trust state.

This command is only available when QoS is in advanced mode.

Syntax

trust

no trust

Parameters

N/A

Default Configuration

The default state is according to the mode selected in the [qos](#) command (advanced mode). The type of trust is determined in [qos advanced-mode trust](#).

Command Mode

Policy-map Class Configuration mode

User Guidelines

Use this command to distinguish the QoS trust behavior for certain traffic from others. For example, incoming traffic with certain DSCP values can be trusted. A class map can be configured to match and trust the DSCP values in the incoming traffic.

The type of trust is determined in [qos advanced-mode trust](#).

Trust values set with this command supersede trust values set on specific interfaces with the [qos trust \(Interface\)](#) Interface Configuration mode command.

The [trust](#) and [set](#) commands are mutually exclusive within the same policy map.

Policy maps, which contain [set](#) or [trust](#) commands or that have ACL classification to an egress interface, cannot be attached by using the [service-policy](#) Interface Configuration mode command.

If specifying [trust cos](#), QoS maps a packet to a queue, the received or default port CoS value, and the CoS-to-queue map.

Example

The following example creates an ACL, places it into a class map, places the class map into a policy map and configures the trust state using the DSCP value in the ingress packet.

```
switchxxxxxx(config)# ip access-list extended ip1
switchxxxxxx(config-mac-a1)# permit ip any any
switchxxxxxx(config-mac-a1)# exit
switchxxxxxx(config)# class-map c1
switchxxxxxx(config-cmap)# match access-group ip1
switchxxxxxx(config-cmap)# exit
switchxxxxxx(config)# policy-map p1
switchxxxxxx(config-pmap)# class c1
switchxxxxxx(config-pmap-c)# trust
```

46.11 set

Use the [set](#) Policy-map Class Configuration mode command to select the value that QoS uses as the DSCP value, the egress queue or to set user priority values.

This command is only available when QoS is in advanced mode.

Syntax

set {*dscp new-dscp* | *queue queue-id* | *cos new-cos*}

no set

Parameters

- **dscp** *new-dscp*—Specifies the new DSCP value for the classified traffic. (Range: 0–63)
- **queue** *queue-id*—Specifies the egress queue. (Range: 1-8)
- **cos** *new-cos*—Specifies the new user priority to be marked in the packet. (Range: 0–15)

Command Mode

Policy-map Class Configuration mode

User Guidelines

The **set** and **trust** commands are mutually exclusive within the same policy map.

To return to the Configuration mode, use the **exit** command. To return to the Privileged EXEC mode, use the **end** command.

Example

The following example creates an ACL, places it into a class map, places the class map into a policy map and sets the DSCP value in the packet to 56 for classes in the policy map called p1.

```
switchxxxxxx(config)# ip access-list extended ip1
switchxxxxxx(config-mac-acl)# permit ip any any
switchxxxxxx(config-mac-acl)# exit
switchxxxxxx(config)# class-map c1
switchxxxxxx(config-cmap)# match access-group ip1
switchxxxxxx(config-cmap)# exit
switchxxxxxx(config)# policy-map p1
switchxxxxxx(config-pmap)# class c1
switchxxxxxx(config-pmap-c)# set dscp 56
```

46.12 police

Use the **police** Policy-map Class Configuration mode command to define the policer for classified traffic. This defines another group of actions for the policy map (per class map).

This command is used after the **policy-map** and **class** commands.

Use the **no** form of this command to remove a policer.

This command is only available when QoS is in advanced mode.

Syntax

police *committed-rate-kbps committed-burst-byte* [*exceed-action* {*drop* | *policed-dscp-transmit*}]

no police

Parameters

- **committed-rate-kbps**—Specifies the average traffic rate (CIR) in kbits per second (bps). (Range: 3–10000000)
- **committed-burst-byte**—Specifies the normal burst size (CBS) in bytes. (Range: 3000–19173960)
- **exceed-action {drop | policed-dscp-transmit}**—Specifies the action taken when the rate is exceeded. The possible values are:
 - **drop**—Drops the packet.
 - **policed-dscp-transmit**—Remarks the packet DSCP, according to the policed-DSCP map as configured by the **qos map policed-dscp** Global Configuration mode command.

Default Usage

N/A

Command Mode

Policy-map Class Configuration mode

User Guidelines

This command only exists in when the device is in Layer 2 mode.

Policing uses a token bucket algorithm. CIR represents the speed with which the token is added to the bucket. CBS represents the depth of the bucket.

Example

The following example defines a policer for classified traffic. When the traffic rate exceeds 124,000 kbps and the normal burst size exceeds 9600 bytes, the packet is dropped. The class is called `class1` and is in a policy map called `policy1`.

```
switchxxxxxx(config)# policy-map policy1
switchxxxxxx(config-pmap)# class class1
switchxxxxxx(config-pmap-c)# police 124000 9600 exceed-action drop
```

46.13 service-policy

Use the **service-policy** Interface Configuration (Ethernet, Port-channel) mode command to bind a policy map to a port/port-channel. Use the **no** form of this command to detach a policy map from an interface.

This command is only available in QoS advanced mode.

Syntax

```
service-policy input policy-map-name
no service-policy input
```

Parameters

policy-map-name—Specifies the policy map name to apply to the input interface. (Length: 1–32 characters)

Command Mode

Interface Configuration (Ethernet, Port-channel) mode

User Guidelines

Only one policy map per interface per direction is supported.

Example

The following example attaches a policy map called Policy1 to the input interface.

```
switchxxxxxx(config-if) # service-policy input policy1
```

46.14 qos aggregate-policer

Use the **qos aggregate-policer** Global Configuration mode command to define the policer parameters that can be applied to multiple traffic classes. Use the **no** form of this command to remove an existing aggregate policer.

This command is only available when QoS is in advanced mode.

Syntax

qos aggregate-policer *aggregate-policer-name* *committed-rate-kbps* *excess-burst-byte* [*exceed-action* {*drop* | *policed-dscp-transmit*}]

no qos aggregate-policer *aggregate-policer-name*

Parameters

- **aggregate-policer-name**—Specifies the aggregate policer name.
- **committed-rate-kbps**—Specifies the average traffic rate (CIR) in kbits per second (kbps). (Range: 3–57982058)
- **excess-burst-byte**—Specifies the normal burst size (CBS) in bytes. (Range: 3000–19173960)
- **exceed-action** {*drop* | *policed-dscp-transmit*}—Specifies the action taken when the rate is exceeded. The possible values are:
 - **drop**—Drops the packet.
 - **policed-dscp-transmit**—Remarks the packet DSCP.

Default Configuration

No aggregate policer is defined.

Command Mode

Global Configuration mode

User Guidelines

This command only exists when the device is in Layer 2.

Define an aggregate policer if the policer aggregates traffic from multiple class maps.

Aggregate policers cannot aggregate traffic from multiple devices. If the aggregate policer is applied to more than one device, the traffic on each device is counted separately and is limited per device.

Traffic from two different ports on the same device can be aggregated for policing purposes.

An aggregate policer can be applied to multiple classes in the same policy map.

An aggregate policer cannot be deleted if it is being used in a policy map. The **no police aggregate** Policy-map Class Configuration mode command must first be used to delete the aggregate policer from all policy maps before using the **no mls qos aggregate-policer** command.

Policing uses a token bucket algorithm. CIR represents the speed with which the token is added to the bucket. CBS represents the depth of the bucket.

Example

The following example defines the parameters of a policer called Policer1 that can be applied to multiple classes in the same policy map. When the average traffic rate exceeds 124,000 kbps or the normal burst size exceeds 9600 bytes, the packet is dropped.

```
switchxxxxxx(config)# qos aggregate-policer policer1 124000 9600
exceed-action drop
```

46.15 show qos aggregate-policer

Use the **show qos aggregate-policer** EXEC mode command to display aggregate policers

This command is only available in QoS advanced mode.

Syntax

show qos aggregate-policer [*aggregate-policer-name*]

Parameters

aggregate-policer-name—Specifies the aggregate policer name.

Default Configuration

All policers are displayed.

Command Mode

EXEC mode

Example

The following example displays the parameters of the aggregate policer called Policer1.

```
switchxxxxxx# show qos aggregate-policer policer1
aggregate-policer policer1 96000 4800 exceed-action drop
not used by any policy map
```

46.16 police aggregate

Use the **police aggregate** Policy-map Class Configuration mode command to apply an aggregate policer to multiple class maps within the same policy map. Use the **no** form of this command to remove an existing aggregate policer from a policy map.

This command is only available in QoS advanced mode.

Syntax

police aggregate *aggregate-policer-name*

no police aggregate *aggregate-policer-name*

Parameters

aggregate-policer-name—Specifies the aggregate policer name.

Command Mode

Policy-map Class Configuration mode

User Guidelines

An aggregate policer can be applied to multiple classes in the same policy map. An aggregate policer cannot be applied across multiple policy maps or interfaces.

Use the **exit** command to return to the Configuration mode. Use the **end** command to return to the Privileged EXEC mode.

Example

The following example applies the aggregate policer called Policer1 to a class called class1 in a policy map called policy1 and class2 in policy map policy2.

```
switchxxxxxx(config)# qos aggregate-policer policer1 124000 9600
exceed-action drop
switchxxxxxx(config)# policy-map policy1
switchxxxxxx(config-pmap)# class class1
switchxxxxxx(config-pmap-c)# police aggregate policer1
switchxxxxxx(config-pmap-c)# exit
switchxxxxxx(config-pmap)# exit
switchxxxxxx(config)# policy-map policy2
switchxxxxxx(config-pmap)# class class2
switchxxxxxx(config-pmap-c)# police aggregate policer1
```

46.17 wrr-queue cos-map

Use the **wrr-queue cos-map** Global Configuration mode command to map Class of Service (CoS) values to a specific egress queue. Use the **no** form of this command to restore the default configuration.

Syntax

wrr-queue cos-map *queue-id cos0... cos7*

no wrr-queue cos-map [*queue-id*]

Parameters

- **queue-id**—Specifies the queue number to which the CoS values are mapped.
- **cos0... cos7**—Specifies up to 8 CoS values to map to the specified queue number. (Range: 0–7)

Default Configuration

[8 queues]The default CoS value mapping to 8 queues is as follows:

CoS value 0 is mapped to queue 3.

CoS value 1 is mapped to queue 1.

CoS value 2 is mapped to queue 2.

CoS value 3 is mapped to queue 4.

CoS value 4 is mapped to queue 5.

CoS value 5 is mapped to queue 6.

CoS value 6 is mapped to queue 7.

CoS value 7 is mapped to queue 8.

Command Mode

Global Configuration mode

User Guidelines

Use this command to distribute traffic to different queues.

Example

The following example maps CoS value 4 and 6 to queue 2.

```
switchxxxxxx(config)# wrr-queue cos-map 2 4 6
```

46.18 wrr-queue bandwidth

Use the **wrr-queue bandwidth** global Configuration command to assign Weighted Round Robin (WRR) weights to egress queues. The weight ratio determines the frequency at which the packet scheduler removes packets from each queue. Use the **no** form of this command to restore the default configuration.

Syntax

wrr-queue bandwidth *weight1 weight2... weighting*

no wrr-queue bandwidth

Parameters

weight1 weight1... weighting the ratio of bandwidth assigned by the WRR packet scheduler to the packet queues. See explanation in the User Guidelines. Separate each value by a space. (Range for each weight: 0–255)

Default Configuration

wrr is disabled by default. The default wrr weight is '1' for all queues.

Command Mode

Global Configuration mode

User Guidelines

The ratio for each queue is defined as the queue weight divided by the sum of all queue weights (the normalized weight). This sets the bandwidth allocation of each queue.

A weight of 0 indicates that no bandwidth is allocated for the same queue, and the shared bandwidth is divided among the remaining queues. It is not recommended to set the weight of a queue to a 0 as it might stop transmission of control-protocols packets generated by the device.

All 7 queues participate in the WRR, excluding the expedite queues, whose corresponding weight is not used in the ratio calculation.

An expedite queue is a priority queue, which is serviced until empty before the other queues are serviced. The expedite queues are designated by the `priority-queue out num-of-queues` command.

Example

The following assigns WRR values to the queues.

```
switchxxxxxx(config)# wrr-queue bandwidth 6 6 6 6 6 6 6 6
```

46.19 priority-queue out num-of-queues

An expedite queue is a strict priority queue, which is serviced until empty before the other lower priority queues are serviced.

Use the `priority-queue out num-of-queues` Global Configuration mode command to configure the number of expedite queues. Use the `no` form of this command to restore the default configuration.

Syntax

`priority-queue out num-of-queues` *number-of-queues*

`no priority-queue out num-of-queues`

Parameters

- **number-of-queues**—Specifies the number of expedite (strict priority) queues. Expedite queues are assigned to the queues with the higher indexes. (Range: 0–8).
There must be either 0 wrr queues or more than one.
- If **number-of-queues** = 0, all queues are assured forwarding (according to wrr weights) If the **number-of-queues** = 8, all queues are expedited (strict priority queues).

Default Configuration

All queues are expedite queues.

Command Mode

Global Configuration mode

User Guidelines

the weighted round robin (WRR) weight ratios are affected by the number of expedited queues, because there are fewer queues participating in WRR. This indicates that the corresponding weight in the `wrr-queue bandwidth` Interface Configuration mode command is ignored (not used in the ratio calculation).

Example

The following example configures the number of expedite queues as 2.

```
switchxxxxxx(config)# priority-queue out num-of-queues 2
```

46.20 traffic-shape

The egress port shaper controls the traffic transmit rate (Tx rate) on a port.

Use the **traffic-shape** Interface Configuration mode command to configure the egress port shaper. Use the **no** form of this command to disable the shaper.

Syntax

traffic-shape *committed-rate* [*committed-burst*]

no traffic-shape

Parameters

- **committed-rate**—Specifies the maximum average traffic rate (CIR) in kbits per second (kbps). (Range: FE, GE: 64kbps–maximum port speed; 10GE: 64Kbps–maximum port speed)
- **committed-burst**—Specifies the maximum permitted excess burst size (CBS) in bytes. (Range: 4096 - 16762902 bytes)

Default Configuration

The shaper is disabled.

Command Mode

Interface Configuration (Ethernet, Port-channel) mode

Example

The following example sets a traffic shaper on *fe1/0/15* on queue 1 when the average traffic rate exceeds 124000 kbps or the normal burst size exceeds 9600 bytes.

```
switchxxxxxx(config)# interface fe1/0/15  
switchxxxxxx(config-if)# traffic-shape 1 124000 9600
```

46.21 traffic-shape queue

The egress port shaper controls the traffic transmit rate (Tx rate) on a queue on a port.

Use the **traffic-shape queue** Interface Configuration mode command to configure the egress queue shaper. Use the **no** form of this command to disable the shaper.

Syntax

traffic-shape queue *queue-id* *committed-rate* [*committed-burst*]

no traffic-shape queue *queue-id*

Parameters

- **queue-id**—Specifies the queue number to which the shaper is assigned. (Range: 1-4)
-

- **committed-rate**—Specifies the average traffic rate (CIR) in kbits per second (kbps). (Range: 64 kbps–maximum port speed)
- **committed-burst**—Specifies the excess burst size (CBS) in bytes. (Range: 4096 - 16762902 bytes)

Default Configuration

The shaper is disabled.

Command Mode

Interface Configuration (Ethernet, Port-channel) mode

Example

The following example sets a shaper on queue 1 on `fe1/0/15` when the average traffic rate exceeds 124000 kbps or the normal burst size exceeds 9600 bytes.

```
switchxxxxxx(config)# interface fe1/0/15
switchxxxxxx(config-if)# traffic-shape 1 124000 9600
```

46.22 rate-limit (Ethernet)

Use the **rate-limit** Interface Configuration mode command to limit the incoming traffic rate on a port. Use the **no** form of this command to disable the rate limit.

Syntax

rate-limit *committed-rate-kbps* [*burst committed-burst-bytes*]

no rate-limit

Parameters

- **committed-rate-kbps**—Specifies the maximum number of kilobits per second of ingress traffic on a port. The range is 3– max port speed.
- **burst committed-burst-bytes**—The burst size in bytes (3000–19173960). If unspecified, defaults to 128K.

Default Configuration

Rate limiting is disabled.

Committed-burst-bytes is 128K.

Command Mode

Interface Configuration (Ethernet) mode

User Guidelines

Storm control and rate-limit (of Unicast packets) cannot be enabled simultaneously on the same port.

Example

The following example limits the incoming traffic rate on `fe1/0/15` to 150,000 kbps.

```
switchxxxxxx(config)# interface fe1/0/15  
switchxxxxxx(config-if)# rate-limit 150000
```

46.23 rate-limit (VLAN)

Use the Layer 2 **rate-limit** (VLAN) Global Configuration mode command to limit the incoming traffic rate for a VLAN. Use the **no** form of this command to disable the rate limit.

Syntax

rate-limit *vlan-id committed-rate committed-burst*

no rate-limit vlan

Parameters

- **vlan-id**—Specifies the VLAN ID.
- **committed-rate**—Specifies the average traffic rate (CIR) in kbits per second (kbps). (Range: 3-57982058)
- **committed-burst**—Specifies the maximum burst size (CBS) in bytes. (Range: 3000-19173960)

Default Configuration

Rate limiting is disabled.

Committed-burst-bytes is 128K.

Command Mode

Global Configuration mode

User Guidelines

The rate limit is calculated separately for each unit in a stack, and for each packet processor in a unit.

Traffic policing in a policy map takes precedence over VLAN rate limiting. If a packet is subject to traffic policing in a policy map and is associated with a VLAN that is rate limited, the packet is counted only in the traffic policing of the policy map.

This command does not work in Layer 3 mode.

Example

The following example limits the rate on VLAN 11 to 150000 kbps or the normal burst size to 9600 bytes.

```
switchxxxxxx(config)# rate-limit 11 150000 9600
```

46.24 qos wrr-queue wrtd

Use the **qos wrr-queue wrtd** Global Configuration mode command to enable Weighted Random Tail Drop (WRTD). Use the **no** form of this command to disable WRTD.

Syntax

qos wrr-queue wrtd

**no qos wrr-queue wrtd****Parameters**

N/A

Default

Disabled

Command Mode

Global Configuration mode

User Guidelines

The command is effective after reset.

Example

```
switchxxxxxx(conf) #>qos wrr-queue wrtd
This setting will take effect only after copying running configuration to startu
p configuration and resetting the device
switchxxxxxx(config) #
```

46.25 show qos wrr-queue wrtd

Use the **show qos wrr-queue wrtd** Exec mode command to display the Weighted Random Tail Drop (WRTD) configuration.

Syntax**show qos wrr-queue wrtd****Parameters**

N/A

Default Configuration

N/A

Command Mode

Exec mode

Example

```
switchxxxxxx# show qos wrr-queue wrtd
Weighted Random Tail Drop is disabled
Weighted Random Tail Drop will be enabled after reset
```

46.26 show qos interface

Use the **show qos interface** EXEC mode command to display Quality of Service (QoS) information on the interface.

Syntax

```
show qos interface [buffers | queueing | policers | shapers | rate-limit] [interface-id]
```

Parameters

- **buffers**—Displays the buffer settings for the interface's queues. For GE ports, displays the queue depth for each of the 8 queues. For FE ports, displays the minimum reserved setting.
- **queueing**—Displays the queue's strategy (WRR or EF), the weight for WRR queues, the CoS to queue map and the EF priority.
- **policers**—Displays all the policers configured for this interface, their settings, and the number of policers currently unused (on a VLAN).
- **shapers**—Displays the shaper of the specified interface and the shaper for the queue on the specified interface.
- **rate-limit**—Displays the rate-limit configuration.
- **interface-id**—Specifies an interface ID. The interface ID can be one of the following types: Ethernet port, or Port-channel.

Default Configuration

N/A

Command Mode

EXEC mode

User Guidelines

If no parameter is specified with the **show qos interface** command, the port QoS mode (DSCP trusted, CoS trusted, untrusted, and so on), default CoS value, DSCP-to-DSCP- map (if any) attached to the port, and policy map (if any) attached to the interface are displayed. If a specific interface is not specified, the information for all interfaces is displayed.

Examples

Example 1 - This is an example of the output from the **show qos interface buffers** command for 8 queues.

```
switchxxxxxx#show qos interface buffers fe1/0/11
fe1/0/11
Notify Q depth:
buffers fe1/0/11
Ethernet fe1/0/11
qid  thresh0  thresh1  thresh2
1     100      100      80
2     100      100      80
3     100      100      80
4     100      100      80
5     100      100      80
6     100      100      80
7     100      100      80
8     100      100      80
```



Example 2 - This is an example of the output from the **show qos interface shapers** command.

```
switchxxxxxx#show qos interface shapers fe1/0/11
fe1/0/11
Port shaper: enable
Committed rate: 192000 bps
Committed burst: 9600 bytes
```

QID	Status	Target Committed Rate [bps]	Target Committed Burst [bytes]
1	Enable	100000	17000
2	Disable	N/A	N/A
3	Enable	200000	19000
4	Disable	N/A	N/A
5	Disable	N/A	N/A
6	Disable	N/A	N/A
7	Enable	178000	8000
8	Enable	23000	1000

Example - 3 This is an example of the output from the **show qos interface policer** command.

```
switchxxxxxx# show qos interface policer fe1/0/11
Ethernet fe1/0/11
Class map: A
Policer type: aggregate
Committed rate: 192000 bps
Committed burst: 9600 bytes
Exceed-action: policed-dscp-transmit
Class map: B
Policer type: single
Committed rate: 192000 bps
Committed burst: 9600 bytes
Exceed-action: drop
Class map: C
Policer type: none
Committed rate: N/A
Committed burst: N/A
Exceed-action: N/A
```

Example 4 - This is an example of the output from the **show qos interface rate-limit** command.

```
switchxxxxxx# show qos interface rate-limit fe1/0/11
```

Port	rate-limit [kbps]	Burst [KBytes]
fe1/0/11	1000	512K

46.27 wrr-queue

Use the **wrr-queue** Global Configuration mode command to enable the tail-drop mechanism on an egress queue. Use the **no** form of this command to disable the tail-drop mechanism on an egress queue.

Syntax

wrr-queue tail-drop

no wrr-queue

Parameters

tail-drop— Specifies the tail-drop mechanism.

Default Configuration

The tail-drop mechanism on an egress queue is disabled.

Command Mode

Global Configuration mode

User Guidelines

This command can only be used if Advanced mode is enabled.

Example

The following example enables the tail-drop mechanism on an egress queue.

```
switchxxxxxx(config)# wrr-queue tail-drop
```

46.28 qos wrr-queue threshold

Use the **qos wrr-queue threshold** Global Configuration mode command to assign queue thresholds globally. Use the **no** form of this command to restore the default configuration.

This command is only available in QoS advanced mode.

Syntax

qos wrr-queue threshold gigabitethernet tengigabitethernet queue-id threshold-percentage

no qos wrr-queue threshold gigabitethernet queue-id

Parameters

- **gigabitethernet**—Specifies that the thresholds are to be applied to Gigabit Ethernet ports.
- **tengigabitethernet**—Specifies that the thresholds are to be applied to 10 Gigabit Ethernet ports.
- **queue-id**—Specifies the queue number to which the tail-drop threshold is assigned.
- **threshold-percentage**—Specifies the queue threshold percentage value.

Default Configuration

The default threshold is 80 percent.

Command Mode

Global Configuration mode

User Guidelines

If the threshold is exceeded, packets with the corresponding Drop Precedence (DP) are dropped until the threshold is no longer exceeded.

Example

The following example assigns a threshold of 80 percent to WRR queue 1.

```
switchxxxxxx(config)# qos wrr-queue threshold gigabitethernet 1 80
```

46.29 qos map policed-dscp

Use the **qos map policed-dscp** Global Configuration mode command to configure the policed-DSCP map for remarking purposes. Use the **no** form of this command to restore the default configuration.

This command is only available in QoS advanced mode.

Syntax

qos map policed-dscp *dscp-list to dscp-mark-down*

no qos map policed-dscp [*dscp-list*]

Parameters

- **dscp-list**—Specifies up to 8 DSCP values, separated by spaces. (Range: 0–63)
- **dscp-mark-down**—Specifies the DSCP value to mark down. (Range: 0–63)

Default Configuration

The default map is the Null map, which means that each incoming DSCP value is mapped to the same DSCP value.

Command Mode

Global Configuration mode.

User Guidelines

The original DSCP value and policed-DSCP value must be mapped to the same queue in order to prevent reordering.

Example

The following example marks incoming DSCP value 3 as DSCP value 5 on the policed-DSCP map.

```
switchxxxxxx(config)# qos map policed-dscp 3 to 5
```

46.30 qos map dscp-queue

Use the **qos map dscp-queue** Global Configuration mode command to configure the DSCP to CoS map. Use the **no** form of this command to restore the default configuration.

Syntax

qos map dscp-queue *dscp-list* *to queue-id*

no qos map dscp-queue [*dscp-list*]

Parameters

- **dscp-list**—Specifies up to 8 DSCP values, separated by spaces. (Range: 0– 63)
- **queue-id**—Specifies the queue number to which the DSCP values are mapped.

.Default Configuration

The default map for 8 queues is as follows.

DSCP value	0-7	8-15	16-23	24-31	32-39	40-47	48-56	57-63
Queue-ID	1	2	3	4	5	6	7	8

Command Mode

Global Configuration mode

Example

The following example maps DSCP values 33, 40 and 41 to queue 1.

```
switchxxxxxx(config)# qos map dscp-queue 33 40 41 to 1
```

46.31 qos map dscp-dp

Use the **qos map dscp-dp** Global Configuration mode command to map the DSCP values to Drop Precedence. Use the **no** form of this command to restore the default configuration.

This command is only available in QoS advanced mode.

Syntax

qos map dscp-dp *dscp-list* *to dp*

no qos map dscp-dp [*dscp-list*]

Parameters

- **dscp-list**—Specifies up to 8 DSCP values, with values separated by a space. (Range: 0–63)
- **dp**—Specifies the Drop Precedence value to which the DSCP values are mapped. (values: 0,2) where 2 is the highest Drop Precedence).

Default Configuration

All the DSCPs are mapped to Drop Precedence 0.

Command Mode

Global Configuration mode.

Example

The following example maps DSCP values 25, 27 and 29 to Drop Precedence 2.

```
switchxxxxxx(config)# qos map dscp-dp 25 27 29 to 2
```

46.32 qos trust (Global)

Use the **qos trust** Global Configuration mode command to configure the system to the basic mode and trust state. Use the **no** form of this command to return to the default configuration.

Syntax

qos trust {*cos* | *dscp*}

no qos trust

Parameters

- **cos**— Specifies that ingress packets are classified with packet CoS values. Untagged packets are classified with the default port CoS value.
- **dscp**— Specifies that ingress packets are classified with packet DSCP values.

Default Configuration

CoS is the default trust mode.

Command Mode

Global Configuration mode

User Guidelines

This command can be used only in QoS basic mode.

Packets entering a QoS domain are classified at its edge. When the packets are classified at the edge, the switch port within the QoS domain can be configured to one of the trusted states because there is no need to classify the packets at every switch within the domain.

Use this command to specify whether the port is trusted and which fields of the packet to use to classify traffic.

When the system is configured with trust DSCP, the traffic is mapped to the queue by the DSCP-queue map.

When the system is configured with trust CoS, the traffic is mapped to the queue by the CoS-queue map.

For an inter-QoS domain boundary, configure the port to the DSCP-trusted state and apply the DSCP-to-DSCP-mutation map if the DSCP values are different in the QoS domains.

Example

The following example configures the system to the DSCP trust state.

```
switchxxxxxx(config)# qos trust dscp
```

46.33 qos trust (Interface)

Use the **qos trust** Interface Configuration (Ethernet, Port-channel) mode command to enable port trust state while the system is in the basic QoS mode. Use the **no** form of this command to disable the trust state on each port.

Syntax

qos trust

no qos trust

Parameters

N/A

Default Configuration

Each port is enabled while the system is in basic mode.

Command Mode

Interface Configuration (Ethernet, Port-channel) mode

Example

The following example configures `fe1/0/15` to the default trust state.

```
switchxxxxxx(config)# interface fe1/0/15
switchxxxxxx(config-if)# qos trust
```

46.34 qos cos

Use the **qos cos** Interface Configuration (Ethernet, Port-channel) mode command to define the default CoS value of a port. Use the **no** form of this command to restore the default configuration.

Syntax

qos cos *default-cos*

no qos cos

Parameters

default-cos—Specifies the default CoS value (VPT value) of the port. If the port is trusted and the packet is untagged, then the default CoS value become the CoS value. (Range: 0–15)

Default Configuration

The default CoS value of a port is 0.

Command Mode

Interface Configuration (Ethernet, Port-channel) mode

User Guidelines

Use the default CoS value to assign a CoS value to all untagged packets entering the interface.

Example

The following example defines the port `fe1/0/15` default CoS value as 3.

```
switchxxxxxx(config)# interface fe1/0/15
switchxxxxxx(config-if)# qos cos 3
```

46.35 qos dscp-mutation

Use the **qos dscp-mutation** Global Configuration mode command to apply the DSCP Mutation map to system DSCP trusted ports. Use the **no** form of this command to restore the trusted port with no DSCP mutation.

Syntax

qos dscp-mutation

no qos dscp-mutation

Parameters

N/A

Default Configuration

N/A

Command Mode

Global Configuration mode.

User Guidelines

Apply the DSCP-to-DSCP-mutation map to a port at the boundary of a Quality of Service (QoS) administrative domain. If two QoS domains have different DSCP definitions, use the DSCP-to-DSCP-mutation map to translate a set of DSCP values to match the definition of another domain. Apply the map to ingress and to DSCP-trusted ports only. Applying this map to a port causes IP packets to be rewritten with newly mapped DSCP values at the ingress ports. If applying the DSCP mutation map to an untrusted port, to class of service (CoS), or to an IP-precedence trusted port.

Global trust mode must be DSCP or CoS-DSCP. In advanced CoS mode, ports must be trusted.

Example

The following example applies the DSCP Mutation map to system DSCP trusted ports.

```
switchxxxxxx(config)# qos dscp-mutation
```

46.36 qos map dscp-mutation

Use the **qos map dscp-mutation** Global Configuration mode command to configure the DSCP to DSCP Mutation table. Use the **no** form of this command to restore the default configuration.

Syntax

qos map dscp-mutation *in-dscp* to *out-dscp*

no qos map dscp-mutation [*in-dscp*]

Parameters

- **in-dscp**—Specifies up to 8 DSCP values to map, separated by spaces. (Range: 0–63)
- **out-dscp**—Specifies up to 8 DSCP mapped values, separated by spaces. (Range: 0–63)

Default Configuration

The default map is the Null map, which means that each incoming DSCP value is mapped to the same DSCP value.

Command Mode

Global Configuration mode.

User Guidelines

This is the only map that is not globally configured. It is possible to have several maps and assign each one to a different port.

Example

The following example changes DSCP values 1, 2, 4, 5 and 6 to DSCP Mutation Map value 63.

```
switchxxxxxx(config)# qos map dscp-mutation 1 2 4 5 6 to 63
```

46.37 show qos map

Use the **show qos map** EXEC mode command to display the various types of QoS mapping.

Syntax

show qos map [**dscp-queue** | **dscp-dp** | **policed-dscp** | **dscp-mutation**]

Parameters

- **dscp-queue**—Displays the DSCP to queue map.
- **dscp-dp**—Displays the DSCP to Drop Precedence map.
- **policed-dscp**—Displays the DSCP to DSCP remark table.
- **dscp-mutation**—Displays the DSCP-DSCP mutation table.

Default Configuration

Display all maps.

Command Mode

EXEC mode

**Example**

The following example displays the QoS mapping information.

```
switchxxxxxx# show qos map dscp-queue
Dscp-queue map:

d1  :   d2  0    1    2    3    4    5    6    7    8    9
--  --  --  --  --  --  --  --  --  --  --  --
0   :           01  01  01  01  01  01  01  01  01  01  01
1   :           01  01  01  01  01  01  01  02  02  02  02
2   :           02  02  02  02  03  03  03  03  03  03  03
3   :           04  04  05  05  05  05  05  05  05  05  05
4   :           06  06  06  06  06  06  06  06  07  07  07
5   :           07  07  07  07  07  07  08  08  08  08  08
6   :           08  08  08  08
```

46.38 clear qos statistics

Use the **clear qos statistics** EXEC mode command to clear the QoS statistics counters.

Syntax

clear qos statistics

Parameters

N/A

Default Configuration

N/A

Command Mode

EXEC mode

Example

The following example clears the QoS statistics counters.

```
switchxxxxxx# clear qos statistics
```

46.39 qos statistics policer

Use the **qos statistics policer** Interface Configuration (Ethernet, Port-channel) mode command to enable counting in-profile and out-of-profile. Use the **no** form of this command to disable counting.

This command is relevant only when policers are defined.

Syntax

qos statistics policer *policy-map-name class-map-name*

no qos statistics policer *policy-map-name class-map-name*

Parameters

- **policy-map-name**—Specifies the policy map name.
- **class-map-name**—Specifies the class map name.

Default Configuration

Counting in-profile and out-of-profile is disabled.

Command Mode

Interface Configuration (Ethernet, Port-channel) mode

Example

The following example enables counting in-profile and out-of-profile on the interface.

```
switchxxxxxx(config-if)# qos statistics policer policy1 class1
```

46.40 qos statistics aggregate-policer

Use the **qos statistics aggregate-policer** Global Configuration mode command to enable counting in-profile and out-of-profile. Use the **no** form of this command to disable counting.

Syntax

qos statistics aggregate-policer *aggregate-policer-name*

no qos statistics aggregate-policer *aggregate-policer-name*

Parameters

aggregate-policer-name—Specifies the aggregate policer name.

Default Configuration

Counting in-profile and out-of-profile is disabled.

Command Mode

Global Configuration mode

Example

The following example enables counting in-profile and out-of-profile on the interface.

```
switchxxxxxx(config)# qos statistics aggregate-policer policer1
```

46.41 qos statistics queues

Use the **qos statistics queues** Global Configuration mode command to enable QoS statistics for output queues. Use the **no** form of this command to disable QoS statistics for output queues.

Syntax

qos statistics queues *set {queue | all} {dp | all} {interface | all}*

no qos statistics queues *set*

Parameters

- **set**—Specifies the counter set number.
- **interface**—Specifies the Ethernet port.
- **queue**—Specifies the output queue number.
- **dp**—Specifies the drop precedence. The available values are: **high**, **low**.

Default Configuration

Set 1: All interfaces, all queues, high DP.

Set 2: All interfaces, all queues, low DP.

Command Mode

Global Configuration mode

User Guidelines

There are no user guidelines for this command.

If the queue parameter is all, traffic in stacking and cascading ports is also counted.

Example

The following example enables QoS statistics for output queues for counter set 1.

```
switchxxxxxx(config)# qos statistics queues 1 all all all
```

46.42 show qos statistics

Use the **show qos statistics** EXEC mode command to display Quality of Service statistical information.

Syntax

show qos statistics

Parameters

N/A

Default Configuration

N/A

Command Mode

EXEC mode

User Guidelines

Up to 16 sets of counters can be enabled for policers. The counters can be enabled in the creation of the policers.

Use the **qos statistics queues** Global Configuration mode command to enable QoS statistics for output queues.

Example

The following example displays Quality of Service statistical information.

```
switchxxxxxx# show qos statistics
Policers
-----
Interface  Policy map  Class      In-profile   Out-of-profile bytes
          -----  -----
          Policy1  Class1     7564575     5433
fe1/0/11  Policy1     Class2     8759        52
fe1/0/11  Policy1     Class1     746587458   3214
fe1/0/12  Policy1     Class1     5326        23
fe1/0/12  Policy1     Class2

Aggregate Policers
-----
Name          In-profile bytes  Out-of-profile bytes
-----
Policer1     7985687          121322

Output Queues
-----
Interface  Queue      DP      Total packets  %TD packets
-----
fe1/0/11   2          High    799921         1.2%
fe1/0/12   All        High    5387326        0.2%
```

46.43 security-suite enable

Use the **security-suite enable** Global Configuration mode command to enable the security suite feature. This feature supports protection against various types of attacks.

When this command is used, hardware resources are reserved. These hardware resources are released when the **no security-suite enable** command is entered.

The security-suite feature can be enabled in one of the following ways:

- **Global-rules-only** - This enables the feature globally but per-interface features are not enabled.
- **All** (no keyword) - The feature is enabled globally and per-interface.

Use the **no** form of this command to disable the security suite feature.

When security-suite is enabled, you can specify the types of protection required. The following commands can be used:

- [security-suite dos protect](#)
- [security-suite dos syn-attack](#)
- [security-suite deny martian-addresses](#)
- [security-suite deny syn](#)
- [security-suite deny icmp](#)
- [security-suite deny fragmented](#)
- [show security-suite configuration](#)
- [security-suite dos protect](#)

Syntax

security-suite enable [*global-rules-only*]

no security-suite enable

Parameters

global-rules-only—Specifies that all the security suite commands are global commands only (they cannot be applied per-interface). This setting saves space in the Ternary Content Addressable Memory (TCAM). If this keyword is not used, security-suite commands can be used both globally and per-interface.

Default Configuration

The security suite feature is disabled.

If **global-rules-only** is not specified, the default is to enable security-suite globally and per interfaces.

Command Mode

Global Configuration mode

User Guidelines

MAC ACLs must be removed before the security-suite is enabled. The rules can be re-entered after the security-suite is enabled.

If ACLs or policy maps are assigned on interfaces, per interface security-suite rules cannot be enabled.

Examples

Example 1 - The following example enables the security suite feature and specifies that security suite commands are global commands only. When an attempt is made to configure security-suite on a port, it fails.

```
switchxxxxxx(config)# security-suite enable global-rules-only
switchxxxxxx(config)# interface gil
switchxxxxxx(config-if)# security-suite dos syn-attack 199 any /10
To perform this command, DoS Prevention must be enabled in the
per-interface mode.
```

Example 2 - The following example enables the security suite feature globally and on interfaces. The security-suite command succeeds on the port.

```
switchxxxxxx(config)# security-suite enable
switchxxxxxx(config)# interface gil
switchxxxxxx(config-if)# security-suite dos syn-attack 199 any /10
switchxxxxxx(config-if)#
```

46.44 security-suite dos protect

Use the **security-suite dos protect** Global Configuration mode command to protect the system from specific well-known Denial of Service (DoS) attacks. There are three types of attacks against which protection can be supplied (see parameters below).

Use the **no** form of this command to disable DoS protection.

Syntax

security-suite dos protect {*add attack* | *remove attack*}

no security-suite dos protect

Parameters

add/remove attack—Specifies the attack type to add/remove. To add an attack is to provide protection against it; to remove the attack is to remove protection.

The possible attack types are:

- **stacheldraht**—Discards TCP packets with source TCP port 16660.
- **invasor-trojan**—Discards TCP packets with destination TCP port 2140 and source TCP port 1024.
- **back-orifice-trojan**—Discards UDP packets with destination UDP port 31337 and source UDP port 1024.

Default Configuration

No protection is configured.

Command Mode

Global Configuration mode

User Guidelines

For this command to work, [security-suite enable](#) must be enabled globally.

Example

The following example protects the system from the Invasor Trojan DOS attack.

```
switchxxxxxx(config)# security-suite dos protect add invasor-trojan
```

46.45 security-suite deny martian-addresses

Use the **security-suite deny martian-addresses** Global Configuration mode command to deny packets containing system-reserved IP addresses or user-defined IP addresses.

Syntax

security-suite deny martian-addresses {*add {ip-address {mask | /prefix-length}}* | *remove {ip-address {mask | /prefix-length}}*} (Add/remove user-specified IP addresses)

security-suite deny martian-addresses reserved {*add* | *remove*} (Add/remove system-reserved IP addresses, see tables below)

no security-suite deny martian-addresses (This command removes addresses reserved by **security-suite deny martian-addresses** {*add {ip-address {mask | /prefix-length}}* | *remove {ip-address {mask | /prefix-length}}*}, and removes all entries added by the user. The user can remove a specific entry by using **remove ip-address {mask | /prefix-length}** parameter.

There is no **no** form of the **security-suite deny martian-addresses reserved** {*add* | *remove*} command. Use instead the **security-suite deny martian-addresses reserved remove** command to remove protection (and free up hardware resources).

Parameters

- **reserved add/remove**—Add or remove the table of reserved addresses below.
- **ip-address**—Adds/discards packets with the specified IP source or destination address.
- **mask**—Specifies the network mask of the IP address.
- **prefix-length**—Specifies the number of bits that comprise the IP address prefix. The prefix length must be preceded by a forward slash (/).
- **reserved**—Discards packets with the source or destination IP address in the block of the reserved (Martian) IP addresses. See the User Guidelines for a list of reserved addresses.

Default Configuration

Martian addresses are allowed.

Command Mode

Global Configuration mode

User Guidelines

For this command to work, [security-suite enable](#) must be enabled globally.

security-suite deny martian-addresses reserved adds or removes the addresses in the following table:

Address block	Present Use
0.0.0.0/8 (except when 0.0.0.0/32 is the source address)	Addresses in this block refer to source hosts on "this" network.
127.0.0.0/8	This block is assigned for use as the Internet host loopback address.
192.0.2.0/24	This block is assigned as "TEST-NET" for use in documentation and example code.
224.0.0.0/4 as source	This block, formerly known as the Class D address space, is allocated for use in IPv4 multicast address assignments.
240.0.0.0/4 (except when 255.255.255.255/32 is the destination address)	This block, formerly known as the Class E address space, is reserved.

Note that if the reserved addresses are included, individual reserved addresses cannot be removed.

Example

The following example discards all packets with a source or destination address in the block of the reserved IP addresses.

```
switchxxxxxx(config) # security-suite deny martian-addresses reserved
add
```


46.46 security-suite deny syn

Use the **security-suite deny syn** Interface Configuration (Ethernet, Port-channel) mode command to block the creation of TCP connections from a specific interface. This a complete block of these connections.

Use the **no** form of this command to permit creation of TCP connections.

Syntax

```
security-suite deny syn {[add {tcp-port | any} {ip-address | any} {mask | /prefix-length}] | [remove {tcp-port | any} {ip-address | any} {mask | /prefix-length}]}
```

```
no security-suite deny syn
```

Parameters

- **ip-address | any**—Specifies the destination IP address. Use **any** to specify all IP addresses.
- **mask**— Specifies the network mask of the destination IP address.
- **prefix-length**—Specifies the number of bits that comprise the destination IP address prefix. The prefix length must be preceded by a forward slash (/).
- **tcp-port | any**—Specifies the destination TCP port. The possible values are: **http**, **ftp-control**, **ftp-data**, **ssh**, **telnet**, **smtp**, **dns**, **ftp**, **ntp**, **snmp** or **port number**. Use **any** to specify all ports.

Default Configuration

Creation of TCP connections is allowed from all interfaces.

If the **mask** is not specified, it defaults to 255.255.255.255.

If the **prefix-length** is not specified, it defaults to 32.

Command Mode

Interface Configuration (Ethernet, Port-channel) mode

User Guidelines

For this command to work, [security-suite enable](#) must be enabled both globally and for interfaces.

The blocking of TCP connection creation from an interface is done by discarding ingress TCP packets with "SYN=1", "ACK=0" and "FIN=0" for the specified destination IP addresses and destination TCP ports.

Example

The following example attempts to block the creation of TCP connections from an interface. It fails because security suite is enabled globally and not per interface.

```
switchxxxxxx(config)# security-suite enable global-rules-only
switchxxxxxx(config)# interface g1
switchxxxxxx(config-if)# security-suite deny syn add any /32 any
To perform this command, DoS Prevention must be enabled in the
per-interface mode.
```



47 Revision History

Table 3: Revision History Franchise Phase 2.5

Revision	Date	Comments
0.2	August 16, 2010	Updated draft.
0.1	May 18, 2011	Initial draft.



Marvell Semiconductor, Inc.
5488 Marvell Lane
Santa Clara, CA 95054, USA

Tel: 1.408.222.2500

Fax: 1.408.988.8279

www.marvell.com

Marvell. Moving Forward Faster



